



# A800-E / F800-E ETHERNET FUNCTION MANUAL

# Ethernet communication function

This manual explains the Ethernet communication specifications. For the functions not found in this manual, refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.

In addition to this manual, please read the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter carefully. Do not use this product until you have a full knowledge of the equipment, safety information and instructions.

Please forward this manual to the end user.




#### **CONTENTS**

1	I	NTRODUCTION	2
	1.1	Ethernet communication overview	2
	1.2	Ethernet connector	3
	1.3	Ethernet cable wiring precautions	4
	1.4	Removal of the Ethernet board	5
2	<b>.</b> F	PARAMETER	6
	2.1	Parameter list (by parameter number)	6
	2.2	Parameter list (by function group)	8
	2.3	(D) Operation command and frequency command	9
	2.	3.1 Selection of the command source during communication operation	9
	2.4	(M) Monitor display and monitor output signal	13
	2.	4.1 Output terminal function selection	13
	2.5	(N) Operation via communication and its settings	14
	2.	5.1 Initial setting of operation via communication	14
		5.2 Initial settings and specifications of Ethernet communication	19
		.5.3 MELSOFT / FA product connection	
		.5.4 SLMP	
		.5.6 CC-Link IE Field Network Basic	
	2.6	Inverter-to-inverter link function	72
3	F	PROTECTIVE FUNCTIONS	75
	3.1	Causes and corrective actions	75
4	. §	SPECIFICATIONS	76
	4.1	Common specifications	76
	4.2	Parameters (functions) and instruction codes under different control methods	80

### 1 INTRODUCTION

### 1.1 Ethernet communication overview

The FR-A800-E/FR-F800-E inverter is equipped with an Ethernet board. Communication with network devices can be made via Ethernet by connecting an Ethernet cable to the Ethernet connector on the Ethernet board.



#### ◆Precautions for Ethernet communication

- In order to protect the inverter and the system against unauthorized access by external systems via network, take security measures including firewall settings.
- Depending on the network environment, the inverter may not operate as intended due to delays or disconnection in communication. Carefully consider the conditions and safety for the inverter on site.

#### Abbreviations

Abbreviation / generic name	Description
DU	Operation panel (FR-DU08)
Operation panel	Operation panel (FR-DU08) and LCD operation panel (FR-LU08)
Parameter unit	Parameter unit (FR-PU07)
PU	Operation panel and parameter unit
Inverter	Mitsubishi FR-A800-E/FR-F800-E inverter
Ethernet board	Ethernet communication board (FR-A8ETH)
Pr.	Parameter number (Number assigned to function)
SLMP	Seamless Message Protocol
iQSS	Mitsubishi iQ Sensor Solution∗ı
TCP/IP	Transmission Control Protocol / Internet Protocol
UDP/IP	User Datagram Protocol / Internet Protocol

<sup>\*1</sup> The solution enables seamless sensor control using a programmable controller, GOT, and other devices. The iQSS contributes to the reduction in the total cost from development to maintenance of production equipment.


#### **◆Trademarks**

- Ethernet is a registered trademark of Fuji Xerox Corporation.
- MODBUS is a registered trademark of SCHNEIDER ELECTRIC USA, INC.

# 1.2 Ethernet connector

### **◆**Ethernet communication specifications

Item	Description
Category	100BASE-TX/10BASE-T
Data transmission speed	100 Mbps (100BASE-TX) / 10 Mbps (10BASE-T)
Transmission method	Baseband
Maximum segment length	100 m between the hub and the inverter
Number of cascade connection stages	Up to 2 (100BASE-TX) / up to 4 (10BASE-T)
Interface	RJ-45
Number of interfaces available	1
IP version	IPv4



#### **◆**Connection cable

Use Ethernet cables compliant with the following standards.

Communication speed	Cable	Connector	Standard
100 Mbps	Category 5 or higher, (shielded / STP) straight cable		100BASE-TX
10 Mbps	Category 3 or higher, (shielded / STP) straight cable	RJ-45 connector	10DASE T
TO MDPS	Category 3 or higher, (UTP) straight cable		100BASE-TX 10BASE-T

#### **♦**Hub

Use a hub that supports transmission speed of the Ethernet.

## 1.3 Ethernet cable wiring precautions

This section explains Ethernet cable connection and the relevant precautions.

#### ◆Handling of the Ethernet cable

- Do not touch the conductors of the cable or the connector on the inverter. Keep the conductors free of dust or dirt. Handling the conductors with oily hands or dust/dirt adhesion to the conductors may cause transmission losses and impair normal data link operation.
- · Check the Ethernet cable for the following points before use.
  - · The cable is not broken.
  - · The cable does not have a short circuit.
  - The connector is properly installed.
- Do not use an Ethernet cable with a broken latch. Doing so may cause the cable to come off or malfunction.
- Do not connect the Ethernet cable to the PU connector. The product could be damaged due to differences in electrical specifications.
- The maximum distance between stations is specified as 100 m. However, the maximum distance may be shorter depending on the environment. For details of the cable, contact your cable manufacturer.

#### **♦**Connecting and disconnecting of the Ethernet cable


Hold the cable connector when connecting and disconnecting the Ethernet cable. Pulling a cable connected to the inverter may damage the inverter or cable, or result in malfunction due to poor contact.

#### ◆Network configuration

Check the network configuration before wiring, and perform correct wiring.

## 1.4 Removal of the Ethernet board

The option connector 2 is not available for use because the Ethernet board is installed in the initial status. The Ethernet board must be removed as follows to install a plug-in option to the option connector 2. (However, Ethernet communication is disabled in that case.)



- (1) Remove the inverter front cover. (For details on how to remove the front cover, refer to Chapter 2 of the inverter's Instruction Manual (Detailed).)
- (2) Remove the three mounting screws to remove the Ethernet board earth plate and the Ethernet board.

#### • NOTE

- For reinstalling the Ethernet board to the inverter, remove the plug-in option installed to the option connector 2 and install the Ethernet board and its earth plate in the reverse order.
- Remove the Ethernet board on the FR-A800-E inverter to install the FR-A8NS and FR-A8AP/FR-A8AL for the SSCNET III(/ H) communication.

# 2 PARAMETER

# **2.1** Parameter list (by parameter number)

The following parameters are dedicated to Ethernet communication. Set the parameters according to application. For other parameters, refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.

Pr.	Pr. group	Name	Setting range	Minimum setting increments	Initial value	Refer to page	Customer setting
190	M400	RUN terminal function selection		1	0	13	
191	M401	SU terminal function selection	-	1	1	13	
192	M402	IPF terminal function selection		1	2*1 9999*2	13 13	
193	M403	OL terminal function selection	242, 342*3	1	3	13	
194	M404	FU terminal function selection		1	4	13	
195	M405	ABC1 terminal function selection	1	1	99	13	
196	M406	ABC2 terminal function selection		1	9999	13	
313	M410	DO0 output selection		1	9999	13	
314	M411	DO1 output selection	242, 342*4	1	9999	13	
315	M412	DO2 output selection	1	1	9999	13	
342	N001	Communication EEPROM write selection	0, 1	1	0	14	
349	N010	Communication reset selection	0, 1	1	0	14	
502	N013	Stop mode selection at communication error	0 to 4	1	0	14	
541	N100	Frequency command sign selection	0, 1	1	0	51	
544	N103	CC-Link extended setting	0, 1, 12, 14, 18, 24, 28, 100, 112, 114, 118, 128	1	0	51	
550	D012	NET mode operation command source selection	0, 1, 5, 9999	1	9999	9	
551	D013	PU mode operation command source selection	1 to 3, 5, 9999	1	9999	9	
779	N014	Operation frequency during communication error	0 to 590 Hz, 9999	0.01 Hz	9999	14	
804*5	D400*5	Torque command source selection	0 to 6	1	0	51	
810*5	H700*5	Torque limit input method selection	0 to 2	1	0	51	
1124	N681	Station number in inverter-to-inverter link	0 to 5, 9999	1	9999	72	
1125	N682	Number of inverters in inverter-to-inverter link system	2 to 6	1	2	72	
1424	N650	Ethernet communication network number	1 to 239	1	1	19	
1425	N651	Ethernet communication station number	1 to 120	1	1	19	
1426	N641	Link speed and duplex mode selection	0 to 4	1	0	19	
1427	N630	Ethernet function selection 1	502, 5000 to 5002, 5006 to 5008, 5010 to 5013, 9999, 45237, 61450	1	5001	19	
1428	N631	Ethernet function selection 2	502, 5000 to 5002, 5006 to 5008, 5010 to 5013, 9999, 45237, 61450	1	45237	19	
1429	N632	Ethernet function selection 3	502, 5000 to 5002, 5006 to 5008, 5010 to 5013, 9999, 45237, 61450	1	9999	19	
1431	N643	Ethernet signal loss detection function selection	0 to 3	1	0	19	
1432	N644	Ethernet communication check time interval	0 to 999.8 s, 9999	0.1 s	9999	19	
1434	N600	Ethernet IP address 1	0 to 255	1	192	19	
1435	N601	Ethernet IP address 2	0 to 255	1	168	19	
1436	N602	Ethernet IP address 3	0 to 255	1	50	19	
1437	N603	Ethernet IP address 4	0 to 255	1	1	19	
1438	N610	Subnet mask 1	0 to 255	1	255	19	
1439	N611	Subnet mask 2	0 to 255	1	255	19	
1440	N612	Subnet mask 3	0 to 255	1	255	19	
1441	N613	Subnet mask 4	0 to 255	1	0	19	
1442	N660	Ethernet IP filter address 1	0 to 255	1	0	19	
1443	N661	Ethernet IP filter address 2	0 to 255	1	0	19	
1444	N662	Ethernet IP filter address 3	0 to 255	1	0	19	
1445	N663	Ethernet IP filter address 4	0 to 255	1	0	19	

Pr.	Pr. group	Name	Setting range	Minimum setting increments	Initial value	Refer to page	Customer setting
1446	N664	Ethernet IP filter address 2 range specification	0 to 255, 9999	1	9999	19	
1447	N665	Ethernet IP filter address 3 range specification	0 to 255, 9999	1	9999	19	
1448	N666	Ethernet IP filter address 4 range specification	0 to 255, 9999	1	9999	19	
1449	N670	Ethernet command source selection IP address 1	0 to 255	1	0	19	
1450	N671	Ethernet command source selection IP address 2	0 to 255	1	0	19	
1451	N672	Ethernet command source selection IP address 3	0 to 255	1	0	19	
1452	N673	Ethernet command source selection IP address 4	0 to 255	1	0	19	
1453	N674	Ethernet command source selection IP address 3 range specification	0 to 255, 9999	1	9999	19	
1454	N675	Ethernet command source selection IP address 4 range specification	0 to 255, 9999	1	9999	19	
1455	N642	Keepalive time	1 to 7200 s	1 s	3600 s	19	

- \*1 The initial value is for standard models and IP55 compatible models.
- \*2 The initial value is for separated converter types.
- \*3 For the other settings, refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.
- \*4 The other available settings depend on the inverter. For details, refer to the description of **Pr.190 to Pr.196 (Output terminal function selection)** in the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.
- \*5 The setting is available for the FR-A800-E only.

# 2.2 Parameter list (by function group)

# D: Operation command and frequency command

Parameters that specify the inverter's command source, and parameters that set the motor driving frequency and torque.

Pr. group	Pr.	Name	Refer to page
D012	550	NET mode operation command source selection	9
D013	551	PU mode operation command source selection	9
D400*1	804*1	Torque command source selection	51

<sup>\*1</sup> The setting is available for the FR-A800-E only.

#### **♦**H: Protective function parameter

Parameters to protect the motor and the inverter.

Pr. group	Pr.	Name	Refer to
group			page
H700*1	810*1	Torque limit input method selection	51

<sup>\*1</sup> The setting is available for the FR-A800-E only.

#### M: Monitor display and monitor output signal

Parameters regarding the inverter's operating status. These parameters are used to set the monitors and output signals.

Pr. group	Pr.	Name	Refer to page
M400	190	RUN terminal function selection	13
M401	191	SU terminal function selection	13
M402	192	IPF terminal function selection	13
M403	193	OL terminal function selection	13
M404	194	FU terminal function selection	13
M405	195	ABC1 terminal function selection	13
M406	196	ABC2 terminal function selection	13
M410	313	DO0 output selection	13
M411	314	DO1 output selection	13
M412	315	DO2 output selection	13

#### ♦N: Operation via communication and its settings

Parameters for communication operation. These parameters set the communication specifications and operation.

Pr. group	Pr.	Name	Refer to page	
N001	342	Communication EEPROM write selection	14	
N010	349	Communication reset selection	14	
N013	502	Stop mode selection at communication error	14	
N014	779	Operation frequency during communication error	14	
N100	541	Frequency command sign selection	51	

Pr.			Refer
	Pr.	Name	to
group			page
N103	544	CC-Link extended setting	51
N600	1434	Ethernet IP address 1	19
N601	1435	Ethernet IP address 2	19
N602	1436	Ethernet IP address 3	19
N603	1437	Ethernet IP address 4	19
N610	1438	Subnet mask 1	19
N611	1439	Subnet mask 2	19
N612	1440	Subnet mask 3	19
N613	1441	Subnet mask 4	19
N630	1427	Ethernet function selection 1	19
N631	1428	Ethernet function selection 2	19
N632	1429	Ethernet function selection 3	19
110.44	4.400	Link speed and duplex mode	40
N641	1426	selection	19
N642	1455	Keepalive time	19
NG 42	1421	Ethernet signal loss detection	40
N643	1431	function selection	19
N644	1432	Ethernet communication check time	10
11044	1432	interval	19
N650	1424	Ethernet communication network	to page 51 19 19 19 19 19 19 19 19 19 19 19 19 19
11030	1424	number	to page  51 19 19 19 19 19 19 19 19 19 19 19 19 19
N651	1425	Ethernet communication station	19
14051	1425	number	
N660	1442	Ethernet IP filter address 1	19
N661	1443	Ethernet IP filter address 2	
N662	1444	Ethernet IP filter address 3	_
N663	1445	Ethernet IP filter address 4	19
N664	1446	Ethernet IP filter address 2 range	19
11001		specification	
N665	1447	Ethernet IP filter address 3 range	19
		specification	page 51 19 19 19 19 19 19 19 19 19 19 19 19 19
N666	1448	Ethernet IP filter address 4 range	19
		specification	
N670	1449	Ethernet command source selection IP address 1	19
		Ethernet command source selection	19 19 19 19 19 19 19 19 19 19 19 19
N671	1450	IP address 2	to page  51 19 19 19 19 19 19 19 19 19 19 19 19 19
		Ethernet command source selection	to page 51 19 19 19 19 19 19 19 19 19 19 19 19 19
N672	1451	IP address 3	19
		Ethernet command source selection	
N673	1452	IP address 4	19
		Ethernet command source selection	
N674	1453	IP address 3 range specification	19
		Ethernet command source selection	
N675	1454	IP address 4 range specification	19
		Station number in inverter-to-	19 19 19 19 19 19 19 19 19 19 19 19 19 1
N681	1124	inverter link	72
NOOC	4405	Number of inverters in inverter-to-	
N682	1125	inverter link system	72
N687   1175		72	

# **2.3** (D) Operation command and frequency command

Purpose	Parameter to set			Refer to page
To select the command source during communication operation	Selection of the command source during communication operation	P.D012, P.D013	Pr.550, Pr.551	9
To select the torque command method in the torque control mode	Torque command source selection	P.D400	Pr.804	51

# 2.3.1 Selection of the command source during communication operation

When the Ethernet connector or a communication option is used, the command source in the network (NET) / PU operation mode can be selected.

Pr.	Name	Initial value	Setting range	Description
			0	The communication option is the command source when in the NET operation mode.
			1	For manufacturer setting. Do not set.
550	NET mode operation command		5	The Ethernet connector is the command source when in the NET operation mode.
D012	source selection	9999	9999	Communication option automatic recognition Normally, the Ethernet connector is the command source. When the communication option is mounted, the communication option is the command source.
			1	For manufacturer setting. Do not set.
			2	The PU connector is the command source when in the PU operation mode.
			3	The USB connector is the command source when in the PU operation mode.
551 D013	PU mode operation command source selection	9999	5	The Ethernet connector is the command source when in the PU operation mode.
			9999	USB automatic recognition Normally, the PU connector is the command source. When the USB is connected, the USB connector is the command source.

# ◆ Selection of command source in the network (NET) operation mode (Pr.550)

- Either of the Ethernet connector or the communication option can be specified for the command source in the NET operation mode.
- For example, whether or not the communication option is mounted, set **Pr.550** = "5" to write parameters or input the start and frequency commands via the Ethernet connector in the NET operation mode.

### NOTE

• In the initial setting, "9999" (communication option automatic recognition) is set for **Pr.550**. Thus, if the communication option is mounted, parameters cannot be written or the start and frequency commands cannot be sent by communications that use the Ethernet connector. (Monitoring or parameter reading can be performed.)

2

GROUP

#### ◆Selection of the command source of the PU operation mode (Pr.551)

- Any of the PU connector, Ethernet connector, or USB connector can be specified for the command source in the PU operation mode.
- In the PU operation mode, set **Pr.551** = "5" to write parameters or input the start and frequency commands via the Ethernet connector. Set **Pr.551** = "3 or 9999" to use the USB connector.



- When **Pr.550** = "5" (NET operation mode, Ethernet connector) and **Pr.551** = "5" (PU operation mode, Ethernet connector), the PU operation mode has precedence.
- · Changed setting values are enabled at power-ON or inverter reset.

Pr.550	Pr.551		Commar	nd source		
setting	setting	PU connector USB connector		Ethernet connector	Communication option	Remarks
	2	PU operation mode	×	×	NET operation mode*1	
	3	×	PU operation mode	×	NET operation mode*1	
0	5	×	×	PU operation mode	NET operation mode*1	
	9999 (initial value)	PU operation mode*2	PU operation mode*2	×	NET operation mode*1	
	2	PU operation mode	×	NET operation mode		
	3	×	PU operation mode	NET operation mode	×	
5	5	×	×	PU operation mode*3	×	Switching to NET operation mode disabled
	9999 (initial value)	PU operation mode*2	PU operation mode*2	NET operation mode	×	
	2	PU operation mode	×	×	NET operation mode*1	With communication option
	2		X	NET operation mode	×	Without communication option
	3	×	PU operation mode	×	NET operation mode*1	With communication option
9999 (initial	3	^	i o operation mode	NET operation mode		Without communication option
value)	5	×	×	PU operation	NET operation mode*1	With communication option
	3	^	^	mode*3	×	Without communication option
	9999 (initial	PU operation	PU operation	×	NET operation mode*1	With communication option
	value)	mode*2	mode*2	NET operation mode	×	Without communication option

<sup>\*1</sup> If the communication option is not mounted, switching to the NET operation mode is not possible.

<sup>\*2</sup> When **Pr.551** = "9999", the priority of the PU command source is defined as follows: USB connector > PU connector.

<sup>\*3</sup> When the CC-Link IE Field Network Basic is used, the NET operation mode has precedence. However, the Ethernet connector is not used as the command source if a communication option is installed while **Pr.550** = "9999".

# **♦**Controllability through communication

Controllability in each of					in each op	peration mode		
					EXT/PU	EXT/PU	NET operation	NET operation
Command	Condition	14		External	combined	combined	(when the	(when a
source	(Pr.551 setting)	Item	PU	(EXT)	operation	operation	Ethernet	communication
55555			operation	operation	mode 1	mode 2	connector is	option is
				орогация	(Pr.79 = 3)	(Pr.79 = 4)	used)*6	used)*7
		Operation (start)	_		,			
	2	command	0	×	×	0	×	
	(PU connector)	Operation (stop)				_		
	9999	command	0	$\Delta*3$	$\Delta*3$	0	$\Delta*3$	
	(automatic	Running frequency	0	×	0	×	×	
	recognition,	Monitor	0	0	0	0	0	
	without USB	Parameter write	O*4	×*5	O*4	O*4	×*5	
Control by	connection)	Parameter read	0	0	0	0	0	
RS-485		Inverter reset	0	0	0	0	0	
communication		Operation (start)						
via PU		command	×	×	×	×	×	
connector		Operation (stop)						
		command	Δ*3	$\Delta*3$	Δ*3	$\Delta*3$	$\Delta*3$	
	Other than the	Running frequency	×	×	×	×	×	
	above	Monitor	0	0	0	0	0	
		Parameter write	X*5	X*5	X*5	X*5	X*5	
		Parameter read	0	0	0	0	0	
		Inverter reset	0	0	0	0	0	
		Operation command						
	3	(start, stop)	0	×	×	0	×	
	(USB connector)	Running frequency	0	×	0	×	×	
	9999	Monitor	0	0	0	0	0	
	(automatic recognition, with USB connection)	Parameter write	O*4	X*5	O*4	O*4	X*5	
		Parameter read	0	0	0	0	0	
Control via		Inverter reset	0	0	0	0	0	
USB		Operation command		0				
connector		(start, stop)	×	×	×	×	×	
		Running frequency	×	×	×	X	×	
	Other than the	Monitor	0	^ O	0	0	^ O	
	above	Parameter write	X*5	X*5	X*5	X*5	X*5	
		Parameter read	0	0	0	0	0	
		Inverter reset	0	0	0	0	0	
		Operation command		0				
		(start, stop)	0	×	×	0	×	
		Running frequency	0	×	0	×	×	
	5	Monitor	0	0	0	0	^ O	
	(Ethernet board)	Parameter write	O*4	X*5	O*4	O*4	X*5	
Control by		Parameter read	0	0	0	0	0	
communication		Inverter reset	0	0	0	0	0	
via Ethernet		Operation command		O	0	0		1
board	Other than the	(start, stop)	×	×	×	×	O*1	×
board	above or when the	Running frequency	×	×	×	×	O*1	×
	CC-Link IE Field	Monitor	×	×	× 0	×	0*1	× 0
	Network Basic is	Parameter write	X*5	X*5	X*5	X*5	O*4	×*5
	selected	Parameter read	0	0	0	0	0*4	0
	Selected	Inverter reset	×	×	×	×	O*2	×
		Operation command	^	Χ	^	×	O*2	×
		•	×	×	×	×	×	O*1
aammu miaatian		(start, stop)						0.1
communication		Running frequency Monitor	×	×	×	×	×	O*1
option (via	_	Parameter write						O*4
communication)			X*5	X*5	X*5	X*5	X*5	
		Parameter read				0		0
External		Inverter reset	×	×	×	×	×	O*2
External		Inverter reset	0	0	0	0	0	
terminal at	_	Operation command	×	0	0	×	×*1	
the control		(start, stop)						
circuit		Frequency setting	×	0	×	O*8	X*1	e-11
						O: Valid ×	: Invalid ∆: Par	tially valid

#### (D) Operation command and frequency command

- \*1 The operation is as set in **Pr.338 Communication operation command source** and **Pr.339 Communication speed command source**. (Refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.)
- \*2 At occurrence of communication error, the inverter cannot be reset.
- \*3 Enabled only when stopped by the PU. "PS" is displayed on the operation panel for the PU stop. The operation is as set in **Pr.75 Reset** selection/disconnected **PU** detection/**PU** stop selection. (Refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.)
- \*4 Writing of some parameters may be disabled by the **Pr.77 Parameter write selection** setting and the operating condition. (Refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.)
- \*5 Some parameters are write-enabled independently of the operation mode and command source presence/absence. Writing is also enabled when **Pr.77** = "2". (Refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.) Parameter clear is disabled.
- \*6 Applicable when **Pr.550 NET mode operation command source selection** = "5" (Ethernet connector enabled), or **Pr.550 NET mode operation command source selection** = "9999" with no communication option connected
- \*7 Applicable when Pr.550 NET mode operation command source selection = "0 (communication option enabled)", or Pr.550 NET mode operation command source selection = "9999" with communication option connected
- \*8 The frequency can be set by multi-speed setting or input through terminal 4.

#### **♦**Operation at fault

			Operation	in each opera	ation mode at	error occurren	ces		
Fault record	Condition (Pr.551 setting)	PU operation	External (EXT) operation	EXT/PU combined operation mode 1 (Pr.79 = 3)	EXT/PU combined operation mode 2 (Pr.79 = 4)	NET operation (when the Ethernet connector is used)*5	NET operation (when a communication option is used)*6		
Inverter fault	_	Stop							
PU connector disconnection	2 (PU connector) 9999 (automatic recognition)	Stop/continue	Stop/continued*1*4						
	Other than 2	Stop/continued*1							
Communication error at PU	2 (PU connector)	Stop/ continued*2	' IContinued I ' IContinued			Continued			
connector	Other than 2	Continued							
Communication error at USB connector	3 (USB connector) 9999 (automatic recognition)	Stop/ continued*2	Continued						
connector	Other than 3	Continued							
Communication	5 (Ethernet board)	Stop/ continued*2	Continued		Stop/ continued*2	Continued			
error at Ethernet board	Other than 5 or when the CC-Link IE Field Network Basic is selected	Continued				Stop/continued*2	Continued		
Communication error at communication option	_	Continued					Stop/continued*3		

- \*1 Selectable with Pr.75 Reset selection/disconnected PU detection/PU stop selection
- \*2 Selectable with Pr.122 PU communication check time interval, Pr.548 USB communication check time interval, and Pr.1432 Ethernet communication check time interval
- \*3 The operation depends on the communication option setting.
- \*4 In the PU JOG operation mode, the operation always stops when the PU is disconnected. The operation at a PU disconnection fault (E.PUE) occurrence is as set in **Pr.75 Reset selection/disconnected PU detection/PU stop selection**.
- \*5 Applicable when **Pr.550 NET mode operation command source selection** = "5" (Ethernet connector enabled), or **Pr.550 NET mode operation command source selection** = "9999" with no communication option connected
- \*6 Applicable when Pr.550 NET mode operation command source selection = "0 (communication option enabled)", or Pr.550 NET mode operation command source selection = "9999" with communication option connected

Purpose	Pa	Refer to page		
To assign functions to the output terminals	Output terminal function assignment	P.M400 to P.M406, P.M410 to P.M412		13

## 2.4.1 Output terminal function selection

Use the following parameters to change the functions of the open collector output terminals, relay output terminals, or virtual terminals of CC-Link IE Field Network Basic.

Pr.	Name		Initial value	Initial set signal	Setting range	
190 M400	RUN terminal function selection		0	RUN (Inverter running)		
191 M401	SU terminal function selection	Open	1	SU (Up to frequency)		
192 M402	IPF terminal function selection	collector	2*1	IPF (Instantaneous power failure/undervoltage)		
141402	Turiction Selection	terminal	9999*2	No function	Inverter-to-inverter linkup (LNK) signal:	
193 M403	OL terminal function selection	terrimai	3	OL (Overload warning)	242 (positive logic), 342 (negative logic)*3	
194 M404	FU terminal function selection		4	FU (Output frequency detection)		
195 M405	ABC1 terminal function selection	Relay	99	ALM (Fault)		
196 M406	ABC2 terminal function selection	output terminal	9999	No function		
313 M410*5	DO0 output selection		9999	No function		
314 M411*5	DO1 output selection		9999	No function	Inverter-to-inverter linkup (LNK) signal: 242 (positive logic), 342 (negative logic)*4	
315 M412*5	DO2 output selection		9999	No function	1.05.07	

- \*1 The initial value is for standard models and IP55 compatible models.
- \*2 The initial value is for separated converter types.
- \*3 For the other settings, refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.
- \*4 The other available settings depend on the inverter. For details, refer to the description of **Pr.190 to Pr.196 (Output terminal function selection)** in the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.
- \*5 The parameter is used when the CC-Link IE Field Network Basic is selected. (Refer to page 57.)

#### ♦Inverter-to-inverter linkup (LNK) signal

• The Inverter-to-inverter linkup (LNK) signal is available to check that the master-slave communication is established. (For the details of the inverter-to-inverter link function, refer to page 72.)

Master/slave	Signal ON condition	Signal OFF condition		
Master	The inverter receives a response from all the slave inverters during initial communication.	The inverter does not receive a response from a slave in communication. The inverter detects a signal loss.		
Slave	The inverter returns a response to the master.	The inverter does not receive any request from the master. The inverter detects a signal loss.		

• To use the LNK signal, set "242 (positive logic) or 342 (negative logic)" in any of **Pr.190 to Pr.196 (Output terminal function selection)** to assign the function to the output terminal.



 Changing the terminal assignment using Pr.190 to Pr.196 (Output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal. 2

GROUP

# **2.5** (N) Operation via communication and its settings

Purpose	Parameter to set					
To start operation via communication	Initial setting of operation via communication	P.N001, P.N010, P.N013, P.N014	Pr.342, Pr.349, Pr.502, Pr.779	14		
To communicate via Ethernet connector	Initial setting of Ethernet communication	P.N600 to P.N603, P.N610 to P.N613, P.N630 to P.N632, P.N641 to P.N644, P.N650, P.N651, P.N660 to P.N666, P.N670 to P.N675	Pr.1424 to Pr.1429, Pr.1431, Pr.1432, Pr.1434 to Pr.1455	19		
	CC-Link IE Field Network Basic	P.N100, P.N103, P.D400, P.H700	Pr.541, Pr.544, Pr.804, Pr.810	51		
Operation via communication using the inverter-to-inverter link function	Inverter-to-inverter link function	P.N681, P.N682	Pr.1124, Pr.1125	72		

# 2.5.1 Initial setting of operation via communication

Set the action at fault occurrence or at writing of parameters when the inverter is performing operation via communication.

Pr.	Name	Initial value	Setting range	Description		
342 N001	Communication EEPROM write selection	0	0	the EEPROM and RAM by		
NUUT	EEFROW WITE SELECTION		1	Parameter values are written to	the RAM only by communication.	
349	Communication reset		0	Enables the error reset function	in any operation mode.	
N010*3	selection	0	1	Enables the error reset function mode.	only in the Network operation	
				Inverter operation when a	Inverter operation after a	
				communication error	communication error is	
			0	occurs	cleared	
	Stop mode selection at communication error	0		Output shutoff "E.EHR" indication*1 ALM signal output	Output stop status continues. ("E.EHR" indication*1)	
502 N013*2			1	Output to decelerate and stop the motor "E.EHR" indication after stop*1 ALM signal output after stop	Output stop status continues. ("E.EHR" indication <sub>*1</sub> )	
			2	Output to decelerate and stop the motor "E.EHR" indication after stop*1	Restart	
			3	Operation continues at the frequency set in <b>Pr.779</b> .	Normal	
			4	Operation continues at the frequency set in <b>Pr.779</b> . "CF" warning indication	Normal	
779	Operation frequency	0000	0 to 590 Hz	Set the frequency for the operation when a communication erroccurs.		
N014	during communication error	9999	9999	Operation continues at the same frequency before the communication error.		

<sup>\*1</sup> If in communication by the communication option, the "E.OP1" indication is displayed.

<sup>\*2</sup> The parameter setting is valid when Pr.1431 Ethernet signal loss detection function selection = "3" or Pr.1432 Ethernet communication check time interval ≠ "9999" during Ethernet communication.

<sup>\*3</sup> The parameter is used when the CC-Link IE Field Network Basic is selected. (Refer to page 51.)

#### 2

#### **◆**Communication EEPROM write selection (Pr.342)

- When parameter write is performed via the inverter PU connector, USB communication, the Ethernet connector, or a communication option, the parameters storage device setting can be switched to RAM only from both EEPROM and RAM. Use this function if parameter settings are changed frequently.
- When changing the parameter values frequently, set "1" in **Pr.342 Communication EEPROM write selection** to write them to the RAM only. The life of the EEPROM will be shorter if parameter write is performed frequently with the setting unchanged from "0 (initial value)" (EEPROM write).

#### • NOTE

- Turning OFF the inverter's power supply clears the modified parameter settings when **Pr.342** = "1" (write to RAM only). Therefore, the parameter values at next power-ON are the values last stored in EEPROM.
- The parameter setting written in RAM cannot be checked on the operation panel. (The values displayed on the operation panel are the ones stored in EEPROM.)


#### ◆Operation selection at a communication error (Pr.502, Pr.779)

- For communication via the Ethernet connector or a communication option, operation at a communication error can be selected. The operation is active under the Network operation mode.
- The operation at a communication error can be selected with Pr.502 when Pr.1431 Ethernet signal loss detection function selection = "3" or Pr.1432 Ethernet communication check time interval ≠ "9999" during Ethernet communication.
- When a communication error is detected during communication via the Ethernet connector while **Pr.1431 Ethernet signal loss detection function selection** = "2 or 3", the alarm (LF) signal is output via an output terminal of the inverter. For the LF signal, set "98 (positive logic) or 198 (negative logic)" in any of **Pr.190 to Pr.196 (Output terminal function selection)** to assign the function to the output terminal. (While communication is performed with a communication option, the LF signal is output only when "3 or 4" is set in **Pr.502**.)

	Pr.502	At fault occurrence			At fault removal		
Fault record	setting	Operation	Indication	Fault (ALM) signal	Operation	Indication	Fault (ALM) signal
	0 (initial value)	Output shutoff	"E. EHR"*1	ON	Output stop status continues.	"E. EHR"*1	ON
	1	Output to	"E.EHR" after	ON after stop	Continues.		
Communication line	2	decelerate and stop the motor	stop*1		Restart*3	Normal	
	3	Operation continues at the	Normal	OFF			OFF
	4	frequency set in <b>Pr.779</b> .*2	"CF" warning				
	0, 3	Output shutoff	"E. 1"	ON	Output stop		
Communication option (when a communication option is used)	1, 2	Output to decelerate and stop the motor	"E. 1" after stop	ON after stop	status continues.	"E. 1"	ON
	4	Operation continues at the frequency set in <b>Pr.779.</b> *2	"CF" warning	OFF	Operation continues at the frequency set in <b>Pr.779</b> .	"CF" warning	OFF

- \*1 If in communication by the communication option, the "E.OP1" indication is displayed.
- \*2 Under position control, the operation is continued to the target position.
- \*3 When the communication error is removed during deceleration, the motor re-accelerates. Under position control, the motor does not re-accelerate even when the communication error is removed during deceleration.


GROUP N • The following charts show operations when a communication line error occurs.



#### NOTE:

When the Pr.1431 setting is changed to a value other than "3" after the operation defined by the Pr.502 setting starts, the
operation will be changed according to the Pr.1431 setting.

• The following charts show operations when a communication option is used and a fault occurs.



#### • NOTE

- When a communication option is used, the protective function [E.OP1 (fault data: HA1)] is activated at error occurrences on the communication line. The protective function [E.1 (fault data: HF1)] is activated at error occurrences in the communication circuit inside the option.
- Fault output indicates the Fault (ALM) signal and an alarm bit output.

ON

OFF

OFF

(ALM) Alarm signal

(LF)

- When the fault output is set enabled, fault records are stored in the faults history. (A fault record is written to the faults history at a fault output.)
- When the fault output is not set enabled, fault record is overwritten to the faults history of the faults history temporarily but not stored
- After the fault is removed, the fault indication goes back to normal indication on the monitor, and the faults history goes back to the previous status.
- When Pr.502 ≠ "0", the normal deceleration time setting (settings of Pr.8, Pr.44, and Pr.45, etc.) is applied as the deceleration time. Normal acceleration time setting (settings of Pr.7 and Pr.44, etc.) is applied as the acceleration time for restart.
- When **Pr.502** = "2, 3, or 4", the inverter operates with the start command and the speed command, which were used before the fault.
- If a communication line error occurs, then the error is removed during deceleration while **Pr.502** = "2", the motor reaccelerates from that point. (When a communication option is used, acceleration does not restart at a communication option error.)
- The **Pr.502** and **Pr.779** settings are valid when communication is performed via the Ethernet connector or a communication option.
- These parameters are valid under the Network operation mode. When performing communication via the Ethernet connector, set Pr.551 PU mode operation command source selection ≠ "5".
- Pr.502 is valid for the device that has the command source under the Network operation mode. If a communication option is
  installed while Pr.550 = "9999 (initial value)", an Ethernet connector communication error occurs and Pr.502 becomes
  invalid.
- If the communication error setting is disabled with the settings of **Pr.502** = "3" and **Pr.1432** = "9999", the inverter does not continue its operation at the frequency set in **Pr.779** when a communication error occurs.
- If a communication error occurs while continuous operation at the frequency set in Pr.779 is selected with Pr.502 = "3 or 4", the inverter operates at the frequency set in Pr.779 even though the speed command source is at the external terminals.
   Example) If a communication error occurs while Pr.339 = "2" and the RL signal is input through an external terminal, the operation is continued at the frequency set in Pr.779.
- · During position control, an error occurs even if "2" is set in Pr.502.

GROUP

### **A CAUTION**

• When Pr.502 = "3" and a communication line error occurs, or Pr.502 = "4" and a communication line error or a communication option fault occurs, the operation continues. When setting "3 or 4" in Pr.502, provide a safety stop countermeasure other than via communication. For example, input a signal (RES, MRS, or X92) through an external terminal or press the PU stop on the operation panel.

#### **◆Error reset operation selection at inverter fault (Pr.349)**

• In the External operation mode or the PU operation mode, use this parameter to disable an error reset command sent through the Ethernet network (CC-Link IE Field Network Basic) or from a communication option.

Pr.349 setting	Description
0 (initial value)	Error reset is enabled independently of operation mode
1	Error reset is enabled only in the network operation mode

# ◆Operation mode switching and communication startup mode (Pr.79, Pr.340)

- · Check the following before switching the operation mode.
  - The inverter is at a stop.
  - Both the STF and STR signals are off.
  - The Pr.79 Operation mode selection setting is correct. (Check the setting on the operation panel of the inverter.)
- The operation mode at power ON and at restoration from instantaneous power failure can be selected. Set a value other than "0" in Pr.340 Communication startup mode selection to select the Network operation mode.
- · After the inverter starts up in the Network operation mode, parameter write can be commanded via the network.

#### • NOTE

- The changed value in Pr.340 is applied after the next power-ON or inverter reset.
- The **Pr.340** setting can be changed on the operation panel in any operation mode.
- When setting a value other than "0" in **Pr.340**, make sure that the communication settings of the inverter are correct.

#### Parameters referred to

Pr.7 Acceleration time, Pr.8 Deceleration time Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter Pr.79 Operation mode selection Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter Pr.340 Communication startup mode selection Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter Pr.550 NET mode operation command source selection page 9 Pr.551 PU mode operation command source selection page 9 Pr.1431 Ethernet signal loss detection function selection page 19 Pr.1432 Ethernet communication check time interval page 19

# 2.5.2 Initial settings and specifications of Ethernet communication

Use the following parameters to perform required settings for Ethernet communication between the inverter and other devices.

To make communication between other devices and the inverter, perform the initial settings of the inverter parameters to match the communication specifications of the devices. Data communication cannot be made if the initial settings are not made or if there is any setting error.

Pr.	Name	Initial value	Setting range	Description			
1434 N600*1	Ethernet IP address 1	192	0 to 255				
1435 N601*1	Ethernet IP address 2	168	0 to 255	Enter the ID address of the inv	erter to be connected to Ethernet.		
1436 N602*1	Ethernet IP address 3	50	0 to 255	Litter the ir address of the life	erter to be connected to Ethernet.		
1437 N603*1	Ethernet IP address 4	1	0 to 255				
1438 N610*1	Subnet mask 1	255	0 to 255				
1439 N611*1	Subnet mask 2	255	0 to 255	Enter the subnet mask of the r	network to which the inverter		
1440 N612*1	Subnet mask 3	255	0 to 255	belongs.			
1441 N613*1	Subnet mask 4	0	0 to 255				
1427 N630*1	Ethernet function selection 1	5001	502, 5000 to 5002, 5006 to 5008, 5010 to 5013, 9999, 45237, 61450				
1428 N631*1	Ethernet function selection 2	45237	502, 5000 to 5002, 5006 to 5008, 5010 to 5013, 9999, 45237, 61450	Set the application, protocol, etc.			
1429 N632*1	Ethernet function selection 3	9999	502, 5000 to 5002, 5006 to 5008, 5010 to 5013, 9999, 45237, 61450				
1426 N641*1	Link speed and duplex mode selection	0	0 to 4	Set the communication speed (full-duplex/half-duplex).	and the communication mode		
1455 N642	Keepalive time	3600 s	1 to 7200 s	When no response is returned (KeepAlive ACK) for the time ( elapsed, the connection will be	s) set in <b>Pr.1455</b> multiplied by 4		
			0	Signal loss detection disabled			
1431	Ethernet signal loss detection function selection		1	A warning (EHR) is output for a signal loss.	Set the availability of the signal loss detection and select the		
N643			2	A warning (EHR) and the Alarm (LF) signal are output for a signal loss	action when Ethernet communication is interrupted by physical factors.		
			3	A protective function (E.EHR) is activated for a signal loss.			

GROUP

#### (N) Operation via communication and its settings

Pr.	Name	Initial value	Setting range	Description
			0	Ethernet communication is available, but the inverter trips in the NET operation mode.
1432 N644	Ethernet communication check time interval	9999	0.1 to 999.8 s	Set the interval of the communication check (signal loss detection) time for all devices with IP addresses in the range specified for Ethernet command source selection ( <b>Pr.1449 to Pr.1454</b> ).  If a no-communication state persists for the permissible time or longer, the inverter will trip.
			9999	No communication check (signal loss detection)
1424 N650*1	Ethernet communication network number	1	1 to 239	Enter the network number.
1425 N651*1	Ethernet communication station number	1	1 to 120	Enter the station number.
1442 N660*1	Ethernet IP filter address	0	0 to 255	
1443 N661*1	Ethernet IP filter address 2	0	0 to 255	
1444 N662*1	Ethernet IP filter address	0	0 to 255	Sat the range of connectable ID addresses for the network
1445 N663*1	Ethernet IP filter address	0	0 to 255	Set the range of connectable IP addresses for the network devices.  (When <b>Pr.1442 to Pr.1445</b> = "0 (initial value)", the function is
1446 N664*1	Ethernet IP filter address 2 range specification	9999	0 to 255, 9999	invalid.)
1447 N665*1	Ethernet IP filter address 3 range specification	9999	0 to 255, 9999	
1448 N666*1	Ethernet IP filter address 4 range specification	9999	0 to 255, 9999	
1449 N670*1	Ethernet command source selection IP address 1	0	0 to 255	
1450 N671*1	Ethernet command source selection IP address 2	0	0 to 255	To limit the network devices that send the operation or speed
1451 N672*1	Ethernet command source selection IP address 3	0	0 to 255	command through the Ethernet network (Modbus/TCP or CC- Link IE Field Network Basic), set the range of IP addresses of the devices. When <b>Pr.1449 to Pr.1452</b> = "0 (initial value)", no IP address is
1452 N673*1	Ethernet command source selection IP address 4	0	0 to 255	specified for sending commands through the Ethernet network. In this case, operation through the Ethernet network (Modbus/TCP or CC-Link IE Field Network Basic) is not available.
1453 N674*1	Ethernet command source selection IP address 3 range specification	9999	0 to 255, 9999	When four or more clients attempt a connection to the inverter during Modbus/TCP communication, the connection attempted from outside of the IP address range set for Ethernet command source selection may be forced to be closed.
1454 N675*1	Ethernet command source selection IP address 4 range specification	9999	0 to 255, 9999	

<sup>\*1</sup> The setting is applied after an inverter reset or power-ON.

#### • NOTE

• The monitored items and parameter settings can be read during communication with the Pr.1432 Ethernet communication check time interval = "0" setting, but an inverter fault occurs instantly when the operation mode is switched to the NET operation mode. When the NET operation mode is selected as the start-up operation mode, communication is performed once, then an Ethernet communication fault (E.EHR) occurs.

To perform operation or parameter writing via communication, set Pr.1432 to "9999" or a value larger than the communication cycle or retry time setting. (Refer to page 25.)

Refer to the Instruction Manual of the device connected via Ethernet, and set **Pr.1427 to Pr.1429 Ethernet function** selection 1 to 3 according to the application and protocol.

A communication socket is provided only for the selected application.

Pr.1427 to Pr.1429 setting	Application*1	Number of connectable clients	Refer to page	
502	Modbus/TCP	TCP/IP	3	39
5000		UDP/IP	No limit	
5001 ( <b>Pr.1427</b> initial value)*2				
5002*2	MELSOFT / FA product connection	TCP/IP	1*3	26
5006	NILLSOI 171A product connection	UDP/IP	No limit	20
5007	]	TCP/IP	1*3	
5008	1	UDP/IP	No limit	1
5010		UDP/IP	No limit	
5011	SLMP	ODF/IF	NO IIIIII	27
5012	SLIVIE	TCP/IP	1*3	21
5013	1	TCF/IF	1*3	
45237 ( <b>Pr.1428</b> setting)	iQSS	UDP/IP	No limit	*4
61450	CC-Link IE Field Network Basic	UDP/IP	No limit	51
9999 ( <b>Pr.1429</b> initial value)		_		

- \*1 If both application and protocol settings are identical in Pr.1427 to Pr.1429, the priority of the setting is defined as follows: Pr.1427 > Pr.1428 > Pr.1429.
  - (Example) When Pr.1427 = "5001", Pr.1428 = "5006", Pr.1429 = "5013", "5001" and "5013" are valid.
- \*2 To connect the inverter and FR Configurator2 via the MELSOFT / FA product for Ethernet communication, set "5001 (initial value)" or "5002" according to the protocol type (UDP/IP or TCP/IP) in any of **Pr.1427 to Pr.1429**.
- \*3 When the inverter is connected with other equipment via a hub, and if the communication between the other equipment and the hub is interrupted and resumed, the communication between the inverter and the other equipment may not be established depending on the specifications of the hub. To re-establish communication with the other equipment, reset the inverter to forcefully close the connection. (Setting a shorter time in **Pr.1455 Keepalive time** is also effective as a preventive measure (refer to page 22).)
- \*4 For details, refer to the Instruction Manual of FR Configurator2.

#### **♦**Communication speed and full-duplex/half-duplex selection (Pr.1426)

Set the communication speed and the communication mode (full-duplex/half-duplex) in **Pr.1426 Link speed and duplex mode selection**.

If the operation is not performed properly in the initial setting (**Pr.1426** = "0"), set **Pr.1426** according to the specifications of the connected hub.


Pr.1426 setting	Communication speed	Full-duplex/half- duplex system	Remarks		
0 (initial value)	Automatic negotiation	Automatic negotiation	The communication speed and the communication mode (half-duplex/full-duplex) are automatically negotiated to ensure the optimum setting.		
1	100 Mbps	Full-duplex	_		
2	100 Mbps	Half-duplex	_		
3	10 Mbps	Full-duplex	_		
4	10 Mbps	Half-duplex	_		

2

GROUP **N** 


#### **♦IP address (Pr.1434 to Pr.1437)**

Enter the IP address of the inverter to be connected to Ethernet in **Pr.1434 to Pr.1437**. (Enter the IP address assigned by the network administrator.)




#### **♦**Subnet mask (Pr.1438 to Pr.1441)

Enter the subnet mask of the network to which the inverter belongs in Pr.1438 to Pr.1441.




#### ◆Keepalive time (Pr.1455)

An alive check message (KeepAlive ACK) is sent to a device if the device does not return any response within the time set in **Pr.1455 Keepalive time** while a TCP connection is established. When no response is returned after the third transmission, the connection will be forced to be closed.



• Set the IP address range for connectable network devices (**Pr.1442 to Pr.1448**) to limit the connectable devices. The IP address setting range depends on the settings in **Pr.1443** and **Pr.1446**, **Pr.1444** and **Pr.1447**, and **Pr.1445** and **Pr.1445** and **Pr.1445** and **Pr.1445**.)



In this case, the IP address range in which Ethernet communication is permitted is "192.168.x (1 to 3).xxx (100 to 150)".

[Setting example 2]				
[	Pr.1442	Pr.1443	Pr.1444	Pr.1445
Ethernet IP address for filtering	192	168	2	100
		_	e is between s set in both ers.	
F10 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -		Pr.1446	Pr.1447	Pr.1448
Filtering range setting for the Ethernet IP address	_	9999	9999	50

In this case, the IP address range in which Ethernet communication is permitted is "192.168.2.xxx (50 to 100)".

- When Pr.1442 to Pr.1445 = "0 (initial value)", the function is invalid.
- When **Pr.1446** to **Pr.1448** = "9999 (initial value)", the range is invalid.

#### **CAUTION**

■ The Ethernet IP filtering function (Pr.1442 to Pr.1448) is provided as a means to prevent unauthorized access (with intentions such as to corrupt programs or data) by external systems, but the function does not prevent it completely. In order to protect the inverter and the system against unauthorized access by external systems, take additional security measures. Mitsubishi Electric Corporation will not take any responsibility for any problems in the inverter and the system incurred by unauthorized access.

The following are examples of measures to prevent unauthorized access.


- Install a firewall.
- Install a personal computer as a relay station, and control the relaying of transmission data using an application program.
- Install an external device as a relay station to control access rights. (For the details of external devices used to control access rights, contact the distributors of the external devices.)

2

GROUP **N** 

#### **◆**Ethernet IP address for command source selection (Pr.1449 to Pr.1454)

- To limit the network devices that send the operation or speed command through the Ethernet network (Modbus/TCP or CC-Link IE Field Network Basic), set the range of IP addresses of the devices.
- When **Pr.1449 to Pr.1452** = "0 (initial value)", no IP address is specified for sending commands through the Ethernet network. In this case, operation through the Ethernet network (Modbus/TCP or CC-Link IE Field Network Basic) is not available.
- When four or more clients attempt a connection to the inverter during Modbus/TCP communication, the connection attempted from outside of the IP address range set for Ethernet command source selection may be forced to be closed.
- The setting range for command source selection depends on the settings in **Pr.1451** and **Pr.1453**, and **Pr.1452** and **Pr.1454**. (Either of the settings can be larger than the other in **Pr.1451** and **Pr.1453**, and **Pr.1452** and **Pr.1454**.)



In this case, the IP address range for command source selection via Ethernet communication is "192.168.x (1 to 3).xxx (100 to 150)".

[Setting example 2]	Pr.1449	Pr.1450	Pr.1451	Pr.1452
Ethernet IP address for command source selection	192	168	2	100
			e is between s set in both ers.	
Command source collection was a cotting			Pr.1453	Pr.1454
Command source selection range setting for the Ethernet IP address	_	_	9999	50

In this case, the IP address range in which Ethernet communication is permitted is "192.168.2.xxx (50 to 100)".

• When "9999 (initial value)" is set in Pr.1453 and Pr.1454, the range is invalid.


#### ◆Ethernet signal loss detection (Pr.1431)

Use **Pr.1431** to set the operation when Ethernet communication is interrupted by physical factors including disconnection of the Ethernet board or Ethernet cable or damages on the Ethernet cable.

Pr.1431 setting	Description	Operation panel display/indicator	LF signal output
0 (initial value)	Detection disabled	_	No
1	Warning output	EHR	No
2	Warning and alarm output	EHR	Yes
3	Protective function (E.EHR)	E.EHR	Yes

#### **◆**Ethernet communication check time interval (Pr.1432)

- If a signal loss (communication stop) is detected between the inverter and all the devices with IP addresses in the range for Ethernet command source selection (**Pr.1449 to Pr.1454**) as a result of a signal loss detection, a communication error (E.EHR) occurs and the inverter trips.
- When "9999 (initial value)" is set in Pr.1432, the communication check (signal loss detection) will not be performed.
- The monitored items and parameter settings can be read via Ethernet when "0" is set in **Pr.1432**, but a communication error (E.EHR) occurs instantly when the operation mode is switched to the Network operation.
- A signal loss detection is made when any of 0.1 s to 999.8 s is set in **Pr.1432**. In order to enable the signal loss detection, data must be sent by connected devices at an interval equal to or less than the time set for the communication check. (The inverter makes a communication check (clearing of communication check counter) regardless of the station number setting of the data sent from the master.)
- Communication check is started at the first communication when the inverter operates in the Network operation mode and the command source is specified as communication via the Ethernet connector.



# ◆Ethernet communication network number (Pr.1424), Ethernet communication station number (Pr.1425)

• When the MELSOFT / FA product connection, SLMP, or iQSS is selected for Ethernet communication, enter the Ethernet communication network number in **Pr.1424** and the Ethernet communication station number in **Pr.1425**.

2

GROUP **N** 

### 2.5.3 MELSOFT / FA product connection


FR Configurator2, GOT, or a relay station (programmable controller) can be connected via Ethernet.

#### ◆Initial setting


- Set any value from "5000 to 5002, 5006 to 5008" in any of **Pr.1427 to Pr.1429 Ethernet function selection 1 to 3** to select the MELSOFT / FA product connection for the application. (For how to set the application value, refer to the Instruction Manual of the device connected via Ethernet.) (Refer to page 21.)
- Enter the Ethernet communication network number in **Pr.1424** and the Ethernet communication station number in **Pr.1425**. (Refer to page 25.)
- Enable the PLC function (**Pr.414 PLC function operation selection** ≠ "0 (initial value)") to use FR Configurator2 (Developer). (For the details of **Pr.414**, refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.)

#### **♦**System configuration


· Direct connection with FR Configrator2



· Direct connection with GOT



· Connection using a relay station (programmable controller)



#### 2

### 2.5.4 SLMP

SLMP is a common protocol for seamless communication between applications. Users do not have to be concerned with network layers or boundaries. SLMP communications are available among devices that can transfer messages by SLMP (programmable controllers, personal computers, HMIs and others). (For the details of the SLMP compatibility of external devices, refer to the Instruction Manual of external devices.)

#### ◆Initial setting

- SLMP can be used when the PLC function is enabled. Set a value other than "0" in **Pr.414 PLC function operation** selection.
- To select SLMP for the application, set any value from "5010 to 5013" in any of **Pr.1427 to Pr.1429 Ethernet function selection 1 to 3**. (For how to set the application value, refer to the Instruction Manual of the device connected via Ethernet.) (Refer to page 21.)
- Enter the Ethernet communication network number in **Pr.1424** and the Ethernet communication station number in **Pr.1425**. (Refer to page 25.)




• The FR-A800-E/FR-F800-E inverter supports binary codes only. (ASCII codes are not supported.)

#### **♦**Communication procedure


• Using TCP/IP

The following is the communication procedure when executing SLMP communication with TCP/IP. With TCP/IP, connections are established when communication is executed, and whether data is received normally or not is checked to ensure reliability of data. However, the line load is high as compared to UDP/IP.



#### • Using UDP/IP

The following is the communication procedure when executing SLMP communication with UDP/IP. With UDP/IP, connections are not established when communication is executed, and whether data is received normally or not is not checked. Therefore, the line load is low. However, data is less reliable as compared to TCP/IP.



GROUP

#### Message format

· Request message format

The following is the format of a request message sent from the external device to the inverter. The request message data length is 2047 bytes at the maximum.

Header	Subheader	network	Destination station No.	I/O NO.	and a database of	Request data length	Monitoring timer	Request data	Footer
--------	-----------	---------	-------------------------------	---------	-------------------	---------------------	------------------	--------------	--------

· Response message format

The following is the format of a response message sent from the inverter to the external device. The response message data length is 2048 bytes at the maximum.

Normal completion

Header Subheader Destination network No.  Destination No. I/O No.  Destination unit obestination unit station No.  I/O No.  Destination network No.  Destination unit obestination unit obestination network No.  Destination network No.  I/O No.  Destination unit obestination network No.  Destination network No.  Destination unit obestination No.  Destination network No.  Destination No.  Destination unit obestination No.  Destination No.  Destina	Footer	
--	--------	--

• Failed cor	mpletion												
Header	Subheader	Destination network No.		Destinatio I/O No.		Destination multidrop station No.	Res	sponse data gth					
			End o	code	Network No. (respond station)	Station No. ding (responstation	nding	Destination ull/O No.	n	Destination multidrop station No.	Command	Subcommand	Footer

Error information

Item Size **Endian** Description Header for TCP/IP or UDP/IP. The header is added by the external device before Header transmission. Subheader Request: H5000 (QnA-compatible 2 bytes Response: HD000 3E frame) Big Subheader Request: H5400 + Serial No.\*1 + H0000 6 bytes (QnA-compatible Response: HD400 + Serial No.\*1 + H0000 4E frame) Specify the network No. of the access The own station has a network No. of H00 destination. Use a hexadecimal value to specify Destination and a station No. of HFF. The other 1 byte the network number. network No. stations have other values. Own station: H00 The request data addressed to the own Other stations: H01 to HEF (1 to 239) station is received regardless of the Specify the station No. of the access destination network No. and station No. settings. Use a hexadecimal value to specify the station The request data addressed to the other Destination station 1 byte No. stations is received when the Pr.1424 and Own station: HFF (when the network No. is H00) Pr.1425 settings are the same. Other stations: H01 to H78 (1 to 120) Destination unit I/O Fixed to H03FF 2 bytes Little No. Destination multidrop station Fixed to H00 1 byte No. Request data Specify the data length from the monitoring timer to the request data in hexadecimal. Little 2 bytes length Example) 24 bytes: H1800

Item	Size	Endian	Description						
			Set the waiting time until the inverter completes reading/writing after receiving a request message from the external device.  When the inverter does not return the response message within the waiting time, the response message will be discarded.  · H0000: Unlimited (until the execution is completed)  · H0001 to HFFFF (1 to 65535): Waiting time (Unit: 0.25 s)  Recommended setting						
			Access destination	Recommended setting					
Monitoring timer	2 bytes	Little		Monitoring, operation command, frequency setting (RAM)	H1 to H40 (0.25 to 10 s)				
			Own station	Parameter read/write, frequency setting (EEPROM)	H1 to H40 (0.25 to 10 s)				
				Parameter clear / all clear	H15 to H40 (5.25 to 10 s)				
				Monitoring, operation command, frequency setting (RAM)	H2 to H40 (0.5 to 60 s)				
			Other station	Parameter read/write, frequency setting (EEPROM)	H2 to H40 (0.5 to 60 s)				
				Parameter clear / all clear	H15 to H40 (5.25 to 60 s)				
Request data	Variable	Little	Specify the cor to page 32.)	mmand, subcommand, and data that indicate th	ne requested operation. (Refer				
Response data length	2 bytes	Little		h from the end code to the response data (whe nen failed) is stored in hexadecimal. (Unit: byte					
End code	2 bytes	Little	error code of th	processing result is stored. The value "0" is store access destination (refer to page 38) is store	ed for failed completion.				
Response data	Variable	Little	When the com- command is st	mand is completed normally, data such as the rored.	read data corresponding to the				
Error information	9 bytes	_	destination unit stations which in the request response is sto when an error	o. (responding station) (1 byte), station No. (rest I/O No. (2 bytes), and destination multidrop st respond errors are stored for failed completion message may be stored because the informationed. The command (2 bytes) and the subcommoccurred are also stored.	ation No. (1 byte) of the . Numbers different from those on on the station with error nand (2 bytes) being issued				
Footer	_	_	The footer is us device before t	sed for the TCP/IP and UDP/IP protocols. The ransmission.	footer is added by the external				

<sup>\*1</sup> The serial No. is given by the external device for message recognition. If a request message with a serial No. is sent, the same serial No. will also be added on the response message. The serial No. is used when multiple request messages are sent from an external device to the same inverter.

GROUP

#### **♦**Commands

• The following table lists the commands and subcommands. (When the inverter receives a command other than listed in the following table, it returns an error code (HC059).)

In bit units H0401 H0001 The inverter reads the v consecutive device num	nbers) in 1-bit units.  value in bit devices (with others) in 16-bit units.	to page
Batch read  In bit units H0401 H0001 consecutive device num  The inverter reads the v consecutive device num  H0001 The inverter reads the v	nbers) in 1-bit units.  value in bit devices (with others) in 16-bit units.	
Batch read In word units H0401  H0001  The inverter reads the v consecutive device num the inverter reads the v	value in bit devices (with nbers) in 16-bit units.	
In word units H0401 Consecutive device num H0001 The inverter reads the v	nbers) in 16-bit units.	
In word units H0401 The inverter reads the v	,	35
1 1H0000 1		
	,	
	value to bit devices (with	
In bit units H1401 H0001 The inverter writes the vicensecutive device num	`	
	value to bit devices (with	
Batch write H0001 consecutive device num	•	35
In word units H1401	value to word devices (with	
H0000 consecutive device num	•	
	value in the devices with the	
	devices with non-consecutive	
H0001 numbers can be specifie		
· · · · · · · · · · · · · · · · · · ·	he bit devices in 16-bit or 32-bit	
Device units.		
memory Read random In word units H0403 The inverter reads the v	value in the devices with the	36
specified numbers. The	devices with non-consecutive	
H0000 numbers can be specifie	ed.	
The value is read from t	he word devices in 1-word or 2-	
word units.		
	value to the bit devices with the	
	rs (each bit has a device	
number). The devices w	vith non-consecutive numbers	
can be specified.		
	value to the bit devices with the	
I INVITE LANGOUM I I HOUDT I .	rs (each set of 16 bits has a	37
	evices with non-consecutive	
In word units H1402 numbers can be specified	value to the word devices with	
	nbers (each word or each set of	
1 1H0000 1 '	number). The devices with	
non-consecutive numbe		
The external device exe	ecutes the remote RUN to the	
Remote run H1001 H0000 inverter.		38
Dragrammable The external device eve	ecutes the remote STOP to the	
controller CPU Remote stop H1002 H0000 Inverter.		38
CDU (investor) model name	ds the model name and model	00
read H0101 H0000 The external device real code of the inverter.		38

#### **◆**Device

• The following table lists the device codes and the range available for each command.

Dev	Туре	Device code	Range*1			
Special relay (SM)		Bit	H91	Refer to the FR-A800/FR-F800 PLC Function Programming Manual.		
Special register (SD)		Word	HA9	Neier to the FK-A000/FK-F000 FEC Function Flogramming Manual.		
Input (X)		Bit	H9C	H0 to H7F (hexadecimal)		
Output (Y)		Bit	H9D	H0 to H7F (hexadecimal)		
Internal relay (M)		Bit	H90	0 to 127 (decimal)		
Data register (D)	Data register (D)		HA8	0 to 255 (decimal)		
	Contact (TS)	Bit	HC1			
Timer (T)	Coil (TC)	DIL	HC0	0 to 15 (decimal)		
	Current value (TN)	Word	HC2			
	Contact (STS)	Bit	HC7	0 (Initial value. Up to 16 retentive timers can be used by PLC		
Retentive timer (ST)	Coil (STC)	DIL	HC6	parameter assignment.)		
	Current value (STN)	Word	HC8	parameter assignment.)		
	Contact (CS)	Bit	HC4			
Counter (C)	Coil (CC)	DIL	HC3	0 to 15 (decimal)		
	Current value (CN)	Word	HC5	1		

<sup>\*1</sup> If write/read is requested from/to any devices outside the range, the error code H4031 is returned. (Refer to page 38.)

#### **♦** Data specified in the command

· Device code

A one byte numerical value is sent.

· Device No. (first device No.) specification

The device No. is specified for reading/writing data.

When consecutive devices are specified, the first device No. is specified. The device No. is specified in decimal or hexadecimal depending on the device type.

A three byte numerical value is sent from the lower byte to the upper byte. If the device No. is a decimal value, convert it to a hexadecimal value.

(Example) Device No. of Internal relay M63 / Input X20



Internal relay M63 has a decimal device No. Convert the decimal value to a hexadecimal value H00003F. The value is sent in the order 3F, 00, and 00. The device No. of Input X20 is regarded as H000020 and sent in the order 20, 00, and 00.

· Specification of the number of devices

The number of devices is specified for reading/writing data.

A two byte numerical value is sent from the lower byte to the upper byte.

(Example) Number of devices: 5 / 20



· Specification of the number of devices for bit access

The number of devices is specified for reading/writing data in bit units. The number is used in the Write random command (refer to page 37).

(Example) Number of devices: 5 / 20




#### (N) Operation via communication and its settings

· Read data / write data

The value read from the device is stored for reading. The value to be written to the device is stored for writing. The data is arranged differently between reading/writing in bit units (subcommand: H0001) and reading/writing in word units (subcommand: H0000).


In bit units (subcommand: H0001)
 Each device is specified in 4 bits. The data is sent from the upper bit for the device with the first device No. and the subsequent devices in order. The ON state is denoted as 1 and the OFF state is denoted as 0.
 (Example) ON/OFF state of five devices starting from M10



• In word units (subcommand: H0000)

When bit devices are used as word data, each device is specified in one bit. The data is stored from the lower byte (bit 0 to bit 7) to the upper byte (bit 8 to bit 15).


(Example) ON/OFF state of 32 devices starting from M16



When word devices are used, one word is specified in 16 bits as follows. The data is stored from the lower byte (bit 0 to bit 7) to the upper byte (bit 8 to bit 15).

The user should switch the values in the upper and lower bytes in the response data for reading.

The user should switch the write values in the upper and lower bytes to store them in the request data for writing.



#### **◆**Details of commands

· Batch read

The inverter reads the value in the specified devices.

· Request data

H01 <sub>1</sub> H04	Subcommand	First device No.	Device	Num of devi	
----------------------	------------	---------------------	--------	-------------------	--

Item	Description
Subcommand	Specify the unit (bit/word) for reading.
First device No.	Specify the number of the first device. (Refer to page 33.)
Device code	Specify the type of the target devices. (Refer to page 32.)
Number of devices	Specify the number of target devices.

· Response data

The value read from the device is stored in hexadecimal.

Batch write

The inverter writes the value to the specified devices.

· Request data

	H01 . H14	Subcommand .	First device No.	Device code	Number of devices	Write data
--	-----------	--------------	---------------------	----------------	-------------------	------------

Item	Description	
Subcommand	Specify the unit (bit/word) for writing.	
First device No.	Specify the number of the first device. (Refer to page 33.)	
Device code	Specify the type of the target devices. (Refer to page 32.)	
Number of devices	Specify the number of target devices.	
Writing data	Specify the value to be written to all the devices specified by the Number of devices in the request data.	

Response data

None

2


GROUP **N** 

### · Read random

The inverter reads the value in the devices with the specified numbers. The devices with non-consecutive numbers can be specified.

Request data

Specify the devices for the specified number of devices.



Item	Description
Subcommand	Specify the unit (bit/word) for reading.
Number of devices for word access	Specify the number of devices for one-word access. (bit device: 16 bits, word device: one word)
Number of devices for double-word access	Specify the number of devices for two-word access. (bit device: 32 bits, word device: two words)
Word access	Specify the devices according to the number set in the request data for word access. It is not necessary to specify the devices when "0" is set.
Double-word access	Specify the devices according to the number set in the request data for double word access. It is not necessary to specify the devices when "0" is set.
Device No.	Specify the number of the devices. (Refer to page 33.)
Device code	Specify the type of the target devices. (Refer to page 32.)

#### · Response data


The value read from the device is stored in hexadecimal.

Data in the devices specified for word access		Data in the dev	vices specified vord access
Word access		Double-word access	
Read data 1	Read data 2	Read data 1	Read data 2

#### · Write random

The inverter writes the value in the devices with the specified numbers. The devices with non-consecutive numbers can be specified.

· Request data



Specify the devices for the specified number of devices.

Item	Description			
Subcommand	Specify the unit (bit/word) for writing.			
Number of devices for bit access				
Number of devices for word access	Specify the number of target devices.			
Number of devices for double- word access				
Word access	Specify the devices according to the number set in the request data for word access. It is not necessary to specify the devices when "0" is set.			
Double-word access	Specify the devices according to the number set in the request data for double word access. It is not necessary to specify the devices when "0" is set.			
Device No.	Specify the number of the devices. (Refer to page 33.)			
Device code	Specify the type of the target devices. (Refer to page 32.)			
	Spec	ify ON/OFF of the	bit devices.	
Cat/roast		Data t	o write	Remarks
Set/reset		ON	OFF	Remarks
		H01	H00	Either of the one byte numerical values is sent.

Response data
 None

GROUP **N** 

· Remote RUN

The external device executes the remote RUN to the inverter.

· Request data

H01, H10	H00 , H00	Mode	Clear mode	H00
----------	-----------	------	---------------	-----

Item	Description		
Mode	Forced execution of the remote RUN is not allowed.	H0100	
	Forced execution of the remote RUN is allowed.	H0300	
Clear mode	Devices are not cleared (initialized).	H00	
	Devices are cleared.	H01, H02	

 Response data None

Remote STOP

The external device executes the remote STOP to the inverter.

· Request data



 Response data None


· CPU (inverter) model name read

The external device reads the model name and model code of the inverter.

· Request data



· Response data



Item	Description	
Model	The inverter model is stored. Up to 16 characters can be stored. If the model name is shorter than 16 characters, a space (H20) is stored instead of a character. (Example) FR-A800-E inverter: FR-A800-E	
Model code	Fixed to H054E	

## **♦**Error code

When the end code is other than "0" (failed completion), one of the error codes shown in the following table will be stored.

Error code	Fault definition
H4031	The device outside of the range is specified.
H4080	Request data fault
H4A01	The network with the No. set in the routing parameter does not exist.  (The destination network No., destination station No., or destination unit I/O No. is different from that of the target inverter.)
HC059	The command or subcommand is specified incorrectly. Or, an unspecified command is received.
HC05B	The inverter cannot read/write data from/to the specified device.
HC05C	The request message has an error.
HC060	The requested operation has an error.  Example) Data is specified incorrectly for the bit device.
HC061	The request data length is inconsistent with the number of data.
HCEE1	The request message size exceeds the allowable range.
HCEE2	The response message size exceeds the allowable range.

# 2.5.5 Modbus/TCP

The Modbus/TCP protocol allows transmission of Modbus messages via Ethernet communication.

# **◆**Communication specifications


· The communication specifications are given below.

Item		Description	
Communication protocol		Modbus/TCP protocol	
Conforming standard		Open Modbus/TCP specification	
Waiting time setting		Not used	
Maximum number of connections		3	
Slave function (server)	Number of simultaneously acceptable request messages	1	

# ◆Initial setting

- To select Modbus/TCP for the application, set "502" in any of **Pr.1427 to Pr.1429 Ethernet function selection 1 to 3**. (Refer to page 21.)
- To limit the network devices that send the operation or speed command through the Ethernet network (Modbus/TCP), set the range of IP addresses (**Pr.1449 to Pr.1454**). (Refer to **page 24**.)
- Set the interval of the communication check (signal loss detection) time in Pr.1432 Ethernet communication check time interval for all devices with IP addresses in the range specified for Ethernet command source selection (Pr.1449 to Pr.1454). (Refer to page 25.)

# ◆Message format



- \*1 The chart shows the performance when the inverter is connected to a master on a 1:1 basis. (It takes 10 ms or more for parameter clear, all parameter clear, or accessing multiple registers.)
- Query

A message is sent to the slave (the inverter) having the address specified by the master.

· Normal response

After the query from the master is received, the slave executes the request function, and returns the corresponding normal response to the master.

· Error response

When an invalid function code, address or data is received by the slave, the error response is returned to the master. This response is appended with an error code that indicates the reason why the request from the master could not be executed.

This response cannot be returned for errors, detected by the hardware, frame error and header check error.

GROUP

# **♦**Message frame (protocol)

· Communication method

Basically, the master sends a query message (inquiry), and slaves return a response message (response). At normal communication, the transaction identifier, protocol identifier, and function code are copied as they are, and at erroneous communication (illegal function code or data code), bit 7 (H80) of the function code is turned ON, and the error code is set at data bytes.

Query messages from master

Transaction identifier	
Protocol identifier	
Length field	
Unit identifier	
Function code	
Eight-bit Data bytes	



Transaction identifier
Protocol identifier
Length field
Unit identifier
Function code
Eight-bit Data bytes

Response message from slave

Message frames comprise the six message fields shown in the figures above.

· Details of protocol

The following table explains the six message fields.

Transaction identifier	Protocol identifier	Length field	Unit identifier	Function	Data
2 × 8 bits	2 × 8 bits	2 × 8 bits	8 bits	8 bits	n × 8 bits

Message field	Description	
Transaction identifier	The master adds the data for the purpose of transaction control.  The same data is returned in the response from the slave.	
Protocol identifier	Fixed to 0. (When the slave receives data other than 0, it does not send the response message.)  0 is returned in the response from the slave.	
Length field	The data length from the unit identifier to the data is stored in byte.	
Unit identifier	Fixed to 255	
Function code	1 to 255 can be set in single byte length (8 bits) for the function code. The master sets the function to be sent to the slave as the request, and the slave performs the requested operation. "Function code list" summarizes the supported function codes. An error response is generated when a function code other than "Function code list" is set.  At a response from the slave, the function code set by the master is returned in the case of a normal response. At an error response, H80 and the function code are returned.	
Data	The format changes according the function code. (Refer to page 42.) The data, for example, includes the byte count, number of bytes, and accessing content of holding registers.	

# **♦**Function code list

Function name	Read/write	Code	Outline	Message format Refer to page
Read holding register	Read	H03	The data of the holding registers is read. The various data of the inverter can be read from MODBUS registers. System environmental variable (Refer to page 48.) Real time monitor (Refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.) Faults history (Refer to page 50.) Model information monitor (Refer to page 50.) Inverter parameters (Refer to page 49.)	page 42
Preset single register	Write	H06	Data is written to a holding register. Data can be written to MODBUS registers to output instructions to the inverter or set parameters. System environmental variable (Refer to page 48.) Inverter parameters (Refer to page 49.)	page 43
Diagnostics	Read	H08	Functions are diagnosed. (communication check only) A communication check can be made since the query message is sent and the query message is returned as it is as the return message (subfunction code H00 function). Subfunction code H00 (Return query data)	page 44
Preset multiple registers	Write	H10	Data is written to multiple consecutive holding registers.  Data can be written to consecutive multiple MODBUS registers to output instructions to the inverter or set parameters.  System environmental variable (Refer to page 48.)  Inverter parameters (Refer to page 49.)	page 45
Read holding register access log	Read	H46	The number of registers that were successfully accessed by the previous communication is read.  Queries by function codes H03 and H10 are supported.  The number and start address of holding registers successfully accessed by the previous communication are returned.  "0" is returned for both the number and start address for queries other than function code H03 and H10.  When the connection is closed, the data in the log is cleared.	page 46

GROUP

# ◆Read holding register (reading data of holding registers) (H03 or 03)

### · Query message

a. Transaction identifier		b. Pro iden	otocol tifier		ngth eld	d. Unit identifier	e. Function	f. Sta add	rting ress	g. No. o	of points
H	L	H	L	H	L	(8 bits)	H03	H	L	H	L
(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)		(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)

#### • Normal response (Response message)

a. Transaction identifier		b. Protocol identifier		c. Length field		d. Unit identifier	e. Function	h. Byte count		i. Data	
H (8 bits)	L (8 bits)	H (8 bits)	L (8 bits)	H (8 bits)	L (8 bits)	(8 bits)	H03 (8 bits)	(8 bits)	H (8 bits)	L (8 bits)	 (n × 16 bits)

#### · Query message setting

	Message	Description
а	Transaction identifier	The master adds the data for the purpose of transaction control.  The same data is returned in the response from the slave.
b	Protocol Identifier	Fixed to 0. (When the slave receives data other than 0, it does not send the response message.)  0 is returned in the response from the slave.
С	Length field	The data length from the unit identifier to the data is stored in byte.
d	Unit identifier	Fixed to 255
е	Function	Set H03.
f	Starting address	Set the holding register address from which to start reading the data.  Starting address = start register address (decimal) - 40001  For example, when start register address 0001 is set, the data of holding register address 40002 is read.
g	No. of points	Set the number of holding registers for reading data. Data can be read from up to 125 registers.

#### · Content of normal response

	Message	Description
h	Byte count	The setting range is H02 to HFA (2 to 250). Twice the number of reads specified by (g) is set.
i	Data	The amount of data specified by (g) is set. Read data is output Hi bytes first followed by Lo bytes, and is arranged as follows: data of start address, data of start address+1, data of start address+2, and so forth.

Example) Read the register values of 41004 (Pr.4) to 41006 (Pr.6) from slave address 17 (H11).

#### Query message

	Transaction identifier		Protocol identifier		igth eld	Unit identifier	Function	Starting address		No. of points	
*1	*1	H00 (8 bits)	H00 (8 bits)	H00 (8 bits)	H06 (8 bits)	H11 (8 bits)	H03 (8 bits)	H03 (8 bits)	HEB (8 bits)	H00 (8 bits)	H03 (8 bits)

\*1 A given value is set.

Normal response (Response message)

Transaction identifier			ocol tifier		igth eld	Unit identifier	Function	Byte count			Da	ata		
*2	*2	H00	H00	H00		H11		H06	H17		H0B	_	H03	HE8
1	_	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)

\*2 The values are the same as those in the query message.

Read value

Register 41004 (**Pr.4**): H1770 (60.00 Hz) Register 41005 (**Pr.5**): H0BB8 (30.00 Hz) Register 41006 (**Pr.6**): H03E8 (10.00 Hz)

# ◆Preset single register (writing data to holding registers) (H06 or 06)

- The content of the system environmental variables and inverter parameters (refer to MODBUS register on page 48) assigned to the holding register area can be written.
- · Query message

a. Transaction identifier			otocol tifier	c. Leng	th field	d. Unit identifier	e. Function	`	gister ress	g. Pres	et data
H (8 bits)	L (8 bits)	H (8 bits)	L (8 bits)	H (8 bits)	L (8 bits)	(8 bits)	H06 (8 bits)	H (8 bits)	L (8 bits)	H (8 bits)	L (8 bits)

• Normal response (Response message)

a. Transaction identifier			otocol tifier	c. Leng	th field	d. Unit identifier	e. Function	f. Req add	gister ress	g. Pres	et data
H (8 bits)	L (8 bits)	H (8 bits)	L (8 bits)	H (8 bits)	L (8 bits)	(8 bits)	H06 (8 bits)	H (8 bits)	L (8 bits)	H (8 bits)	L (8 bits)

· Query message setting

	Message	Description
а	Transaction identifier	The master adds the data for the purpose of transaction control.  The same data is returned in the response from the slave.
b	Protocol identifier	Fixed to 0. (When the slave receives data other than 0, it does not send the response message.)  0 is returned in the response from the slave.
С	Length field	The data length from the unit identifier to the data is stored in byte.
d	Unit identifier	Fixed to 255
е	Function	Set H06.
f	Register address	Set the holding register address to write data to. Register address = holding register address (decimal) - 40001 For example, when register address 0001 is set, data is written to holding register address 40002.
g	Preset data	Set the data to write to the holding register. Write data is fixed at 2 bytes.

• Content of normal response
With a normal response, the contents in the response are the same as those in (a) to (g) of the query message.

Example) Write 60 Hz (H1770) to 40014 (running frequency RAM) of slave address 5 (H05).

## Query message

\*1 A given value is set.

Normal response (Response message)

The same data as those in the query message

2

GROUP N

# **◆**Diagnostics (diagnosis of functions) (H08 or 08)

- A communication check can be made since the query message is sent and the query message is returned as it is as the return message (subfunction code H00 function).
   Subfunction code H00 (Return query data)
- · Query message

a. Transaction identifier			otocol tifier	c. Leng	th field	d. Unit identifier	e. Function	f. Subf	unction	g. [	Data
H	L	H	L	H	L	(8 bits)	H08	H00	H00	H	L
(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)		(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)

• Normal response (Response message)

a. Transaction identifier		b. Protocol identifier		c. Leng	. Length field d. Uni		e. Function	f. Subfi	unction	g. [	Data
H	L	H	L	H	L	(8 bits)	H08	H00	H00	H	L
(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)		(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)

#### · Query message setting

	Message	Description
а	Transaction identifier	The master adds the data for the purpose of transaction control. The same data is returned in the response from the slave.
b	Protocol identifier	Fixed to 0. (When the slave receives data other than 0, it does not send the response message.)  0 is returned in the response from the slave.
С	Length field	The data length from the unit identifier to the data is stored in byte.
d	Unit identifier	Fixed to 255
е	Function	Set H08.
f	Subfunction	Set H0000.
g	Data	Any data 2 bytes long can be set. The setting range is H0000 to HFFFF.

· Content of normal response

With a normal response, the contents in the response are the same as those in (a) to (g) of the query message.

# ◆Preset multiple registers (writing data to multiple holding registers) (H10 or 16)

- Data can be written to multiple holding registers.
- · Query message

a. Transaction identifier		b. Pro iden		c. Le	_	d. Unit identifier	e. Function	f. Sta addı	•	g. N Poi	ints	h. Byte count		i. D	ata
Н	L	Н	L	Н	L	(8 bits)	H10	Н	L	Н	L	(8 bits)	Н	L	
(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(o bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(o bits)	(8 bits)	(8 bits)	$(n\times2\times8\ bits)$

• Normal response (Response message)

a. Transaction identifier			otocol tifier		ength eld	d. Unit identifier	e. Function	f. Sta	•	g. N Poi	o. of nts
H	L	H	L	H	L	(8 bits)	H10	H	L	H	L
(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)		(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)

· Query message setting

	Message	Description
а	Transaction identifier	The master adds the data for the purpose of transaction control.  The same data is returned in the response from the slave.
b	Protocol identifier	Fixed to 0. (When the slave receives data other than 0, it does not send the response message.)  0 is returned in the response from the slave.
С	Length field	The data length from the unit identifier to the data is stored in byte.
d	Unit identifier	Fixed to 255
е	Function	Set H10.
f	Starting address	Set the holding register address from which to start writing the data.  Starting address = start register address (decimal) - 40001  For example, when start register address 0001 is set, the data of holding register address 40002 is read.
g	No. of Points	Set the number of holding registers for writing data. Data can be written to up to 125 registers.
h	Byte count	The setting range is H02 to HFA (2 to 250). Set the value set in (g) multiplied by 2.
i	Data	The amount of data specified by (g) is set. Write data is output Hi bytes first followed by Lo bytes, and is arranged as follows: data of start address, data of start address+1, data of start address+2, and so forth.

· Content of normal response

With a normal response, the contents in the response are the same as those in (a) to (g) of the query message.

Example) Write 0.5 s (H05) to 41007 (Pr.7) and 1 s (H0A) to 41008 (Pr.8) of slave address 25 (H19).

#### Query message

Transaction identifier		Protocol identifier		Len fie	igth eld	Unit identifier	Function	n Starting No. of address points		Byte count		Data			
*1	*1	H00 (8 bits)	H00 (8 bits)			_	H10 (8 bits)	H03 (8 bits)	HEE (8 bits)		 H04 (8 bits)	H00 (8 bits)			H0A (8 bits)

\*1 A given value is set.

Normal response (Response message)

	action tifier	Prot iden		igth eld	Unit identifier	Function	Starting address		No. of points	
*2	*2		 H00 (8 bits)	H06 (8 bits)	H19 (8 bits)	H10 (8 bits)		HEE (8 bits)	H00 (8 bits)	H02 (8 bits)

st2 The values are the same as those in the query message.

2

GROUP **N** 

# ◆Read holding register access log (H46 or 70)

• Queries by function codes H03 and H10 are supported.

The number and start address of holding registers successfully accessed by the previous communication are returned. "0" is returned for both the number and start address for queries other than the function codes above.

· Query message

a. Transaction identifier		b. Protocol identifier		c. Length field		d. Unit identifier	e. Function	
Н	H L		L	Н	L	(8 bits)	H46	
(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(O Dito)	(8 bits)	

· Normal response (Response message)

	nsaction ntifier	b. Pro iden	tocol tifier	c. Le fie	ngth eld	d. Unit identifier	e. Function	f. Starting address		g. No. of points	
H	L	H	L	H	L	(8 bits)	H46	H	L	H	L
(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)		(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)

#### · Query message setting

	Message	Description
а	Transaction identifier	The master adds the data for the purpose of transaction control.  The same data is returned in the response from the slave.
b	Protocol identifier	Fixed to 0. (When the slave receives data other than 0, it does not send the response message.)  0 is returned in the response from the slave.
С	Length field	The data length from the unit identifier to the data is stored in byte.
d	Unit identifier	Fixed to 255
е	Function	Set H46.

### · Content of normal response

	Message	Description					
f	Starting address	The start address of the holding register that was successfully accessed is returned. Starting address = start register address (decimal) - 40001 For example, when start address 0001 is returned, the holding register address that was successfully accessed is 40002.					
g	No. of points	The number of holding registers that were successfully accessed is returned.					

Example) Read the successful register start address and number of successful accesses from slave address 25 (H19).

### Query message

	Transaction identifier		Protocol identifier		h field	Unit identifier	Function
*1	*1	H00 (8 bits)	H00 (8 bits)	H00 (8 bits)	H02 (8 bits)	H19 (8 bits)	H46 (8 bits)

\*1 A given value is set.

Normal response (Response message)

	Transa iden			ocol tifier	Lengt	h field	Unit identifier	Function		rting ress	No. of	points
ſ	*2	*2	H00	H00	H00	H06	H19	H10	H03	HEE	H00	H02
l	**2	*2	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)

\*2 The values are the same as those in the query message.

Two successful reads of start address 41007 (Pr.7) are returned.

# **♦Error response**

- An error response is returned if the query message received from the master contains an illegal function, address or data. No response is returned for parity, overrun, framing, and busy errors.
- Error response (Response message)

a Transa iden	action		otocol tifier		ngth eld	d. Unit identifier	e. Function	f. Exception code
H (8 bits)	L (8 bits)	H (8 bits)	L (8 bits)	H (8 bits)	L (8 bits)	(8 bits)	H80 + Function (8 bits)	(8 bits)

	Message	Description			
а	Transaction identifier	The master adds the data for the purpose of transaction control.  The same data is returned in the response from the slave.			
b	Protocol identifier	Fixed to 0. (When the slave receives data other than 0, it does not send the response message.)  0 is returned in the response from the slave.			
С	Length field	The data length from the unit identifier to the data is stored in byte.			
d	Unit identifier	Fixed to 255			
е	Function	The function code requested by the master + H80 is set.			
f	Exception code	The codes in the following table are set.			

#### · Error code list

Code	Error item	Error description
01	ILLEGAL FUNCTION	The query message from the master has a function code that cannot be handled by the slave.
02	ILLEGAL DATA ADDRESS*1	The query message from the master has a register address that cannot be handled by the slave.  (No parameter, parameter cannot be read, parameter cannot be written)
03	ILLEGAL DATA VALUE	The query message from the master has data that cannot be handled by the slave. (Out of parameter write range, a mode is specified, other error)
06	SLAVE DEVICE BUSY	The request message cannot be processed because the slave is executing another operation.

- \*1 An error response is not returned in the following cases:
  - · Function code H03 (reading data of holding registers)
  - When the number of registers is specified as one or more and there are one or more holding registers from which data can be read
  - · Function code H10 (writing data to multiple holding registers)

When the number of registers is specified as one or more and there are one or more holding registers to which data can be written In other words, when function code H03 or H10 is used and multiple holding registers are accessed, an error response is not returned even if a nonexistent holding register or holding register that cannot be read or written from/to is accessed.

# • NOTE

An error response is returned if none of the accessed holding registers exist. When an accessed holding register does not
exist, the read value is 0 and the written data is invalid.

2

N

# **♦**MODBUS register

- The following shows the MODBUS registers for system environment variables (read/write), real time monitor items (read), parameters (read/write), faults history data (read/write), and model information monitor items (read).
- · System environment variables

Register	Definition	Read/write	Remarks
40002	Inverter reset	Write	Any value
40003	Parameter clear	Write	Set H965A.
40004	All parameter clear	Write	Set H99AA.
40006	Parameter clear*1	Write	Set H5A96.
40007	All parameter clear*1	Write	Set HAA99.
40009	Inverter status / control input command*2	Read/write	Refer to the following.
40010	Operation mode / inverter setting*3	Read/write	Refer to the following.
40014	Running frequency (RAM value)	Read/write	The frequency indication can be changed to the indication in rotations per minute according to the Pr.37, Pr.144, and Pr.811*4
40015	Running frequency (EEPROM value)	Write	settings. (Refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.)

- \*1 Settings in the communication parameters are not cleared.
- \*2 The data is written as a control input command for writing. The data is read as the inverter status for reading.
- \*3 The data is written as an operation mode setting for writing. The data is read as the operation mode status for reading.
- \*4 The **Pr.811** setting is available only for the FR-A800-E inverter.

#### [Inverter status / control input command]

D:4	Definition					
Bit	Control input command	Inverter status				
0	Stop command	RUN (Inverter running)*7				
1	Forward rotation command	During forward rotation				
2	Reverse rotation command	During reverse rotation				
3	RH (High-speed command)*5	SU (Up to frequency)*7				
4	RM (Middle-speed operation command)*5	OL (Overload)*7				
5	RL (Low-speed operation command)*5	IPF (Instantaneous power failure)*7*8				
6	JOG (JOG operation)*5	FU (Frequency detection)*7				
7	RT (Second function selection)*5	ABC1 (Fault)*7				
8	AU (Current input selection)*5	ABC2 (—)*7				
9	CS (Automatic restart after instantaneous power failure)*5	Safety monitor output				
10	MRS (Output stop)*5*6	0				
11	STP (STOP) (Start self-holding)*5	0				
12	RES (Inverter reset)*5	0				
13	0	0				
14	0	0				
15	0	Fault occurrence				

\*5 The signal within parentheses ( ) is the initial status. The input signal function can be changed using **Pr.180 to Pr.189 (Input terminal function selection)**. JOG operation/automatic restart after instantaneous power failure/start self-holding selection/reset cannot be controlled over a network, so in the initial status bit6, bit9, bit11, and bit12 are invalid. To use bit6, bit9, bit11, and bit12, change the signal by **Pr.185**, **Pr.186**, **Pr.189**.

For details of Pr.180 to Pr.189, refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.

- \*6 The inverter run enable signal is in the initial status for the separated converter type.
- \*7 The signal within parentheses ( ) is the initial status. The output signal function can be changed using **Pr.190 to Pr.196 (Output terminal function selection)**.

For details of Pr.190 to Pr.196, refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.

\*8 No function is assigned in the initial status for the separated converter type.

#### [Operation mode / inverter setting]

Mode	Read value	Write value
EXT	H0000	H0010*9
PU	H0001	H0011*9
EXT JOG	H0002	_
PU JOG	H0003	_
NET	H0004	H0014
PU + EXT	H0005	

\*9 Writing is available depending on the **Pr.79 and Pr.340** settings. For details, refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.

The restrictions depending on the operation mode changes according to the computer link specifications.

### · Real time monitor

For the details of the register numbers and the monitor items for the real time monitor, refer to the description of Pr.52 in the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.

Parameters

Pr.	Register	Parameter name	Read/write	Remarks
		Refer to the Instruction Manual		
0 to 999	41000 to 41999	(Detailed) of the FR-A800/FR-F800 inverter for parameter names.	Read/write	The parameter number +41000 is the register number.
C2 (902)	41902	Terminal 2 frequency setting bias (frequency)	Read/write	
C3 (902)	42092	Terminal 2 frequency setting bias (analog value)	Read/write	Analog value (%) set to C3 (902)
03 (302)	43902	Terminal 2 frequency setting bias (terminal analog value)	Read	Analog value (%) of the voltage (current) applied to terminal 2
125 (903)	41903	Terminal 2 frequency setting gain (frequency)	Read/write	
C4 (903)	42093	Terminal 2 frequency setting gain (analog value)	Read/write	Analog value (%) set to C4 (903)
C4 (903)	43903	Terminal 2 frequency setting gain (terminal analog value)	Read	Analog value (%) of the voltage (current) applied to terminal 2
C5 (904)	41904	Terminal 4 frequency setting bias (frequency)	Read/write	
C6 (004)	42094	Terminal 4 frequency setting bias (analog value)	Read/write	Analog value (%) set to C6 (904)
C6 (904)	43904	Terminal 4 frequency setting bias (terminal analog value)	Read	Analog value (%) of the current (voltage) applied to terminal 4
126 (905)	41905	Terminal 4 frequency setting gain (frequency)	Read/write	
C7 (905)	42095	Terminal 4 frequency setting gain (analog value)	Read/write	Analog value (%) set to C7 (905)
C7 (903)	43905	Terminal 4 frequency setting gain (terminal analog value)	Read	Analog value (%) of the current (voltage) applied to terminal 4
C12 (917)	41917	Terminal 1 bias frequency (speed)	Read/write	
	42107	Terminal 1 bias (speed)	Read/write	Analog value (%) set to C13 (917)
C13 (917)	43917	Terminal 1 bias (speed) (terminal analog value)	Read	Analog value (%) of the voltage applied to terminal 1
C14 (918)	41918	Terminal 1 gain frequency (speed)	Read/write	
	42108	Terminal 1 gain (speed)	Read/write	Analog value (%) set to C15 (918)
C15 (918)	43918	Terminal 1 gain (speed) (terminal analog value)	Read	Analog value (%) of the voltage applied to terminal 1
C16 (919)	41919	Terminal 1 bias command (torque/ magnetic flux)	Read/write	
	42109	Terminal 1 bias (torque/magnetic flux)	Read/write	Analog value (%) set to C17 (919)
C17 (919)	43919	Terminal 1 bias (torque/magnetic flux) (terminal analog value)	Read	Analog value (%) of the voltage applied to terminal 1
C18 (920)	41920	Terminal 1 gain command (torque/ magnetic flux)	Read/write	
	42110	Terminal 1 gain (torque/magnetic flux)	Read/write	Analog value (%) set to C19 (920)
C19 (920)	43920	Terminal 1 gain (torque/magnetic flux) (terminal analog value)	Read	Analog value (%) of the voltage applied to terminal 1
	42115	Motor temperature detection calibration (analog input)	Read/write	
C29 (925)	43925	Motor temperature detection calibration (analog input) (terminal analog value)	Read	Analog value (%) between terminals TH1 and TH2 of the FR-A8AZ
C30 (926)	41926	Terminal 6 bias frequency (speed)	Read/write	
330 (320)	42116	Terminal 6 bias (speed)	Read/write	Analog value (%) set to C31 (926)
C31 (926)	43926	Terminal 6 bias (speed)	Read	Analog value (%) of the voltage applied to terminal 6 of the FR-A8AZ
C32 (927)	41927	(terminal analog value) Terminal 6 gain frequency (speed)	Read/write	LIG I IN-MOME
002 (821)	42117	Terminal 6 gain (speed)	Read/write	Anglog value (%) set to C32 (927)
C33 (927)	43927	Terminal 6 gain (speed)	Read/write	Analog value (%) set to C33 (927)  Analog value (%) of the voltage applied to terminal 6 of
C24 (000)	44000	(terminal analog value)	Dood houst	the FR-A8AZ
C34 (928)	41928	Terminal 6 bias command (torque)	Read/write	

Pr.	Register	Parameter name	Read/write	Remarks
	42118	Terminal 6 bias (torque)	Read/write	Analog value (%) set to C35 (928)
C35 (928) 43928		Terminal 6 bias (torque) (terminal analog value)	Read	Analog value (%) of the voltage applied to terminal 6 of the FR-A8AZ
C36 (929)	41929	Terminal 6 gain command (torque)	Read/write	
	42119	Terminal 6 gain (torque)	Read/write	Analog value (%) set to C37 (929)
C37 (929)	43929	Terminal 6 gain (torque) (terminal analog value)	Read	Analog value (%) of the voltage applied to terminal 6 of the FR-A8AZ
C8 (930)	41930	Current output bias signal	Read/write	
C9 (930)	42120	Current output bias current	Read/write	Analog value (%) set to C9 (930)
C10 (931)	41931	Current output gain signal	Read/write	
C11 (931)	42121	Current output gain current	Read/write	Analog value (%) set to C11 (931)
C38 (932)	41932	Terminal 4 bias command (torque/ magnetic flux)	Read/write	
	42122	Terminal 4 bias (torque/magnetic flux)	Read/write	Analog value (%) set to C39 (932)
C39 (932)	43932	Terminal 4 bias (torque/magnetic flux) (terminal analog value)	Read	Analog value (%) of the current (voltage) applied to terminal 4
C40 (933)	41933	Terminal 4 gain command (torque/ magnetic flux)	Read/write	
	42123	Terminal 4 gain (torque/magnetic flux)	Read/write	Analog value (%) set to C41 (933)
C41 (933)	43933	Terminal 4 gain (torque/magnetic flux) (terminal analog value)	Read	Analog value (%) of the current (voltage) applied to terminal 4
C42 (934)	41934	PID display bias coefficient	Read/write	
	42124	PID display bias analog value	Read/write	Analog value (%) set to C43 (934)
C43 (934)	43934	PID display bias analog value (terminal analog value)	Read	Analog value (%) of the current (voltage) applied to terminal 4
C44 (935)	41935	PID display gain coefficient	Read/write	
	42125	PID display gain analog value	Read/write	Analog value (%) set to C45 (935)
C45 (935)	43935	PID display gain analog value (terminal analog value)	Read	Analog value (%) of the current (voltage) applied to terminal 4
1000 to 45000 to Refer to the Instruction Manual		Read/write	The parameter number + 44000 is the register number.	

## • Faults history

Register	Definition	Read/write	Remarks
40501	Faults history 1	Read/write	
40502	Faults history 2	Read	Being 2 bytes in length, the data is stored as H00OO.
40503	Faults history 3	Read	Refer to the lowest 1 byte for the error code. (Refer to the list of
40504	Faults history 4	Read	fault displays in the Instruction Manual (Detailed) of the FR-A800 inverter for error codes.)
40505	Faults history 5	Read	Performing write using the register 40501 batch-clears the faults
40506	Faults history 6	Read	history.
40507	Faults history 7	Read	Set any value as data.
40508	Faults history 8	Read	

### · Model information monitor

Register	Definition	Read/write	Remarks
44001	Inverter type (1st and 2nd characters)	Read	
44002	Inverter type (3rd and 4th characters)	Read	
44003	Inverter type (5th and 6th characters)	Read	
44004	Inverter type (7th and 8th characters)	Read	The inverter type can be read in ASCII code.
44005	Inverter type (9th and 10th characters)	Read	H20 (blank code) is set for blank area.
44006	Inverter type (11th and 12th characters)	Read	Example) For the "FR-A840-E1 (FM type)",
44007	Inverter type (13th and 14th characters)	Read	H46, H52, H2D, H41, H38, H34, H30, H2D, H45, H31, H20H20
44008	Inverter type (15th and 16th characters)	Read	
44009	Inverter type (17th and 18th characters)	Read	
44010	Inverter type (19th and 20th characters)	Read	
44011	Capacity (1st and 2nd characters)	Read	The capacity in the inverter model can be read in ASCII code. Data is read in increments of 0.1 kW, and rounds down to 0.01 kW
44012	Capacity (3rd and 4th characters)	Read	increments. H20 (blank code) is set for blank area.
44013	Capacity (5th and 6th characters)	Read	Example) 0.75K" 7" (H20, H20, H20, H20, H37)



<sup>•</sup> When a 32-bit parameter setting or monitor item is read and the value to be read exceeds HFFFF, HFFFF is returned.

# 2.5.6 CC-Link IE Field Network Basic

The CC-Link IE Field Network Basic enables CC-Link IE communication using the general-purpose Ethernet-based technology. The CC-Link IE Field Network Basic is suited to small-scale equipment for which high-speed control is not necessary, and can coexist with the standard Ethernet TCP/IP (HTTP, FTP, etc.).

Pr.	Name	Initial value	Setting range	Description
541	Frequency command	0	0	Frequency command without sign
N100	sign selection	U	1	Frequency command with sign
544 N103*1	CC-Link extended setting	0	0, 1, 12, 14, 18, 24, 28, 100, 112, 114, 118, 128	The function of the remote registers can be extended when the CC-Link IE Field Network Basic is used.
804 D400*2	Torque command source selection	0	0 to 6	In the torque control mode, the torque command source can be selected.
810 H700*2	Torque limit input method selection	0	0 to 2	The torque limit input method can be selected.

- \*1 The setting is applied after an inverter reset or power-ON.
- \*2 The setting is available for the FR-A800-E only.

# **♦**Communication specifications

Item		Description
Transmission speed		100 Mbps
Communication method		UDP/IP
Connectable units		Master: 1 Slave: up to 64
Topology		Star
Number of occupied stations		Occupies one station
	RX	64 (8 bytes)
Maximum number of links per	RY	64 (8 bytes)
station	RWr	32 (64 bytes)
	RWw	32 (64 bytes)
Reference response time*1		Within 15 ms

<sup>\*1</sup> The reference response time is the period from when the inverter receives a command from the master until the inverter returns the response to the master.

# ♦Initial setting

- To select the CC-Link IE Field Network Basic for the application, set "61450" in any of **Pr.1427 to Pr.1429 Ethernet** function selection 1 to 3. (Refer to page 21.)
- To limit the network devices that send the command through the Ethernet network (CC-Link IE Field Network Basic), set the range of IP addresses (**Pr.1449 to Pr.1454**). (Refer to **page 24**.)
- Use Pr.1432 Ethernet communication check time interval to set the interval of the check time (for signal loss detection)
  for all devices with IP addresses in the range specified for Ethernet command source selection (Pr.1449 to Pr.1454). (Refer
  to page 25.)

# • NOTE

- To use the CC-Link IE Field Network Basic, do not install the FR-A8NC to the inverter. (Doing so disables communication through the CC-Link IE Field Network Basic.)
- When the CC-Link IE Field Network Basic is used, a communication error (E.EHR) occurs regardless of the Pr.1432
   Ethernet communication check time interval setting in the following cases: the data addressed to the own station is not received for the predetermined timeout period or longer, or the status bit of the cyclic transmission addressed to the own station turns OFF (when the master gives a command to stop the cyclic transmission). (For the details of the timeout period, status bit of the cyclic transmission, and command to stop the cyclic transmission, refer to the Instruction Manual of the master controller which supports the CC-Link IE Field Network Basic.)

2

GROUP

# **♦CC-Link extended setting (Pr.544)**

• Use this parameter to select the function of the remote registers for the CC-Link IE Field Network Basic.

Pr.544 setting	Description	Refer to page	
0 (initial setting)	Compatible with CC-Link Ver.1		53
1	Compatible with CC-Link Ver.1		54
12	Compatible with the double setting of CC-Link Ver.2		54
14	Compatible with the quadruple setting of CC-Link Ver.2		54
18	Compatible with the octuple setting of CC-Link Ver.2		55
24	Compatible with the quadruple setting of CC-Link Ver.2		54
28	Compatible with the octuple setting of CC-Link Ver.2		55
100	Compatible with CC-Link Ver.1		
112	Compatible with the double setting of CC-Link Ver.2		
114	Compatible with the quadruple setting of CC-Link Ver.2	<del>*</del> 1	
118	Compatible with the octuple setting of CC-Link Ver.2		
128	Compatible with the octuple setting of CC-Link Ver.2		

<sup>\*1</sup> Refer to the PLC function programming manual.

# ◆Frequency command with sign (Pr.541)

- The start command (forward/reverse rotation) can be inverted by adding a plus or minus sign to the value of the frequency command sent through the CC-Link IE Field Network Basic.
- The **Pr.541 Frequency command sign selection** setting is applied to the frequency command from RWw1. (Refer to page 58.)

Speed setting using Pr.37 and Pr.144	Pr.541 setting	Sign	Setting range	Actual frequency command
Not used	0	Not used	0 to 59000	0 to 590.00 Hz
Not used	1	With	-32768 to 32767 (two's complement)	-327.68 to 327.67 Hz
With	0	Not used	0 to 65535	It depends on Pr.37, Pr.144, Pr.811*1
vvitn	1	With	-32768 to 32767 (two's complement)	(in 1 or 0.1 increments)

<sup>\*1</sup> **Pr.811** is only available for the FR-A800-E.

• Relationship between the start command and sign (Pr.541="1")

Start command	Sign of the frequency command	Actual run command
Forward rotation	+	Forward rotation
Forward rotation	-	Reverse rotation
Reverse rotation	+	Reverse rotation
Reverse rotation	-	Forward rotation



- When Pr.541 = 1 (with sign)
- When EEPROM write is specified with the RYE, write mode error (error code H01) will occur.
- When concurrent execution of both RYD and RYE is enabled (when a value other than 0 is set in **Pr.544**) and both RYD and RYE are turned on, RYD has precedence.
- When power is turned on (inverter reset), the initial setting status of the sign bit is "positive" and the set frequency is "0 Hz". (The motor does not operate at the frequency set before turning OFF the power (inverter reset).)
- When set frequency is written with the instruction code of HED and HEE, the sign of the frequency command is not changed.
- Setting Pr.811 Set resolution switchover ="1 or 11" changes the increment from 1 r/min to 0.1 r/min.

# ♦I/O signal list

## ◆ When Pr.544 = "0" (compatible with CC-Link Ver.1)

• Remote I/O (32 points)

Device	Signal	Referto	Device	Signal	Referto
No.*6		page	No.*6		page
RYn0	Forward rotation command*3	56	RXn0	Forward running	57
RYn1	Reverse rotation command*3	56	RXn1	Reverse running	57
RYn2	High-speed operation command (terminal RH function)*1	56	RXn2	Running (terminal RUN function)*4	57
RYn3	Middle-speed operation command (terminal RM function)*1	56	RXn3	Up to frequency (terminal SU function)*4	57
RYn4	Low-speed operation command (terminal RL function)*1	56	RXn4	Overload alarm (terminal OL function)*4	57
RYn5	Jog operation command (terminal Jog function)*1	56	RXn5	Instantaneous power failure (terminal IPF function)*4	57
RYn6	Second function selection (terminal RT function)*I	56	RXn6	Frequency detection (terminal FU function)*4	57
RYn7	Current input selection (terminal AU function)*1	56	RXn7	Error (terminal ABC1 function)*4	57
RYn8	Selection of automatic restart after instantaneous power failure (terminal CS function)*1, *2	56	RXn8	— (terminal ABC2 function)*4	57
RYn9	Output stop (terminal MRS function)*1	56	RXn9	Pr.313 assignment function (DO0)*5	57
RYnA	Start self-holding selection (terminal STOP function)*1	56	RXnA	Pr.314 assignment function (DO1)*5	57
RYnB	Reset (terminal RES function)*1	56	RXnB	Pr.315 assignment function (DO2)*5	57
RYnC	Monitor command	56	RXnC	Monitoring	57
RYnD	Frequency setting command (RAM)	56	RXnD	Frequency setting completion (RAM)	57
RYnE	Frequency setting command (RAM, EEPROM)	56	RXnE	Frequency setting completion (RAM, EEPROM)	57
RYnF	Instruction code execution request	56	RXnF	Instruction code execution completion	57
RY(n+1)0 to RY(n+1)7	Reserved	_	RX(n+1)0 to RX(n+1)7	Reserved	_
RY(n+1)8	Not used (initial data process completion flag)	_	RX(n+1)8	Not used (initial data process request flag)	_
RY(n+1)9	Not used (initial data process request flag)	_	RX(n+1)9	Not used (initial data process completion flag)	_
RY(n+1)A	Error reset request flag	56	RX(n+1)A	Error status flag	57
RY(n+1)B			RX(n+1)B	Remote station ready	57
to RY(n+1)F	Reserved		RX(n+1)C to RX(n+1)F	Reserved	

- \*1 These signals are set in the initial status. Using **Pr.180 to Pr.189**, you can change input signal functions. Refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter for details of **Pr.180 to Pr.189**.
- \*2 For the FR-F800-E, no function is assigned in the initial setting.
- \*3 The signals are fixed. They cannot be changed using parameters.
- \*4 These signals are set in the initial status. Using **Pr.190 to Pr.196**, you can change output signal functions. Refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter for details of **Pr.190 to Pr.196**.
- \*5 Output signal can be assigned using **Pr.313 to Pr.315**. The setting range depends on the inverter. For details, refer to the description of **Pr.190** to **Pr.196** (Output terminal function selection) in the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.
- \*6 "n" indicates a value determined according to the station number setting.
- · Remote register

Address*9	Descr	Referto	
Address*9	Upper 8 bits	Lower 8 bits	page
RWwn	Monitor code 2	Monitor code 1	58
RWwn+1	Set frequency (0.01 Hz increments) / torque command*8		58
RWwn+2	H00 (arbitrary)*7	Instruction code	58
RWwn+3	Write data		58

Address*9	Description	Refer to page
RWrn	First monitor value	59
RWrn+1	Second monitor value	59
RWrn+2	Reply code	59
RWrn+3	Read data	59

- \*7 The above 8 bit is always H00 even if a value other than H00 is set.
- \*8 For the FR-A800-E, when **Pr.804=**"3 or 5" during torque control under Real sensorless vector control or vector control, a torque command value is set in RWwn+1.
- \*9 "n" indicates a value determined according to the station number setting.



GROUE

## ◆ When Pr.544 = "1" (compatible with CC-Link Ver.1)

Remote I/O (32 points)
 Same as when Pr.544 = 0 (Refer to page 53.)

· Remote register

Address*2	Descr	Referto	
Address*2	Upper 8 bits	Lower 8 bits	page
RWwn	Monitor code 2	Monitor code 1	58
RWwn+1	Set frequency (0.01 Hz increments) / torque command*1		58
RWwn+2	Link parameter extended setting	Instruction code	58
RWwn+3	Write data	•	58

Address*2	Descr	Referto	
Audi ess*2	Upper 8 bits	Lower 8 bits	page
RWrn	First monitor value	First monitor value	
RWrn+1	Second monitor value		59
RWrn+2	Reply code 2 Reply code 1		59
RWrn+3	Read data		59

<sup>\*1</sup> For the FR-A800-E, when **Pr.804=**"3 or 5" during torque control under Real sensorless vector control or vector control, a torque command value is set in RWwn+1.

# ◆ When Pr.544 = "12" (Compatible with the double setting of CC-Link Ver.2)

• Remote I/O (32 points)
Same as when **Pr.544** = 0 (Refer to **page 53**.)

· Remote register

Address*2	Desci	Referto	
Address*2	Upper 8 bits	Lower 8 bits	page
RWwn	Monitor code 2	Monitor code 1	58
RWwn+1	Set frequency (0.01 Hz increments) / torque command*1		58
RWwn+2	Link parameter extended setting	Instruction code	58
RWwn+3	Write data		58
RWwn+4	Monitor code 3		58
RWwn+5	Monitor code 4		58
RWwn+6	Monitor code 5		58
RWwn+7	Monitor code 6		58

Address*2	Descr	Referto	
Address*2	Upper 8 bits	Lower 8 bits	page
RWrn	First monitor value		59
RWrn+1	Second monitor value		59
RWrn+2	Reply code 2	Reply code 1	59
RWrn+3	Read data		59
RWrn+4	Third monitor value		59
RWrn+5	Fourth monitor value		59
RWrn+6	Fifth monitor value		59
RWrn+7	Sixth monitor value		59

<sup>\*1</sup> For the FR-A800-E, when **Pr.804=**"3 or 5" during torque control under Real sensorless vector control or vector control, a torque command value is set in RWwn+1.

## ◆ When Pr.544 = "14 or 24" (compatible with the quadruple setting of CC-Link Ver.2)

• Remote I/O (32 points (64 points occupied))
Same as when **Pr.544** = 0 (Refer to **page 53**.)

· Remote register

Address <sub>*4</sub>	Descr	ription	Referto
Address*4	Upper 8 bits	Lower 8 bits	page
RWwn	Monitor code 2	Monitor code 1	58
RWwn+1	Set frequency (0.01 F	Iz increments)	58
RWwn+2	Link parameter extended setting	Instruction code	58
RWwn+3	Write data	•	58
RWwn+4	Monitor code 3		58
RWwn+5	Monitor code 4		58
RWwn+6	Monitor code 5		58
RWwn+7	Monitor code 6		58
RWwn+8	Faults history No.	H00	58
RWwn+9	PID set point (0.01%	increments)*1	58
RWwn+A	PID measured value (0.01% increments)*1		58
RWwn+B	PID deviation (0.01% increments)*1		58
RWwn+C	Torque command or to Torque command or to quadrant)*3	•	58, 63

Address*4	Descr	ription	Referto
Address*4	Upper 8 bits Lower 8 bi		page
RWrn	First monitor value		59
RWrn+1	Second monitor val	ue	59
RWrn+2	Reply code 2	Reply code 1	59
RWrn+3	Read data		59
RWrn+4	Third monitor value	:	59
RWrn+5	Fourth monitor valu	ie	59
RWrn+6	Fifth monitor value		59
RWrn+7	Sixth monitor value		59
RWrn+8	Faults history No.	Fault data	59
RWrn+9	Fault record (outpu	t frequency)	59
RWrn+A	Fault record (outpu	t current)	59
RWrn+B	Fault record (outpu	59	
RWrn+C	Fault record (energ	ization time)	59

<sup>\*2 &</sup>quot;n" indicates a value determined according to the station number setting.

<sup>\*2 &</sup>quot;n" indicates a value determined according to the station number setting.

Address*4	Descr	Referto	
Audress*4	Upper 8 bits	Lower 8 bits	page
RWwn+D	H00 (Free)*2 / Torque	58	
RWwn+E	H00 (Free)*2 / Torque	58	
RWwn+F	H00 (Free)*2 / Torque	limit (4th quadrant)*3	58

Address*4	Descr	Referto	
Audie55*4	Upper 8 bits	Lower 8 bits	page
RWrn+D			
RWrn+E	H00 (Free)		_
RWrn+F			

- \*1 Valid when **Pr.128**="50, 51, 60, or 61".
- \*2 Applicable when **Pr.544=**"14".
- \*3 Applicable when **Pr.544=**"24".
- \*4 "n" indicates a value determined according to the station number setting.

# ◆ When Pr.544 = "18 or 28" (compatible with the octuple setting of CC-Link Ver.2)

- Remote I/O (32 points (128 points occupied))
  Same as when **Pr.544** = 0 (Refer to **page 53**.)
- · Remote register

A diduanc	Desci	ription	Referto	Address	Desci	ription	Referto
Address*4	Upper 8 bits	Lower 8 bits	page	Address <sub>*4</sub>	Upper 8 bits	Lower 8 bits	page
RWwn	Monitor code 2	Monitor code 1	58	RWrn	First monitor value		59
RWwn+1	Set frequency (0.01 h	Iz increments)	58	RWrn+1	Second monitor va	lue	59
RWwn+2	Link parameter extended setting	Instruction code	58	RWrn+2	Reply code 2 Reply code 1		59
RWwn+3	Write data		58	RWrn+3	Read data	•	59
RWwn+4	Monitor code 3		58	RWrn+4	Third monitor value		59
RWwn+5	Monitor code 4		58	RWrn+5	Fourth monitor valu	ıe	59
RWwn+6	Monitor code 5		58	RWrn+6	Fifth monitor value		59
RWwn+7	Monitor code 6		58	RWrn+7	Sixth monitor value	)	59
RWwn+8	Faults history No.	H00	58	RWrn+8	Faults history No.	Fault data	59
RWwn+9	PID set point (0.01%	increments)*1	58	RWrn+9	Fault record (output	t frequency)	59
RWwn+A	PID measured value	(0.01% increments)*1	58	RWrn+A	Fault record (output	t current)	59
RWwn+B	PID deviation (0.01%	increments)*1	58	RWrn+B	Fault record (output	t voltage)	59
RWwn+C	Torque command or torque command or toque quadrant)*3	58, 63	RWrn+C	Fault record (energization time)		59	
RWwn+D	H00 (Free)*2 / Torque	58	RWrn+D				
RWwn+E	H00 (Free)*2 / Torque	e limit (3rd quadrant)*3	58	RWrn+E	H00 (Free)		_
RWwn+F	H00 (Free)*2 / Torque	e limit (4th quadrant)*3	58	RWrn+F	1		
RWwn+10	Link parameter extended setting	Instruction code	59	RWrn+10	Reply code		59
RWwn+11	Write data	J	59	RWrn+11	Read data		59
RWwn+12	Link parameter extended setting	Instruction code	59	RWrn+12	Reply code		59
RWwn+13	Write data	J	59	RWrn+13	Read data		59
RWwn+14	Link parameter extended setting	Instruction code	59	RWrn+14	Reply code		59
RWwn+15	Write data		59	RWrn+15	Read data		59
RWwn+16	Link parameter extended setting	Instruction code	59	RWrn+16	Reply code		59
RWwn+17	Write data		59	RWrn+17	Read data		59
RWwn+18	Link parameter extended setting		59	RWrn+18	Reply code		59
RWwn+19	Write data		59	RWrn+19	Read data		59
RWwn+1A				RWrn+1A			†
RWwn+1B	1			RWrn+1B	1		1
RWwn+1C	1			RWrn+1C	1		
RWwn+1D	H00 (Free)		-	RWrn+1D	H00 (Free)		-
RWwn+1E	†			RWrn+1E	1		1
RWwn+1F	-			RWrn+1F	1		

- \*1 Valid when **Pr.128**="50, 51, 60, or 61".
- \*2 Applicable when **Pr.544=**"18".
- \*3 Applicable when **Pr.544=**"28".
- \*4 "n" indicates a value determined according to the station number setting.

GROUP N

# **◆**Details of input and output signals

The following device No. are those for station 1. For stations 2 and later, the device No. are different. (Refer to the master module manual for correspondence between the device No. and station number)

## Output signals (master module to inverter)

The output signals from the master module are indicated. (Input signals to inverter)

Device No.	Signal		Description			
RY0	Forward rotation command*3	Stop command     Forward rotation start	When "1" is set, a start command is input to the inverter.			
RY1	Reverse rotation command*3	Stop command     Reverse rotation start	When "1" is set in RY0 and RY1, a stop command is inpu			
RY2	High-speed operation command (terminal RH function)*1					
RY3	Middle-speed operation command (terminal RM function)*1					
RY4	Low-speed operation command (terminal RL function)*1					
RY5	Jog operation command (terminal Jog function)*1					
RY6	Second function selection (terminal RT function)*1	Functions assigned to tern	ninals RH, RM, RL, JOG, RT, AU, CS, MRS, STOP, and RES			
RY7	Current input selection (terminal AU function)*1	are activated.				
RY8	Selection of automatic restart after instantaneous power failure (terminal CS function)*1, *2	-				
RY9	Output stop (terminal MRS function)*1					
RYA	Start self-holding selection (terminal STOP function)*1					
RYB	Reset (RES terminal function)*1					
RYC	Monitor command	When "1" is set in RYC, the monitored value is set in the remote register RWr0, 1, 7, and "1" is set in the monitoring (RXC). While "1" is set in RYC, the monitored dat always updated.				
RYD*5	Frequency setting command / torque command <sub>*6</sub> (RAM)	of the inverter.*4 After the writing completes completion (RXD). Under Real sensorless vercontrol, the following value • During torque control*8: 7	e set frequency/torque command (RWw1) is written to RAM s, "1" is set in the frequency setting / torque command ctor control, vector control, and PM sensorless vector e is also written to RAM at the same time. Torque command value position control: Torque limit value			
RYE*5	Frequency setting command / torque command •6 (RAM, EEPROM)	and EEPROM of the inversetting / torque command Under Real sensorless vecontrol, the following value • During torque control • During speed control / po To change the frequency of	ctor control, vector control, and PM sensorless vector e is also written to RAM and EEPROM at the same time. Torque command value position control: Torque limit value ( <b>Pr.544</b> ≠ "24 or 28") consecutively, be sure to write data to the inverter RAM.			
RYF*5	Instruction code execution request	RWw2, 10, 12, 14, 16 and request (RXF) after compl execution error occurs, a v 14, 16, 18).	ocesses corresponding to the instruction codes set to 18 are executed. "1" is set in the instruction code execution etion of instruction codes. When an instruction code value other than "0" is set in the reply code (RWr2, 10, 12,			
RY1A	Error reset request flag	When "1" is set in RY1A a error status flag (RX1A).*7	t an inverter fault, the inverter is reset, then "0" is set in the			

- \*1 Signal names are initial values. Using **Pr.180 to Pr.189**, you can change input signal functions. Note that some of signals do not accept a command from the network according to the **Pr.338** and **Pr.339** settings. For example, the RES signal (the function assigned to terminal RES) in RYB cannot be controlled via network. Refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter for details of **Pr.180 to Pr.189**, **Pr.338**, and **Pr.339**.
- \*2 For the FR-F800-E, no function is assigned in the initial setting.
- st3 The signals are fixed. They cannot be changed using parameters.
- \*4 While "1" is set in the frequency setting command (RYD), the set frequency (RWw1) is always applied.
- \*5 If "1" is set in these registers at the same time while **Pr.544** = "0," only one of these is executed.
- \*6 The torque command / torque limit setting is available only for the FR-A800-E.
- \*7 Refer to page 18 for operation conditions of inverter reset.
- \*8 Torque control cannot be performed with a PM motor.

## 2

## ◆ Input signals (inverter to master module)

The input signals to the master module are indicated. (Output signals from inverter)

Device No.	Signal	Description		
RX0	Forward running	O: Other than forward running (during stop or reverse rotation)     Forward running		
RX1	Reverse running	O: Other than reverse running (during stop or forward rotation)     Reverse running		
RX2	Running (terminal RUN function)*1			
RX3	Up to frequency (terminal SU function)*1			
RX4	Overload alarm (terminal OL function)*1			
RX5	Instantaneous power failure (terminal IPF function)*1	Functions assigned to terminals RUN, SU, OL, IPF, FU, ABC1 and ABC2 activate.		
RX6	Frequency detection (terminal FU function)*1	activate.		
RX7	Fault (terminal ABC1 function)*1			
RX8	— (terminal ABC2 function)*1	1		
RX9	— (DO0 function)*2			
RXA	— (DO1 function)*2	Functions assigned to <b>Pr.313 to Pr.315</b> are activated.		
RXB	— (DO2 function)*2	1		
RXC	Monitoring	After "1" is set in the monitor command (RYC), and the monitored value is set in the remote register Rwr0, 1, 4 to 7, "1" is set in this signal. When "0" is set in the monitor command (RYC), "0" is set in this signal.		
RXD	Frequency setting completion/torque command setting completion (RAM)*3	After "1" is set in the frequency setting command/torque command (RYD) and the frequency setting command/torque command is written to the inverter RAM, "1" is set in this signal. When "0" is set in the frequency setting command/torque command (RYD), "0" is set in this signal.		
RXE	Frequency setting completion/torque command setting completion (RAM, EEPROM)*3	After "1" is set in the frequency setting command/torque command (RYE) and the frequency setting command/torque command is written to the inverter RAM and EEPROM, "1" is set in this signal. When "0" is set in the frequency setting command/torque command (RYE), "0" is set in this signal.		
RXF	Instruction code execution completion	After "1" is set in the instruction code execution request (RYF) and the processes corresponding to the instruction codes (RWw2, 10, 12, 14, 16 and 18) are executed, "1" is set in this signal. When "0" is set in the instruction code execution request (RYF), "0" is set in this signal.		
RX1A	Error status flag	When an inverter error occurs (protective function is activated), "1" is set in this signal.		
RX1B	Remote station ready	When the inverter goes into the ready status upon completion of initial setting after power-on or hardware reset, "1" is set in this signal. When an inverter error occurs (protective function is activated), "0" is set in this signal. The signal is used as an interlock signal during the write to/read from the master module.		

- \*1 Signal names are initial values. Using **Pr.190 to Pr.196**, you can change output signal functions. Refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter for details of **Pr.190 to Pr.196**.
- \*2 Signals are not assigned in the initial setting. Use **Pr.313 to Pr.315** to assign signals to the devices RX9 to RXB. The setting range depends on the inverter. For details, refer to the description of **Pr.190 to Pr.196 (Output terminal function selection)** in the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.
- \*3 The torque command setting is available only for the FR-A800-E.

# **♦**Details of remote register

# • Remote register (master module to inverter)

• Remote register definition

Device No.	Signal		Description				
RWw0	Monitor code1, 2	Set the monitor code to be referenced specified monitored items will be stored	(Refer to page 62). When "1" is set in RYC, data of d in RWr0, RWr1.				
	Set frequency*1, *2	Specify the set frequency or speed (machine speed). At this time, whether to write to RAM or EEPROM is decided with the RYD and RYE settings. After setting the set frequency in this register, set "1" in RYD or RYE to write the frequency. After writing of frequency is completed, "1" is set in RXD or RXE in response to the input command.  The setting range is 0 to 590.00 Hz (0.01 Hz increments). Write "59000" when setting 590.00 Hz.					
RWw1	Torque command value *4	When performing torque control under Real sensorless vector control or vector control wit Pr.544 CC-Link extended setting = 0, 1, 12, and Pr.804 Torque command source selection 3, 5, specify torque command value. The value is written to the inverter either by RYD or left Pr.805 Torque command value (RAM) and Pr.806 Torque command value (RAM, EEP are also updated at the same time. The setting range and setting increments depend on the Pr.804 setting. (Refer to page 63.)					
RWw2	Link parameter extended setting/ Instruction code	Set the instruction code for execution of operation mode rewrite, parameter read/write, error reference, error clear, etc. (Refer to <b>page 60</b> .) Set "1" in RYF to execute the corresponding instruction after completing the register setting. "1" is set in RXF after completing the execution of the instruction. When a value other than "0 (100)" is set in <b>Pr.544</b> , upper eight bits are link parameter extended setting.  Example) When reading <b>Pr.160</b> , instruction code is H0200.					
RWw3	Write data	Set the data specified by the RWw2 instruction code. (When required) Set "1" in RYF after setting RWw2 and this register. Set "0" when the write code is not required.					
RWw4	Monitor code 3						
RWw5	Monitor code 4	Set the monitor code to be monitored. I	By setting "1" in RYC after setting, the specified monitored				
RWw6	Monitor code 5	data is stored in RWr4 to 7.					
RWw7	Monitor code 6						
RWw8	Faults history No.	Set how many fault records in past to be read. Back to eight fault records in past can be read. (lower 8 bits is H00) Upper 8 bits: H00 (latest fault) to H07 (eight faults in past) When H08 to HFF is set to the lower 8 bits, the fault record becomes an undetermined value.					
RWw9	PID set point*3	Set the PID set point Setting range: "0 to 100.00%"	• Input a value 100 times greater than the value to be set For example, input "10000" when setting 100.00%.				
RWwA	PID measured value*3	Set the PID measured value Setting range: "0 to 100.00%"	• Refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter for details of PID control.				
RWwB	PID deviation*3	Set the PID deviation. Setting range: "-100.00% to 100.00%"					
	Torque command value *4	vector control / vector control), torque of the inverter by RYD or RYE. <b>Pr.805</b> an	<b>Pr.804</b> = "3 or 5" during torque control (Real sensorless command values can be specified. The value is written to d <b>Pr.806</b> are also updated at the same time. The setting d on the <b>Pr.804</b> setting. If the data outside the range is set,				
RWwC	Torque limit value*4	When Pr.544 = "14 or 18", Pr.804 = "3 or 5", and Pr.810 Torque limit input method selection = "2" during speed control or position control (Real sensorless vector control / vector control / PM sensorless vector control), torque limit values can be specified. The value is written to the inverter by RYD or RYE. Pr.805 and Pr.806 are also updated at the same time. The setting range and the setting increment depend on the Pr.804 setting (absolute value). If the data outside the					
RWwC, RWwD, RWwE, RWwF	Torque limit level (1st quadrant to 4th quadrant)*4	range is set, the previous setting is retained.  When <b>Pr.544</b> = "24 or 28" and <b>Pr.810</b> = "2" during speed control or position control (Real sensorless vector control / vector control / PM sensorless vector control), torque limit values can be specified for each of the 1st to the 4th quadrants. (Setting range: 0 to 40000 (0 to 400%), setting increment: 0.01%)  The value is written to the inverter by RYD. (EEPROM write by RYE is disabled.)  When "HFFFF" is set in RWwD to RWwF, the RWwC setting is applied to the operation in the target quadrant.  When a value within the setting range of <b>Pr.805</b> or <b>Pr.806</b> is entered in RWwC while <b>Pr.804</b> = "3 or 5", the <b>Pr.805/Pr.806</b> setting is updated. If the data outside the range is set, the previous setting is retained.					

Device No.	Signal	Description
RWw10, RWw12, RWw14, RWw16, RWw18	Link parameter extended setting/ Instruction code	Set the instruction code (Refer to page 60.) for execution of operation mode rewrite, parameter read/write, error reference, error clear, etc. The instructions are executed in the following order by setting "1" in RYF after completing the register setting: RWw2, 10, 12, 14, 16, then 18. After completing the execution up to RWw18, "1" is set in RXF. Set HFFFF to disable an instruction by RWw10 to 18. (RWw2 is always executed.)  The first 8bits are link parameter extended setting.  Example) When reading <b>Pr.160</b> , instruction code is H0200.
RWw11, RWw13, RWw15, RWw17, RWw19	Write data	Set the data specified by the instruction code of RWw10, 12, 14, 16, and 18. (when required) RWw10 and 11, 12 and 13, 14 and 15, 16 and 17, and 18 and 19 correspond each other. Set "1" in RYF after setting the instruction codes (RWw10, 12, 14, 16, and 18) and the corresponding register.  Set "0" when the write code is not required.

- \*1 The display can be changed to rotations per minute according to the Pr.37, Pr.144, and Pr.811 settings. (Pr.811 is only available for the FR-A800-E.) For details, refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.
- \*2 When Pr.541 Frequency command sign selection = 1, the setting value has either + or -. When the setting value is negative, the command is inversed from starting command.
  - Setting range: -327.68 Hz to 327.67 Hz (-327.68 to 327.67) 0.01 Hz increments
  - For details refer to page 52.
- \*3 When Pr.128 = "50, 51, 60, 61", they are valid. If the data outside the range is set, the previous setting is retained. Refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter for details of Pr.128.
- \*4 The setting is available only for the FR-A800-E.

## Remote register (inverter to master module)

· Remote register definition

Device No.	Signal	Description
RWr0	First monitor value	When "1" is set in RYC, the specified monitored data is set to the lower 8 bits of the monitor code (RWw0).
RWr1	Second monitor value (Output frequency*1)	When "0" is set to the upper 8 bits of the monitor code (RWw0), the current output frequency is always set. When a value other than "0" is set to the upper 8 bits of the monitor code (RWw0) while "1" is set in RYC, the monitor data specified by the upper 8 bits of the monitor code (RWw0) is set.
	Reply code (when <b>Pr.544</b> = 0)	When "1" is set in RYD or RYE, the reply code for the frequency setting command is set. When "1" is set in RYF, the reply code corresponding to the instruction code RWw2 is set. The value "0" is set for a normal reply and any digit other than "0" is set for data fault, mode error, etc. (Refer to page 60.)
RWr2	Reply code 1 (when <b>Pr.544</b> ≠ 0)	Lower 8 bits of RWr2 When "1" is set in RYD or RYE, the reply code for the frequency setting command (torque command / torque limit) is set. (Refer to page 60.)
	Reply code 2 (when <b>Pr.544</b> ≠ 0)	Upper 8 bits of RWr2 When "1" is set in RYF, the reply code corresponding to the instruction code RWw2 is set. (Refer to page 60.)
RWr3	Read data	For a normal reply, the reply data to the instruction specified by the instruction code is set.
RWr4	Third monitor value	
RWr5	Fourth monitor value	When "1" is set in RYC, the monitored data specified by the monitor code (RWw4 to 7) is saved.
RWr6	Fifth monitor value	
RWr7	Sixth monitor value	
RWr8	Fault record (fault data)	The fault data of faults history No. specified by RWw8 is stored in the lower 8bits. Faults history No. specified is echo backed to the upper 8 bits.
RWr9	Fault record (output frequency)	Output frequency of the faults history No. specified in RWw8 is stored.
RWrA	Fault record (output current)	Output current of the faults history No. specified in RWw8 is stored.
RWrB	Fault record (output voltage)	Output voltage of the faults history No. specified in RWw8 is stored.
RWrC	Fault record (energization time)	Energization time of the faults history No. specified in RWw8 is stored.
RWr10 to RWr19	Reply code	When "1" is set in RYF, the reply codes corresponding to the instruction code RWw10, 12, 14, 16, and 18 are set. The value "0" is set for a normal reply and other than "0" is set for data fault, mode error, etc. (Refer to page 60.)
	Read data	For a normal reply, the reply data to the instruction specified by the instruction code is set.

\*1 When position control is selected for the FR-A800-E, the number of pulses is monitored when **Pr.430** ≠ "9999".

GROUP

· Reply code definition


The reply to the instruction execution is set to RWr2, 10, 12, 14, 16, 18.

When executing the frequency setting (RYD, RYE) or instruction code execution (RYF), check the reply code (RWr2) in the remote register after execution.

	Data	Item	Alarm definition	Remarks			
	H0000	Normal	Normal No error (normal completion of instruction code				
			execution)	<b>Pr.544</b> = 0			
Reply code	H0001	Write mode error	Parameter write was attempted during operation	• Reply code to RWw10, 12, 14,			
reply code	110001	Write mode error	other than a stop in the network operation mode.	16, and 18 when <b>Pr.544</b> = 18			
	H0002	Parameter selection error	Unregistered code number was set.				
	H0003	Setting range error	Set data is outside the permissible data range.				
	H00	Normal	No error (normal completion of instruction code				
	ПОО	Normal	execution)				
	H01	Write mode error	Parameter write was attempted during operation				
Reply code 1*1	1101	Write mode endi	other than a stop in the network operation mode.				
		Frequency command /					
	H03	torque command / torque	The value outside the range is set.	Donly and to DWr2 when			
		limit setting range error		Reply code to RWr2 when Pr.544 ≠ 0			
	H00	Normal	No error (normal completion of instruction code	P1.544 ≠ 0			
	ПОО	Normal	execution)				
Bonly code 2	H01	Write mode error	Parameter write was attempted during operation				
Reply code 2	1101	Write mode endi	other than a stop in the network operation mode.				
	H02	Parameter selection error	Unregistered code number was set.				
	H03	Setting range error	Set data is outside the permissible data range.				

<sup>\*1</sup> The contents of the reply code 1 are changed when torque commands are given or the torque is limited from the FR-A800-E (when **Pr.544=**"14, 18, 24, or 28").

The upper 4 bits of the reply code 1 are used as the reply code to the torque command / torque limit, and the lower 4 bits are used as the reply code to the frequency command.



Example) The error code is H0030 when the torque command value is outside the setting range.



Reply code to the torque command

### Instruction codes

Set the instruction code using a remote register (RWw) (Refer to page 58.)

The definition read by the instruction code is stored in the remote register (RWr). (Refer to page 59.)

	Item	Read/ write	Instruction code	Description		
Operation mode		Read	Н7В	H0000: Network operation mode H0001: External operation mode, External JOG operation mode H0002: PU operation mode, External/PU combined operation mode 1 and 2, PUJOG operation mode		
	oporation mode		H0000: Network operation mode HFB H0001: External operation mode H0002: PU operation mode ( <b>Pr.79</b> = "6")			
	Output frequency/ speed*1, *2	I Read I		H0000 to HFFFF Output frequency: Increments 0.01 Hz (The display can be changed to the rotations per minute using <b>Pr.37</b> , <b>Pr.144</b> and <b>Pr.811</b> *6. (Refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.))		
Monitor	Monitor Output current		H70	H0000 to HFFFF Output current (hexadecimal): Increments 0.01 A / 0.1 A*4		
	Output voltage	output voltage Read H71		H0000 to HFFFF Output voltage (hexadecimal): Increments 0.1 V		
	Special monitor	Read	H72	H0000 to HFFFF: Check the data of the monitor selected by the instruction code HF3.		
	Special monitor	Read	H73	H01 to HFF: Monitor selection data		
	selection No.	Write	HF3*3	Refer to monitor code. (Refer to page 62.)		

	lia m	Read/	Instruction				\aaavintia	<u> </u>	
	Item	write	code				escriptio	on	
				H0000	to HFFFF: Last	two fault rec	For	instruction code H74, d data H30A0	
Monitor	Faults history	Read	H74 to H77	H74 H75 H76	second fault in past Fourth fault in past Sixth fault in past	Third fault in p	past	Last fault (H30)  Last fault (H30)  Last fault THT	ılt
				(Detail	ed) of the FR-A	800/FR-F800	inverter.	Current fault O	
Set frequ	iency (RAM)	- Read	H6D	H0000 (The d		requency in ( anged to the	0.01 Hz inc rotations p		
Set frequ	iency (EEPROM)	rcau	H6E	contro	ne FR-A800-E, v	nsorless vec	tor control	2" and <b>Pr.804=</b> "3 or 5" during or vector control, torque comi on <b>Pr.804</b> .	
Set frequ	Write the set frequency/speed into the RAM or EEPROM. H0000 to HE678 (0 to 590.00 Hz): frequency in 0.01 Hz incremer (The display can be changed to the rotations per minute using Pr Pr.811*6. (Refer to the Instruction Manual (Detailed) of the FR-A8 inverter.))			n 0.01 Hz increments per minute using <b>Pr.37</b> , <b>Pr.14</b> 4 tailed) of the FR-A800/FR-F80	00				
	Set frequency (RAM and EEPROM)*5 Write HEE		HEE	<ul> <li>• To change the set frequency consecutively, write data to the inverter RAM. (Instruction code: HED)</li> <li>• For the FR-A800-E, when Pr.544="0, 1, or 12" and Pr.804="3 or 5" under torque control under Real sensorless vector control or vector control, torque commands are given.</li> <li>The setting range depends on Pr.804.</li> </ul>					
Paramete	or	Read	H00 to H63	Refer to the instruction code in the Instruction Manual (Detailed) of the FR-A800/ FR-F800 inverter to read and write as required.     Write to Pr.77 and Pr.79 is disabled.     When setting Pr.100 and later, set link parameter extended setting.					
Taramet	<b>.</b>	Write	H80 to HE3	<ul> <li>• Set 65520 (HFFF0) as a parameter value "8888" and 65535 (HFFFF) as "9999".</li> <li>• When changing the parameter values frequently, set "1" in Pr.342 to write them to the RAM. (Refer to page 14.)</li> </ul>					
Faults his	story batch clear	Write	HF4		: Clears the faul				
				Wheth data. (Refer t	O: Clear, x: Not	nunication pa clear) n Manual (De	rameters o	or not can be selected according FR-A800/FR-F800 inverter parameters.	_
					Clear t	ype	Data	Communication Pr.	
All param	neter clear	Write	HFC		Parameter clea	ar	H9696 H5A5A	O ×*7	
					All parameter	clear -	H9966 H55AA	O X+7	
				When clear is executed for H9696 or H9966, communication-related parameter settings also return to the initial values. When resuming operation, set the parameters again. Executing clear will clear the instruction code HEC, HF3, and HFF settings.					
Inverter r	reset	Write	HFD	H9696: Resets the inverter.					
	meter extended	Read	H7F	H00 to H0D: Parameter description is changed according to the instruction code					
setting*8	setting*8 Write HFF		HFF	<ul> <li>(extended) setting. Refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter for instruction code (extended) settings.</li> </ul>					
	parameter	Read	H6C	to HE1 with th	with the link pa e link parameter	rameter exter	nded settin	truction codes H5E to H61 an g = "1", H11 to H23 and H91 t	
changing	<b>*</b> 9	Write	HEC	H01: A	requency*10 nalog value set nalog value inpo				



- \*1 When "100" is set in Pr.52 Operation panel main monitor selection, frequency setting is monitored during a stop and output frequency is monitored during running.
- \*2 When position control is selected for the FR-A800-E, the number of pulses is monitored when Pr.430 ≠ "9999".
- Write data is in hexadecimal, and only last two digits are valid. (The upper two digits are ignored.)
- \*4 Differs according to capacities.
- \*5 Setting from the remote register (RWw1) is also available.
- \*6 Pr.811 is only available for the FR-A800-E.
- \*7 Turning OFF the power supply while clearing parameters with H5A5A or H55AA sets back the communication parameter settings to the initial settinas
- Setting is valid only when **Pr.544** = "0". When **Pr.544** ≠ "0", set using RWw2 or RWw10, 12, 14, 16, or 18. (Refer to page 58.)
- \*9 Reading or writing is available when the link parameter extended setting = "1 or 9".
- \*10 Gain frequencies can be written using Pr.125 (instruction code H99) and Pr.126 (instruction code H9A) also.

# NOTE:

· When the 32-bit parameter setting or monitor description are read and the read value exceeds HFFFF, the reply data will be

#### Monitor codes

Information about the inverter can be monitored by setting the special monitor selection No. of the instruction code and monitor code using the remote registers, RWw0 and RWw4 to 7.

- For the monitor code (RWw0), select the first monitor description (RWr0) from the lower 8 bits and the second monitor description (RWr1) from the upper 8 bits.
  - (Example) When output current is selected for the first monitor (RWr0) and running speed is selected for the second monitor (RWr1) → monitor code (RWw0) is H0602
- When Pr.544 = "12, 14, or 18", descriptions of monitor codes 3 (RWw4) to 6 (RWw7) can be selected.

Monitor code	Second monitor description (the first 8 bits)	First, third to sixth monitor description (the last 8 bits)	Increments
H00	Output frequency	No monitoring (monitor value is 0)	0.01 Hz
H01	Output frequency		0.01 Hz
H02	Output current		0.01 A/0.1 A
H03	Output voltage		0.1 V
-			



- The monitor codes from H01 and up and their contents are the same as those of the RS-485 communication dedicated monitor.
  - For the details of the monitor code and monitor description, refer to the section of the monitor display in the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.
- · When the remote registers RWw0 and RWw4 to 7 are used for monitoring, H00 (output frequency), H01 (output frequency), and H05 (set frequency) always indicate the frequency regardless of the settings of Pr.37, Pr.144, and Pr.811. (Pr.811 is only available for the FR-A800-E.)

# ◆Torque command / torque limit using the CC-Link IE Field Network Basic (only for the FR-A800-E)

Torque commands can be given or the torque can be limited on the CC-Link IE Field Network Basic under Real sensorless vector control, Vector control, or PM sensorless vector control. The value is used to limit the torque during speed control or position control, and to give a torque command during torque control. To limit the torque, set **Pr.810 Torque limit input method selection** ="2". The torque command / torque limit setting method can be selected using **Pr.804 Torque command source selection**. (Torque control cannot be performed with a PM motor.)

Pr.	Name	Initial value	Setting range	Description	
			0	Torque command by terminal1 analog input	
		1	Torque command / torque limit using the CC-Link IE Field Network Basic • Torque command / torque limit (-400% to 400%) by the parameter setting ( <b>Pr.805</b> or <b>Pr.806</b> )*1, *2		
		ommand	2	Torque command by the pulse train input (FR-A8AL)	
	Torque		3	Torque command / torque limit using the CC-Link IE Field Network Basic  • Torque command / torque limit (-400% to 400%) by the parameter setting ( <b>Pr.805</b> or <b>Pr.806</b> )*1, *2  • Setting is available using the remote register RWw1 or RWwC. (-400% to 400%)*2	
804	source		4	Torque command by 16 bit digital input (FR-A8AX)	
	selection	selection		5	Torque command / torque limit using the CC-Link IE Field Network Basic • Torque command / torque limit (-327.68% to 327.67%) by the parameter setting (Pr.805 or Pr.806)*1, *2 • Setting is available using the remote register RWw1 or RWwC. (-327.68% to 327.67%)*2
		6	Torque command / torque limit using the CC-Link IE Field Network Basic • Torque command / torque limit (-327.68% to 327.67%) by the parameter setting (Pr.805 or Pr.806)*1, *2		
	Torque limit	•	0	Internal torque limit (torque limited by parameter settings)	
810	input method		1	External torque limit (torque limited by terminals 1 and 4)	
	selection		2	Internal torque limit 2 (torque limit using the CC-Link IE Field Network Basic)	

- \*1 Can also be set from operation panel or parameter unit.
- \*2 When a negative value is set as the torque limit, the torque is limited by the absolute value.

# List of I/O devices whose function is changed according to the parameter settings and the control method

Pr.544	I/O device	V/F control / Advanced magnetic flux	Real sensorless vector control / vector control / PM sensorless vector control		
setting	I/O device	vector control	Speed control / position control	Torque control*4	
_	RYD	Frequency setting command (RAM)	Frequency setting / torque limit command (RAM)	Torque command (RAM)	
_	RYE	Frequency setting command (RAM, EEPROM)	Frequency setting / torque limit command (RAM, EEPROM)	Torque command (RAM, EEPROM)	
_	RXD	Frequency setting completion (RAM)	Frequency setting / torque limit completion (RAM)	Torque command completion (RAM)	
_	RXE	Frequency setting completion (RAM, EEPROM)	Frequency setting / torque limit completion (RAM, EEPROM)	Torque command completion (RAM, EEPROM)	
0, 1, 12	RWw1	Cot fraguency	Set frequency	Torque command*1	
14, 18, 24, 28	RVVWI	Set frequency	Set frequency	—	
0, 1, 12			_	—	
14, 18	RWwC	_	Torque limit*1, *2	Torque command*1	
24, 28	1		Torque limit (1st quadrant)*2, *3	Torque command*1	
24, 28	RWwD to RWwF	_	Torque limit (2nd quadrant to 4th quadrant)*2, *3	_	

- \*1 **Pr.804** ="3 or 5" must be set.
- \*2 **Pr.810** = "2" must be set.
- \*3 RYE is disabled.
- \*4 Torque control cannot be performed with a PM motor.

ROUP N

# ◆ Torque command setting method and parameter for speed limit

Pr.804 setting	Pr.544 setting	Torque command setting method (Any method below can be chosen)	Parameter for speed limit
3, 5	0, 1, 12	Set the torque command value in RWwn+1, and "1" in RYD or RYE.  Set the instruction code HED or HEE in RWwn+2, the torque command value in RWwn+3, and "1" in RYF. (Torque command value can be read by the instruction code H6D and H6E.)  Set H08 in the link parameter extended setting (HFF), the instruction code H85 or H86 in RWwn+2, the torque command value in RWwn+3, and "1" in RYF. (write to Pr.805 or Pr.806)	Pr.808, Pr.809
	14, 18, 24, 28	Set the torque command value in RWwn+C, and "1" in RYD or RYE.     Set H08 in the link parameter extended setting (HFF), the instruction code H85 or H86 in RWwn+2, the torque command value in RWwn+3, and "1" in RYF. (write to Pr.805 or Pr.806)	Pr.807
1, 6	0, 1, 12, 14, 18, 24, 28	Set H08 in the link parameter extended setting (HFF), the instruction code H85 or H86 in RWwn+2, the torque command value in RWwn+3, and "1" in RYF. (write to <b>Pr.805</b> or <b>Pr.806</b> )	Pr.007
0, 4	_	Torque command using the CC-Link IE Field Network Basic is not available.	

# ◆ Torque limit setting method

Pr.804 setting	Pr.810 setting	Pr.544 setting	Torque limit setting method (Any method below can be chosen)
		14, 18	<ul> <li>Set the torque limit value in RWwn+C, and "1" in RYD or RYE.</li> <li>Set H08 in the link parameter extended setting (HFF), the instruction code H85 or H86 in RWwn+2, the torque limit value in RWwn+3, and "1" in RYF. (write to Pr.805 or Pr.806)</li> </ul>
3, 5	2	24, 28	<ul> <li>Set the torque limit value individually for each of the four quadrants in RWwn+C to RWwn+F, and set "1" in RYD. (EEPROM write by RYE is disabled.)</li> <li>Set H08 in the link parameter extended setting (HFF), the instruction code H85 or H86 in RWwn+2, the torque limit value in RWwn+3, and "1" in RYF. (write to Pr.805 or Pr.806)</li> </ul>
1, 6		0, 1, 12, 14, 18, 24, 28	Set H08 in the link parameter extended setting (HFF), the instruction code H85 or H86 in RWwn+2, the torque limit value in RWwn+3, and "1" in RYF. (write to <b>Pr.805</b> or <b>Pr.806</b> )

# ◆ Relationship between the Pr.804 setting, the setting range, and the actual torque command / torque limit (when setting is made using the CC-Link IE Field Network Basic)


Pr.804 setting	Setting range	Actual torque command	Actual torque limit
1, 3	600 to 1400 (1% increments)*1	-400 to 400%	0 to 400%
5, 6	-32768 to 32767 (two's complement)*1	-327.68 to 327.67%	0 to 327.67%

st 1 The torque limit setting is defined as an absolute value.

This chapter provides programming examples which control the inverter with sequence programs.

Item	Program example	Refer to page
Reading the inverter status	Reading the inverter status from the buffer memory of the master station	66
Setting the operation mode	Selecting the network operation mode	67
Setting the operation commands	Commanding the forward rotation and middle speed signals	67
Setting the monitoring function	Monitoring the output frequency	68
Reading a parameter value	Reading the value of Pr.7 Acceleration time	68
Writing a parameter value	Setting "3.0 s" in Pr.7 Acceleration time	69
Setting the running frequency (running speed)	Setting to 50.00 Hz	69
Reading the fault records	Reading the inverter faults	70
Inverter reset	Perform inverter reset at an inverter alarm occurrence.	70

· System configuration example (when the MELSEC iQ-R series programmable controller is used)




 Network parameter setting of the master station Network parameters are set as below.

Item	Setting conditions
Start I/O No.	0000
Туре	Master
All connect count	2
Remote input (RX)	X1000
Remote output (RY)	Y1000
Remote register (RWr)	W0


Setting conditions
W100
3
,

• The relation between the device of the programmable controller CPU and remote I/O (RX, RY) of the remote device station is as follows: The devices used actually are indicated in shaded regions.




2

• The relation between the device of the programmable controller CPU and remote register (RWw, RWr) of the remote device station is as follows: The devices used actually are indicated in shaded regions.



## Program example for reading the inverter status

The following program turns on Y00 of the output unit when station 1 inverter is running




## Program example for setting the operation mode

The following explains a program to write various data to the inverter.

The following explains a program to change the operation mode of station 1 inverter to network operation.

- Operation mode write code: HFB (hexadecimal)
- Network operation set data: H0000 (hexadecimal) (Refer to page 60.)
- The reply code at the time of instruction code execution is set to D2. (Refer to page 60.)



## Program example for setting the operation commands

The following program gives a forward command and middle speed command to station 1 inverter

```
М0
-О-
                                                                                            Check the data link status of the station 1
                                                                                     Y1000
                                                                                            Forward rotation command (RY00)
                                                                                            Middle speed operation command (RY03)
   Y100F
                                                                Y1000
    b15
                                     b7
                                                                 b0
                                                                                       RY0F to RY00
     0
                                     0
                                         0
                                                                                      RY1F to RY10
                                        [Run command]
                                                                                   1. ON
                                                 Middle speed Forward rotation
                                                                                   0: OFF
     Run command
     b0: Forward rotation command
                                                  b6: Second function selection (RT)*1
     b1: Reverse rotation command
                                                  b7 : Terminal 4 input selection (AU)*1
     b2 : High-speed operation command (RH)*1 b8 : Selection of automatic restart after instantaneous power failure (CS)*1, *2
     b3 : Middle-speed operation command (RM)*1 b9 : Output stop (MRS)*1
     b4 : Low-speed operation command (RL)*1
                                                 b10 : Start self-holding selection (STOP)*1
     b5 : Jog operation selection (JOG)*1
                                                  b11 : Inverter reset (RES)*1
These signals are initial values. You can change input signals using Pr.180 to Pr.189 (Input terminal function selection).
 Note that some of the signals do not receive a command from the programmable controller depending on the setting.
 (Refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter for details.)
 For the FR-F800-E, no function is assigned in the initial setting.
```

GROUP

## Program example for monitoring the output frequency


The following explains a program to read monitor functions of the inverter.

The following program reads the output frequency of station 1 inverter to D1.

Output frequency read code: H0001 (hexadecimal)

Refer to page 62 for the monitor codes.


(Example) The output frequency of 60Hz is indicated as H1770 (6000).



## Program example for parameter reading

The following program reads Pr.7 Acceleration time of station 1 inverter to D1.

- Pr.7 Acceleration time reading instruction code: H07 (hexadecimal)
- Refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter for details of the parameter instruction codes.
- The reply code at the time of instruction code execution is set to D2. (Refer to page 60.)



# • NOTE

• For parameters having numbers 100 and later, change their link parameter extended settings (set them to other than H00). Refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter for details.


## Program example for parameter writing

The following program changes the setting of Pr.7 Acceleration time of station 1 inverter to 3.0 s.

- · Acceleration time writing instruction code: H87 (hexadecimal)
- · Acceleration time set data: K30 (decimal)

For the parameter instruction codes, refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.

The reply code at the time of instruction code execution is set to D2. (Refer to page 60.)




# NOTE

- For parameters having numbers 100 and later, change their link parameter extended settings (set them to other than H00). Refer to the parameter list of the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter for settings.
- For other functions, refer to the instruction codes. (Refer to page 60.)

### Program example for setting the running frequency

The following program example changes the running frequency of station 1 inverter to 50.00 Hz
 Set frequency: K5000 decimal

The reply code at the time of instruction code execution is set to D2. (Refer to page 60.)



To continuously change the running frequency from the programmable controller
 When the frequency (speed) setting completion (example: X100D) switches on, make sure that the reply code in the remote register is 0000H and change the set data (example: W101) continuously.

GROUE N


· Program example for writing data to EEPROM

Modify the program on page 69 as follows:


Frequency setting command Y100D → Y100E

Frequency setting completion  $X100D \rightarrow X100E$ 

<Timing chart when writing to RAM>



<Timing chart when writing to EEPROM>



- \*1 For EEPROM, write is made only once when Y100E is switched on.
- \*2 If the set data is changed with Y100E on, it is not reflected on the inverter.


## Program example for fault record reading

The following program reads fault records of station 1 inverter to D1.

• Faults history No. 1, No. 2 reading instruction code: H74 (hexadecimal)


For the error codes, refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.

The reply code at the time of instruction code execution is set to D2. (Refer to page 60.)



## Program example for resetting the inverter at inverter error

The following is a program example for resetting station 1 inverter.



# NOTE

- The above inverter reset using RY1A may be made only when an inverter error occurs. When **Pr.349 Communication reset selection** = "0", inverter reset is available independently of the operation mode.
- When using the instruction code execution request (RYF) with the instruction code (HFD) and data (H9696) to reset the inverter, set a value other than "0" in **Pr.340 Communication startup mode selection** or change the operation mode to the network operation mode. (For the program example, refer to page 67.)
- Refer to page 18 for operation conditions of inverter reset.

## **♦**Instructions

## Operating and handling instructions

• The inverter only accepts the commands from the programmable controller during operation using the CC-Link IE Field Network Basic.

The run command from external and parameter unit is ignored.

- · If multiple inverters have the same station number, the communication cannot be performed properly.
- The inverter protective function (E.EHR) is activated if data communication stops for more than the time set in **Pr.1432 Ethernet communication check time interval** due to a fault such as a programmable controller fault or a break in the Ethernet cable, during operation through the CC-Link IE Field Network Basic.
- If the programmable controller (master station) is reset during operation through the CC-Link IE Field Network Basic or
  if the programmable controller is powered off, data communication stops and the inverter protective function (E.EHR) is
  activated.

To reset the programmable controller (master station), switch the operation mode to the external operation once, then reset the programmable controller.

• When **Pr.340** = "0 (initial value)", any inverter whose main power is restored is reset to return to the external operation mode. To resume the network operation, therefore, set the operation mode to the network operation using the programmable controller program.

Set a value other than "0" in **Pr.340** to start in the network operation mode after inverter reset. (For the details of **Pr.340**, refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.)

## Troubleshooting

Description	Check point
Operation mode does not switch to the network operation mode	Check that the Ethernet cable is installed correctly. (Check for a fault such as a contact fault or break in the cable.)
	Check that the inverter is in the External operation mode.
	Check that the operation mode switching program is running.
	Check that the operation mode switching program has been written correctly.
	Check that the inverter starting program is running.
Inverter does not start in the Network operation mode	Check that the inverter starting program has been written correctly.
Network operation mode	Check that Pr.338 Communication operation command source is not set to external.

#### Parameters referred to

Pr.37 Speed display, Pr.144 Speed setting switchover Transcription Manual (Detailed) of the FR-A800/FR-F800 inverter Pr.811 Set resolution switchover Transcription Manual (Detailed) of the FR-A800 inverter

2

N N

### 2.6 Inverter-to-inverter link function

The inverter-to-inverter link function enables communication between multiple inverters connected by Ethernet in a small-scale system by using the I/O devices and special registers of the PLC function.

The inverter-to-inverter link function is enabled by simply setting **Pr.1124 Station number in inverter-to-inverter link** and **Pr.1125 Number of inverters in inverter-to-inverter link system**.

Pr.	Name	Initial value	Setting range	Description
1124	Station number in inverter-to- inverter link	9999	0 to 5	Set the station number for the inverter-to-inverter link function.
N681+1			9999	Inverter-to-inverter link function disabled
1125 N682*1	Number of inverters in inverter- to-inverter link system	2	2 to 6	Set the total number of inverters used for the inverter-to-inverter link function.

<sup>\*1</sup> The setting is applied after an inverter reset or power-ON.

#### **♦**Communication specifications

Item		Description	
Transmission speed		100 Mbps (Do not use the function at 10 Mbps.)	
Connectable units		Master: 1 Slave: up to 5	
Topology		Star	
Maximum number of links per station	Output device	16 (2 bytes)	
waximum number of links per station	Special register	8 (16 bytes)	

#### **♦**Setting procedure


- **1** Set a value other than "0" in Pr.414 PLC function operation selection to enable the PLC function.
- **2** To set the inverter as the master, set "0" in Pr.1124 Station number in inverter-to-inverter link, and to set the inverter as a slave, select a station number from 1 to 5 and set the number in Pr.1124.
- 3 Set the total number of inverters used for the inverter-to-inverter link function in Pr.1125 Number of inverters in inverter-to-inverter link system. For example, set "3" in Pr.1125 when two slave inverters and the master inverter are used.
- **4** Use FR Configurator2 to write sequence programs to the master inverter.

#### NOTE

- Use different station numbers for different devices. (If different devices have the same station number, the communication cannot be performed properly.
- Set consecutive numbers for the station numbers. (Do not skip any numbers like 1, 2, then 4.)
- When Pr.1124 is set to a value equal to or larger than the value set in Pr.1125, normal communication is not available.
- Use the Inverter-to-inverter linkup (LNK) signal to check that the master-slave communication is established. (For the details of the LNK signal, refer to page 13.)
- To detect the interruption of the inverter-to-inverter link communication and activate the protective function, set **Pr.997 Fault initiation** in advance, and create and execute a sequence program to activate the protective function by the input of the signal loss detection signal from the external sensor.
- For the details of the PLC function, refer to the PLC Function Programming Manual and the Instruction Manual of FR Configurator2
- For the details of FR Configurator2, refer to the Instruction Manual of FR Configurator2.

The following shows the system configuration for using the inverter-to-inverter link function. The master inverter can communicate with the slave inverters through one or two hubs (refer to the description of **Pr.1124** for the master/slave setting).

(Communication using the inverter-to-inverter function is not available for the inverters directly connected to the router.)



#### **◆**Device map

The following shows the I/O devices and special registers used for the inverter-to-inverter link function. (For the details of the other I/O devices and special registers, refer to the PLC Function Programming Manual.)

#### I/O device map (master)

Device No.	Name	Device No.	Name
X40 to X4F	Inverter-to-inverter link input (from slave 1 to master)	Y40 to Y4F	Inverter-to-inverter link output (from master to slave 1)
740 to 74F	inverter-to-inverter link input (from slave 1 to master)	140 10 145	inverter-to-inverter link output (from master to slave 1)
X50 to X5F	Inverter-to-inverter link input (from slave 2 to master)	Y50 to Y5F	Inverter-to-inverter link output (from master to slave 2)
X60 to X6F	Inverter-to-inverter link input (from slave 3 to master)	Y60 to Y6F	Inverter-to-inverter link output (from master to slave 3)
X70 to X7F	Inverter-to-inverter link input (from slave 4 to master)	Y70 to Y7F	Inverter-to-inverter link output (from master to slave 4)
X80 to X8F	Inverter-to-inverter link input (from slave 5 to master)	Y80 to Y8F	Inverter-to-inverter link output (from master to slave 5)

#### ◆I/O device map (slave)

Device No.	Name	Device No.	Name
X40 to X4F	Inverter-to-inverter link input (from master to slave)	Y40 to Y4F	Inverter-to-inverter link output (from slave to master)

#### Special register (common)

Device No.	Name	Description		
		The station	number in the inverter-to-inverter link is stored	
		b15	b8 b7 b0	
		Reserved	d (H00) Station No.	
		Value	Station No.	
		H00	Master	
SD1460	Station number in inverter-to-inverter link	H01	Slave 1	
		H02	Slave 2	
		H03	Slave 3	
		H04	Slave 4	
		H05	Slave 5	
		HFF	Function disabled	

2

GROUP

#### Inverter-to-inverter link function

Device No.	Name			Description	
		The communication status of the slaves in the inverter-to-inverter link is stored.  (In the slave inverter, only its own communication status is indicated.)  b15  b5 b4  b0			
SD1461	Communication status of inverter-to- inverter link	Bit	Target station	Description	
		0	Slave 1		
		1	Slave 2	O. The Bullion of a stablish of	
		2	Slave 3	0: The link is not established. 1: The link is established.	
		3	Slave 4	1. The link is established.	
		4	Slave 5		

#### ◆ Special register (master)

Device No.	Name	Description
SD1470 to SD1477	Inverter-to-inverter link receive data 1 to 8 (slave 1)	Data 1 to 8 received from slave 1
SD1478 to SD1485	Inverter-to-inverter link send data 1 to 8 (slave 1)	Data 1 to 8 sent to slave 1
SD1486 to SD1493	Inverter-to-inverter link receive data 1 to 8 (slave 2)	Data 1 to 8 received from slave 2
SD1494 to SD1501	Inverter-to-inverter link send data 1 to 8 (slave 2)	Data 1 to 8 sent to slave 2
SD1502 to SD1509	Inverter-to-inverter link receive data 1 to 8 (slave 3)	Data 1 to 8 received from slave 3
SD1510 to SD1517	Inverter-to-inverter link send data 1 to 8 (slave 3)	Data 1 to 8 sent to slave 3
SD1518 to SD1525	Inverter-to-inverter link receive data 1 to 8 (slave 4)	Data 1 to 8 received from slave 4
SD1526 to SD1533	Inverter-to-inverter link send data 1 to 8 (slave 4)	Data 1 to 8 sent to slave 4
SD1534 to SD1541	Inverter-to-inverter link receive data 1 to 8 (slave 5)	Data 1 to 8 received from slave 5
SD1542 to SD1549	Inverter-to-inverter link send data 1 to 8 (slave 5)	Data 1 to 8 sent to slave 5

#### ◆ Special register (slave)

Device No.	Name	Description
SD1470 to SD1477	Inverter-to-inverter link receive data 1 to 8 (master)	Receive data 1 to 8 from master
SD1478 to SD1485	Inverter-to-inverter link send data 1 to 8 (master)	Send data 1 to 8 to master
SD1486 to SD1549	For manufacturer setting. Do not set.	

## **◆**Troubleshooting

Condition	Possible cause	Countermeasure
	The same station number is assigned to multiple inverters.	Set Pr.1124 correctly.
	The station numbers are not consecutive.	Set <b>Pr.1124</b> so that the station numbers are consecutive.
Communication is not established.	The specified number of inverters in the system is not correct.  (Pr.1124 is set to a value equal to or larger than the value set in Pr.1125.)	Set <b>Pr.1125</b> correctly.
	The connection is half-duplex.	Use full-duplex connection. (When Pr.1426 Link speed and duplex mode selection = "0 (initial value)", check that the hub and the Ethernet cable are compatible with full-duplex connection.)
	The inverter is not reset after <b>Pr.1124</b> and <b>Pr.1125</b> are set.	Reset the inverter.
A command sent by the master is not applied to a slave.	The PLC function is disabled.	Set a value other than "0" in <b>Pr.414</b> to enable the PLC function.

## 3 PROTECTIVE FUNCTIONS

## 3.1 Causes and corrective actions

#### **♦**Warning

Output is not shut off when a protective function is activated.

Operation panel indication	EHR	EHR	FR-LU08 indication	Fault	
Name	Ethernet communic	cation fault			
Description	Appears when Ethernet communication is interrupted by physical factors while <b>Pr.1431 Ethernet signal loss detection function selection</b> = "1 or 2".				
Check point		nernet board is installed in the Ethernet cable.	onto the connector s	ecurely.	
Corrective action		,	connected to the Eth	ernet connector. Check that the Ethernet	

#### **♦**Fault

When a protective function is activated, the inverter trips and a fault signal is output.

Operation panel indication	E.EHR	E. EHR	FR-LU08 indication	Fault		
Name	Ethernet communication fault (Data code: 231 (HE7))*1					
Description	<ul> <li>Appears when Ethernet communication is interrupted by physical factors while Pr.1431 Ethernet signal loss detection function selection = "3".</li> <li>The inverter trips when Ethernet communication is cut off for the time set in Pr.1432 Ethernet communication check time interval or longer between the inverter and all devices with the IP addresses in the range specified for the Ethernet command source selection (Pr.1449 to Pr.1454).</li> <li>Stops the inverter output when excessive noise occurs around the inverter.</li> <li>When the CC-Link IE Field Network Basic is used, the inverter output is shut off when the data addressed to the own station is not received for the predetermined timeout period or longer, or when the status bit of the cyclic transmission addressed to the own station turns OFF (when the master controller gives a command to stop the cyclic transmission). (For the details of the timeout period, status bit of the cyclic transmission, and command to stop the cyclic transmission, refer to the Instruction Manual of the master controller which supports the CC-Link IE Field Network Basic.)</li> </ul>					
Check point	Check that the Ethernet board is installed onto the connector securely. Check for a break in the Ethernet cable. Check that the Pr.1432 setting is not too short. Check for excessive noise around the inverter. When the CC-Link IE Field Network Basic is used, check that the timeout period set in the master is not shorter than the period during which the inverter does not receive the data addressed to the own station. When the CC-Link IE Field Network Basic is used, check that the status bit of the cyclic transmission addressed to the own station is not OFF.					
Corrective action	<ul> <li>Connect the Ethernet board securely.</li> <li>Check that the Ethernet cable is correctly connected to the Ethernet connector. Check that the Ethernet cable is not broken.</li> <li>Set a larger value in Pr.1432.</li> <li>When excessive noise occurs around the inverter, change the communication setting of the master. (The noise may be reduced by setting a shorter timeout period or increasing the number of retries in the communication setting of the master.)</li> <li>When the CC-Link IE Field Network Basic is used, set a timeout period longer than the period during which the inverter does not receive the data addressed to the own station.</li> <li>When the CC-Link IE Field Network Basic is used, turn ON the status bit of the cyclic transmission addressed to the own station.</li> </ul>					

<sup>\*1</sup> The data code is used for checking the fault detail via communication or for setting **Pr.997 Fault initiation**. (Refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.)

## 4 SPECIFICATIONS

## **4.1** Common specifications

#### **♦FR-A800-E**

	• •	<b>1-70</b>	_				
	Со	ntrol met	thod	Soft-PWM control, high carrier frequency PWM control (selectable among V/F control, Advanced magnetic flux vector control, Real sensorless vector control), Optimum excitation control, vector control*1, and PM sensorless vector control			
	Ou	tput freq	uency range	0.2 to 590 Hz (The upper-limit frequency is 400 Hz under Advanced magnetic flux vector control, Real sensorless vector control, vector control-1, and PM sensorless vector control.)			
	Frequency setting			0.015 Hz/60 Hz (0 to 10 V/12 bits for terminals 2 and 4) 0.03 Hz/60 Hz (0 to 5 V/11 bits or 0 to 20 mA/approx. 11 bits for terminals 2 and 4, 0 to ±10 V/12 bits for terminal 1) 0.06 Hz/60 Hz (0 to ±5 V/11 bits for terminal 1)			
	resolution		Digital input	0.01 Hz			
Suc	Fre	equency	Analog input	Within ±0.2% of the max. output frequency (25°C ± 10°C)			
atio	aco	curacy	Digital input	Within 0.01% of the set output frequency			
specifications		ltage/frec aracteris		Base frequency can be set from 0 to 590 Hz. Constant-torque/variable-torque pattern or adjustable 5 points V/F can be selected.			
		arting tor	·	SLD Rating:120% 0.3 Hz, LD Rating:150% 0.3 Hz, ND Rating:200% 0.3 Hz•3, HD Rating:250% 0.3 Hz•3 (Real sensorless vector control, vector control•1)			
Control	To	rque boo	st	Manual torque boost			
Ö	tim	ne setting		0 to 3600 s (acceleration and deceleration can be set individually), linear or S-pattern acceleration/deceleration mode, backlash countermeasures acceleration/deceleration can be selected.			
		injection duction r		Operation frequency (0 to 120 Hz), operation time (0 to 10 s), operation voltage (0 to 30%) variable			
		all preven eration le		Activation range of stall prevention operation (SLD rating: 0 to 120%, LD rating: 0 to 150%, ND rating: 0 to 220%, HD rating: 0 to 280%). Whether to use the stall prevention or not can be selected. (V/F control, Advanced magnetic flux vector control)			
	Toı	rque limit	level	Torque limit value can be set (0 to 400% variable). (Real sensorless vector control, vector control-1, PM sensorless vector control)			
		equency tting	Analog input	rminals 2 and 4: 0 to 10 V, 0 to 5 V, 4 to 20 mA (0 to 20 mA) are available. rminal 1: -10 to +10 V, -5 to +5 V are available.			
		jnal	Digital input	Input using the setting dial of the operation panel or parameter unit Four-digit BCD or 16-bit binary (when used with option FR-A8AX)			
	Sta	art signal		Forward and reverse rotation or start signal automatic self-holding input (3-wire input) can be selected.			
s	Input signals (twelve terminals)			Low-speed operation command, Middle-speed operation command, High-speed operation command, Second function selection, Terminal 4 input selection, Jog operation selection, Selection of automatic restart after instantaneous power failure, flying start, Output stop, Start self-holding selection, Forward rotation command, Reverse rotation command, Inverter reset  The input signal can be changed using Pr.178 to Pr.189 (Input terminal function selection).			
ioi		Pulse tra	ain input	100 kpps			
Operation specifications		Operational functions		Maximum and minimum frequency settings, multi-speed operation, acceleration/deceleration pattern, thermal protection, DC injection brake, starting frequency, JOG operation, output stop (MRS), stall prevention, regeneration avoidance, increased magnetic excitation deceleration, DC feeding 4, frequency jump, rotation display, automatic restart after instantaneous power failure, electronic bypass sequence, remote setting, automatic acceleration/deceleration, retry function, carrier frequency selection, fast-response current limit, forward/reverse rotation prevention, operation mode selection, slip compensation, droop control, load torque high-speed frequency control, speed smoothing control, traverse, auto tuning, applied motor selection, gain tuning, RS-485 communication, Ethernet communication, PID control, PID precharge function, easy dancer control, cooling fan operation selection, stop selection (deceleration stop/coasting), powerfailure deceleration stop function, stop-on-contact control, PLC function, life diagnosis, maintenance timer, current average monitor, multiple rating, orientation control-1, speed control, torque control, position control, pre-excitation, torque limit, test run, 24 V power supply input for control circuit, safety stop function, anti-sway control			
		তি Open collector output (five terminals) Relay output (two terminals)		Inverter running, Up to frequency, Instantaneous power failure/undervoltage*4, Overload warning, Output frequency detection, Fault The output signal can be changed using <b>Pr.190 to Pr.196 (Output terminal function selection)</b> . Fault codes of the inverter can be output (4 bits) from the open collector.			
	Output	Pulse tra (FM type	ain output e)	50 kpps			
	ter		train output FM type)	Max. 2.4 kHz: one terminal (output frequency) The monitored item can be changed using <b>Pr.54 FM/CA terminal function selection</b> .			
ion	Current output (CA type)		•	Max. 20 mADC: one terminal (output frequency) The monitored item can be changed using <b>Pr.54 FM/CA terminal function selection.</b>			
Indication	Ľ	Volt	age output	Max. 10 VDC: one terminal (output frequency) The monitored item can be changed using <b>Pr.158 AM terminal function selection.</b>			
드		peration panel	Operating status	Output frequency, Output current, Output voltage, Frequency setting value The monitored item can be changed using <b>Pr.52 Operation panel main monitor selection</b> .			
		R-DU08)	Fault record	A fault record is displayed when a fault occurs. Past 8 fault records and the conditions immediately before the fault (output voltage/current/frequency/cumulative energization time/year/month/date/time) are saved.			

	Protective/ warning function	Protective function	Overcurrent trip during acceleration, Overcurrent trip during constant speed, Overcurrent trip during deceleration or stop, Regenerative overvoltage trip during acceleration, Regenerative overvoltage trip during constant speed, Regenerative overvoltage trip during deceleration or stop, Inverter overload trip, Motor overload trip, Heatsink overheat, Instantaneous power failure-4, Undervoltage-4, Input phase loss-4-5, Stall prevention stop, Loss of synchronism detection-5, Brake transistor alarm detection-6, Output side earth (ground) fault overcurrent, Output short circuit, Output phase loss, External thermal relay operation-5, PTC thermistor operation-5, Option fault, Communication option fault, Parameter storage device fault, PU disconnection, Retry count excess-5, CPU fault, Operation panel power supply short circuit, 24 VDC power fault, Abnormal output current detection-5, Inrush current limit circuit fault-4, Ethernet communication fault-5, Analog input fault, USB communication fault, Safety circuit fault, Overspeed occurrence-5, Speed deviation excess detection-1-5, Signal loss detection-1-5, Excessive position fault-1-5, Brake sequence fault-5, Encoder phase fault-1-5, 4 mA input fault-5, Pre-charge fault-5, PID signal fault-5, Option fault, Opposite rotation deceleration fault-5, Internal circuit fault, Abnormal internal temperature-7, Magnetic pole position unknown-1
		Warning function	Fan alarm, Stall prevention (overcurrent), Stall prevention (overvoltage), Regenerative brake pre-alarm*5*6, Electronic thermal relay function pre-alarm, PU stop, Speed limit indication*5, Parameter copy, Safety stop, Maintenance timer 1 to 3*5, USB host error, Home position return setting error*5, Home position return uncompleted*5, Home position return parameter setting error*5, Operation panel lock*5, Password locked*5, Parameter write error, Copy operation error, 24 V external power supply operation, Internal fan alarm*7, Continuous operation during communication fault, Ethernet communication fault
	Surrounding air temperature		-10°C to +50°C (non-freezing) (LD, ND, HD ratings) -10°C to +40°C (non-freezing) (SLD rating, IP55 compatible model)
Environment	Surrounding air humidity		95% RH or less (non-condensing) (With circuit board coating (conforming to IEC60721-3-3 3C2/3S2), IP55 compatible model) 90% RH or less (non-condensing) (Without circuit board coating)
Ş	Storage t	emperature*8	-20°C to +65°C
ū	Atm	osphere	Indoors (without corrosive gas, flammable gas, oil mist, dust and dirt, etc.)
	Altitud	e/vibration	1000 m or lower <sub>9</sub> , 5.9 m/s <sup>2</sup> <sub>*10</sub> or less at 10 to 55 Hz (directions of X, Y, Z axes)

- \*1 Available only when a vector control compatible option is installed.
- \*2 For PM sensorless vector control, refer to the Instruction Manual (Detailed) of the FR-A800 inverter.
- \*3 In the initial setting of the FR-A820-00340(5.5K) or higher and the FR-A840-00170(5.5K) or higher, it is limited to 150% by the torque limit level.
- \*4 Enabled only for standard models and IP55 compatible models.
- \*5 This protective function is not available in the initial status.
- \*6 Enabled only for standard models.
- \*7 Available for the IP55 compatible model only.
- \*8  $\;\;$  Temperature applicable for a short time, e.g. in transit.
- \*9 For the installation at an altitude above 1000 m (up to 2500 m), consider a 3% reduction in the rated current per altitude increase of 500 m.
- $*10~2.9~\text{m/s}^2$  or less for the FR-A840-04320(160K) or higher.

#### **♦FR-F800-E**

	Control me	thod	Soft-PWM control, high carrier frequency PWM control (selectable among V/F control (Optimum excitation control), Advanced magnetic flux vector control (Advanced optimum excitation control) and PM motor control)
	Output frea	uency range	0.2 to 590 Hz (The upper-limit frequency is 400 Hz under Advanced magnetic flux vector control, and PM motor control.)
			0.015 Hz/60 Hz (terminal 2, 4: 0 to 10 V/12 bits)
	Frequency setting	Analog input	0.03 Hz/60 Hz (0 to 5 V/11 bits or 0 to 20 mA/approx. 11 bits for terminals 2 and 4, 0 to ±10 V/12 bits for terminal 1)
	resolution	B: 11 1 1	0.06 Hz/60 Hz (0 to ±5 V/11 bits for terminal 1)
S		Digital input	0.01 Hz
ior	Frequency	Analog input Digital input	Within ±0.2% of the max. output frequency (25°C ±10°C)
cal	accuracy Voltage/free		Within 0.01% of the set output frequency
cifi	characteris	•	Base frequency can be set from 0 to 590 Hz. Constant-torque/variable-torque pattern or adjustable 5 points V/F can be selected.
be		Induction	
Control specifications	Starting	motor	120% 0.5 Hz (Advanced magnetic flux vector control)
ntr	torque	IPM motor	50%
Co	Torque boo	st	Manual torque boost
	Acceleratio	n/deceleration	0 to 3600 s (acceleration and deceleration can be set individually), linear or S-pattern acceleration/deceleration mode,
	time setting		backlash countermeasures acceleration/deceleration can be selected.
	DC injection		Operation frequency (0 to 120 Hz), operation time (0 to 10 s), operation voltage (0 to 30%) variable
	(induction r		
	Stall prevention operation level		Activation range of stall prevention operation (SLD rating: 0 to 120%, LD rating: 0 to 150%). Whether to use the stall prevention or not can be selected. (V/F control, Advanced magnetic flux vector control)
	Frequency setting	Analog input	Terminals 2 and 4: 0 to 10 V, 0 to 5 V, 4 to 20 mA (0 to 20 mA) are available.  Terminal 1: -10 to +10 V, -5 to 5 V are available.
	signal	Digital input	Input using the setting dial of the operation panel or the parameter unit Four-digit BCD or 16-bit binary (when used with option FR-A8AX)
	Start signal		Forward and reverse rotation or start signal automatic self-holding input (3-wire input) can be selected.
			Low-speed operation command, Middle-speed operation command, High-speed operation command, Second function
	Input signals (twelve		selection, Terminal 4 input selection, Jog operation selection, Output stop, Start self-holding selection, Forward rotation
S	terminals)		command, Reverse rotation command, Inverter reset
Ö	Pulso tr	ain input	The input signal can be changed using <b>Pr.178 to Pr.189 (Input terminal function selection)</b> .  100 kpps
cati	i disc ti	ин прис	Maximum and minimum frequency settings, multi-speed operation, acceleration/deceleration pattern, thermal protection,
Operation specifications	Operational functions		DC injection brake, starting frequency, JOG operation, output stop (MRS), stall prevention, regeneration avoidance, increased magnetic excitation deceleration, DC feeding*1, frequency jump, rotation display, automatic restart after instantaneous power failure, electronic bypass sequence, remote setting, retry function, carrier frequency selection, fast-response current limit, forward/reverse rotation prevention, operation mode selection, slip compensation, speed smoothing control, traverse, auto tuning, applied motor selection, RS-485 communication, Ethernet communication, PID control, PID pre-charge function, cooling fan operation selection, stop selection (deceleration stop/coasting), power-failure deceleration stop function, PLC function, life diagnosis, maintenance timer, current average monitor, multiple rating, test run, 24 V power supply input for control circuit, safety stop function, self power management, BACnet communication, PID gain tuning, cleaning, load characteristics storage, emergency drive*1
	Output signal Open collector output (five terminals) Relay output (two terminals)		Inverter running, Up to frequency, Instantaneous power failure/undervoltage*1, Overload warning, Output frequency detection, Fault The output signal can be changed using <b>Pr.190 to Pr.196 (Output terminal function selection)</b> . Fault codes of the inverter can be output (4 bits) from the open collector.
		ain output	50 kpps
	1 4100 11	Pulse train	**
		output (FM type)	Max. 2.4 kHz: one terminal (output frequency) The monitored item can be changed using <b>Pr.54 FM/CA terminal function selection</b> .
ation	For meter	Current output (CA type)	Max. 20 mADC: one terminal (output frequency) The monitored item can be changed using <b>Pr.54 FM/CA terminal function selection</b> .
Indication		Voltage output	Max. 10 VDC: one terminal (output frequency) The monitored item can be changed using <b>Pr.158 AM terminal function selection</b> .
	Operation panel	Operating status	Output frequency, output current, output voltage, frequency setting value The monitored item can be changed using <b>Pr.52 Operation panel main monitor selection</b> .
	(FR-DU08)	Fault record	Fault record is displayed when a fault occurs. Past 8 fault records and the conditions immediately before the fault (output voltage/current/frequency/cumulative energization time/year/month/date/time) are saved.
wai	otective/ rning ction	Protective function	Overcurrent trip during acceleration, Overcurrent trip during constant speed, Overcurrent trip during deceleration or stop, Regenerative overvoltage trip during acceleration, Regenerative overvoltage trip during constant speed, Regenerative overvoltage trip during deceleration or stop, Inverter overload trip (electronic thermal relay function), Motor overload trip (electronic thermal relay function), Heatsink overheat, Instantaneous power failure-1, Undervoltage-1, Input phase loss-1-2 Stall prevention stop, Loss of synchronism detection-2, Upper limit fault detection, Lower limit fault detection, Brake transistor alarm detection-1, Output side earth (ground) fault overcurrent, Output short circuit, Output phase loss, Externa thermal relay operation-2, PTC thermistor operation-2, Option fault, Communication option fault, Parameter storage device fault, PU disconnection, Retry count excess-2, CPU fault, Operation panel power supply short circuit, 24 VDC power fault Abnormal output current detection-2, Inrush current limit circuit fault-1, Ethernet communication fault-2, Analog input fault, USB communication fault, Safety circuit fault, Overspeed occurrence-2, 4 mA input fault-2, Pre-charge fault-2, PID signal fault-2, Internal circuit fault, User definition error in the PLC function
		Warning function	Fan alarm, Stall prevention (overcurrent), Stall prevention (overvoltage), Regenerative brake pre-alarm*1*2, Electronic thermal relay function pre-alarm, PU stop, Parameter copy, Safety stop, Maintenance timer 1 to 3*2, USB host error, Operation panel lock*2, Password locked*2, Parameter write error, Copy operation error, 24 V external power supply operation, Load fault warning, Emergency drive in operation*1, Continuous operation during communication fault, Etherne communication fault

#### **Common specifications**

<b>1</b>	Surrounding air temperature	-10°C to +50°C (non-freezing) (LD rating) -10°C to +40°C (non-freezing) (SLD rating)
amuc	Surrounding air humidity	With circuit board coating (conforming to IEC60721-3-3 3C2/3S2): 95% RH or less (non-condensing) Without circuit board coating: 90% RH or less (non-condensing)
Į.į	Storage temperature*3	-20°C to +65°C
ĺ	Atmosphere	Indoors (without corrosive gas, flammable gas, oil mist, dust and dirt, etc.)
	Altitude/vibration	1000 m or lower <sub>*4</sub> , 5.9 m/s <sup>2</sup> or less <sub>*5</sub> at 10 to 55 Hz (directions of X, Y, Z axes)

- \*1 Available only for the standard model.
- \*2 This protective function is not available in the initial status.
- \*3 Temperature applicable for a short time, e.g. in transit.
- \*4 For the installation at an altitude above 1000 m (up to 2500 m), consider a 3% reduction in the rated current per altitude increase of 500 m.
- \*5 2.9 m/s<sup>2</sup> or less for the FR-F840-04320(185K) or higher.

# **4.2** Parameters (functions) and instruction codes under different control methods

The following table shows the Ethernet communication parameters, the corresponding instruction codes, and the availability of the parameters by control method.

For information on the instruction codes and availability of other parameters by control method, refer to the Instruction Manual (Detailed) of the FR-A800/FR-F800 inverter.

			truct code*				C	ontro	ol me	thod	*2			Pa	rame	ter
							V	ecto	r	Sens	orless	P	M			
Pr.	Name	Read	Write	Extended	A//E	Magneticflux	Speed control	Torque control	4	Speed control *6	Torque control	Speed control	Position control	€*KOD	Clear∗3	All clear*3
1124	Station number in inverter-to-inverter link	18	98	В	0	0	0	0	0	0	0	0	0	0	O*4	O*4
	Number of inverters in inverter-to-inverter link system	19	99	В	0	0	0	0	0	0	0	0	0	0	O*4	O*4
	Ethernet communication network number	18	98	Е	0	0	0	0	0	0	0	0	0	0	O*4	O*4
	Ethernet communication station number	19	99	E	0	0	0	0	0	0	0	0	0	0	O*4	O*4
1426	Link speed and duplex mode selection	1A	9A	E	0	0	0	0	0	0	0	0	0	0	O*4	O*4
	Ethernet function selection 1	1B	9B	E	0	0	0	0	0	0	0	0	0	0	O*4	O*4
1428	Ethernet function selection 2	1C	9C	E	0	0	0	0	0	0	0	0	0	0	O*4	O*4
1429	Ethernet function selection 3	1D	9D	E	0	0	0	0	0	0	0	0	0	0	O*4	O*4
1431	Ethernet signal loss detection function selection	1F	9F	Е	0	0	0	0	0	0	0	0	0	0	O*4	O*4
1432	Ethernet communication check time interval	20	A0	E	0	0	0	0	0	0	0	0	0	0	O*4	O*4
	Ethernet IP address 1	22	A2	E	0	0	0	0	0	0	0	0	0	×	O*4	O*4
	Ethernet IP address 2	23	A3	E	0	0	0	0	0	0	0	0	0	×	O*4	O*4
	Ethernet IP address 3	24	A4	E	0	0	0	0	0	0	0	0	0	×	O*4	O*4
1437	Ethernet IP address 4	25	A5	E	0	0	0	0	0	0	0	0	0	×	0*4	O*4
1438	Subnet mask 1	26	A6	E	0	0	0	0	0	0	0	0	0	0	O*4	O*4
	Subnet mask 2	27	A7	E	0	0	0	0	0	0	0	0	0	0	0*4	O*4
	Subnet mask 3	28	A8	E E	0	0	0	0	0	0	0	0	0	0	0*4	O*4
1441 1442	Subnet mask 4 Ethernet IP filter address 1	29 2A	A9 AA	E	0	0	0	0	0	0	0	0	0	0	0*4	O*4
	Ethernet IP filter address 2	2A 2B	AB	E	0	0	0	0	0	0	0	0	0	0	O*4	O*4
	Ethernet IP filter address 3	2C	AC	E	0	0	0	0	0	0	0	0	0	0	0*4	O*4
	Ethernet IP filter address 4	2D	AD	E	0	0	0	0	0	0	0	0	0	0	O*4	O*4
	Ethernet IP filter address 2 range								)					)	0 **4	0**4
1446	specification	2E	AE	Е	0	0	0	0	0	0	0	0	0	0	O*4	O*4
	Ethernet IP filter address 3 range specification	2F	AF	Е	0	0	0	0	0	0	0	0	0	0	O*4	O*4
1448	Ethernet IP filter address 4 range specification	30	В0	Е	0	0	0	0	0	0	0	0	0	0	O*4	O*4
1449	Ethernet command source selection IP address 1	31	В1	Е	0	0	0	0	0	0	0	0	0	0	O*4	O*4
1450	Ethernet command source selection IP address 2	32	B2	E	0	0	0	0	0	0	0	0	0	0	O*4	O*4
	Ethernet command source selection IP address 3	33	ВЗ	E	0	0	0	0	0	0	0	0	0	0	O*4	O*4
11457	Ethernet command source selection IP address 4	34	B4	E	0	0	0	0	0	0	0	0	0	0	O*4	O*4
11453	Ethernet command source selection IP address 3 range specification	35	B5	E	0	0	0	0	0	0	0	0	0	0	O*4	O*4
1454	Ethernet command source selection IP address 4 range specification	36	В6	Е	0	0	0	0	0	0	0	0	0	0	O*4	O*4
1455	Keepalive time	37	В7	Е	0	0	0	0	0	0	0	0	0	0	O*4	O*4

#### Parameters (functions) and instruction codes under different control methods

- \*1 Instruction codes are used to read or write parameters through the Ethernet network (Modbus/TCP or CC-Link IE Field Network Basic). (Refer to page 39 for the details of the Modbus/TCP, and page 51 for the details of the CC-Link IE Field Network Basic.)
- \*2 Function availability under each control method is as follows:
  - O: Available
  - x : Not available
- \*3 For "parameter copy", "parameter clear", and "all parameter clear", "O" indicates the function is available, and "x" indicates the function is not available.
- \*4 Communication parameters that are not cleared by Parameter clear (All parameter clear) through the Ethernet network (Modbus/TCP or CC-Link IE Field Network Basic). (Refer to page 39 for the details of the Modbus/TCP, and page 51 for the details of the CC-Link IE Field Network Basic).
- \*5 Position control is enabled when an MM-CF IPM motor is used with the low-speed range high-torque characteristic enabled (**Pr.788 Low speed range torque characteristic selection = "9999"** (initial value)).
- \*6 FR-A800-E only

\*The manual number is given on the bottom left of the back cover.

Print Date	*Manual Number	Revision
May 2016	IB(NA)-0600628ENG-A	First edition
Nov. 2016	IB(NA)-0600628ENG-B	Addition
		• FR-F800-E
		CC-Link IE Field Network Basic
		Inverter-to-inverter link function


## MITSUBISHI ELECTRIC CORPORATION HEAD OFFICE: TOKYO BUILDING 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN





## **INSTRUCTION MANUAL (DETAILED)**

FR-F820-00046(0.75K) to 04750(110K) FR-F840-00023(0.75K) to 06830(315K) FR-F842-07700(355K) to 12120(560K)



INTRODUCTION	1
INSTALLATION AND WIRING	2
PRECAUTIONS FOR USE OF THE INVERTER	3
BASIC OPERATION	4
PARAMETERS	5
PROTECTIVE FUNCTIONS	6
PRECAUTIONS FOR MAINTENANCE AND INSPECTION	7

Thank you for choosing this Mitsubishi inverter.

This Instruction Manual (Detailed) provides instructions for advanced use of the FR-F800 series inverters.

Incorrect handling might cause an unexpected fault. Before using this inverter, always carefully read this Instruction Manual and the Instruction Manual (Startup) [IB-0600545] packed with the product to use this product correctly.

#### Safety Instructions

Do not attempt to install, operate, maintain or inspect the product until you have read through this Instruction Manual (Detailed) and appended documents carefully and can use the equipment correctly. Do not use this product until you have a full knowledge of the equipment, safety information and instructions.

Installation, operation, maintenance and inspection must be performed by qualified personnel. Here, an expert means a person who meets all the conditions below.

- A person who took a proper engineering training. Such training may be available at your local Mitsubishi Electric office. Contact your local sales office for schedules and locations
- A person who can access operating manuals for the protective devices (e.g. light curtain) connected to the safety control system. A person who has read and familiarized himself/herself with the manuals.

In this Instruction Manual (Detailed), the safety instruction levels are classified into "Warning" and "Caution"

**A** Warning

Incorrect handling may cause hazardous conditions, resulting in death or severe injury.

**⚠** Caution

Incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause only material damage.

**⚠** Caution The

level may even lead to a serious

consequence according to conditions. Both instruction levels must be followed because these are important to personal

#### Electric Shock Prevention

#### Warning

- While the inverter power is ON, do not open the front cover or the wiring cover. Do not run the inverter with the front cover or the wiring cover removed. Otherwise you may access the exposed high voltage terminals or the charging part of the circuitry and get an electric shock.
- Even if power is OFF, do not remove the front cover except for wiring or periodic inspection. You may accidentally touch the
- hard a periodic inspection. For may accelerately observed the charged inverter circuits and get an electric shock.
   Before wiring or inspection, LED indication of the operation panel must be switched OFF. Any person who is involved in wiring or inspection shall wait for at least 10 minutes after the power supply has been switched OFF and check that there are no residual voltage using a tester or the like. The capacitor is charged with high voltage for some time after power OFF, and it is dangerous.
- This inverter must be earthed (grounded). Earthing (grounding) must conform to the requirements of national and local safety regulations and electrical code (NEC section 250, IEC 536 class 1 and other applicable standards). A neutral-point earthed (grounded) power supply for 400V class inverter in compliance with EN standard must be used.
- Any person who is involved in wiring or inspection of this
- equipment shall be fully competent to do the work.

  The inverter must be installed before wiring. Otherwise you may get an electric shock or be injured.

  Setting dial and key operations must be performed with dry
- hands to prevent an electric shock. Otherwise you may get an electric shock
- Do not subject the cables to scratches, excessive stress, heavy
- loads or pinching. Otherwise you may get an electric shock.

   Do not change the cooling fan while power is ON. It is dangerous Do not touch the printed circuit board or handle the cables with
   Do not touch the printed circuit board or handle the cables with
- wet hands. Otherwise you may get an electric shock.

   When measuring the main circuit capacitor capacity, the DC voltage is applied to the motor for 1s at powering OFF. Never touch the motor terminal, etc. right after powering OFF to prevent an electric shock.
- An PM motor is a synchronous motor with high-performance magnets embedded in the rotor. Motor terminals holds highvoltage while the motor is running even after the inverter power is turned OFF. Before wiring or inspection, the motor must be confirmed to be stopped. In an application, such as fan and blower, where the motor is driven by the load, a low-voltage manual motor starter must be connected at the inverter's output side, and wiring and inspection must be performed while the motor starter is open. Otherwise you may get an electric shock

#### Fire Prevention

- Inverter must be installed on a nonflammable wall without holes (so that nobody touches the inverter heatsink on the rear side, etc.). Mounting it to or near flammable material may cause a fire.
- If the inverter has become faulty, the inverter power must be switched OFF. A continuous flow of large current may cause a
- Do not connect a resistor directly to the DC terminals P/+ and N/ . Doing so could cause a fire.
- Be sure to perform daily and periodic inspections as specified in the Instruction Manual. If a product is used without any inspection, a burst, breakage, or a fire may occur.

#### Injury Prevention

#### 

- The voltage applied to each terminal must be the ones specified in the Instruction Manual. Otherwise burst, damage, etc. may
- The cables must be connected to the correct terminals. Otherwise burst, damage, etc. may occur.
- The polarity (+ and -) must be correct. Otherwise burst, damage, etc. may occur.
- While power is ON or for some time after power-OFF, do not touch the inverter as it will be extremely hot. Touching these devices may cause a burn

#### Additional Instructions

The following instructions must be also followed. If the product is handled incorrectly, it may cause unexpected fault, an injury, or an electric shock.

#### !\ Caution

#### Transportation and Mounting

- Any person who is opening a package using a sharp object, such as a knife and cutter, must wear gloves to prevent injuries caused by the edge of the sharp object.
- The product must be transported in correct method that corresponds to the weight. Failure to do so may lead to injuries.
- Do not stand or rest heavy objects on the product.
  Do not stack the boxes containing inverters higher than the number recommended.
- When carrying the inverter, do not hold it by the front cover; it may fall off or fail.
- During installation, caution must be taken not to drop the inverter as doing so may cause injuries.

  The product must be installed on the surface that withstands the
- weight of the inverter.
- Do not install the product on a hot surface.
- The mounting orientation of the inverter must be correct.
- The inverter must be installed on a strong surface securely with screws so that it will not drop.
- Do not install or operate the inverter if it is damaged or has parts missing.
- Foreign conductive objects must be prevented from entering the inverter. That includes screws and metal fragments or other flammable substance such as oil.
- As the inverter is a precision instrument, do not drop or subject it to impact.
- The surrounding air temperature for LD model must be between -10 and +50°C (non-freezing). The surrounding air temperature for SLD model must be between -10 and +40°C (non-freezing). Otherwise the inverter may be damaged.
- The ambient humidity must be 95%RH or less (noncondensing). Otherwise the inverter may be damaged. (Refer to page 26 for details.)

#### 

#### Transportation and Mounting

- The storage temperature (applicable for a short time, e.g. during transit) must be between -20 and +65°C. Otherwise the inverter may be damaged.
- The inverter must be used indoors (without corrosive gas, flammable gas, oil mist, dust and dirt etc.) Otherwise the inverter may be damaged.
- The inverter must be used at an altitude of 2500 m or less above sea level, with 5.9 m/s<sup>2</sup> or less<sub>1</sub> vibration at 10 to 55 Hz (directions of X, Y, Z axes). Otherwise the inverter may be damaged. (Refer to page 26 for details.)

  If halogen-based materials (fluorine, chlorine, bromine, iodine,
- etc.) infiltrate into a Mitsubishi product, the product will be damaged. Halogen-based materials are often included in fumigant, which is used to sterilize or disinfest wooden packages. When packaging, prevent residual fumigant components from being infiltrated into Mitsubishi products, or use an alternative sterilization or disinfection method (heat disinfection, etc.) for packaging. Sterilization of disinfection of wooden package should also be performed before packaging the product.

#### Wiring

- Do not install a power factor correction capacitor or surge suppressor/capacitor type filter on the inverter output side. These devices on the inverter output side may be overheated or
- The output side terminals (terminals U, V, and W) must be
- connected correctly. Otherwise the motor will rotate inversely.

  PM motor terminals (U, V, W) hold high-voltage while the PM
- motor is running even after the power is turned OFF. Before wiring, the PM motor must be confirmed to be stopped. Otherwise you may get an electric shock.

  Never connect an PM motor to the commercial power supply. Applying the commercial power supply to input terminals (U,V, W) of an PM motor will burn the PM motor. The PM motor must be connected with the output terminals (U, V, W) of the inverter. Trial run
- Before starting operation, each parameter must be confirmed and adjusted. A failure to do so may cause some machines to make unexpected motions
- 2.9 m/s<sup>2</sup> or less for the FR-F840-04320(185K) or higher.

#### A Warning

#### Usage

- Everyone must stay away from the equipment when the retry function is set as it will restart suddenly after a trip.
- STOP Since pressing a key may not stop output depending on the function setting status, separate circuit and switch that make an emergency stop (power OFF, mechanical brake operation for emergency stop, etc.) must be provided.
- OFF status of the start signal must be confirmed before resetting the inverter fault. Resetting inverter fault with the start signal ON
- restarts the motor suddenly.

   Do not use an PM motor for an application where the PM motor is driven by its load and runs at a speed higher than the maximum motor speed.
- Use this inverter only with three-phase induction motors or with an PM motor. Connection of any other electrical equipment to the inverter output may damage the equipment.
- Do not modify the equipment.
   Do not perform parts removal which is not instructed in this manual. Doing so may lead to fault or damage of the product.

#### Caution

#### Usage

- The electronic thermal relay function does not guarantee protection of the motor from overheating. It is recommended to install both an external thermal and PTC thermistor for overheat protection
- Do not use a magnetic contactor on the inverter input for frequent starting/stopping of the inverter. Otherwise the life of the inverter decreases.
- The effect of electromagnetic interference must be reduced by using a noise filter or by other means. Otherwise nearby electronic equipment may be affected.
- Appropriate measures must be taken to suppress harmonics. Otherwise power supply harmonics from the inverter may heat/ damage the power factor correction capacitor and generator.
- When driving a 400V class motor by the inverter, the motor must be an insulation-enhanced motor or measures must be taken to suppress surge voltage. Surge voltage attributable to the wiring constants may occur at the motor terminals, deteriorating the insulation of the motor.
- When parameter clear or all parameter clear is performed, the required parameters must be set again before starting operations. because all parameters return to their initial values.
- The inverter can be easily set for high-speed operation. Before changing its setting, the performances of the motor and machine must be fully examined.
- Stop status cannot be hold by the inverter's brake function. In addition to the inverter's brake function, a holding device must be installed to ensure safety.

  Before running an inverter which had been stored for a long
- period, inspection and test operation must be performed.
- Static electricity in your body must be discharged beforeyou touch the product.

  Only one PM motor can be connected to an inverter.
- An PM motor must be used under PM motor control. Do not use a synchronous motor, induction motor, or synchronous induction
- Do not connect an PM motor in the induction motor control but not control settings). Do not use an induction motor in the PM motor control settings. It will cause a failure.
   In the system with an PM motor, the inverter power must be turned ON before closing the contacts of the contactor at the
- output side.
- When the emergency drive operation is performed, the operation is continued or the retry is repeated even when a fault occurs, which may damage or burn the inverter and motor. Before restarting the normal operation after using the emergency drive function, make sure that the inverter and motor have no fault.

#### Emergency stop

- A safety backup such as an emergency brake must be provided to prevent hazardous conditions to the machine and equipment in case of inverter failure.
- When the breaker on the inverter input side trips, thewiring must be checked for fault (short circuit), and internalparts of the drive unit for a damage, etc. The cause of the trip must be identified and removed before turning ON the power of the breaker.
- When a protective function activates, take an appropriate corrective action, then reset the inverter, and resume the operation.

#### Maintenance, inspection and parts replacement

Do not carry out a megger (insulation resistance) test on the control circuit of the inverter. It will cause a failure.

The inverter must be treated as industrial waste.

#### **General instruction**

 Many of the diagrams and drawings in the Instruction Manual show the product without a cover or partially open for explanation. Never operate the product in this manner. The cover must be always reinstalled and the instruction in the Instruction Manual must be followed when operating the product. For more details on the PM motor, refer to the Instruction Manual of the PM motor.

IN	TRODUCTION	11
1.1 P	oduct checking and accessories	12
1.2 C	omponent names	14
1.3 O	peration steps	15
1.4 A	oout the related manuals	16
2 IN	STALLATION AND WIRING	17
2.1 P	eripheral devices	18
2.1.1	Inverter and peripheral devices	18
2.1.2	Peripheral devices	
2.2 R	emoval and reinstallation of the operation panel or the front covers	22
2.3 In	stallation of the inverter and enclosure design	26
2.3.1	Inverter installation environment	
2.3.2	Cooling system types for inverter enclosure	
2.3.3	Inverter installation	
2.3.4	Heatsink protrusion attachment procedure	
2.4 To	erminal connection diagrams	33
2.5 M	ain circuit terminals	37
2.5.1	Details on the main circuit terminals	
2.5.2	Terminal layout of the main circuit terminals, wiring of power supply and the motor	
2.5.3	Applicable cables and the wiring length	
2.5.4	Earthing (grounding) precautions	45
2.6 C	ontrol circuit	46
2.6.1	Details on the control circuit terminals	46
2.6.2	Control logic (sink/source) change	
2.6.3	Wiring of control circuit	
2.6.4	Wiring precautions	
2.6.5 2.6.6	When using separate power supplies for the control circuit and the main circuit	
2.6.7	Safety stop function	
2.7 C	ommunication connectors and terminals	60
2.7.1	PU connector	60
2.7.2	USB connector	
2.7.3	RS-485 terminal block	62
2.8 C	onnection of stand-alone option units	63
2.8.1	Connection of the brake unit (FR-BU2)	63
2.8.2	Connection of the brake unit (FR-BU)	
2.8.3	Connection of the brake unit (BU type)	
2.8.4	Connection of the high power factor converter (FR-HC2)	
2.8.5	Connection of the power regeneration common converter (FR-CV)	
2.8.6	Connection of the power regeneration converter (MT-RC)	
2.8.7	Connection of the DC reactor (FR-HEL)	68

## 3 PRECAUTIONS FOR USE OF THE INVERTER 71

3.1	Electro-magnetic interference (EMI) and leakage currents	72
3.1	Leakage currents and countermeasures	72
3.1		
3.1	Built-in EMC filter	76
3.2	Power supply harmonics	77
3.2	Power supply harmonics	77
3.2	P. Harmonic suppression guidelines	78
3.3	nstallation of a reactor	80
3.4	Power-OFF and magnetic contactor (MC)	81
3.5	Countermeasures against deterioration of the 400 V class motor insulation	82
3.6	Checklist before starting operation	83
3.7	ailsafe system which uses the inverter	85
E	ASIC OPERATION	87
4.1	Operation panel (FR-DU08)	88
4.1	Components of the operation panel (FR-DU08)	88
4.1	Pasic operation of the operation panel	89
4.1		
4.′	Changing the parameter setting value	91
4.2	Monitoring the inverter status	92
4.2	5 · · · · · · · · · · · · · · · · · · ·	
4.2		
4.2	B Displaying the set frequency	92
4.3	Easy operation mode setting (easy setting mode)	93
4.4	requently-used parameters (simple mode parameters)	95
4.4	Simple mode parameter list	95
4.5	Basic operation procedure (PU operation)	97
4.5		
4.5		
4.5		
4.5		
4.5	Using an analog signal (current input) to give a frequency command	101
1.6	Basic operation procedure (External operation)	102
4.6		
4.6		
4.6		
4.6		
4.6		
4.6		•
4.7	Basic operation procedure (JOG operation)	109

4.7.1 4.7.2	Performing JOG operation using external signals	
PA	RAMETERS	111
5.1 Par	ameter List	112
5.1.1	Parameter list (by parameter number)	112
5.1.2	Group parameter display	
5.1.3	Parameter list (by function group)	134
i.2 Coi	ntrol method	141
5.2.1	Changing the control method	143
5.2.2	Selecting the Advanced magnetic flux vector control	
5.2.3	Selecting the PM motor control	149
5.3 Spe	eed control under PM motor control	153
5.3.1	Setting procedure of PM motor control	153
5.3.2	Performing high-accuracy, fast-response control (gain adjustment for PM motor control)	
5.3.3	Troubleshooting in the speed control	157
5.3.4	Torque detection filter	158
.4 (E)	Environment setting parameters	159
5.4.1	Real time clock function	160
5.4.2	Reset selection/disconnected PU detection/PU stop selection	162
5.4.3	PU display language selection	164
5.4.4	Buzzer control	164
5.4.5	PU contrast adjustment	
5.4.6	Display-off mode	
5.4.7	Resetting USB host errors	
5.4.8	Setting dial potentiometer mode/key lock operation selection	
5.4.9	Frequency change increment amount setting.	
5.4.10 5.4.11	Multiple rating setting	
5.4.11	Parameter write selection	
5.4.13	Password function	
5.4.14	Free parameter	
5.4.15	Setting multiple parameters as a batch	_
5.4.16	Extended parameter display and user group function	
5.4.17	PWM carrier frequency and Soft-PWM control	
5.4.18	Inverter parts life display	180
5.4.19	Maintenance timer alarm	184
5.4.20	Current average value monitor signal	185
5.5 (F)	Setting of acceleration/deceleration time and acceleration/deceleration pattern	187
5.5.1	Setting the acceleration and deceleration time	187
5.5.2	Acceleration/deceleration pattern	
5.5.3	Remote setting function	194
5.5.4	Starting frequency and start-time hold function	
5.5.5	Minimum motor speed frequency	198
5.6 (D)	Operation command and frequency command	199
5.6.1	Operation mode selection	200
5.6.2	Startup in Network operation mode at power-ON	
5.6.3	Start command source and frequency command source during communication operation	210
5.6.4	Reverse rotation prevention selection	
5.6.5	Frequency setting via pulse train input	
5.6.6	JOG operation	221

5.6.7	Operation by multi-speed setting	222
5.7 (H)	Protective function parameter	224
5.7.1	Motor overheat protection (electronic thermal O/L relay)	225
5.7.2	Cooling fan operation selection	
5.7.3	Earth (ground) fault detection at start	234
5.7.4	Varying the activation level of the undervoltage protective function	234
5.7.5	Initiating a protective function	235
5.7.6	I/O phase loss protection selection	235
5.7.7	Retry function	236
5.7.8	Emergency drive	
5.7.9	Limiting the output frequency (maximum/minimum frequency)	245
5.7.10	Avoiding the mechanical resonance points (frequency jump)	246
5.7.11	Stall prevention operation	
5.7.12	Load characteristics fault detection	255
5.7.13	Motor overspeeding detection	259
5.8 (M)	Monitor display and monitor output signal	260
5.8.1	Speed display and rotations per minute setting	261
5.8.2	Monitor indicator selection using operation panel or via communication	
5.8.3	Monitor display selection for terminals FM/CA and AM	
5.8.4	Monitor display selection for terminals FM/CA and AM	
5.8.5	Energy saving monitor	
5.8.6	Output terminal function selection	
5.8.7	Output frequency detection	
5.8.8	Output current detection function	
5.8.9	Output torque detection	
5.8.10	Remote output function	
5.8.11	Analog remote output function	
5.8.12	Fault code output selection	302
5.8.13	Pulse train output of output power	
5.8.14	Detection of control circuit temperature	304
5.9 (T)	Multi-Function Input Terminal Parameters	305
5.9.1	Analog input selection	306
5.9.2	Analog input terminal (terminal 1, 4) function assignment	
5.9.3	Analog input compensation	
5.9.4	Analog input responsiveness and noise elimination	
5.9.5	Frequency setting voltage (current) bias and gain	
5.9.6	Bias and gain for voltage (current) setting of stall prevention operation level	
5.9.7	Checking of current input on analog input terminal	
5.9.8	Input terminal function selection	
5.9.9	Inverter output shutoff signal	
5.9.10	Selecting operation condition of the second function selection signal (RT)	
5.9.11	Start signal operation selection	
5.10 (C)	Motor constant parameters	337
5.10.1	Applied motor	
5.10.1	Offline auto tuning	
5.10.3	Offline auto tuning for a PM motor (motor constants tuning)	
5.10.4	Online auto tuning	
0.10.1	Crimic data taring	
5.11 (A)	Application parameters	362
5.11.1	Electronic bypass function	363
5.11.2	Self power management	
5.11.3	Traverse function	373
5.11.4	Cleaning function	
5.11.5	PID control	
5.11.6	PID gain tuning	
5.11.7	Changing the display increment of the numerical values used in PID control	399

Automatic restart after instantaneous power failure/flying start with an IPM motor	420
Power failure time deceleration-to-stop function	426
PLC function	431
Trace function	433
Operation via communication and its settings	441
Wiring and configuration of PU connector	441
Wiring and configuration of RS-485 terminals	443
Initial setting of operation via communication	446
Initial settings and specifications of RS-485 communication	449
Mitsubishi inverter protocol (computer link communication)	
Modbus-RTU communication specification	465
BACnet MS/TP protocol	480
USB device communication	493
Automatic connection with GOT	494
Control parameters	495
Manual torque boost	496
Base frequency, voltage	497
Load pattern selection	499
·	
·	
•	
Stop selection	507
·	
·	
Speed smoothing control	519
ameter clear / all parameter clear	520
bying and verifying parameters on the operation panel	521
Parameter copy	521
Parameter verification	
oying and verifying parameters using USB memory	524
ecking parameters changed from their initial values (Initial value change list)	527
OTECTIVE FUNCTIONS	529
erter fault and alarm indications	530
et method for the protective functions	530
eck and clear of the faults history	531
list of fault displays	533
ises and corrective actions	535
	Wiring and configuration of RS-485 terminals Initial setting of operation via communication Initial settings and specifications of RS-485 communication Mitsubishi inverter protocol (computer link communication) Modbus-RTU communication specification BAChet MS/TP protocol USB device communication Automatic connection with GOT  Control parameters Manual torque boost Base frequency, voltage Load pattern selection Energy saving control Adjustable 5 points V/F SF-PR slip amount adjustment mode DC injection brake Output stop function Stop selection Regeneration avoidance function Increased magnetic excitation deceleration Slip compensation Speed smoothing control  ameter clear / all parameters on the operation panel Parameter copy Parameter verification Dying and verifying parameters using USB memory Decking parameters changed from their initial values (Initial value change list)  DTECTIVE FUNCTIONS  Perter fault and alarm indications Sect method for the protective functions Oct and clear of the faults history Ulist of fault displays

	eck first when you have a trouble	5
6.6.1	Motor does not start	
6.6.2	Motor or machine is making abnormal acoustic noise	
6.6.3	Inverter generates abnormal noise	5
6.6.4	Motor generates heat abnormally	
6.6.5	Motor rotates in the opposite direction	5
6.6.6	Speed greatly differs from the setting	<u>5</u>
6.6.7	Acceleration/deceleration is not smooth	5
6.6.8	Speed varies during operation	5
6.6.9	Operation mode is not changed properly	5
6.6.10	Operation panel (FR-DU08) display is not operating	5
6.6.11	Motor current is too large	<u> </u>
6.6.12	Speed does not accelerate	
6.6.13	Unable to write parameter setting	
6.6.14	Power lamp is not lit	
	ECAUTIONS FOR MAINTENANCE AND SPECTION	56
7.1 Ins	pection item	
7.1.1	Daily inspection	
7.1.2	Periodic inspection	
7.1.3	Daily and periodic inspection	
7.1.4	Checking the inverter and converter modules	
7.1.5	Cleaning	
7.1.6	Replacement of parts	
7.1.7	Inverter replacement	
7.2 Me	asurement of main circuit voltages, currents and powers	į.
7.2.1	Measurement of powers	
7.2.2	Measurement of voltages and use of PT	
7.2.3	Measurement of currents	
7.2.4	Use of CT and transducer	
7.2.5	Measurement of inverter input power factor	
7.2.6	Measurement of converter output voltage (across terminals P and N)	
7.2.7	Measurement of inverter output frequency	
7.2.8	Insulation resistance test using megger	
7.2.9	Pressure test	
	ECIFICATIONS	57
SP	ECIFICATIONS erter rating	
<b>SP</b>		
<b>SP</b>   8.1 Inv	erter rating tor rating	
<b>SP</b>	erter rating	
8.1 Inv 8.2 Mo 8.2.1 8.2.2	erter rating  tor rating  Premium high-efficiency IPM motor [MM-EFS (1500 r/min) series]	
8.1 Inv 8.2 Mo 8.2.1 8.2.2 8.3 Co	erter rating  tor rating  Premium high-efficiency IPM motor [MM-EFS (1500 r/min) series]	· · · · · · · · · · · · · · · · · · ·
8.1 Inv 8.2 Mo 8.2.1 8.2.2 8.3 Co	erter rating  tor rating  Premium high-efficiency IPM motor [MM-EFS (1500 r/min) series]  Premium high-efficiency IPM motor [MM-THE4 (1500 r/min) series]  mmon specifications	

APPENDIX	<b>593</b>
Appendix1 For customers replacing the conventional model with this inverter	594
Appendix2 Specification comparison between PM motor control and induction motor control	596
Appendix3 Parameters (functions) and instruction codes under different control methods	597
Appendix4 For customers using HMS network options	610

## **MEMO**

# 1 INTRODUCTION

The contents described in this chapter must be read before using this product.

Always read the instructions before using the equipment.

For the "INTRODUCTION" of the separated converter type, refer to the FR-F802 (Separated Converter Type) Instruction Manual (Hardware) [IB-0600550ENG].

1.1	Product checking and accessories12
	Component names14
1.3	Operation steps15
	About the related manuals16

<abbreviations></abbreviations>	
DU	Operation panel (FR-DU08)
Operation panel	Operation panel (FR-DU08) and LCD operation panel (FR-LU08)
Parameter unit	Parameter unit (FR-PU07)
PU	Operation panel and parameter unit
Inverter	Mitsubishi inverter FR-F800 series
Pr	Parameter number (Number assigned to function)
PU operation	Operation using the PU (operation panel/parameter unit)
External operation	Operation using the control circuit signals
Combined operation	Combined operation using the PU (operation panel/parameter unit) and
	External operation
Mitsubishi standard motor	SF-JR
Mitsubishi constant-torque motor .	SF-HRCA
Mitsubishi IPM motor	MM-EFS/MM-THE4
<trademarks></trademarks>	

- Microsoft and Visual C++ are registered trademarks of Microsoft Corporation in the United States and other countries.
- BACnet<sup>®</sup> is a registered trademark of the ASHRAE (American Society of Heating, Refrigerating and Air-Conditioning Engineers).
- Other company and product names herein are the trademarks and registered trademarks of their respective owners.
- <Notes on descriptions in this Instruction Manual>
- Connection diagrams in this Instruction Manual appear with the control logic of the input terminals as sink logic, unless otherwise specified. (For the control logic, refer to page 50.)


#### Harmonic Suppression Guidelines

All the models of the inverters used by specific consumers are covered by "the Harmonic Suppression Guidelines for Consumers Who Receive High Voltage or Special High Voltage". (For details, refer to page 78.)

## 1.1 Product checking and accessories

Unpack the product and check the rating plate and the capacity plate of the inverter to ensure that the model agrees with the order and the product is intact.

#### Inverter model



\*1 Specification differs by the type. Major differences are shown in the table below.

		Initial setting				
Туре	Monitor output	Built-in EMC filter	Control logic	Rated frequency	Pr.19 Base frequency voltage	Pr.570 Multiple rating setting
FM (terminal FM equipped model)	Terminal FM (pulse train output) Terminal AM (analog voltage output (0 to ±10 VDC))	OFF	Sink logic	60 Hz	9999 (same as the power supply voltage)	1 (LD rating)
CA (terminal CA equipped model)	Terminal CA (analog current output (0 to 20 mADC)) Terminal AM (analog voltage output (0 to ±10 VDC))	ON	Source logic	50 Hz	8888 (95% of the power supply voltage)	0 (SLD rating)

#### NOTE

Hereinafter, the inverter model name consists of the rated current and the applicable motor capacity.
 (Example) FR-F820-00046(0.75K)

#### Accessory

· Fan cover fixing screws

These screws are necessary for compliance with the EU Directives. (Refer to Instruction Manual (Startup).)

Capacity	Screw size (mm)	Quantity
FR-F820-00105(2.2K) to FR-F820-00250(5.5K) FR-F840-00083(3.7K), FR-F840-00126(5.5K)	M3 × 35	1
FR-F820-00340(7.5K), FR-F820-00490(11K) FR-F840-00170(7.5K), FR-F840-00250(11K)	M3 × 35	2
FR-F820-00630(15K) to FR-F820-00930(22K) FR-F840-00310(15K) to FR-F840-00620(30K)	M4 × 40	2

• Eyebolt for hanging the inverter

Capacity	Eyebolt Size	Quantity
FR-F840-04320(185K) to FR-F840-06830(315K)	M12	2



#### How to read the SERIAL number

Rating plate example

□ <u>O</u> <u>O</u> <u>OOOOOO</u>


Symbol Year Month Control number

**SERIAL** 

The SERIAL consists of one symbol, two characters indicating the production year and month, and six characters indicating the control number. The last digit of the production year is indicated as the Year, and the Month is indicated by 1 to 9, X (October), Y (November), or Z (December).


## **1.2** Component names

Component names are shown below.



Symbol Name Descripti		Description	Refer to page
(a)	PU connector	Connects the operation panel or the parameter unit. This connector also enables the RS-485 communication.	60
(b)	USB A connector	Connects a USB memory device.	61
(c)	USB mini B connector	Connects a personal computer and enables communication with FR Configurator2.	61
(d)	RS-485 terminals	Enables RS-485, Modbus-RTU communication and BACnet communication.	62
(e)	Plug-in option connector1		Instruction
(f)	Plug-in option connector2	Connects a plug-in option or a communication option.	Manual of
(g)	Plug-in option connector3		the option
(h)	Voltage/current input switch	Selects between voltage and current for the terminal 2 and 4 inputs.	306
(i)	Control circuit terminal block	Connects cables for the control circuit.	46
(j)	EMC filter ON/OFF connector	Turns ON/OFF the EMC filter.	76
(k)	Main circuit terminal block	Connects cables for the main circuit.	37
(l)	Charge lamp	Stays ON while the power is supplied to the main circuit.	
(m)	Wiring cover	This cover is removable without unplugging cables. (FR-F820-01250(30K) or lower, FR-F840-00620(30K) or lower)	
(n)	Alarm lamp	Turns ON when the protective function of the inverter is activated.	38
(o)	Power lamp	Stays ON while the power is supplied to the control circuit (R1/L11, S1/L21).	38
(p)	Front cover (upper side)	Remove this cover for the installation of the product, installation of a plug-in (communication) option, RS-485 terminal wiring, switching of the voltage/current input switch, etc.	
(p)	Front cover (lower side)	Remove this cover for wiring.	
(r)	Operation panel (FR-DU08)	Operates and monitors the inverter.	
(s)	Cooling fan	Cools the inverter. (FR-F820-00105(2.2K) or higher, FR-F840-00083(3.7K) or higher.)	

## 1.3 Operation steps



Symbol	Overview	Refer to page
(a)	Install the inverter.	26
(b)	Perform wiring for the power supply and the motor.	38
(c)	Select the control method (V/F control, Advanced magnetic flux vector control, or PM motor control).	143
(d)	Input the start command via communication.	441
(e)	The PU gives both start and frequency commands. (PU operation mode)	97
(f)	The PU gives a start command, and inputs to terminal RH, RM, and RL give a frequency command. (External/PU combined operation mode 2)	99
(g)	The PU gives a start command, and voltage input to terminal 2 gives a frequency command. (External/PU combined operation mode 2)	100
(h)	The PU gives a start command, and current input to terminal 4 gives a frequency command. (External/PU combined operation mode 2)	101
(i)	Inputs to terminal STF and STR give a start command, and the PU gives a frequency command. (External/PU combined operation mode 1)	102
(j)	Inputs to terminal STF and STR give a start command, and inputs to terminal RH, RM, and RL give a frequency command. (External operation mode)	104
(k)	Inputs to terminal STF and STR give a start command, and voltage input to terminal 2 gives a frequency command. (External operation mode)	105
(I)	Inputs to terminal STF and STR give a start command, and current input to terminal 4 gives a frequency command. (External operation mode)	107

## **1.4** About the related manuals

The manuals related to FR-F800 are shown below.

Manual name	Manual number
FR-F800 Instruction Manual (Startup)	IB-0600545
FR-F802 (Separated Converter Type) Instruction Manual (Hardware)	IB-0600550ENG
FR-CC2 (Converter unit) Instruction Manual	IB-0600543ENG
FR Configurator 2 Instruction Manual	IB-0600516ENG
FR-A800/F800 PLC function programming manual	IB-0600492ENG
FR-A800/F800 Safety stop function instruction manual	BCN-A23228-001


# 2 INSTALLATION AND WIRING

This chapter explains the "installation" and the "wiring" of this product. Always read the instructions before using the equipment. For the "INSTALLATION AND WIRING" of the separated converter type, refer to the FR-F802 (Separated Converter Type) Instruction Manual (Hardware) [IB-0600550ENG].

2.1	Peripheral devices	18
2.2	Removal and reinstallation of the operation panel or the fr	ont
	covers	22
2.3	Installation of the inverter and enclosure design	2 <mark>6</mark>
2.4	Terminal connection diagrams	33
2.5	Main circuit terminals	37
2.6	Control circuit	46
2.7	Communication connectors and terminals	60
2.8	Connection of stand-alone option units	63

## 2.1 Peripheral devices

## 2.1.1 Inverter and peripheral devices



#### • NOTE

- To prevent an electric shock, always earth (ground) the motor and inverter.
- Do not install a power factor correction capacitor or surge suppressor or capacitor type filter on the inverter's output side. Doing so will cause the inverter to trip or the capacitor and surge suppressor to be damaged. If any of the above devices is connected, immediately remove it. When installing a molded case circuit breaker on the output side of the inverter, contact the manufacturer of the molded case circuit breaker.
- · Electromagnetic wave interference

The input/output (main circuit) of the inverter includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the inverter. In this case, activating the EMC filter may minimize interference. (Refer to page 76.)

- For details of options and peripheral devices, refer to the respective Instruction Manual.
- A PM motor cannot be driven by the commercial power supply.
- A PM motor is a motor with permanent magnets embedded inside. High voltage is generated at the motor terminals while the motor is running. Before closing the contactor at the output side, make sure that the inverter power is ON and the motor is stopped.

Symbol	Name	Overview	Refer to page	
(a) Inverter (FR-F800)		The life of the inverter is influenced by the surrounding air temperature. The surrounding air temperature should be as low as possible within the permissible range. This must be noted especially when the inverter is installed in an enclosure.  Incorrect wiring may lead to damage of the inverter. The control signal lines must be kept fully away from the main circuit lines to protect them from noise.  The built-in EMC filter can reduce the noise.		
(b)	Three-phase AC power supply	Must be within the permissible power supply specifications of the inverter.	578	
(c)	Molded case circuit breaker (MCCB), earth leakage circuit breaker (ELB), or fuse	Must be selected carefully since an inrush current flows in the inverter at power ON.	20	
(d)	Magnetic contactor (MC)	Install this to ensure safety.  Do not use this to start and stop the inverter. Doing so will shorten the life of the inverter.	81	
(e)	AC reactor (FR-HAL)	Install this to suppress harmonics and to improve the power factor. An AC reactor (FR-HAL) (option) is required when installing the inverter near a large power supply system (1000 kVA or more). Under such condition, the inverter may be damaged if you do not use a reactor.  Select a reactor according to the applied motor capacity.	80	
(f) DC reactor (FR-HEL)		Install this to suppress harmonics and to improve the power factor. Select a reactor according to the applicable motor capacity. For the FR-F820-03160(75K) or higher and the FR-F840-01800(75K) or higher, always connect the FR-HEL. When using the DC reactor with the FR-F820-02330(55K) or lower, FR-F840-01160(55K) or lower, remove the jumper across terminals P/+ and P1 before connecting the DC reactor to the inverter.	80	
(g)	Noise filter (FR-BLF)	The FR-F820-02330(55K) or lower, FR-F840-01160(55K) or lower are equipped with the common mode choke.	74	
(h)	High power factor converter (FR-HC2)	Suppresses the power supply harmonics significantly. Install this as required.	66	
(i)	Power regeneration common converter (FR-CV*1)	Provides a large braking copability Install this as required	67	
(j)	Power regeneration converter (MT-RC*2)	Provides a large braking capability. Install this as required.	68	
(k)	Brake unit (FR-BU2, FR-BU*1)	Allows the inverter to provide the optimal regenerative braking capability.	00	
(l)	Resistor unit (FR-BR*1, MT-BR5*2)	Install this as required.	63	
(m)	USB connection	A USB (Ver. 1.1) cable connects the inverter with a personal computer.  A USB memory device enables parameter copies and the trace function.	61	
(n)	Noise filter (FR-BSF01, FR-BLF)	Install this to reduce the electromagnetic noise generated from the inverter. The noise filter is effective in the range from about 0.5 MHz to 5 MHz.  A wire should be wound four turns at maximum.	74	
(o)	Induction motor	Connect a squirrel-cage induction motor.	_	
(p)	Contactor Example) No-fuse switch (DSN type)	Connect this for an application where a PM motor is driven by the load even while the inverter power is OFF. Do not open or close the contactor while the inverter is running (outputting).		
(p)	IPM motor (MM-EFS, MM-THE4)	Use the specified motor. An IPM motor cannot be driven by the commercial power supply.	580	

 $<sup>* 1 \</sup>quad \hbox{Compatible with the FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower.} \\$ 

 $<sup>* 2 \</sup>quad \text{Compatible with the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.} \\$ 

## 2.1.2 Peripheral devices

Check the model of the inverter you purchased. Appropriate peripheral devices must be selected according to the capacity. Refer to the table below to prepare appropriate peripheral devices.

• 200 V class

Motor output (kW)	Applicable inverter model	Molded case circuit breaker (MCCB) *2 or earth leakage circuit breaker (ELB) (NF, NV type) Power factor improving (AC or DC) reactor		Power factor im	gnetic contactor *3  aproving (AC or DC) eactor
		Without	With	Without	With
0.75	FR-F820-00046(0.75K)	10A	10A	S-T10	S-T10
1.5	FR-F820-00077(1.5K)	15A	15A	S-T10	S-T10
2.2	FR-F820-00105(2.2K)	20A	15A	S-T10	S-T10
3.7	FR-F820-00167(3.7K)	30A	30A	S-T21	S-T10
5.5	FR-F820-00250(5.5K)	50A	40A	S-N25	S-T21
7.5	FR-F820-00340(7.5K)	60A	50A	S-N25	S-N25
11	FR-F820-00490(11K)	75A	75A	S-N35	S-N35
15	FR-F820-00630(15K)	125A	100A	S-N50	S-N50
18.5	FR-F820-00770(18.5K)	150A	125A	S-N65	S-N50
22	FR-F820-00930(22K)	175A	150A	S-N80	S-N65
30	FR-F820-01250(30K)	225A	175A	S-N95	S-N80
37	FR-F820-01540(37K)	250A	225A	S-N150	S-N125
45	FR-F820-01870(45K)	300A	300A	S-N180	S-N150
55	FR-F820-02330(55K)	400A	350A	S-N220	S-N180
75	FR-F820-03160(75K)	_	400A	_	S-N300
90	FR-F820-03800(90K)	_	400A	_	S-N300
110	FR-F820-04750(110K)	_	500A	_	S-N400

- \*1 Assumes the use of an IPM motor MM-EFS/MM-THE4 or a Mitsubishi 4-pole standard motor with the power supply voltage of 200 VAC 50 Hz.
- \*2 Select an MCCB according to the power supply capacity.
  Install one MCCB per inverter.

  For the use in the United States or Canada, provide the appropriate UL and cUL listed fuse or UL489 molded case circuit breaker (MCCB) that is suitable for branch circuit protection. (Refer to the Instruction Manual (Startup).)
- \*3 The magnetic contactor is selected based on the AC-1 class. The electrical durability of magnetic contactor is 500,000 times. When the magnetic
  - contactor is used for emergency stops during motor driving, the electrical durability is 25 times.

If using an MC for emergency stop during motor driving, select an MC regarding the inverter input side current as JEM1038-AC-3 class rated current. When using an MC on the inverter output side for commercial-power supply operation switching using a general-purpose motor, select an MC regarding the rated motor current as JEM1038-AC-3 class rated current.


#### • NOTE

- When the inverter capacity is larger than the motor capacity, select an MCCB and a magnetic contactor according to the inverter model, and select cables and reactors according to the motor output.
- When the breaker on the inverter's input side trips, check for the wiring fault (short circuit), damage to internal parts of the inverter etc. The cause of the trip must be identified and removed before turning ON the power of the breaker.

#### • 400 V class

Motor output (kW) *1	Applicable inverter model	Molded case circuit breaker (MCCB) *2 or earth leakage circuit breaker (ELB) (NF, NV type) Power factor improving (AC or DC) reactor		Input-side magnetic contactor +3  Power factor improving (AC or DC) reactor	
		0.75	FR-F840-00023(0.75K)	5A	5A
1.5	FR-F840-00038(1.5K)	10A	10A	S-T10	S-T10
2.2	FR-F840-00052(2.2K)	10A	10A	S-T10	S-T10
3.7	FR-F840-00083(3.7K)	20A	15A	S-T10	S-T10
5.5	FR-F840-00126(5.5K)	30A	20A	S-T21	S-T12
7.5	FR-F840-00170(7.5K)	30A	30A	S-T21	S-T21
11	FR-F840-00250(11K)	50A	40A	S-T21	S-T21
15	FR-F840-00310(15K)	60A	50A	S-N25	S-T21
18.5	FR-F840-00380(18.5K)	75A	60A	S-N25	S-N25
22	FR-F840-00470(22K)	100A	75A	S-N35	S-N25
30	FR-F840-00620(30K)	125A	100A	S-N50	S-N50
37	FR-F840-00770(37K)	150A	125A	S-N65	S-N50
45	FR-F840-00930(45K)	175A	150A	S-N80	S-N65
55	FR-F840-01160(55K)	200A	175A	S-N80	S-N80
75	FR-F840-01800(75K)	_	225A	_	S-N95
90	FR-F840-02160(90K)	_	225A	_	S-N150
110	FR-F840-02600(110K)	_	225A	_	S-N180
132	FR-F840-03250(132K)	_	400A	_	S-N220
150	FR-F840-03610(160K)	_	400A	_	S-N300
160	FR-F840-03610(160K)	_	400A	_	S-N300
185	FR-F840-04320(185K)	_	400A	_	S-N300
220	FR-F840-04810(220K)	_	500A	_	S-N400
250	FR-F840-05470(250K)	_	600A	_	S-N600
280	FR-F840-06100(280K)	_	600A	_	S-N600
315	FR-F840-06830(315K)	_	700A	_	S-N600

- \*1 Assumes the use of an IPM motor MM-EFS/MM-THE4 or a Mitsubishi 4-pole standard motor with the power supply voltage of 400 VAC 50 Hz.
- \*2 Select an MCCB according to the power supply capacity. Install one MCCB per inverter.
  For the use in the United States or Canada, provide the appropriate UL and cUL listed fuse or UL489 molded case circuit breaker (MCCB) that is suitable for branch circuit protection. (Refer to the Instruction Manual (Startup).)



\*3 Magnetic contactor is selected based on the AC-1 class. The electrical durability of magnetic contactor is 500,000 times. When the magnetic contactor is used for emergency stops during motor driving, the electrical durability is 25 times.

If using an MC for emergency stop during motor driving, select an MC regarding the inverter input side current as JEM1038-AC-3 class rated current. When using an MC on the inverter output side for commercial-power supply operation switching using a general-purpose motor, select an MC regarding the rated motor current as JEM1038-AC-3 class rated current.


#### • NOTE

- When the inverter capacity is larger than the motor capacity, select an MCCB and a magnetic contactor according to the inverter model, and select cables and reactors according to the motor output.
- When the breaker on the inverter's input side trips, check for the wiring fault (short circuit), damage to internal parts of the inverter etc. The cause of the trip must be identified and removed before turning ON the power of the breaker.


# **2.2** Removal and reinstallation of the operation panel or the front covers

#### **♦**Removal and reinstallation of the operation panel

Loosen the two screws on the operation panel.
 (These screws cannot be removed.)




 Press the upper edge of the operation panel while pulling out the operation panel.




To reinstall the operation panel, align its connector on the back with the PU connector of the inverter, and insert the operation panel. After confirming that the operation panel is fit securely, tighten the screws. (Tightening torque: 0.40 to 0.45 N·m)

## ◆Removal of the front cover (lower side) (FR-F820-01540(37K) or lower, FR-F840-00770(37K) or lower)




- (a) Loosen the screws on the front cover (lower side). (These screws cannot be removed.)
- (b) While holding the areas around the installation hooks on the sides of the front cover (lower side), pull out the terminal block cover using its upper side as a support.
- (c) With the front cover (lower side) removed, wiring of the main circuit terminals and control circuit terminals can be performed.

## ◆Removal of the front cover (upper side) (FR-F820-01540(37K) or lower, FR-F840-00770(37K) or lower)



- (a) With the front cover (lower side) removed, loosen the mounting screw(s) on the front cover (upper side). (The screw(s) cannot be removed.)
  - $(FR-F820-00340(7.5K)\ to\ FR-F820-01540(37K)\ and\ FR-F840-00170(7.5K)\ to\ FR-F840-00770(37K)\ have\ two\ mounting\ screws.)$
- (b) While holding the areas around the installation hooks on the sides of the front cover (upper side), pull out the cover using its upper side as a support.
- (c) With the front cover (upper side) removed, wiring of the RS-485 terminals and installation of the plug-in option can be performed.

## ◆Reinstallation of the front covers (FR-F820-01540(37K) or lower, FR-F840-00770(37K) or lower)




- (a) Insert the upper hooks of the front cover (upper side) into the sockets of the inverter.Securely install the front cover (upper side) to the inverter by fixing the hooks on the sides of the cover into place.
- (b) Tighten the mounting screw(s) at the lower part of the front cover (upper side). (FR-F820-00340(7.5K) to FR-F820-01540(37K) and FR-F840-00170(7.5K) to FR-F840-00770(37K) have two mounting screws.)
- (c) Install the terminal block cover by inserting the upper hook into the socket of the front cover (lower side).
- (d) Tighten the mounting screws at the lower part of the front cover (lower side).

#### • NOTE


 When installing the front cover (upper side), fit the connector of the operation panel securely along the guides of the PU connector.

# ◆Removal of the front cover (lower side) (FR-F820-01870(45K) or higher, FR-F840-00930(45K) or higher)




- (a) When the mounting screws are removed, the front cover (lower side) can be removed.
- (b) With the front cover (lower side) removed, wiring of the main circuit terminals can be performed.

# ◆Removal of the front cover (upper side) (FR-F820-01870(45K) or higher, FR-F840-00930(45K) or higher)



- (a) With the front cover (lower side) removed, loosen the mounting screws on the front cover (upper side). (These screws cannot be removed.)
- (b) Holding the areas around the installation hooks on the sides of the front cover (upper side), pull out the cover using its upper side as a support.
- (c) With the front cover (upper side) removed, wiring of the RS-485 terminals and installation of the plug-in option can be performed.

# ◆Reinstallation of the front covers (FR-F820-01870(45K) or higher, FR-F840-00930(45K) or higher)



- (a) Insert the upper hooks of the front cover (upper side) into the sockets of the inverter.

  Securely install the front cover (upper side) to the inverter by fixing the hooks on the sides of the cover into place.
- (b) Tighten the mounting screw(s) at the lower part of the front cover (upper side).
- (c) Fasten the front cover (lower side) with the mounting screws.



• Fully make sure that the front covers are installed securely. Always tighten the mounting screws of the front covers.

# 2.3 Installation of the inverter and enclosure design

When designing or manufacturing an inverter enclosure, determine the structure, size, and device layout of the enclosure by fully considering the conditions such as heat generation of the contained devices and the operating environment. An inverter unit uses many semiconductor devices. To ensure higher reliability and long period of operation, operate the inverter in the ambient environment that completely satisfies the equipment specifications.

### 2.3.1 Inverter installation environment

The following table lists the standard specifications of the inverter installation environment. Using the inverter in an environment that does not satisfy the conditions deteriorates the performance, shortens the life, and causes a failure. Refer to the following points, and take adequate measures.

#### ◆Standard environmental specifications of the inverter

Iter	n	Descript	ion				
Surrounding air	LD	-10 to +50°C (non-freezing)	Measurement position × Inverter 5 cm				
temperature	SLD	-10 to +40°C (non-freezing)	(1.97 inches)  Measurement position  (1.97 inches)  5 cm (1.97 inches)				
Ambient humidity		With circuit board coating (conforming to IEC60721-3-3 3C2/3S2): 95% RH or less (non-condensing), Without circuit board coating: 90% RH or less (non-condensing)					
Storage temperate	ure	-20 to +65°C*1					
Atmosphere		Indoors (free from corrosive gas, flammable gas, oil mist, dust and dirt)					
Altitude		Maximum 1,000 m above sea level.*2					
Vibration		5.9 m/s <sup>2</sup> or less*3 at 10 to 55 Hz (directions of X, Y, Z axes)					

- \*1 Temperature applicable for a short time, e.g. in transit.
- \*2 For the installation at an altitude above 1,000 m (3280.80 feet) up to 2,500 m (8202 feet), derate the rated current 3% per 500 m (1640.40 feet).
- \*3 2.9 m/s<sup>2</sup> or less for the FR-F840-04320(185K) or higher.

## ◆Temperature

The permissible surrounding air temperature of the inverter is between -10°C and +50°C (-10°C and +40°C at the SLD rating). Always operate the inverter within this temperature range. Operation outside this range will considerably shorten the service lives of the semiconductors, parts, capacitors and others. Take the following measures to keep the surrounding air temperature of the inverter within the specified range.

- (a) Measures against high temperature
- Use a forced ventilation system or similar cooling system. (Refer to page 28.)
- Install the enclosure in an air-conditioned electric chamber.
- · Block direct sunlight.
- Provide a shield or similar plate to avoid direct exposure to the radiated heat and wind of a heat source.
- · Ventilate the area around the enclosure well.
- (b) Measures against low temperature
- Provide a space heater in the enclosure.
- Do not power OFF the inverter. (Keep the start signal of the inverter OFF.)
- (c) Sudden temperature changes
- · Select an installation place where temperature does not change suddenly.
- Avoid installing the inverter near the air outlet of an air conditioner.
- · If temperature changes are caused by opening/closing of a door, install the inverter away from the door.

### **♦**Humidity

Operate the inverter within the ambient air humidity of usually 45 to 90% (up to 95% with circuit board coating). Too high humidity will pose problems of reduced insulation and metal corrosion. On the other hand, too low humidity may cause a spatial electrical breakdown.

The insulation distance defined in JEM1103 "Control Equipment Insulator" is humidity of 45 to 85%.

(a) Measures against high humidity

- · Make the enclosure enclosed, and provide it with a hygroscopic agent.
- Provide dry air into the enclosure from outside.
- · Provide a space heater in the enclosure.
- (b) Measures against low humidity

Air with proper humidity can be blown into the enclosure from outside. Also when installing or inspecting the unit, discharge your body (static electricity) beforehand, and keep your body away from the parts and patterns.

(c) Measures against condensation

Condensation may occur if frequent operation stops change the in-enclosure temperature suddenly or if the outside air temperature changes suddenly.

Condensation causes such faults as reduced insulation and corrosion.

- Take the measures against high humidity in (a).
- Do not power OFF the inverter. (Keep the start signal of the inverter OFF.)

#### **◆**Dust, dirt, oil mist

Dust and dirt will cause such faults as poor contacts, reduced insulation and cooling effect due to the moisture-absorbed accumulated dust and dirt, and in-enclosure temperature rise due to a clogged filter. In an atmosphere where conductive powder floats, dust and dirt will cause such faults as malfunction, deteriorated insulation and short circuit in a short time. Since oil mist will cause similar conditions, it is necessary to take adequate measures.

#### Countermeasure

- Place the inverter in a totally enclosed enclosure.
   Take measures if the in-enclosure temperature rises. (Refer to page 28.)
- · Purge air.

Pump clean air from outside to make the in-enclosure air pressure higher than the outside air pressure.

## **♦**Corrosive gas, salt damage

If the inverter is exposed to corrosive gas or to salt near a beach, the printed board patterns and parts will corrode or the relays and switches will result in poor contact.

In such places, take the measures given in the previous paragraph.

## **♦**Explosive, flammable gases

As the inverter is non-explosion proof, it must be contained in an explosion-proof enclosure. In places where explosion may be caused by explosive gas, dust or dirt, an enclosure cannot be used unless it structurally complies with the guidelines and has passed the specified tests. This makes the enclosure itself expensive (including the test charges). The best way is to avoid installation in such places and install the inverter in a non-hazardous place.

## ◆High altitude

Use the inverter at an altitude of within 1000 m. For the installation at an altitude above 1,000 m (3280.80 feet) up to 2,500 m (8202 feet), derate the rated current 3% per 500 m (1640.40 feet).

If it is used at a higher place, it is likely that thin air will reduce the cooling effect and low air pressure will deteriorate dielectric strength.

#### **♦**Vibration, impact

The vibration resistance of the inverter is up to 5.9 m/s<sup>2</sup> (2.9 m/s<sup>2</sup> or less for the FR-F840-04320(185K) or higher) at 10 to 55 Hz frequency and 1 mm amplitude for the directions of X, Y, Z axes. Applying vibration and impacts for a long time may loosen the structures and cause poor contacts of connectors, even if those vibration and impacts are within the specified values. Especially when impacts are applied repeatedly, caution must be taken because such impacts may break the installation feet.

#### Countermeasure

- · Provide the enclosure with rubber vibration isolators.
- Strengthen the structure to prevent the enclosure from resonance.
- · Install the enclosure away from the sources of the vibration.

# 2.3.2 Cooling system types for inverter enclosure

From the enclosure that contains the inverter, the heat of the inverter and other equipment (transformers, lamps, resistors, etc.) and the incoming heat such as direct sunlight must be dissipated to keep the in-enclosure temperature lower than the permissible temperatures of the in-enclosure equipment including the inverter.


The cooling systems are classified as follows in terms of the cooling calculation method.

- (a) Cooling by natural heat dissipation from the enclosure surface (totally enclosed type)
- (b) Cooling by heatsink (aluminum fin, etc.)
- (c) Cooling by ventilation (forced ventilation type, pipe ventilation type)
- (d) Cooling by heat exchanger or cooler (heat pipe, cooler, etc.)

	Cooling system	Enclosure structure	Comment
	Natural ventilation (enclosed, open type)	INV	This system is low in cost and generally used, but the enclosure size increases as the inverter capacity increases. This system is for relatively small capacities.
Natural cooling	Natural ventilation (totally enclosed type)	NV NV	Being a totally enclosed type, this system is the most appropriate for hostile environment having dust, dirt, oil mist, etc. The enclosure size increases depending on the inverter capacity.
	Heatsink cooling	Heatsink INV	This system has restrictions on the heatsink mounting position and area. This system is for relatively small capacities.
Forced cooling	Forced ventilation		This system is for general indoor installation. This is appropriate for enclosure downsizing and cost reduction, and often used.
	Heat pipe	Heat pipe	This is a totally enclosed for enclosure downsizing.

### 2.3.3 Inverter installation


#### **♦**Inverter placement



Fix six positions for the FR-F840-04320(185K) or higher.

- Install the inverter on a strong surface securely with screws.
- · Leave enough clearances and take cooling measures.
- · Avoid places where the inverter is subjected to direct sunlight, high temperature and high humidity.
- · Install the inverter on a nonflammable wall surface.
- When encasing multiple inverters, install them in parallel as a cooling measure.
- For heat dissipation and maintenance, keep clearance between the inverter and the other devices or enclosure surface.

  The clearance below the inverter is required as a wiring space, and the clearance above the inverter is required as a heat dissipation space.



- \*I For the FR-F820-00250(5.5K) or lower and FR-F840-00126(5.5K) or lower, allow 1 cm (0.39 inches) or more clearance.
- \*2 When using the FR-F820-01250(30K) or lower and FR-F840-00620(30K) or lower at the surrounding air temperature of 40°C (104°F) or less (30°C (86°F) or less for the SLD rated inverter), side-by-side installation (0 cm clearance) is available.
- \*3 For replacing the cooling fan of the FR-F840-04320(185K) or higher, 30 cm (11.81 inches) of space is necessary in front of the inverter. Refer to page 567 for fan replacement.

#### Installation orientation of the inverter

Install the inverter on a wall as specified. Do not mount it horizontally or in any other way.


#### **◆**Above the inverter

Heat is blown up from inside the inverter by the small fan built in the unit. Any equipment placed above the inverter should be heat resistant.

#### **◆**Arrangement of multiple inverters

When multiple inverters are placed in the same enclosure, generally arrange them horizontally as shown in the right figure (a). When it is inevitable to arrange them vertically to minimize space, take such measures as to provide guides since heat from the bottom inverters can increase the temperatures in the top inverters, causing inverter failures.


When mounting multiple inverters, fully take caution not to make the surrounding air temperature of the inverter higher than the permissible value by providing ventilation and increasing the enclosure size.



Arrangement of multiple inverters

#### Arrangement of the ventilation fan and inverter

Heat generated in the inverter is blown up from the bottom of the unit as warm air by the cooling fan. When installing a ventilation fan for that heat, determine the place of ventilation fan installation after fully considering an air flow. (Air passes through areas of low resistance. Make an airway and airflow plates to expose the inverter to cool air.)



Arrangement of the ventilation fan and inverter


# 2.3.4 Heatsink protrusion attachment procedure

When encasing FR-F840-04320(185K) or higher to an enclosure, the heat generated in the enclosure can be greatly reduced by protruding the heatsink of the inverter.

When installing the inverter in a compact enclosure, etc., this installation method is recommended.


#### Panel cutting

Cut the panel of the enclosure according to the inverter capacity.




#### Shift and removal of a rear side installation frame

One installation frame is attached to each of the upper and lower parts of the inverter. Change the position of the rear side installation frame on the upper and lower sides of the inverter to the front side as shown on the right. When changing the installation frames, make sure that the installation orientation is correct.



#### Installation of the inverter

Push the inverter heatsink portion outside the enclosure and fix the enclosure and inverter with upper and lower installation frame.






- Having a cooling fan, the cooling section which comes out of the enclosure cannot be used in the environment of water drops, oil, mist, dust, etc.
- Be careful not to drop screws, dust etc. into the inverter and cooling fan section.

# 2.4 Terminal connection diagrams

### ◆FM type



#### **Terminal connection diagrams**


- \*1 For the FR-F820-03160(75K) or higher and the FR-F840-01800(75K) or higher, always connect a DC reactor (FR-HEL), which is available as an option. (To select a DC reactor, refer to page 578, and select one according to the applicable motor capacity.)

  When a DC reactor is connected to the FR-F820-02330(55K) or lower or the FR-F840-01160(55K) or lower, if a jumper is installed across the terminals P1 and P/+, remove the jumper before installing the DC reactor.
- \*2 When using separate power supply for the control circuit, remove the jumper between R1/L11 and S1/L21.
- \*3 The function of these terminals can be changed with the input terminal assignment (Pr.178 to Pr.189). (Refer to page 329.)
- \*4 Terminal JOG is also used as a pulse train input terminal. Use Pr.291 to choose JOG or pulse.
- \*5 Terminal input specifications can be changed by analog input specification switchover (**Pr.73**, **Pr.267**). To input a voltage, set the voltage/current input switch OFF. To input a current, set the voltage/current input switch ON. (Refer to page 306.)
- \*6 It is recommended to use 2 W 1  $k\Omega$  when the frequency setting signal is changed frequently.
- \*7 Do not use terminals PR and PX. Please do not remove the jumper connected to terminals PR and PX.
- \*8 The function of these terminals can be changed with the output terminal assignment (Pr.195, Pr.196). (Refer to page 288.)
- \*9 The function of these terminals can be changed with the output terminal assignment (Pr.190 to Pr.194). (Refer to page 288.)
- \*10 The terminal FM can be used to output pulse trains as open collector output by setting **Pr.291**.
- \*11 Not required when calibrating the scale with the operation panel.
- \*12 No function is assigned in the initial status. Assign the function using Pr.186 CS terminal function selection. (Refer to page 329.)

#### • NOTE

- To prevent a malfunction due to noise, keep the signal cables 10 cm (3.94 inches) or more away from the power cables. Also, separate the main circuit cables at the input side from the main circuit cables at the output side.
- After wiring, wire offcuts must not be left in the inverter.
   Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter clean.
   When drilling mounting holes in an enclosure etc., take caution not to allow chips and other foreign matter to enter the inverter.
- Set the voltage/current input switch correctly. Incorrect setting may cause a fault, failure or malfunction.

## **◆**CA type



#### **Terminal connection diagrams**

- \*1 For the FR-F820-03160(75K) or higher and the FR-F840-01800(75K) or higher, always connect a DC reactor (FR-HEL), which is available as an option. (To select a DC reactor, refer to page 578, and select one according to the applicable motor capacity.)

  When a DC reactor is connected to the FR-F820-02330(55K) or lower or the FR-F840-01160(55K) or lower, if a jumper is installed across the terminals P1 and P/+, remove the jumper before installing the DC reactor.
- \*2 When using separate power supply for the control circuit, remove the jumper between R1/L11 and S1/L21.
- \*3 The function of these terminals can be changed with the input terminal assignment (Pr.178 to Pr.189). (Refer to page 329.)
- \*4 Terminal JOG is also used as a pulse train input terminal. Use Pr.291 to choose JOG or pulse.
- \*5 Terminal input specifications can be changed by analog input specification switchover (**Pr.73**, **Pr.267**). To input a voltage, set the voltage/current input switch OFF. To input a current, set the voltage/current input switch ON. (Refer to page 306.)
- \*6 It is recommended to use 2 W 1  $k\Omega$  when the frequency setting signal is changed frequently.
- \*7 Do not use terminals PR and PX. Please do not remove the jumper connected to terminals PR and PX.
- \*8 The function of these terminals can be changed with the output terminal assignment (Pr.195, Pr.196). (Refer to page 288.)
- \*9 The function of these terminals can be changed with the output terminal assignment (Pr.190 to Pr.194). (Refer to page 288.)
- \*10 No function is assigned in the initial status. Assign the function using Pr.186 CS terminal function selection. (Refer to page 329.)

#### • NOTE


- To prevent a malfunction due to noise, keep the signal cables 10 cm (3.94 inches) or more away from the power cables. Also, separate the main circuit cables at the input side from the main circuit cables at the output side.
- After wiring, wire offcuts must not be left in the inverter.
   Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter clean.
   When drilling mounting holes in an enclosure etc., take caution not to allow chips and other foreign matter to enter the inverter.
- Set the voltage/current input switch correctly. Incorrect setting may cause a fault, failure or malfunction.


# 2.5 Main circuit terminals

# 2.5.1 Details on the main circuit terminals

Terminal symbol	Terminal name	Terminal function description	Refer to page
R/L1, S/L2, T/L3	AC power input	Connect these terminals to the commercial power supply.  Do not connect anything to these terminals when using the high power factor converter (FR-HC2) or the power regeneration common converter (FR-CV).	_
U, V, W	Inverter output	Connect these terminals to a three-phase squirrel cage motor or a PM motor.	_
R1/L11, S1/L21	Power supply for the control circuit	Connected to the AC power supply terminals R/L1 and S/L2. To retain the fault display and fault output, or to use a high power factor converter (FR-HC2) or a power regeneration common converter (FR-CV), remove the jumpers across terminals R/L1 and R1/L11 and across S/L2 and S1/L21, and supply external power to these terminals.  The power capacity necessary when separate power is supplied from R1/L11 and S1/L21 differs according to the inverter capacity. FR-F820-00630(15K) or lower, FR-F840-00380(18.5K) or lower 60 VA FR-F820-00770(18.5K) or higher, FR-F840-00470(22K) or higher 80 VA	55
P/+, N/-	Brake unit connection	Connect the brake unit (FR-BU2, FR-BU, BU), power regeneration	
P3, N/-	Brake unit connection FR-F820-00770(18.5K) to 01250(30K) FR-F840-00470(22K) to 01800(75K)	common converter (FR-CV), power regeneration converter (MT-RC), high power factor converter (FR-HC2), or DC power supply (under DC feeding mode).  When connecting multiple inverters, FR-F820-00770(18.5K) to 01250(30K) or FR-F840-00470(22K) to 01800(75K), in parallel using the FR-CV, FR-HC2, or a DC power supply, always use either terminal P/+ or P3 for the connection. (Do not use the terminals P/+ and P3 together.)	63
P/+, P1	DC reactor connection FR-F820-02330(55K) or lower FR-F840-01160(55K) or lower	Remove the jumper across terminals P/+ and P1, and connect a DC reactor.  When a DC reactor is not connected, the jumper across terminals P/+ and P1 should not be removed.	69
	DC reactor connection FR-F820-03160(75K) or higher FR-F840-01800(75K) or higher	Always connect a DC reactor, which is available as an option.	
PX, PR		The terminal PX is equipped in the FR-F820-00490(11K) or lower and the ne terminal PR is equipped in the FR-F820-01250(30K) or lower and the FR-F820-01250(30K) are lower and the FR-F820-01250(30K).	_
	Earth (ground)	For earthing (grounding) the inverter chassis. This must be earthed (grounded).	45

# 2.5.2 Terminal layout of the main circuit terminals, wiring of power supply and the motor






- \*1 Terminals P3 and PR of the FR-F820-01540(37K) are not provided with a screw. Do not connect anything to this.
- \*2 For FR-F840-01800(75K), a jumper is not installed across the terminals P1 and P/+. Always connect a DC reactor (FR-HEL), which is available as an option, across the terminals P1 and P/+.

#### Main circuit terminals

### • NOTE


- Make sure the power cables are connected to the R/L1, S/L2, and T/L3. (Phase need not be matched.) Never connect the power cable to the U, V, and W of the inverter. Doing so will damage the inverter.
- Connect the motor to U, V, and W. The phase need to be matched.
- When wiring the inverter main circuit conductor of the FR-F840-05470(250K) or higher, tighten a nut from the right side of the conductor. When wiring two wires, place wires on both sides of the conductor. (Refer to the drawing on the right.) For wiring, use bolts (nuts) provided with the inverter.




Handling of the wiring cover
 (FR-F820-00630(15K) to 00930(22K), FR-F84000310(15K) to 00620(30K))
 For the hook of the wiring cover, cut off the necessary
parts using a pair of needle-nose pliers etc.



 Cut off the same number of lugs as wires. If parts where no wire is put through have been cut off (10 mm or more), protective structure (JEM1030) becomes an open type (IP00).





## 2.5.3 Applicable cables and the wiring length

Select a recommended cable size to ensure that the voltage drop will be 2% or less.

If the wiring distance is long between the inverter and motor, the voltage drop in the main circuit wires will cause the motor torque to decrease especially at a low speed.

The following table indicates a selection example for the wiring length of 20 m.

#### **♦LD** rating (Pr.570 Multiple rating setting = "1")

• 200 V class (220 V input power supply)

		Tightening torque N•m	Crimping		Cable gauge								
Applicable inverter	Terminal		terr	ninal	H	IIV cables	s, etc. (	mm²) •1	AWG/	MCM •2	PVC	cables, e	tc. (mm²) •3
model	Size +4		R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W	P/+, P1	Earthing (grounding) cable	R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W	Earthing (grounding) cable
FR-F820-00046(0.75K) to 00105(2.2K)	M4	1.5	2-4	2-4	2	2	2	2	14	14	2.5	2.5	2.5
FR-F820-00167(3.7K)	M4	1.5	5.5-4	5.5-4	3.5	3.5	3.5	3.5	12	12	4	4	4
FR-F820-00250(5.5K)	M4	1.5	5.5-4	5.5-4	5.5	5.5	5.5	5.5	10	10	6	6	6
FR-F820-00340(7.5K)	M5	2.5	14-5	8-5	14	8	14	5.5	6	8	16	10	16
FR-F820-00490(11K)	M5	2.5	14-5	14-5	14	14	14	8	6	6	16	16	16
FR-F820-00630(15K)	M5	2.5	22-5	22-5	22	22	22	14	4	4	25	25	16
FR-F820-00770(18.5K)	M6	4.4	38-6	38-6	38	38	38	14	2	2	35	35	25
FR-F820-00930(22K)	M8 (M6)	7.8	38-8	38-8	38	38	38	22	2	2	35	35	25
FR-F820-01250(30K)	M8 (M6)	7.8	60-8	60-8	60	60	60	22	1/0	1/0	50	50	25
FR-F820-01540(37K)	M8 (M6)	7.8	80-8	80-8	80	80	80	22	3/0	3/0	70	70	35
FR-F820-01870(45K)	M10 (M8)	14.7	100-10	100-10	100	100	100	38	4/0	4/0	95	95	50
FR-F820-02330(55K)	M10 (M8)	14.7	100-10	100-10	100	100	100	38	4/0	4/0	95	95	50
FR-F820-03160(75K)	M12 (M8)	24.5	150-12	150-12	125	125	150	38	250	250	_	_	_
FR-F820-03800(90K)	M12 (M8)	24.5	150-12	150-12	150	150	2×100	38	2×4/0	2×4/0	_	_	_
FR-F820-04750(110K)	M12 (M8)	24.5	100-12	100-12	150	150	2×100	38	2×4/0	2×4/0	_	_	_

• 400 V class (440 V input power supply)

			Crin	nping	Cable gauge								
Applicable inverter	Terminal screw Size +4	Tightening torque N•m	terminal		HIV cables, etc. (mm <sup>2</sup> ) •1			AWG/MCM •2		PVC	cables, e	tc. (mm²) •₃	
model			R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W	P/+, P1	Earthing (grounding) cable	R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W	Earthing (grounding) cable
FR-F840-00023(0.75K) to 00083(3.7K)	M4	1.5	2-4	2-4	2	2	2	2	14	14	2.5	2.5	2.5
FR-F840-00126(5.5K)	M4	1.5	2-4	2-4	2	2	3.5	3.5	12	14	2.5	2.5	4
FR-F840-00170(7.5K)	M4	1.5	5.5-4	5.5-4	3.5	3.5	3.5	3.5	12	12	4	4	4
FR-F840-00250(11K)	M4	1.5	5.5-4	5.5-4	5.5	5.5	5.5	5.5	10	10	6	6	10
FR-F840-00310(15K)	M5	2.5	8-5	8-5	8	8	8	5.5	8	8	10	10	10
FR-F840-00380(18.5K)	M5	2.5	14-5	8-5	14	8	14	8	6	8	16	10	16
FR-F840-00470(22K)	M6	4.4	14-6	14-6	14	14	22	14	6	6	16	16	16
FR-F840-00620(30K)	M6	4.4	22-6	22-6	22	22	22	14	4	4	25	25	16
FR-F840-00770(37K)	M6	4.4	22-6	22-6	22	22	22	14	4	4	25	25	16
FR-F840-00930(45K)	M8	7.8	38-8	38-8	38	38	38	22	1	2	50	50	25
FR-F840-01160(55K)	M8	7.8	60-8	60-8	60	60	60	22	1/0	1/0	50	50	25
FR-F840-01800(75K)	M8	7.8	60-8	60-8	60	60	60	22	1/0	1/0	50	50	25
FR-F840-02160(90K)	M10	14.7	60-10	60-10	60	60	60	22	1/0	1/0	50	50	25
FR-F840-02600(110K)	M10	14.7	80-10	80-10	80	80	80	22	3/0	3/0	70	70	35
FR-F840-03250(132K)	M10 (M12)	14.7	100-10	100-10	100	100	100	38	4/0	4/0	95	95	50
FR-F840-03610(160K)	M10 (M12)	14.7	150-10	150-10	125	125	100	38	250	250	120	120	70
FR-F840-04320(185K)	M12 (M10)	24.5	150-12	150-12	150	150	150	38	300	300	150	150	95
FR-F840-04810(220K)	M12 (M10)	24.5	100-12	100-12	2×100	2×100	2×100	60	2×4/0	2×4/0	2×95	2×95	95
FR-F840-05470(250K)	M12 (M10)	46	100-12	100-12	2×100	2×100	2×100	60	2×4/0	2×4/0	2×95	2×95	95
FR-F840-06100(280K)	M12 (M10)	46	150-12	150-12	2×125	2×125	2×125	60	2×250	2×250	2×120	2×120	120
FR-F840-06830(315K)	M12 (M10)	46	150-12	150-12	2×150	2×150	2×125	60	2×300	2×300	2×150	2×150	150

- For FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower, this cable gauge is with the continuous maximum permissible temperature of 75°C (HIV cable (600 V class 2 vinyl-insulated cable), etc.). Assumes that the surrounding air temperature is 50°C or less and the wiring distance is 20 m or less.
  - For FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher, this cable gauge is with the continuous maximum permissible temperature of 90°C or higher (LMFC (heat resistant flexible cross-linked polyethylene insulated cable), etc.). Assumes that the surrounding air temperature is 50°C or less and the wiring is in-enclosure.
- \*2 For all the 200 V class capacities and FR-F840-00930(45K) or lower, this cable gauge is with the continuous maximum permissible temperature of 75°C (THHW cable). This is assumes a surrounding air temperature of 40°C or less and wiring distance of 20 m or less.

  For FR-F840-01160(55K) or higher, this cable gauge is with continuous maximum permissible temperature of 90°C (THHN cable). This assumes a surrounding air temperature of 40°C or lower and in-enclosure wiring. (Selection example for use mainly in the United States.)
- \*3 For FR-F820-00770(18.5K) or lower and FR-F840-00930(45K) or lower, the cable gauge is with the continuous maximum permissible temperature of 70°C (PVC cable). This assumes a surrounding air temperature of 40°C or less and wiring distance of 20 m or less. For FR-F820-00930(22K) or higher and FR-F840-01160(55K) or higher, this cable gauge is with continuous maximum permissible temperature of 90°C (XLPE cable). This assumes a surrounding air temperature of 40°C and in-enclosure wiring. (Selection example for use mainly in Europe.)
- \*4 The terminal screw size indicates the size of the terminal screw for R/L1, S/L2, T/L3, U, V, W, P/+, N/-, P1, P3, and the screw for earthing
  - The screw size for earthing (grounding) of FR-F820-00930(22K) or higher is indicated in parentheses.
  - The screw size for P/+ terminal for connecting an option to FR-F840-03250 (132K) or FR-F840-03610 (160K) is indicated in parentheses.
  - The screw size for earthing (grounding) of FR-F840-04320(185K) or higher is indicated in parenthesis.

### **♦**SLD rating (Pr.570 Multiple rating setting = "0")

• 200 V class (220 V input power supply)

		screw lightening L	Crimping terminal		Cable gauge								
Applicable inverter	Terminal screw Size +4				ŀ	HIV cables, etc. (mm <sup>2</sup> ) •1			AWG/MCM •2		PVC	cables, e	tc. (mm²) •3
model			R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W	P/+, P1	Earthing (grounding) cable	R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W	Earthing (grounding) cable
FR-F820-00046(0.75K) to 00105(2.2K)	M4	1.5	2-4	2-4	2	2	2	2	14	14	2.5	2.5	2.5
FR-F820-00167(3.7K)	M4	1.5	5.5-4	5.5-4	3.5	3.5	3.5	3.5	12	12	4	4	4
FR-F820-00250(5.5K)	M4	1.5	5.5-4	5.5-4	5.5	5.5	5.5	5.5	10	10	6	6	6
FR-F820-00340(7.5K)	M5	2.5	14-5	8-5	14	8	14	5.5	6	8	16	10	16
FR-F820-00490(11K)	M5	2.5	14-5	14-5	14	14	14	8	6	6	16	16	16
FR-F820-00630(15K)	M5	2.5	22-5	22-5	22	22	22	14	4	4	25	25	16
FR-F820-00770(18.5K)	M6	4.4	38-6	38-6	38	38	38	14	2	2	50	50	25
FR-F820-00930(22K)	M8(M6)	7.8	38-8	38-8	38	38	38	22	2	2	50	50	25
FR-F820-01250(30K)	M8(M6)	7.8	60-8	60-8	60	60	60	22	1/0	1/0	50	50	25
FR-F820-01540(37K)	M8(M6)	7.8	80-8	80-8	80	80	80	22	3/0	3/0	70	70	35
FR-F820-01870(45K)	M10(M8)	14.7	100-10	100-10	100	100	100	38	4/0	4/0	95	95	50
FR-F820-02330(55K)	M10(M8)	14.7	100-10	100-10	100	100	100	38	4/0	4/0	95	95	50
FR-F820-03160(75K)	M12(M8)	24.5	150-12	150-12	125	125	150	38	250	250	-	-	_
FR-F820-03800(90K)	M12(M8)	24.5	100-12	100-12	150	150	2×100	38	2×4/0	2×4/0	_	_	_
FR-F820-04750(110K)	M12(M8)	24.5	100-12	100-12	2×100	2×100	2×100	60	2×4/0	2×4/0	_	_	_

• 400 V class (440 V input power supply)

			Crin	nping	Cable gauge								
Applicable inverter	Terminal screw Size +4	Tightening torque N•m		ninal	ŀ	IIV cable	s, etc. (	(mm²) •1	AWG/MCM •2		PVC	cables, e	tc. (mm²) •3
model			R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	u, v, w	P/+, P1	Earthing (grounding) cable	R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W	Earthing (grounding) cable
FR-F840-00023(0.75K) to 00083(3.7K)	M4	1.5	2-4	2-4	2	2	2	2	14	14	2.5	2.5	2.5
FR-F840-00126(5.5K)	M4	1.5	2-4	2-4	2	2	3.5	3.5	12	14	2.5	2.5	4
FR-F840-00170(7.5K)	M4	1.5	5.5-4	5.5-4	3.5	3.5	3.5	3.5	12	12	4	4	4
FR-F840-00250(11K)	M4	1.5	5.5-4	5.5-4	5.5	5.5	5.5	5.5	10	10	6	6	10
FR-F840-00310(15K)	M5	2.5	8-5	8-5	8	8	8	5.5	8	8	10	10	10
FR-F840-00380(18.5K)	M5	2.5	14-5	8-5	14	8	14	8	6	8	16	10	16
FR-F840-00470(22K)	M6	4.4	14-6	14-6	14	14	22	14	6	6	16	16	16
FR-F840-00620(30K)	M6	4.4	22-6	22-6	22	22	22	14	4	4	25	25	16
FR-F840-00770(37K)	M6	4.4	22-6	22-6	22	22	22	14	4	4	25	25	16
FR-F840-00930(45K)	M8	7.8	38-8	38-8	38	38	38	22	1	2	50	50	25
FR-F840-01160(55K)	M8	7.8	60-8	60-8	60	60	60	22	1/0	1/0	50	50	25
FR-F840-01800(75K)	M8	7.8	60-8	60-8	60	60	60	22	1/0	1/0	50	50	25
FR-F840-02160(90K)	M10	14.7	80-10	80-10	80	80	80	22	3/0	3/0	70	70	35
FR-F840-02600(110K)	M10	14.7	100-10	100-10	100	100	100	38	4/0	4/0	95	95	50
FR-F840-03250(132K)	M10(M12)	14.7	150-10	150-10	125	125	100	38	250	250	120	120	70
FR-F840-03610(160K)	M10(M12)	14.7	150-10	150-10	150	150	150	38	300	300	150	150	95
FR-F840-04320(185K)	M12(M10)	24.5	100-12	100-12	2×100	2×100	2×100	60	2×4/0	2×4/0	2×95	2×95	95
FR-F840-04810(220K)	M12(M10)	24.5	100-12	100-12	2×100	2×100	2×100	60	2×4/0	2×4/0	2×95	2×95	95
FR-F840-05470(250K)	M12(M10)	46	150-12	150-12	2×125	2×125	2×125	60	2×250	2×250	2×120	2×120	120
FR-F840-06100(280K)	M12(M10)	46	150-12	150-12	2×150	2×150	2×125	60	2×300	2×300	2×150	2×150	150
FR-F840-06830(315K)	M12(M10)	46	200-12	200-12	2×200	2×200	2×150	100	2×350	2×350	2×185	2×185	2×95

- \*1 For all the 200 V class capacities and FR-F840-01160(55K) or lower, this cable gauge is with the continuous maximum permissible temperature of 75°C (HIV cable (600 V class 2 vinyl-insulated cable), etc.). Assumes that the surrounding air temperature is 50°C or less and the wiring distance is 20 m or less
  - FR-F840-01800(75K) or higher, this cable gauge is with the continuous maximum permissible temperature of 90°C or higher (LMFC (heat resistant flexible cross-linked polyethylene insulated cable), etc.). Assumes that the surrounding air temperature is 50°C or less and the wiring is in-enclosure.
- \*2 For all the 200 V class capacities and FR-F840-00930(45K) or lower, this cable gauge is with the continuous maximum permissible temperature of 75°C (THHW cable). This is assumes a surrounding air temperature of 40°C or less and wiring distance of 20 m or less.

  For FR-F840-01160(55K) or higher, this cable gauge is with continuous maximum permissible temperature of 90°C (THHN cable). This assumes a surrounding air temperature of 40°C or lower and in-enclosure wiring. (Selection example for use mainly in the United States.)
- \*3 For FR-F820-00930(22K) or lower and FR-F840-00930(45K) or lower, the cable gauge is with the continuous maximum permissible temperature of 70°C (PVC cable). This assumes a surrounding air temperature of 40°C or less and wiring distance of 20 m or less.

  For FR-F820-01250(30K) or higher and FR-F840-01160(55K) or higher, this cable gauge is with continuous maximum permissible temperature of 90°C (XLPE cable). This assumes a surrounding air temperature of 40°C and in-enclosure wiring. (Selection example for use mainly in Europe.)
- \*4 The terminal screw size indicates the size of the terminal screw for R/L1, S/L2, T/L3, U, V, W, P/+, N/-, P1, P3, and the screw for earthing (grounding).

The screw size for earthing (grounding) of FR-F820-00930(22K) or higher is indicated in parentheses.

The screw size for P/+ terminal for connecting an option to FR-F840-03250 (132K) or FR-F840-03610 (160K) is indicated in parentheses.

The screw size for earthing (grounding) of FR-F840-04320(185K) or higher is indicated in parenthesis.

The line voltage drop can be calculated by the following formula:

Line voltage drop [V]= 
$$\frac{\sqrt{3} \times \text{wire resistance}[\text{m}\Omega/\text{m}] \times \text{wiring distance}[\text{m}] \times \text{current}[\text{A}]}{1000}$$

Use a larger diameter cable when the wiring distance is long or when it is desired to decrease the voltage drop (torque reduction) in the low speed range.

## NOTE


- Tighten the terminal screw to the specified torque.
  - A screw that has been tightened too loosely can cause a short circuit or malfunction.
  - A screw that has been tightened too tightly can cause a short circuit or malfunction due to the unit breakage.
- Use crimping terminals with insulation sleeves to wire the power supply and motor.

#### **◆Total wiring length**

#### With induction motor

Connect one or more induction motors within the total wiring length shown in the following table.

Pr.72 setting (carrier frequency)	FR-F820-00046(0.75K) FR-F840-00023(0.75K)	FR-F820-00077(1.5K) FR-F840-00038(1.5K)	FR-F820-00105(2.2K) or higher FR-F840-00052(2.2K) or higher
2 (2 kHz) or lower	300 m	500 m	500 m
3 (3 kHz) or higher	200 m	300 m	500 m



When driving a 400 V class motor by the inverter, surge voltages attributable to the wiring constants may occur at the motor terminals, deteriorating the insulation of the motor. In this case, take one of the following measures.

 Use a "400 V class inverter-driven insulation-enhanced motor" and set Pr.72 PWM frequency selection according to the wiring length.

Wiring length 50 m or shorter	Wiring length 50 m to 100 m	Wiring length longer than 100 m
15 (14.5 kHz) or lower	9 (9 kHz) or lower	4 (4 kHz) or lower

 For the FR-F840-01160(55K) or lower, connect a surge voltage suppression filter (FR-ASF-H/FR-BMF-H) at the output side of the inverter. For the FR-F840-01800(75K) or higher, connect a sine wave filter (MT-BSL/BSC) at the output side of the inverter.

#### With PM motor

Use the following length of wiring or shorter when connecting a PM motor.

Voltage class	Pr.72 setting (carrier frequency)	FR-F820-00077(1.5K) or lower, FR-F840-00038(1.5K) or lower	FR-F820-00105(2.2K) or higher, FR-F840-00052(2.2K) or higher
200 V	0 (2 kHz) to 15 (14 kHz)	100 m	100 m
	5 (2 kHz) or lower	100 m	100 m
400 V	6 to 9 (6 kHz)	50 m	100 m
	10 (10 kHz) or higher	50 m	50 m

Use one PM motor for one inverter. Multiple PM motors cannot be connected to an inverter.



- Especially for long-distance wiring or wiring with shielded cables, the inverter may be affected by a charging current caused by stray capacitances of the wiring, leading to an activation of the overcurrent protection, malfunction of the fast-response current limit operation, or even to an inverter failure. It may also cause a malfunction or fault of the equipment connected ON the inverter output side. Stray capacitances of the wiring differ by the installation condition, use the total wiring length in the table above as reference values. If the fast-response current limit function malfunctions, disable this function. (Refer to **Pr.156 Stall prevention operation selection** on **page 248**.)
- A surge voltage suppression filter (FR-ASF-H/FR-BMF-H) can be used under V/F control and Advanced magnetic flux vector control. A sine wave filter (MT-BSL/BSC) can be used under V/F control. Do not use the filters under different control methods.
- For the details of Pr.72 PWM frequency selection, refer to page 179.
- For the details of the surge voltage suppression filter (FR-ASF-H/FR-BMF-H) and the sine wave filter (MT-BSL/BSC), refer to the Instruction Manual of each option.
- Refer to page 82 to drive a 400 V class motor by an inverter.

## 2.5.4 Earthing (grounding) precautions

· Always earth (ground) the motor and inverter.

### **♦**Purpose of earthing (grounding)

Generally, an electrical apparatus has an earth (ground) terminal, which must be connected to the ground before use. An electrical circuit is usually insulated by an insulating material and encased. However, it is impossible to manufacture an insulating material that can shut off a leakage current completely, and actually, a slight current flows into the case. The purpose of earthing (grounding) the case of an electrical apparatus is to prevent operators from getting an electric shock from this leakage current when touching it.

To avoid the influence of external noises, this earthing (grounding) is important to audio equipment, sensors, computers and other apparatuses that handle low-level signals or operate very fast.

### **◆**Earthing (grounding) methods and earthing (grounding) work

As described previously, earthing (grounding) is roughly classified into an electrical shock prevention type and a noise-influenced malfunction prevention type. Therefore, these two types should be clearly distinguished, and the following work must be done to prevent the leakage current having the inverter's high frequency components from entering the malfunction prevention type earthing (grounding):

Whenever possible, use the independent earthing (grounding) for the inverter.
 If independent earthing (grounding) (I) is not available, use (II) common earthing (grounding) in the figure below where the inverter is connected with the other equipment at an earthing (grounding) point. Do not use the other equipment's earthing


(grounding) cable to earth (ground) the inverter as shown in (III).


A leakage current containing many high frequency components flows into the earthing (grounding) cables of the inverter and peripheral devices. Because of this, the inverter must be earthed (grounded) separately from EMI-sensitive devices. In a high building, it may be effective to use the EMI prevention type earthing (grounding) connecting to an iron structure frame, and electric shock prevention type earthing (grounding) with the independent earthing (grounding) together. This inverter must be earthed (grounded). Earthing (Grounding) must conform to the requirements of national and local safety regulations and electrical codes. (NEC section 250, IEC 536 class 1 and other applicable standards).


A neutral-point earthed (grounded) power supply for 400 V class inverter in compliance with EN standard must be used. Use the thickest possible earthing (grounding) cable. The earthing (grounding) cable should be the size indicated in the table on page 41.

The earthing (grounding) point should be as close as possible to the inverter, and the earth (ground) wire length should be as short as possible.

Run the earthing (grounding) cable as far away as possible from the I/O wiring of equipment sensitive to noises and run them in parallel in the minimum distance.







Ang.

To be compliant with the EU Directive (Low Voltage Directive), refer to the Instruction Manual (Startup).

# 2.6 Control circuit

# 2.6.1 Details on the control circuit terminals

Input signal function of the terminals in	can be selected by setting Pr.178 to Pr.196 (I/O terminal function selection)
(Refer to page 329.)	

# ♦Input signal

Туре	Terminal Symbol	Terminal name	Terminal function des	scription	Rated specification	Refer to page
	STF	Forward rotation start	Turn ON the STF signal to start forward rotation and turn it OFF to stop.	When the STF and STR signals are turned	Input resistance	335
	STR	Reverse rotation start	Turn ON the STR signal to start reverse rotation and turn it OFF to stop.	ON simultaneously, the stop command is given.	4.7 kΩ Voltage when	
	STP (STOP)	Start self-holding selection	Turn ON the STP (STOP) signal to self-h	nold the start signal.	contacts are open: 21 to 27 VDC	335
	RH, RM, RL	Multi-speed selection	Multi-speed can be selected according to RM and RL signals.		When contacts are short-circuited: 4 to	222
		Jog mode selection	Turn ON the JOG signal to enable JOG and turn ON the start signal (STF or STF		6 mADC	221
	JOG	Pulse train input	Terminal JOG is also used as a pulse tra as a pulse train input terminal, change the (maximum input pulse: 100k pulses/s)	Input resistance 2 $k\Omega$ When contacts are short-circuited: 8 to 13 mADC	218	
	RT	Second function selection	cond function. ond torque boost" and rning ON the RT signal		333	
	MRS	Output stop	Turn ON the MRS signal (20 ms or more output. Use this signal to shut off the inverter ou motor with an electromagnetic brake.		Input resistance 4.7 kΩ	332
Contact input	RES	Reset	Use this signal to reset a fault output profunction is activated. Turn ON the RES sithen turn it OFF.  In the initial setting, reset is set always-ereset can be set enabled only at fault occurred recovers about 1 s after the reset is released.	Voltage when contacts are open: 21 to 27 VDC When contacts are short-circuited: 4 to 6 mADC	162	
	AU	Terminal 4 input selection	The terminal 4 function is available only turned ON. Turning the AU signal ON makes terminal		306	
	CS	No function	Use Pr.186 CS terminal function select assignment.	tion for function		_
		Contact input common (sink)*2	Common terminal for the contact input to terminal FM.	erminal (sink logic),		
	SD	External transistor common (source)*3	Connect this terminal to the power suppl transistor output (open collector output) programmable controller, in the source lo by undesirable current.	_	_	
		24 VDC power supply common	Common terminal for the 24 VDC power terminal +24) Isolated from terminals 5 and SE.			
	PC	External transistor common (sink)*2	Connect this terminal to the power suppl transistor output (open collector output) programmable controller, in the sink logic undesirable currents.	device, such as a	Power supply voltage range 19.2 to 28.8 VDC	51
		Contact input common (source)*3	Common terminal for contact input termi	nal (source logic).	Permissible load current 100 mA	
		24 VDC power supply	Can be used as a 24 VDC 0.1 A power s	supply.		

Type	Terminal Symbol	Terminal name	Terminal function description	Rated specification	Refer to page
	10E	Frequency setting	When connecting the frequency setting potentiometer at an initial status, connect it to the terminal 10.	10 VDC ±0.4 V Permissible load current 10 mA	306
	10	power supply	Change the input specifications of the terminal 2 using <b>Pr.73</b> when connecting it to the terminal 10E.	5 VDC ±0.5 V Permissible load current 10 mA	306
Frequency setting	2	Frequency setting (voltage)	Inputting 0 to 5 VDC (or 0 to 10 V, 0 to 20 mA) provides the maximum output frequency at 5 V (10 V, 20 mA) and makes input and output proportional. Use <b>Pr.73</b> to switch among input 0 to 5 VDC (initial setting), 0 to 10 VDC, and 0 to 20 mA. Set the voltage/current input switch in the ON position to select current input (0 to 20 mA). *1	When voltage is input: Input resistance 10 $k\Omega \pm 1 \ k\Omega$ Maximum permissible	306
	4	Frequency setting (current)	Inputting 4 to 20 mADC (or 0 to 5 V, 0 to 10 V) provides the maximum output frequency at 20 mA and makes input and output proportional. This input signal is valid only when the AU signal is ON (terminal 2 input is invalid). Use <b>Pr.267</b> to switch among input 4 to 20 mA (initial setting), 0 to 5 VDC, and 0 to 10 VDC. Set the voltage/current input switch in the OFF position to select voltage input (0 to 5 V/0 to 10 V). *1 Use <b>Pr.858</b> to switch terminal functions.	voltage 20 VDC When current is input: Input resistance $245 \Omega \pm 5 \Omega$ Permissible maximum current 30 mA Voltage/current input switch switch2 switch1	306
	1	Frequency setting auxiliary	Inputting 0 to ±5 VDC or 0 to ±10 VDC adds this signal to terminal 2 or 4 frequency setting signal. Use <b>Pr.73</b> to switch between input 0 to ±5 VDC and 0 to ±10 VDC (initial setting). Use <b>Pr.868</b> to switch terminal functions.	Input resistance 10 $k\Omega \pm 1 \ k\Omega$ Permissible maximum voltage $\pm 20 \ VDC$	306
	5	Frequency setting common	Common terminal for frequency setting signal (terminal 2, 1 or 4) and analog output terminal AM, CA. Do not earth (ground).	_	306
Thermistor	10 2	PTC thermistor input	For receiving PTC thermistor outputs.  C thermistor input When PTC thermistor is valid ( <b>Pr.561</b> ≠ "9999"), the terminal 2 is not available for frequency setting.		225
External power supply input	+24	24 V external power supply input	For connecting a 24 V external power supply.  If a 24 V external power supply is connected, power is supplied to the control circuit while the main power circuit is OFF.	Input voltage 23 to 25.5 VDC Input current 1.4 A or less	57

<sup>\*1</sup> Set **Pr.73**, **Pr.267**, and the voltage/current input switch correctly, then input an analog signal in accordance with the setting.

Applying a voltage with the voltage/current input switch ON (current input is selected) or a current with the switch OFF (voltage input is selected) could cause component damage of the inverter or analog circuits of output devices. (For the details, refer to **page 306**.)

<sup>\*2</sup> Sink logic is initially set for the FM-type inverter.

<sup>\*3</sup> Source logic is initially set for the CA-type inverter.

## **♦**Output signal

Type	Terminal Symbol	Terminal name	Terminal function des	cription	Rated specification	Refer to page
Relay	A1, B1, C1	Relay output 1 (fault output)	1 changeover contact output that indicat protective function has been activated a stopped. Fault: discontinuity across B and C (con C), Normal: continuity across Band C (d and C)	Contact capacity 230 VAC 0.3 A (power factor = 0.4)	288	
	A2, B2, C2	Relay output 2	1 changeover contact output	00 120 0.071	288	
	RUN	Inverter running	Switched to LOW when the inverter outp to or higher than the starting frequency ( Switched to HIGH during stop or DC inje		288	
	SU	Up to frequency	Switched to LOW when the output frequency is within the set frequency range ±10% (initial value). Switched to HIGH during acceleration/deceleration and at a stop.		Permissible load 24 VDC (maximum 27 VDC) 0.1 A (The voltage drop is 2.8 V at maximum while the signal is ON.)	
Open collector	OL	Overload warning	Switched to LOW when stall prevention is activated by the stall prevention function. Switched to HIGH when stall prevention is canceled.	Fault code (4 bits) output. (Refer to	while the signal is	259
Open	IPF	Instantaneous power failure	Switched to LOW when an instantaneous power failure occurs or when the undervoltage protection is activated.		transistor is ON (conducted). HIGH is when the transistor is OFF (not	414, 426
	FU	Frequency detection	Switched to LOW when the inverter output frequency is equal to or higher than the preset detection frequency, and to HIGH when it is less than the preset detection frequency.		conducted).	294
	SE	Open collector output common	Common terminal for terminals RUN, SU	J, OL, IPF, FU	_	_
Pulse	FM	For meter  Output item: Output frequency (initial setting)  Permissib current 2 if For full sc 1440 puls		Permissible load current 2 mA For full scale 1440 pulses/s	273	
Pu	NPN open collector output  Outputs a selected monitored (such as output frequency) ar several monitored items. The not output during an inverter items.	(such as output frequency) among several monitored items. The signal is not output during an inverter reset.  The output signal is proportional to the	This terminal can be used for open collector outputs by setting <b>Pr.291</b> .	Maximum output pulse 50k pulses/s Permissible load current 80 mA	218	
Analog	AM	Analog voltage output	magnitude of the corresponding monitoring item. Use Pr.55, Pr.56, and Pr.866 to set full scales for the monitored output frequency, output current, and torque. (Refer to page 273.)	Output item: Output frequency (initial setting)	Output signal 0 to $\pm 10$ VDC, Permissible load current 1 mA (load impedance 10 k $\Omega$ or more) Resolution 8 bits	273
	CA *2	Analog current output		Load impedance 200 $\Omega$ to 450 $\Omega$ Output signal 0 to 20 mADC	273	

<sup>\*1</sup> Terminal FM is provided in the FM-type inverter.
\*2 Terminal CA is provided in the CA-type inverter.

## **♦**Communication

Туре	_	erminal ymbol	Terminal name	Terminal function description			
Connection on a 1:1 basis only) Conforming standard: EIA-485 (RS-485) Transmission format: Multidrop link Communication speed: 4800 to 115200 bps		Conforming standard: EIA-485 (RS-485) Transmission format: Multidrop link Communication speed: 4800 to 115200 bps		441			
RS-485	<u>∞</u> TXD+		Inverter transmission terminal	The DO 405 terminals analyse the communication by DO 405			
	5 terminals	TXD-	inverter transmission terminal	The RS-485 terminals enables the communication by RS-485.  Conforming standard: EIA-485 (RS-485)			
		RXD+	Inverter reception terminal	Transmission format: Multidrop link	•		443
	-485	RXD-	inverter reception terminal	Communication speed: 300 to 115200 bps Overall length: 500 m			
	RS	SG	Earthing (grounding)	O Totali Totigani 555 m			
_			USB A connector	A connector (receptacle) A USB memory device enables parameter copies and the trace function.	Interface: Conforms to USB1.1 (USB2.0 full-speed	61	
USB	_		USB B connector	Mini B connector (receptacle) Connected to a personal computer via USB to enable setting, monitoring, test operations of the inverter by FR Configurator2.	compatible) Transmission speed: 12 Mbps	61	

# **♦**Safety stop signal

Terminal Symbol	Terminal name	Terminal function description	Rated specification	Refer to page
S1	Safety stop input (Channel 1)	The terminals S1 and S2 are used for the safety stop input signal for the safety relay module. The terminals S1 and S2 are used at the same time (dual channel).  Inverter output is shutoff by shortening/opening between terminals S1 and SIC, or between S2 and SIC.	Input resistance 4.7 kΩ Input current 4 to 6	
S2	Safety stop input (Channel 2)	In the initial status, terminals S1 and S2 are shorted with the terminal PC by shorting wires. The terminal SIC is shorted with the terminal SD. Remove the shorting wires and connect the safety relay module when using the safety stop function.	mADC (with 24 VDC input)	
SIC	Safety stop input terminal common	Common terminal for terminals S1 and S2.	_	
so	Safety monitor output (open collector output)	Indicates the safety stop input signal status.  Switched to LOW when the status is other than the internal safety circuit failure. Switched to HIGH during the internal safety circuit failure status.  (LOW is when the open collector output transistor is ON (conducted). HIGH is when the transistor is OFF (not conducted).)  Refer to the Safety stop function instruction manual (BCN-A23228-001) when the signal is switched to HIGH while both terminals S1 and S2 are open. (Please contact your sales representative for the manual.)	Permissible load D24 VDC (27 VDC at maximum), 0.1 A (The voltage drop is 3.4 V at maximum while the signal is ON.) (The voltage drop is 3.4 V at maximum while the signal is ON.)	58
SOC Safety monitor output terminal common Common terminal for terminal SO.		Common terminal for terminal SO.	_	

# 2.6.2 Control logic (sink/source) change

Change the control logic of input signals as necessary.


To change the control logic, change the jumper connector position on the control circuit board.

Connect the jumper connector to the connector pin of the desired control logic.

The control logic of input signals is initially set to the sink logic (SINK) for the FM type.

The control logic of input signals is initially set to the source logic (SOURCE) for the CA type.

(The output signals may be used in either the sink or source logic independently of the jumper connector position.)






- Make sure that the jumper connector is installed correctly.
- · Never change the control logic while power is ON.

## ♦Sink logic and source logic

- In the sink logic, a signal switches ON when a current flows from the corresponding signal input terminal.

  Terminal SD is common to the contact input signals. Terminal SE is common to the open collector output signals.
- In the source logic, a signal switches ON when a current flows into the corresponding signal input terminal.


  Terminal PC is common to the contact input signals. Terminal SE is common to the open collector output signals.
  - Current flow concerning the input/output signal when sink logic is selected
- Current flow concerning the input/output signal when source logic is selected



· When using an external power supply for transistor output


#### Sink logic

Use the terminal PC as a common terminal, and perform wiring as shown below. (Do not connect terminal SD of the inverter with the terminal 0 V of the external power supply. When using terminals PC-SD as a 24 VDC power supply, do not install an external power supply in parallel with the inverter. Doing so may cause a malfunction in the inverter due to undesirable currents.)



#### Source logic


Use the terminal SD as a common terminal, and perform wiring as shown below. (Do not connect terminal PC of the inverter with the terminal +24 V of the external power supply. When using terminals PC-SD as a 24 VDC power supply, do not install an external power supply in parallel with the inverter. Doing so may cause a malfunction in the inverter due to undesirable currents.)



## 2.6.3 Wiring of control circuit

### **♦**Control circuit terminal layout

Recommended cable gauge: 0.3 to 0.75 mm<sup>2</sup>



\*1 This terminal operates as the terminal FM for the FM type, and as the terminal CA for the CA type.

#### **♦**Wiring method

· Power supply connection


For the control circuit wiring, strip off the sheath of a cable, and use it with a blade terminal. For a single wire, strip off the sheath of the wire and apply directly.

Insert the blade terminal or the single wire into a socket of the terminal.

(1)Strip off the sheath for the below length. If the length of the sheath peeled is too long, a short circuit may occur with neighboring wires. If the length is too short, wires might come off.

Wire the stripped cable after twisting it to prevent it from becoming loose. In addition, do not solder it.










(2)Crimp the blade terminal.

Insert wires to a blade terminal, and check that the wires come out for about 0 to 0.5 mm from a sleeve.

Check the condition of the blade terminal after crimping. Do not use a blade terminal of which the crimping is inappropriate, or the face is damaged.





Blade terminals commercially available (as of February 2012)
 Phoenix Contact Co., Ltd.


Cable gauge		Crimping tool		
(mm²)	With insulation sleeve	Without insulation sleeve	For UL wire*1	name
0.3	AI 0,5-10WH	_	_	
0.5	AI 0,5-10WH	_	AI 0,5-10WH-GB	]
0.75	AI 0,75-10GY	A 0,75-10	AI 0,75-10GY-GB	CRIMPFOX 6
1	AI 1-10RD	A 1-10	AI 1-10RD/1000GB	CKIIVIFFOX 0
1.25, 1.5	AI 1,5-10BK	A 1,5-10	AI 1,5-10BK/1000GB*2	]
0.75 (for two wires)	AI-TWIN 2 × 0,75-10GY	_	_	1

- \*1 A blade terminal with an insulation sleeve compatible with the MTW wire which has a thick wire insulation.
- \*2 Applicable for the terminal A1, B1, C1, A2, B2, C2.


#### NICHIFU Co., Ltd.

Cable gauge Blade terminal product number		Insulation product number	Crimping tool product number	
0.3 to 0.75	BT 0.75-11	VC 0.75	NH 69	

(3)Insert the wires into a socket.




When using a single wire or stranded wires without a blade terminal, push the open/close button all the way down with a flathead screwdriver, and insert the wire.



#### • NOTE

- · When using stranded wires without a blade terminal, twist enough to avoid short circuit with a nearby terminals or wires.
- Place the flathead screwdriver vertical to the open/close button. In case the blade tip slips, it may cause an inverter damage or injury.
- Wire removal

Pull the wire while pushing the open/close button all the way down firmly with a flathead screwdriver.





- Pulling out the wire forcefully without pushing the open/close button all the way down may damage the terminal block.
- Use a small flathead screwdriver (tip thickness: 0.4 mm/tip width: 2.5 mm).

If a flathead screwdriver with a narrow tip is used, terminal block may be damaged.

Commercially available products (as of February 2012)

Name	Model	Manufacturer
Driver	SZF 0- 0,4 × 2,5	Phoenix Contact Co., Ltd.


 Place the flathead screwdriver vertical to the open/close button. In case the blade tip slips, it may cause an inverter damage or injury.

## **◆**Common terminals of the control circuit (SD, PC, 5, SE)

- Terminals SD (sink logic), PC (source logic), 5, and SE are common terminals (0V) for I/O signals. (All common terminals are isolated from each other.) Do not earth (ground) these terminals. Avoid connecting the terminal SD (sink logic) with 5, the terminal PC (source logic) with 5, and the terminal SE with 5.
- In the sink logic, terminal SD is a common terminal for the contact input terminals (STF, STR, STP (STOP), RH, RM, RL, JOG, RT, MRS, RES, AU, CS) and the pulse train output terminal (FM\*1). The open collector circuit is isolated from the internal control circuit by photocoupler.
- In the source logic, terminal PC is a common terminal for the contact input terminals (STF, STR, STP (STOP), RH, RM, RL, JOG, RT, MRS, RES, AU, CS). The open collector circuit is isolated from the internal control circuit by photocoupler.
- Terminal 5 is a common terminal for the frequency setting terminals (2, 1 or 4) and the analog output terminals (AM, CA\*2). It should be protected from external noise using a shielded or twisted cable.
- Terminal SE is a common terminal for the open collector output terminals (RUN, SU, OL, IPF, FU). The contact input circuit is isolated from the internal control circuit by photocoupler.
  - \*1 Terminal FM is provided in the FM-type inverter.
  - \*2 Terminal CA is provided in the CA-type inverter.

#### Signal inputs by contactless switches

The contact input terminals of the inverter (STF, STR, STP (STOP), RH, RM, RL, JOG, RT, MRS, RES, AU, CS) can be controlled using a transistor instead of a contact switch as shown below.



#### 2.6.4 **Wiring precautions**

- It is recommended to use a cable of 0.3 to 0.75 mm<sup>2</sup> for the connection to the control circuit terminals.
- The wiring length should be 30 m (200 m for the terminal FM) at the maximum.
- · Use two or more parallel micro-signal contacts or twin contacts to prevent contact faults when using contact inputs since the control circuit input signals are microcurrents.






- To suppress EMI, use shielded or twisted cables for the control circuit terminals and run them away from the main and power circuits (including the 200 V relay

  - sequence circuit). For the cables connected to the control circuit terminals, connect their shields to the common terminal of the connected control circuit terminal. When connecting an external power supply to the terminal PC, however, connect the shield of the power supply cable to the negative side of the external power supply. Do not directly earth (ground) the shield
- · Always apply a voltage to the fault output terminals (A1, B1, C1, A2, B2, C2) via a relay coil, lamp, etc.
- For the FR-F820-03160(75K) or higher and FR-F840-02160(90K) or higher, separate the wiring of the control circuit away from the wiring of the main circuit.

Make cuts in rubber bush of the inverter side and lead the wires through.



# 2.6.5 When using separate power supplies for the control circuit and the main circuit


# ◆Cable size for the control circuit power supply (terminals R1/L11 and S1/L21)

· Terminal screw size: M4

Cable gauge: 0.75 mm<sup>2</sup> to 2 mm<sup>2</sup>
 Tightening torque: 1.5 N·m

#### **◆**Connection method


#### <Connection diagram>




When a fault occurs, opening of the electromagnetic contactor (MC) on the inverter power supply side results in power loss in the control circuit, disabling the fault output signal retention. Terminals R1/L11 and S1/L21 are provided to hold a fault signal. In this case, connect the power supply terminals R1/L11 and S1/L21 of the control circuit to the input side of the MC.

Do not connect the power cable to incorrect terminals. Doing so may damage the inverter.

- FR-F820-00250(5.5K) or lower, FR-F840-00126(5.5K) or lower
  - (a) Remove the upper screws.
  - (b) Remove the lower screws.
  - (c) Remove the jumper.
  - (d) Connect the separate power supply cable for the control circuit to <u>the lower</u> terminals (R1/L11, S1/L21).





- FR-F820-00340(7.5K) to FR-F820-00630(15K), FR-F840-00170(7.5K) to FR-F840-00380(18.5K)
  - (a) Remove the upper screws.
  - (b) Remove the lower screws.
  - (c) Remove the jumper.
  - (d) Connect the separate power supply cable for the control circuit to the upper terminals (R1/L11, S1/L21).



#### **Control circuit**

- FR-F820-00770(18.5K) or higher, FR-F840-00470(22K) or higher
  - (a) Remove the upper screws.
  - (b) Remove the lower screws.
  - (c) Pull the jumper toward you to remove.
  - (d) Connect the separate power supply cable for the control circuit to the upper terminals (R1/L11, S1/L21).





## • NOTE

- When using separate power supplies, always remove the jumpers across terminals R/L1 and R1/L11 and across S/L2 and S1/L21. The inverter may be damaged if the jumpers are not removed.
- The voltage should be the same as that of the main control circuit when the control circuit power is supplied from other than the input side of the MC.
- The power capacity necessary when separate power is supplied from R1/L11 and S1/L21 differs according to the inverter capacity.

Inverter	Power supply capacity
FR-F820-00630(15K) or lower FR-F840-00380(18.5K) or lower	60 VA
FR-F820-00770(18.5K) or higher FR-F840-00470(22K) or higher	80 VA

• If the main circuit power is switched OFF (for 0.1 s or more) then ON again, the inverter is reset and a fault output will not be held.

# 2.6.6 When supplying 24 V external power to the control circuit

Connect a 24 V external power supply across terminals +24 and SD. Connecting a 24 V external power supply enables I/O terminal ON/OFF operation, operation panel displays, control functions, and communication during communication operation even at power-OFF of inverter's main circuit power supply. When the main circuit power supply is turned ON, the power supply source changes from the 24 V external power supply to the main circuit power supply.

#### **♦** Specification of the applicable 24 V external power supply

Item	Rated specification
Input voltage	23 to 25.5 VDC
Input current	1.4 A or less

Commercially available products (as of October 2013)

Model	Manufacturer
S8JX-N05024C *1 Specifications: Capacity 50 W, output voltage (DC) 24 V, output current 2.1 A Installation method: Front installation with cover	
or	OMRON Corporation
S8VS-06024 *I	
Specifications: Capacity 60W, output voltage (DC) 24 V, output current 2.5 A Installation method: DIN rail installation	

<sup>\*1</sup> For the latest information about OMRON power supply, contact OMRON corporation.

### ◆Starting and stopping the 24 V external power supply operation

- Supplying 24 V external power while the main circuit power is OFF starts the 24 V external power supply operation. Likewise, turning OFF the main circuit power while supplying 24 V external power starts the 24 V external power supply operation.
- Turning ON the main circuit power stops the 24 V external power supply operation and enables the normal operation.


## • NOTE

- When the 24 V external power is supplied while the main circuit power supply is OFF, the inverter operation is disabled.
- In the initial setting, when the main power supply is turned ON during the 24 V external power supply operation, a reset is performed in the inverter, then the power supply changes to the main circuit power supply. (The reset can be disabled using **Pr.30**. (Refer to **page 508**.))

## **◆**Confirming the 24 V external power supply input

• During the 24 V external power supply operation, "EV" flickers on the operation panel. The alarm lamp also flickers. Thus, the 24 V external power supply operation can be confirmed even when the operation panel is removed.





• During the 24 V external power supply operation, the 24 V external power supply operation signal (EV) is output. To use the EV signal, set "68 (positive logic) or 168 (negative logic)" in one of **Pr.190 to Pr.196 (output terminal function selection)** to assign function to an output terminal.

#### ◆Operation while the 24 V external power is supplied

- Faults history and parameters can be read and parameters can be written (when the parameter write from the operation panel is enabled) using the operation panel keys.
- The safety stop function is invalid during the 24 V external power supply operation.
- During the 24 V external power supply operation, monitored items and signals related to inputs to main circuit power supply, such as output current, converter output voltage, and IPF signal, are invalid.
- The faults, which have occurred when the main circuit power supply is ON, continue to be output after the power supply is changed to the 24 V external power supply. Perform the inverter reset or turn OFF then ON the power to reset the faults.
- The retry function is invalid for all faults during the 24 V external power supply.
- If the power supply changes from the main circuit power supply to the 24 V external power supply while measuring the main circuit capacitor's life, the measurement completes after the power supply changes back to the main circuit power supply (**Pr.259** = "3").
- The output data is retained when "1 or 11" is set in Pr.495 Remote output selection.

#### NOTE

- Inrush current equal to or higher than the 24 V external power supply specification may flow at power-ON. Confirm that the power supply and other devices are not affected by the inrush current and the voltage drop caused by it. Depending on the power supply, the inrush current protection may be activated to disable the power supply. Select the power supply and capacity carefully.
- When the wiring length between the external power supply and the inverter is long, the voltage often drops. Select the appropriate wiring size and length to keep the voltage in the rated input voltage range.
- In a serial connection of several inverters, the current increases when it flows through the inverter wiring near the power supply. The increase of the current causes voltage to drop further. When connecting different inverters to different power supplies, use the inverters after confirming that the input voltage of each inverter is within the rated input voltage range.
   Depending on the power supply, the inrush current protection may be activated to disable the power supply. Select the power supply and capacity carefully.
- "E.SAF or E.P24" may appear when the start-up time of the 24 V power supply is too long (less than 1.5 V/s) in the 24 V external power supply operation.
- "E.P24" may appear when the 24 V external power supply input voltage is low. Check the external power supply input.
- Do not touch the control circuit terminal block (circuit board) during the 24 V power supply operation (when conducted). Otherwise you may get an electric shock or burn.

# 2.6.7 Safety stop function

## **◆Function description**

The terminals related to the safety stop function are shown below.

Terminal symbol	Terminal function description					
S1 *1	For input of the safety stop channel 1.	Between S1 and SIC, S2 and SIC  Open: In safety stop mode				
S2 *1	For input of the safety stop channel 2.	Short: Other than the safety stop mode.				
SIC *1	Common terminal for S1 and S2.					
so	Outputs when an alarm or failure is detected.  The signal is output when no internal safety circuit failure*2 exists.  OFF: Internal safety circuit failure*2 ON: No internal safety circuit failure*2					
SOC	Open collector output (terminal SO) common	•				


- \*I In the initial status, terminals S1 and PC, S2 and PC, and SIC and SD are respectively shorted with shorting wires. To use the safety stop function, remove all the shortening wires, and then connect to the safety relay module as shown in the following connection diagram.
- \*2 At an internal safety circuit failure, the operation panel displays one of the faults shown on the next page.

## • NOTE

 Use the terminal SO to output a fault and to prevent restarting of the inverter. The signal cannot be used as safety stop input terminal to other devices.

### **◆**Connection diagram

To prevent automatic restart after a fault occurrence, connect the reset button of a safety relay module or a safety programmable controller across the terminals SO and SOC. The reset button acts as the feedback input for the safety relay module or the safety programmable controller.



### **♦**Safety stop function operation

Input	Internal safety Input terminal *		minal *1,*2	Output terminal	Inverter running status	-	on panel ation
power	circuit status	<b>S</b> 1	S2	SO		E.SAF *6	<b>SA</b> *7
OFF	_	_	_	OFF	Output shutoff (Safe state)	Not displayed	Not displayed
	Normal	ON	ON	ON *3	Drive enabled	Not displayed	Not displayed
	Normal	ON	OFF	OFF *4	Output shutoff (Safe state)	Displayed	Displayed
	Normal	OFF	ON	OFF *4	Output shutoff (Safe state)	Displayed	Displayed
	Normal	OFF	OFF	ON *3	Output shutoff (Safe state)	Not displayed	Displayed
ON	Fault	ON	ON	OFF	Output shutoff (Safe state)	Displayed	Not displayed *5
	Fault	ON	OFF	OFF	Output shutoff (Safe state)	Displayed	Displayed
	Fault	OFF	ON	OFF	Output shutoff (Safe state)	Displayed	Displayed
	Fault	OFF	OFF	OFF	Output shutoff (Safe state)	Displayed	Displayed

- \*1 ON: The transistor is conducted. OFF: The transistor is not conducted.
- \*2 When not using the safety stop function, short across terminals S1 and PC, S2 and PC, and SIC and SD to use the inverter. (In the initial status, terminals S1 and PC, S2 and PC, and SIC and SD are respectively shorted with shorting wires.)
- \*3 If any of the protective functions shown in the following table is activated, the terminal SO turns OFF.

Error definition	Operation panel indication
Option fault	E.OPT
Communication option fault	E.OP1
Parameter storage device fault	E.PE
Retry count excess	E.RET
Parameter storage device fault	E.PE2
Operation panel power supply short circuit/ RS-485 terminals power supply short circuit	E.CTE

Error definition	Operation panel indication
24 VDC power fault	E.P24
Safety circuit fault	E.SAF
Overspeed occurrence	E.OS
CPU fault	E.CPU
	E.5 to E.7
Internal circuit fault	E.13

- 4 If the internal safety circuit is operated normally, the terminal SO remains ON until E.SAF is displayed, and the terminal SO turns OFF when E.SAF is displayed.
- \*5 SA is displayed when the terminals S1 and S2 are identified as OFF due to the internal safety circuit failure.
- \*6 If another fault occurs at the same time as E.SAF, the other fault can be displayed.
- \*7 If another warning occurs at the same time as SA, the other warning can be displayed.


For more details, refer to the Safety stop function instruction manual (BCN-A23228-001). (Find a PDF copy of this manual in the CD-ROM enclosed with the product.

#### 2.7 Communication connectors and terminals

#### 2.7.1 PU connector

#### Mounting the operation panel or the parameter unit on the enclosure surface

Having an operation panel or a parameter unit on the enclosure surface is convenient. With a connection cable, the operation panel or the parameter unit can be mounted to the enclosure surface and connected to the inverter.
 Use the option FR-CB2[], or connectors and cables available on the market.
 (To mount the operation panel, the optional connector (FR-ADP) is required.)
 Securely insert one end of the connection cable until the stoppers are fixed.



#### • NOTE

- Refer to the following table when fabricating the cable on the user side. Keep the total cable length within 20 m.
- · Commercially available products (as of November 2013)

Name	Model	Manufacturer
Communication cable	SGLPEV-T (Cat5e/300 m) 24AWG × 4P	Mitsubishi Cable Industries, Ltd.
RJ-45 connector	5-554720-3	Tyco Electronics


#### ◆Communication operation

Using the PU connector enables communication operation from a personal computer, etc. When the PU connector is
connected with a personal, FA or other computer by a communication cable, a user program can run to monitor the inverter
or read and write parameters.

Communication can be performed with the Mitsubishi inverter protocol (computer link operation).

For the details, refer to page 441.

#### 2.7.2 USB connector



#### **◆USB** host communication

Interface		Conforms to USB1.1
Transmission speed		12 Mbps
Wiring length		Maximum 5 m
Connector		USB A connector (receptacle)
Compatible	Format	FAT32
Compatible USB memory	Capacity	1 GB or more (used in the recorder mode of the trace function)
COD Memory	Encryption function	Not available

Different inverter data can be saved in a USB memory device.
 The USB host communication enables the following functions.

Function	Description	Refer to page
Parameter copy	<ul> <li>Copies the parameter setting from the inverter to the USB memory device. A maximum of 99 parameter setting files can be saved in a USB memory device.</li> <li>The parameter setting data copied in the USB memory device can be copied to other inverters. This function is useful in backing up the parameter setting or for sharing the parameter setting among multiple inverters.</li> <li>The parameter setting file can be copied onto a personal computer from the USB memory device and edited using FR Configurator2.</li> </ul>	524
Trace	<ul> <li>The monitored data and output status of the signals can be saved in a USB memory device.</li> <li>The saved data can be imported to FR Configurator2 to diagnose the operating status of the inverter.</li> </ul>	433
PLC function data copy	<ul> <li>This function copies the PLC function project data to a USB memory device when the PLC function is used.</li> <li>The PLC function project data copied in the USB memory device can be copied to other inverters.</li> <li>This function is useful in backing up the parameter setting and for allowing multiple inverters to operate by the same sequence programs.</li> </ul>	431

- When the inverter recognizes the USB memory device without any problem, 📙 🗕 🛱 is briefly displayed on the operation panel.
- When the USB memory device is removed, 🖺 🚉 is briefly displayed on the operation panel.
- The operating status of the USB host can be checked on the LED display of the inverter.

LED display status	Operating status	
OFF	No USB connection.	
ON	The communication is established between the inverter and the USB device.	
Flickering rapidly	ckering rapidly  The USB memory device is being accessed. (Do not remove the USB memory device.)	
Flickering slowly	Error in the USB connection.	

- When a device such as a USB battery charger is connected to the USB connector and an excessive current (500 mA or more) flows, USB host error []F (UF warning) is displayed on the operation panel.
- When the UF warning appears, the USB error can be canceled by removing the USB device and setting **Pr.1049** = "1". (The UF warning can also be canceled by resetting the inverter power or resetting with the RES signal.)



- Do not connect devices other than a USB memory device to the inverter.
- If a USB device is connected to the inverter via a USB hub, the inverter cannot recognize the USB memory device properly.

#### **♦USB** device communication

The inverter can be connected to a personal computer with a USB (Ver. 1.1) cable.

Parameter setting and monitoring can be performed by FR Configurator2.

Interface	Conforms to USB1.1
Transmission speed	12 Mbps
Wiring length	Maximum 5 m
Connector	USB mini B connector (receptacle)
Power supply	Self-powered



<sup>•</sup> For the details of FR Configurator2, refer to the Instruction Manual of FR Configurator2.


#### 2.7.3 RS-485 terminal block

#### **◆**Communication operation

Conforming standard	EIA-485 (RS-485)
Transmission format Multidrop link	
Communication speed	maximum 115200 bps
Overall length	500 m
Connection cable	Twisted pair cable (4 pairs)

The RS-485 terminals enable communication operation from a personal computer, etc. When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program can run to monitor the inverter or read and write parameters.

Communication can be performed with the Mitsubishi inverter protocol (computer link operation) and Modbus-RTU protocol. For the details, refer to page 443.



#### 2.8 Connection of stand-alone option units


The inverter accepts a variety of stand-alone option units as required.

Incorrect connection will cause inverter damage or accident. Connect and operate the option unit carefully in accordance with the corresponding option unit manual.

#### 2.8.1 Connection of the brake unit (FR-BU2)


Connect the brake unit (FR-BU2(H)) as shown below to improve the braking capability during deceleration.

#### ◆Connection example with the GRZG type discharging resistor



- \*1 When wiring, make sure to match the terminal symbol (P/+, N/-) at the inverter side and at the brake unit (FR-BU2) side. (Incorrect connection will damage the inverter and brake unit.)
- \*2 When the power supply is 400 V class, install a stepdown transformer.
- \*3 The wiring distance between the inverter and brake unit (FR-BU2), and between the brake unit (FR-BU2) and discharging resistor must be within 5 m. Even when the wires are twisted, the cable length must be within 10 m.
- \*4 It is recommended to install an external thermal relay to prevent overheat of the discharging resistor.
- \*5 For the connection method of the discharging resistor, refer to the Instruction Manual of the FR-BU2.
- · Recommended external thermal relay


Brake unit	Discharging resistor	Recommended external thermal relay	
FR-BU2-1.5K	GZG 300W-50Ω (one)	TH-N20CXHZ 1.3A	
FR-BU2-3.7K	GRZG 200-10Ω	TH-N20CXHZ 3.6A	
TR-602-3.7K	(three in series)	TTI-NZUCATIZ 3.0A	
FR-BU2-7.5K	GRZG 300-5Ω	TH-N20CXHZ 6.6A	
1 K-BOZ-7.5K	(four in series)		
FR-BU2-15K	GRZG 400-2Ω	TH-N20CXHZ 11A	
11K-D02-15K	(six in series)	TIT-NZUGATIZ TIA	
FR-BU2-H7.5K	GRZG 200-10Ω	TH-N20CXHZ 3.6A	
110-D02-117.5IX	(six in series)	TTI-NZOOATIZ 3.0A	
FR-BU2-H15K	GRZG 300-5Ω	TH-N20CXHZ 6.6A	
TR-BOZ-ITISK	(eight in series)		
FR-BU2-H30K	GRZG 400-2Ω	TH-N20CXHZ 11A	
111-002-1130K	(twelve in series)	TIFNZUGANZ TIA	



#### NOTE

- Set "1" in Pr.0 Brake mode selection of the FR-BU2 to use a GRZG type discharging resistor.
- Do not remove the jumper across terminals P/+ and P1 except when connecting a DC reactor (FR-HEL).

#### ◆Connection example with the FR-BR-(H) resistor unit



- \*1 When wiring, make sure to match the terminal symbol (P/+, N/-) at the inverter side and at the brake unit (FR-BU2) side. (Incorrect connection will damage the inverter and brake unit.)
- \*2 When the power supply is 400 V class, install a stepdown transformer.
- \*3 The wiring distance between the inverter and brake unit (FR-BU2), and between the brake unit (FR-BU2) and resistor unit (FR-BR) must be within 5 m. Even when the wire is twisted, the cable length must be within 10 m.
- \*4 The contact between TH1 and TH2 is closed in the normal status and is open at a fault.




• Do not remove the jumper across terminals P/+ and P1 except when connecting a DC reactor (FR-HEL).

#### **◆**Connection example with the MT-BR5 type resistor unit

After wiring securely, set Pr.30 Regenerative function selection = "1".

Set Pr.0 Brake mode selection = "2" in the brake unit FR-BU2.




- \*1 When wiring, make sure to match the terminal symbol (P/+, N/-) at the inverter side and at the brake unit (FR-BU2) side. (Incorrect connection will damage the inverter and brake unit.)
- \*2 When the power supply is 400 V class, install a stepdown transformer.
- \*3 The wiring distance between the inverter and brake unit (FR-BU2), and between the brake unit (FR-BU2) and resistor unit (MT-BR5) must be within 5 m. Even when the wire is twisted, the cable length must be within 10 m
- \*4 The contact between TH1 and TH2 is open in the normal status and is closed at a fault.
- \*5 The CN8 connector used with the MT-BU5 type brake unit is not used.



 The stall prevention (overvoltage), oL, does not occur while Pr.30 Regenerative function selection = "1". (Refer to page 508.)

#### 2.8.2 Connection of the brake unit (FR-BU)

Connect the brake unit (FR-BU2(H)) as shown below to improve the braking capability during deceleration. The FR-BU is compatible with FR-F820-02330(55K) or lower and FR-F840-01160(55K) and lower.




- \*1 When wiring, make sure to match the terminal symbol (P/+, N/-) at the inverter side and at the brake unit (FR-BU(H)) side. (Incorrect connection will damage the inverter.)
- \*2 When the power supply is 400 V class, install a stepdown transformer.
- \*3 The wiring distance between the inverter and brake unit (FR-BU2), and between the brake unit (FR-BU2) and discharging resistor must be within 5 m. Even when the cable is twisted, the wiring length must be within 10 m.

#### • NOTE

- If the transistors in the brake unit should becomes faulty, the resistor will overheat. Install a magnetic contactor on the inverter's input side and configure a circuit that shut off the current in case of a fault.
- Do not remove the jumper across terminals P/+ and P1 except when connecting a DC reactor (FR-HEL).

#### 2.8.3 Connection of the brake unit (BU type)

Connect the brake unit (BU type) correctly as shown below. Incorrect connection will damage the inverter. Remove the jumpers across terminals HB and PC and terminals TB and HC of the brake unit and fit one across terminals PC and TB. The BU type is compatible with FR-F820-02330(55K) or lower and FR-F840-01160(55K) and lower.



\*1 When the power supply is 400 V class, install a stepdown transformer.


#### • NOTE

- The wiring distance between the inverter and brake unit (BU type), and between the brake unit (BU type) and discharging resistor must be within 2 m. Even when the cable is twisted, the wiring length must be within 5 m.
- If the transistors in the brake unit should becomes faulty, the resistor will overheat and result in a fire. Install a magnetic contactor on the inverter's input side and configure a circuit that shut off the current in case of a fault.
- Remove the jumper across terminals P/+ and P1 only when connecting a DC reactor (FR-HEL).

# 2.8.4 Connection of the high power factor converter (FR-HC2)

When connecting the high power factor converter (FR-HC2) to suppress power harmonics, perform wiring securely as shown below. Incorrect connection will damage the high power factor converter and the inverter.

After making sure that the wiring is correct, set "rated motor voltage" in **Pr.19 Base frequency voltage** (under V/F control) or **Pr.83 Rated motor voltage** (under other than V/F control) and "2" in **Pr.30 Regenerative function selection**. (Refer to **page 508**.)



- \*I Remove jumpers between terminal R/L1 and R1/L11 as well as between S/L2 and S1/L21, and connect the power supply for the control circuit to terminals R1/L11 and S1/L21. Do not connect anything to power input terminals (R/L1, S/L2, T/L3). Incorrect connection will damage the inverter. (E.OPT (option fault) will occur. (Refer to page 546.)
- \*2 Do not install an MCCB across the terminals P/+ and N/- (across terminals P and P/+ or across N and N/-). Connecting the opposite polarity of terminals N/- and P/+ will damage the inverter.
- \*3 Use **Pr.178 to Pr.189 (input terminal function selection)** to assign the terminals used for the X10 (X11) signal. (Refer to **page 329.**) For RS-485 or any other communication where the start command is only transmitted once, use the X11 signal to save the operation mode at the time of an instantaneous power failure.
- \*4 Assign the IPF signal to an FR-HC2 terminal. (Refer to the Instruction Manual of FR-HC2.)
- \*5 Always connect the FR-HC2 terminal RDY to a terminal where the X10 signal or MRS signal is assigned in the inverter. Always connect the FR-HC2 terminal SE to the inverter terminal SD. Not connecting these terminals may damage the FR-HC2.
- \*6 Always connect the R/L1, S/L2, and T/L3 terminals of FR-HC2 to the power supply. Operating the inverter without connecting them will damage the FR-HC2.
- \*7 Do not install an MCCB or MC between the reactor 1 terminals (R/L1, S/L2, T/L3) and the FR-HC2 terminals (R4/L14, S4/L24, T4/L34). It will not operate properly.
- \*8 Securely perform grounding (earthing) by using the grounding (earthing) terminal
- \*9 Installation of a fuse is recommended. (Refer to the Instruction Manual of FR-HC2.)
- \*10 Outside box is not available for FR-HC2-H280K or higher. Connect filter capacitors, inrush current limit resistors, and magnetic contactors. (Refer to the Instruction Manual of FR-HC2.)

#### NOTE


- The voltage phases of terminals R/L1, S/L2, and T/L3 and the voltage phases of terminals R4/L14, S4/L24, and T4/L34 must be matched.
- The control logic (sink logic/source logic) of the high power factor converter and the inverter must be matched. (Refer to page 50.)
- Do not connect a DC reactor (FR-HEL) to the inverter when FR-HC2 is connected.

## 2.8.5 Connection of the power regeneration common converter (FR-CV)

When connecting the power regeneration common converter (FR-CV), connect the inverter terminals (P/+, N/-) and the power regeneration common converter (FR-CV) terminals as shown below so that their symbols match with each other.

The FR-CV is applicable to FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower.

After making sure that the wiring is correct, set "2" in Pr.30 Regenerative function selection. (Refer to page 508.)




- \*1 Remove jumpers between terminals R/L1 and R1/L11 as well as between S/L2 and S1/L21, and connect the power supply for the control circuit to terminals R1/L11 and S1/L21. Do not connect anything to power input terminals (R/L1, S/L2, T/L3). Incorrect connection will damage the inverter. (E.OPT (option fault) will occur. (Refer to page 546.)
- \*2 Do not insert an MCCB between terminals P/+ and N/- (between terminals P/L+ and P/+ or between N/L- and N/-). Connecting the opposite polarity of terminals N/- and P/+ will damage the inverter.
- \*3 Use Pr.178 to Pr.189 (input terminal function selection) to assign the terminals used for the X10 signal. (Refer to page 329.)
- \*4 Be sure to connect the power supply and terminals R/L11, S/L21, and T/MC1. Operating the inverter without connecting them will damage the power regeneration common converter.
- \*5 Always connect terminal RDYB of the FR-CV to the inverter terminal where the X10 signal or the MRS signal is assigned to. Always connect terminal SE of the FR-CV to the inverter terminal SD. Not connecting these terminals may damage the FR-CV.

#### NOTE

- The voltage phases of terminals R/L11, S/L21, and T/MC1 and the voltage phases of terminals R2/L1, S2/L2, and T2/L3 must be matched.
- Use the sink logic (factory setting) when the FR-CV is connected. It cannot be connected when the source logic is selected.
- Do not connect a DC reactor (FR-HEL) to the inverter when FR-CV is connected.


# 2.8.6 Connection of the power regeneration converter (MT-RC)

When connecting the power regeneration converter (MT-RC), perform wiring securely as shown below. Incorrect connection will damage the power regeneration converter and the inverter. The MT-RC is applicable to FR-F840-01800(75K) or higher. After making sure that the wiring is correct, set "1" in **Pr.30 Regenerative function selection**.




#### • NOTE

- When using the inverter with the MT-RC, install a magnetic contactor (MC) at
  the input side of the inverter so that power is supplied to the inverter after 1 s or
  more has elapsed after powering ON the MT-RC. When power is supplied to
  the inverter prior to the MT-RC, the inverter and the MT-RC may be damaged
  or the MCCB may trip or be damaged.
- When connecting the power coordination reactor and others, refer to Instruction Manual of the MT-RC for precautions.




#### 2.8.7 Connection of the DC reactor (FR-HEL)

• Keep the surrounding air temperature within the permissible range (-10°C to +50°C). Keep enough clearance around the reactor because it heats up. (Take 10 cm or more clearance on top and bottom and 5 cm or more on left and right regardless of the installation direction.)



• When using the DC reactor (FR-HEL), connect it across terminals P/+ and P1. For the FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower, the jumper connected across terminals P/+ and P1 must be removed. Otherwise, the reactor will not be effective.



- Select a DC reactor according to the applied motor capacity. (Refer to page 578.) For the FR-F820-03160(75K) or higher and the FR-F840-01800(75K) or higher, always connect a DC reactor.
- Since the DC reactor (FR-HEL) is electrically connected to the enclosure through mounting screws, the DC reactor is earthed (grounded) by being securely mounted to the enclosure. However, if the DC reactor is not earthed (grounded) securely enough, an earthing (grounding) cable may be used.

When using an earthing (grounding) cable for FR-HEL-(H)55K or lower, wire the cable to the installation hole where varnish is removed. For FR-HEL-(H)75K or higher, use an earth (ground) terminal to perform earthing (grounding). (Refer to the Instruction Manual of the FR-HEL.)

#### NOTE

- The wiring distance must be within 5 m.
- As a reference, the cable gauge for the connection must be equal to or larger than that of the power supply cables (R/L1, S/L2, T/L3) and the earthing (grounding) cable. (Refer to page 41.)

#### **MEMO**

# PRECAUTIONS FOR USE OF THE INVERTER

This chapter explains the precautions for use of this product. Always read the instructions before using the equipment. For the "PRECAUTIONS FOR USE OF THE INVERTER" of the separated converter type, refer to the FR-F802 (Separated Converter Type) Instruction Manual (Hardware) [IB-0600550ENG].

3.1	Electro-magnetic interference (EMI) and leakage currents	72
3.2	Power supply harmonics	77
3.3	Installation of a reactor	80
3.4	Power-OFF and magnetic contactor (MC)	81
3.5	Countermeasures against deterioration of the 400 V class	;
	motor insulation	82
3.6	Checklist before starting operation	83
3.7	Failsafe system which uses the inverter	85

# 3.1 Electro-magnetic interference (EMI) and leakage currents

#### 3.1.1 Leakage currents and countermeasures

Capacitances exist between the inverter I/O cables, other cables and earth and in the motor, through which a leakage current flows. Since its value depends on the static capacitances, carrier frequency, etc., low acoustic noise operation at the increased carrier frequency of the inverter will increase the leakage current. Therefore, take the following countermeasures. Select the earth leakage current breaker according to its rated sensitivity current, independently of the carrier frequency setting.

#### **◆To-earth (ground) leakage currents**

Leakage currents may flow not only into the inverter's own line but also into the other lines through the earthing (grounding) cable, etc. These leakage currents may operate earth leakage circuit breakers and earth leakage relays unnecessarily.

- Suppression technique
- If the carrier frequency setting is high, decrease the Pr.72 PWM frequency selection setting.
   Note that motor noise increases. Selecting Pr.240 Soft-PWM operation selection makes the sound inoffensive.
- By using earth leakage circuit breakers designed for harmonic and surge suppression in the inverter's own line and other line, operation can be performed with the carrier frequency kept high (with low noise).
- •To-earth (ground) leakage currents
- Take caution as long wiring will increase the leakage current. Decreasing the carrier frequency of the inverter reduces the leakage current.
- Increasing the motor capacity increases the leakage current. The leakage current of the 400 V class is larger than that of the 200 V class.

#### **◆Line-to-line leakage currents**


Harmonics of leakage currents flowing in static capacitances between the inverter output cables may operate the external thermal relay unnecessarily. When the wiring length is long (50 m or more) for the 400 V class small-capacity models (FR-F840-00170(7.5K) or lower), the external thermal relay is likely to operate unnecessarily because the ratio of the leakage current to the rated motor current increases.

●Line-to-line leakage current example (200 V class)

Motor	Rated motor	Leakage current (mA) *1	
capacity (kW)	current (A)	Wiring length 50 m	Wiring length 100 m
0.4	1.8	310	500
0.75	3.2	340	530
1.5	5.8	370	560
2.2	8.1	400	590
3.7	12.8	440	630
5.5	19.4	490	680
7.5	25.6	535	725

- Motor: SF-JR 4P
- · Carrier frequency: 14.5 kHz
- Cable: 2 mm<sup>2</sup>, 4 cores
- · Cabtyre cable

\*1 The leakage currents of the 400 V class are about twice as large.



#### Countermeasures

- Use Pr.9 Electronic thermal O/L relay.
- If the carrier frequency setting is high, decrease the Pr.72 PWM frequency selection setting.
   Note that motor noise increases. Selecting Pr.240 Soft-PWM operation selection makes the sound inoffensive.
   To ensure that the motor is protected against line-to-line leakage currents, it is recommended to use a temperature sensor to directly detect motor temperature.

Installation and selection of the molded case circuit breaker

Install a molded case circuit breaker (MCCB) on the power receiving side to protect the wiring at the inverter input side. Select an MCCB according to the inverter input side power factor, which depends on the power supply voltage, output frequency and load. Especially for a completely electromagnetic MCCB, a slightly large capacity must be selected since its operation characteristic varies with harmonic currents. (Check it in the data of the corresponding breaker.) As an earth leakage current breaker, use the Mitsubishi earth leakage current breaker designed for harmonics and surge suppression.

#### Selecting the rated sensitivity current for the earth leakage circuit breaker

When using an earth leakage circuit breaker with the inverter circuit, select its rated sensitivity current as follows, independently of the PWM carrier frequency.

· Breaker designed for harmonic and surge suppression Ig1, Ig2: Leakage currents in wire path during commercial power

 $I\Delta n \ge 10 \times (Ig1 + Ign + Igi + Ig2 + Igm)$ 

· Standard breaker

100

60

40

20 \_eakage


currents 80

Rated sensitivity current

Rated sensitivity current

 $I\Delta n \ge 10 \times \{Ig1 + Ign + Igi + 3 \times (Ig2 + Igm)\}\$ 


Example of leakage current of cable path per 1km during the commercial power supply operation when the CV cable is routed in metal conduit (200V 60Hz)



Leakage current example of

three-phase induction motor

during the commercial



5 3.7 7.5 15223755 2.2 5.5 11 18.5 3045 Motor capacity (kW)


supply operation

Ign: Leakage current of inverter input side noise filter


Igm: Leakage current of motor during commercial power supply operation

Igi: Leakage current of inverter unit

Example of leakage current per 1km during the commercial power supply operation when the CV cable is routed in metal conduit




Leakage current example of threephase induction motor during the commercial power supply operation



For " \,\" connection, the amount of leakage current is appox.1/3 of the above value

<Example>



		Breaker designed for harmonic and surge suppression	Standard breaker
	Leakage current Ig1 (mA)	33 × 5	m 0 m = 0.17
	Leakage current Ign (mA)	0 (without noise filter)	
v	Leakage current Igi (mA)	the following table	
	Leakage current Ig2 (mA)	33 × 50	m 0 m = 1.65
	Motor leakage current Igm (mA)	0.18	
	Total leakage current (mA)	3.00	6.66
	Rated sensitivity current (mA) (≥ Ig × 10)	30	100

 Inverter leakage current (with and without EMC filter) Input power conditions

(200 V class: 220 V/60 Hz, 400 V class: 440 V/60 Hz,

power supply unbalance within 3%)

	Voltage	EMC filter	
	(V)	ON (mA)	OFF (mA)
Phase earthing	200	22	1
(grounding)	400	35	2
Earthed-neutral system	400	2	1

#### • NOTE


- Install the earth leakage circuit breaker (ELB) on the input side of the inverter.
- In the A connection earthed-neutral system, the sensitivity current is blunt against a ground fault in the inverter output side.
   Earthing (Grounding) must conform to the requirements of national and local safety regulations and electrical codes. (NEC section 250, IEC 536 class 1 and other applicable standards)
- When the breaker is installed on the output side of the inverter, it may be unnecessarily operated by harmonics even if the effective value is within the rating.
  - In this case, do not install the breaker since the eddy current and hysteresis loss will increase, leading to temperature rise.
- The following models are standard breakers: BV-C1, BC-V, NVB, NV-L, NV-G2N, NV-G3NA, NV-2F, earth leakage relay (except NV-ZHA), and NV with AA neutral wire open-phase protection. The other models are designed for harmonic and surge suppression: NV-C/NV-S/MN series, NV30-FA, NV50-FA, BV-C2, earth leakage alarm breaker (NF-Z), NV-ZHA, and NV-H.

### 3.1.2 Countermeasures against inverter-generated EMI

Some electromagnetic noises enter the inverter to cause the inverter malfunction, and others are radiated by the inverter to cause the peripheral devices to malfunction. Though the inverter is designed to have high immunity performance, it handles low-level signals, so it requires the following basic techniques. Also, since the inverter chops outputs at high carrier frequency, that could generate electromagnetic noises. If these electromagnetic noises cause peripheral devices to malfunction, EMI countermeasures should be taken to suppress noises. These techniques differ slightly depending on EMI paths.

- · Basic techniques
  - Do not run the power cables (I/O cables) and signal cables of the inverter in parallel with each other and do not bundle them.
  - Use shielded twisted pair cables for the detector connecting and control signal cables and connect the sheathes of the shielded cables to terminal SD.
  - Ground (Earth) the inverter, motor, etc. at one point.
- Techniques to reduce electromagnetic noises that enter and cause a malfunction of the inverter (EMI countermeasures) When devices that generate many electromagnetic noises (which use magnetic contactors, electromagnetic brakes, many relays, for example) are installed near the inverter and the inverter may malfunction due to electromagnetic noises, the following countermeasures must be taken:
  - Provide surge suppressors fordevices that generate many electromagnetic noises to suppress electromagnetic noises.
  - Install data line filters (page 75) to signal cables.
  - Ground (Earth) the shields of the detector connection and control signal cables with cable clamp metal.
- Techniques to reduce electromagnetic noises that are radiated by the inverter to cause the peripheral devices to malfunction (EMI countermeasures)

Inverter-generated noises are largely classified into those radiated by the cables connected to the inverter and inverter main circuits (I/O), those electromagnetically and electrostatically induced to the signal cables of the peripheral devices close to the main circuit power supply, and those transmitted through the power supply cables.



Noise propagation path	Countermeasure
(a)(b)(c)	When devices that handle low-level signals and are liable to malfunction due to electromagnetic noises, e.g. instruments, receivers and sensors, are contained in the enclosure that contains the inverter or when their signal cables are run near the inverter, the devices may malfunction due to by air-propagated electromagnetic noises. The following countermeasures must be taken:  Install easily affected devices as far away as possible from the inverter.  Run easily affected signal cables as far away as possible from the inverter and its I/O cables.  Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them.  Set the EMC filter ON/OFF connector of the inverter to the ON position. (Refer to page 76.)  Inserting a line noise filter into the output suppresses the radiated noise from the cables.  Use shielded cables as signal cables and power cables and run them in individual metal conduits to produce further effects.
(d)(e)(f)	When the signal cables are run in parallel with or bundled with the power cables, magnetic and static induction noises may be propagated to the signal cables to cause malfunction of the devices and the following countermeasures must be taken:  Install easily affected devices as far away as possible from the inverter.  Run easily affected signal cables as far away as possible from the inverter and its I/O cables.  Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them.  Use shielded cables as signal cables and power cables and run them in individual metal conduits to produce further effects.
(g)	When the power supplies of the peripheral devices are connected to the power supply of the inverter in the same line, inverter-generated noises may flow back through the power supply cables to cause malfunction of the devices and the following countermeasures must be taken:  • Set the EMC filter ON/OFF connector of the inverter to the ON position. (Refer to page 76.)  • Install the line noise filter (FR-BLF, FR-BSF01) to the power cables (output cables) of the inverter.
(h)	When a closed loop circuit is formed by connecting the peripheral device wiring to the inverter, leakage currents may flow through the earthing (grounding) cable of the inverter to cause the device to malfunction. In that case, disconnecting the earthing (grounding) cable from the device may stop the malfunction of the device.

#### Data line filter

Data line filter is effective as an EMI countermeasure. Provide a data line filter for the detector cable, etc.


<Example> Data line filter: ZCAT3035-1330 (by TDK)

: ESD-SR-250 (by NEC TOKIN)


Impedance (ZCAT3035-1330)

Impedance ( $\Omega$ )						
10 to 100 MHz	100 to 500 MHz					
80	150					

The impedance values above are reference values, and not guaranteed values.



#### ●EMI countermeasure example



Do not earth (ground) control cable.



• For compliance with the EU EMC Directive, refer to the Instruction Manual (Startup).


#### 3.1.3 Built-in EMC filter

This inverter is equipped with a built-in EMC filter (capacitive filter) and a common mode choke.

These filters are effective in reducing air-propagated noise on the input side of the inverter.

To enable the EMC filter, fit the EMC filter ON/OFF connector to the ON position. The FM type is initially set to "disabled" (OFF), and the CA type to "enabled" (ON).


The input side common mode choke, which is built in the FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower inverter, is always enabled regardless of the EMC filter ON/OFF connector setting.



- <How to enable or disable the filter>
- Before removing a front cover, check to make sure that the indication of the inverter operation panel is OFF, wait for at least 10 minutes after the power supply has been switched OFF, and check that there is no residual voltage using a tester or the like.
- For FR-F820-00105(2.2K) or higher and FR-F840-00023(0.75K) or higher
  - When disconnecting the connector, push the fixing tab and pull the connector straight without pulling the cable or forcibly pulling the connector with the tab fixed.

When installing the connector, also engage the fixing tab securely.

(If it is difficult to disconnect the connector, use a pair of needle-nose pliers, etc.)



- For FR-F820-00077(1.5K) or lower
  - Remove the control circuit terminal block. (Refer to page 570)
  - Connect the shorting wire to the corresponding terminal to enable or disable the filter. Connect the wire to the terminal in the same way as general wiring of the control circuit terminal block. (Refer to page 52)
  - After switching, reinstall the control circuit terminal block as it was.

#### • NOTE

- Fit the connector or shorting wire to either ON or OFF position.
- Enabling (turning ON) the EMC filter increases leakage current. (Refer to page 73.)

#### **A WARNING**

 While power is ON or when the inverter is running, do not open the front cover. Otherwise you may get an electric shock.

#### 3.2 Power supply harmonics

#### 3.2.1 Power supply harmonics

The inverter may generate power supply harmonics from its converter circuit to affect the power generator, power factor correction capacitor etc. Power supply harmonics are different from noise and leakage currents in source, frequency band and transmission path. Take the following countermeasure suppression techniques.


#### · The differences between harmonics and noises

Item	Harmonics	Noise
Frequency	Normally 40th to 50th degrees or less (3 kHz or less).	High frequency (several 10 kHz to 1 GHz order).
Location	To-electric channel, power impedance.	To-space, distance, wiring path,
Quantitative understanding	Theoretical calculation possible.	Random occurrence, quantitative grasping difficult.
Generated amount	Nearly proportional to the load capacity.	Changes with the current variation ratio. (Gets larger as switching speed increases.)
Affected equipment immunity	Specified by standards per equipment.	Different depending on maker's equipment specifications.
Countermeasure	Provide a reactor.	Increase distance.

#### Countermeasures

The harmonic current generated from the inverter to the input side differs according to various conditions such as the wiring impedance, whether a reactor is used or not, and output frequency and output current on the load side.

For the output frequency and output current, we understand that this should be calculated in the conditions under the rated load at the maximum operating frequency.



#### • NOTE

• The power factor improving capacitor and surge suppressor on the inverter output side may be overheated or damaged by the harmonic components of the inverter output. Also, since an excessive current flows in the inverter to activate overcurrent protection, do not provide a capacitor and surge suppressor on the inverter output side when the motor is driven by the inverter. For power factor improvement, install a reactor on the inverter input side or in the DC circuit.

#### 3.2.2 Harmonic suppression guidelines

Harmonic currents flow from the inverter to a power receiving point via a power transformer. The Harmonic Suppression Guidelines was established to protect other consumers from these outgoing harmonic currents.


The three-phase 200 V input specifications 3.7 kW or lower were previously covered by "the Harmonic Suppression Guidelines for Household Appliances and General-purpose Products" and other models were covered by "the Harmonic Suppression Guidelines for Consumers Who Receive High Voltage or Special High Voltage". However, the transistorized inverter has been excluded from the target products covered by "the Harmonic Suppression Guidelines for Household Appliances and General-purpose Products" in January 2004 and "the Harmonic Suppression Guideline for Household Appliances and General-purpose Products" was repealed on September 6, 2004.

All capacity and all models of general-purpose inverter used by specific consumers are now covered by "the Harmonic Suppression Guidelines for Consumers Who Receive High Voltage or Special High Voltage" (hereinafter referred to as "the Specific Consumer Guidelines").

- "Specific Consumer Guidelines"
   This guideline sets forth the maximum harmonic currents outgoing from a high-voltage or especially high-voltage receiving consumer who will install, add or renew harmonic generating equipment. If any of the maximum values is exceeded, this guideline requires that consumer to take certain suppression measures.
- · Maximum Values of Outgoing Harmonic Currents per 1kW Contract Power

Received power voltage	5th	7th	11th	13th	17th	19th	23rd	Over 23rd
6.6 kV	3.5	2.5	1.6	1.3	1.0	0.9	0.76	0.70
22 kV	1.8	1.3	0.82	0.69	0.53	0.47	0.39	0.36
33 kV	1.2	0.86	0.55	0.46	0.35	0.32	0.26	0.24

#### **◆**Application of the specific consumer guidelines



#### · Conversion factors for FR-F800 series

Classification	C	Circuit type	Conversion coefficient Ki
		Without reactor	K31 = 3.4
2	Three-phase bridge (Capacitor smoothing)	With reactor (AC side)	K32 = 1.8
3		With reactor (DC side)	K33 = 1.8
		With reactors (AC, DC sides)	K34 = 1.4
5	Self-excitation three-phase bridge	When a high power factor converter is used	K5 = 0

#### · Equivalent Capacity Limits

Received power voltage	Reference capacity
6.6 kV	50 kVA
22/33 kV	300 kVA
66 kV or more	2000 kVA

• Harmonic content (Values of the fundamental current is 100%)

Reactor	5th	7th	11th	13th	17th	19th	23rd	25th
Not used	65	41	8.5	7.7	4.3	3.1	2.6	1.8
Used (AC side)	38	14.5	7.4	3.4	3.2	1.9	1.7	1.3
Used (DC side)	30	13	8.4	5.0	4.7	3.2	3.0	2.2
Used (AC, DC sides)	28	9.1	7.2	4.1	3.2	2.4	1.6	1.4

• Calculation of equivalent capacity P0 of harmonic generating equipment

"Equivalent capacity" is the capacity of a 6-pulse converter converted from the capacity of consumer's harmonic generating equipment and is calculated by the following equation: If the sum of equivalent capacities is higher than the limit in Table 3, harmonics must be calculated with the following procedure:

#### $P0 = \sum (Ki \times Pi) [kVA]$

Ki: Conversion coefficient (Refer to Table 2)

Pi: Rated capacity of harmonic generating equipment \*1[kVA]

i: Number indicating the conversion circuit type

- \*1 Rated capacity: Determined by the capacity of the applied motor and found in Table 5. The rated capacity used here is used to calculate the generated harmonic amount and is different from the power supply capacity required for actual inverter drive.
- Calculation of outgoing harmonic current
   Outgoing harmonic current = fundamental wave current (value converted from received power voltage) × operation ratio × harmonic content
  - Operation ratio: Operation ratio = actual load factor × operation time ratio during 30 minutes
  - · Harmonic content: Found in Table 4.
- · Rated capacities and outgoing harmonic currents of inverter-driven motors

Applicable	Rated current (A)		Fundamental wave current Rated		Outgoing harmonic current converted from 6.6 kV (mA)  (No reactor, 100% operation ratio)							
motor (kW)	200 V	400 V	converted from 6.6 kV (mA)	capacity (kVA)	5th	7th	11th	13th	17th	19th	23rd	25th
0.4	1.61	0.81	49	0.57	31.85	20.09	4.165	3.773	2.107	1.519	1.274	0.882
0.75	2.74	1.37	83	0.97	53.95	34.03	7.055	6.391	3.569	2.573	2.158	1.494
1.5	5.50	2.75	167	1.95	108.6	68.47	14.20	12.86	7.181	5.177	4.342	3.006
2.2	7.93	3.96	240	2.81	156.0	98.40	20.40	18.48	10.32	7.440	6.240	4.320
3.7	13.0	6.50	394	4.61	257.1	161.5	33.49	30.34	16.94	12.21	10.24	7.092
5.5	19.1	9.55	579	6.77	376.1	237.4	49.22	44.58	24.90	17.95	15.05	10.42
7.5	25.6	12.8	776	9.07	504.4	318.2	65.96	59.75	33.37	24.06	20.18	13.97
11	36.9	18.5	1121	13.1	728.7	459.6	95.29	86.32	48.20	34.75	29.15	20.18
15	49.8	24.9	1509	17.6	980.9	618.7	128.3	116.2	64.89	46.78	39.24	27.16
18.5	61.4	30.7	1860	21.8	1209	762.6	158.1	143.2	79.98	57.66	48.36	33.48
22	73.1	36.6	2220	25.9	1443	910.2	188.7	170.9	95.46	68.82	57.72	39.96
30	98.0	49.0	2970	34.7	1931	1218	252.5	228.7	127.7	92.07	77.22	53.46
37	121	60.4	3660	42.8	2379	1501	311.1	281.8	157.4	113.5	95.16	65.88
45	147	73.5	4450	52.1	2893	1825	378.3	342.7	191.4	138.0	115.7	80.10
55	180	89.9	5450	63.7	3543	2235	463.3	419.7	234.4	169.0	141.7	98.10

Applicable		ted nt (A)	Fundamental wave current	Rated	Out	•	armonic				•	mA)
motor (kW)	200 V	400 V	converted from 6.6 kV (mA)	capacity (kVA)	5th	7th	11th	13th	17th	19th	23rd	25th
75	245	123	7455	87.2	2237	969	626	373	350	239	224	164
90	293	147	8909	104	2673	1158	748	445	419	285	267	196
110	357	179	10848	127	3254	1410	911	542	510	347	325	239
132	-	216	13091	153	3927	1702	1100	655	615	419	393	288
160	-	258	15636	183	4691	2033	1313	782	735	500	469	344
220	-	355	21515	252	6455	2797	1807	1076	1011	688	645	473
250	-	403	24424	286	7327	3175	2052	1221	1148	782	733	537
280	-	450	27273	319	8182	3545	2291	1364	1282	873	818	600
315	-	506	30667	359	9200	3987	2576	1533	1441	981	920	675
355	-	571	34606	405	10382	4499	2907	1730	1627	1107	1038	761
400	-	643	38970	456	11691	5066	3274	1949	1832	1247	1169	857
450	-	723	43818	512	13146	5696	3681	2191	2060	1402	1315	964
500	-	804	48727	570	14618	6335	4093	2436	2290	1559	1462	1072
560	-	900	54545	638	16364	7091	4582	2727	2564	1746	1636	1200
630	-	1013	61394	718	18418	7981	5157	3070	2886	1965	1842	1351

• Determining if a countermeasure is required


A countermeasure for harmonics is required if the following condition is satisfied: outgoing harmonic current > maximum value per 1 kW contract power × contract power


· Harmonic suppression techniques

No.	Item	Description
1	Reactor installation (FR-HAL, FR-HEL)	Install an AC reactor (FR-HAL) on the AC side of the inverter or a DC reactor (FR-HEL) on its DC side, or install both to suppress outgoing harmonic currents.
2	High power factor converter (FR-HC2)	This converter trims the current waveform to be a sine waveform by switching the rectifier circuit (converter module) with transistors. Doing so suppresses the generated harmonic amount significantly. Connect it to the DC area of an inverter. Use the high power factor converter (FR-HC2) with the accessories that come as standard.
3	Installation of power factor improving capacitor	When used with a reactor connected in series, the power factor improving correction capacitor can absorb harmonic currents.
4	Transformer multi-phase operation	Use two transformers with a phase angle difference of 30° as in $\bot$ - $\triangle$ and $\triangle$ - $\triangle$ combinations to provide an effect corresponding to 12 pulses, reducing low-degree harmonic currents.
5	Passive filter (AC filter)	A capacitor and a reactor are used together to reduce impedances at specific frequencies. Harmonic currents are expected to be absorbed greatly by using this technique.
6	Active filter	This filter detects the current in a circuit generating a harmonic current and generates a harmonic current equivalent to a difference between that current and a fundamental wave current to suppress the harmonic current at the detection point. Harmonic currents are expected to be absorbed greatly by using this technique.

#### 3.3 Installation of a reactor

When the inverter is connected near a large-capacity power transformer (1000 kVA or more) or when a power factor correction capacitor is to be switched over, an excessive peak current may flow in the power input circuit, damaging the converter circuit. To prevent this, always install an AC reactor (FR-HAL), which is available as an option.





#### **3.4** Power-OFF and magnetic contactor (MC)

#### ◆Inverter input side magnetic contactor (MC)


On the inverter input side, it is recommended to provide an MC for the following purposes: (Refer to page 20 for selection.)

- To disconnect the inverter from the power supply at activation of a protective function or at malfunctioning of the driving system (emergency stop, etc.).
- To prevent any accident due to an automatic restart at power restoration after an inverter stop made by a power failure.
- To separate the inverter from the power supply to ensure safe maintenance and inspection work.

If using an MC for emergency stop during operation, select an MC regarding the inverter input side current as JEM1038-AC-3 class rated current.

#### • NOTE

• Since repeated inrush currents at power ON will shorten the life of the converter circuit (switching life is about 1,000,000 times), frequent starts and stops of the magnetic contactor must be avoided. Turn ON/OFF the inverter start controlling terminals (STF, STR) to run/stop the inverter.



- Inverter start/stop circuit example
   As shown on the left, always use the start signal (ON or OFF of STF(STR) signal) to make a start or stop.
  - \*1 When the power supply is 400 V class, install a stepdown transformer.
  - \*2 Connect the power supply terminals R1/L11, S1/L21 of the control circuit to the input side of the MC to hold an alarm signal when the inverter's protective circuit is a ctivated. At this time, remove jumpers across terminals R/L1 and R1/L11 and S/L2 and S1/L21. (Refer to page 55 for removal of the jumper.)

#### ◆Handling of the magnetic contactor on the inverter's output side

Switch the magnetic contactor between the inverter and motor only when both the inverter and motor are at a stop. When the magnetic contactor is turned ON while the inverter is operating, overcurrent protection of the inverter and such will activate. When an MC is provided to switch to a commercial power supply, for example, it is recommended to use the electronic bypass function **Pr.135 to Pr.139** (Refer to page 363). (The commercial power supply operation is not available with PM motors.)

#### ◆Handling of the manual contactor on the inverter's output side

A PM motor is a synchronous motor with high-performance magnets embedded inside. High-voltage is generated at the motor terminals while the motor is running even after the inverter power is turned OFF. In an application where the PM motor is driven by the load even after the inverter is powered OFF, a low-voltage manual contactor must be connected at the inverter's output side.

#### • NOTE

- Before wiring or inspection for a PM motor, confirm that the PM motor is stopped. In an application, such as fan and blower, where the motor is driven by the load, a low-voltage manual contactor must be connected at the inverter's output side, and wiring and inspection must be performed while the contactor is open. Otherwise you may get an electric shock.
- Do not open or close the contactor while the inverter is running (outputting).

# 3.5 Countermeasures against deterioration of the 400 V class motor insulation

In the PWM type inverter, a surge voltage attributable to wiring constants is generated at the motor terminals. Especially in a 400 V class motor, the surge voltage may deteriorate the insulation. When the 400 V class motor is driven by the inverter, consider the following countermeasures:

Countermeasures

(With induction motor)

It is recommended to take one of the following countermeasures:

- Rectifying the motor insulation and limiting the PWM carrier frequency according to the wiring length For the 400 V class motor, use an <u>insulation-enhanced motor</u>.
   Specifically,
  - Order a "400 V class inverter-driven insulation-enhanced motor".
  - For the dedicated motor such as the constant-torque motor and low-vibration motor, use an "inverter-driven dedicated motor"
  - Set Pr.72 PWM frequency selection as indicated below according to the wiring length.

	Wiring length				
	50 m or shorter	50 m to 100 m	Longer than 100 m		
Pr.72 PWM frequency selection	15 (14.5 kHz) or lower	9 (9 kHz) or lower	4 (4 kHz) or lower		

- · Suppressing the surge voltage on the inverter side
  - For the FR-F840-01160(55K) or lower, connect the surge voltage suppression filter (FR-ASF-H/FR-BMF-H) to the output side
  - For the FR-F840-01800(75K) or higher, connect the sine wave filter (MT-BSL/BSC) to the output side.

#### (With PM motor)

• When the wiring length exceeds 50 m, set "9" (6 kHz) or less in Pr.72 PWM frequency selection.

#### • NOTE

- For the details of **Pr.72 PWM frequency selection**, refer to **page 179**. (When using an optional sine wave filter (MT-BSL/BSC), set "25" (2.5 kHz) in **Pr.72**.)
- For the details of the surge voltage suppression filter (FR-ASF-H/FR-BMF-H) and the sine wave filter (MT-BSL/BSC), refer to the Instruction Manual of each option.
- A surge voltage suppression filter (FR-ASF-H/FR-BMF-H) can be used under V/F control and Advanced magnetic flux vector control.

A sine wave filter (MT-BSL/BSC) can be used under V/F control. Do not use the filters under different control modes.

#### 3.6 Checklist before starting operation

The FR-F800 series inverter is a highly reliable product, but incorrect peripheral circuit making or operation/handling method may shorten the product life or damage the product.

Before starting operation, always recheck the following points.

Checkpoint	Countermeasure	Refer	Check
•		to page	by user
Crimping terminals are insulated.	Use crimping terminals with insulation sleeves to wire the power supply and the motor.	-	
The wiring between the power supply (R/L1, S/L2, T/L3) and the motor (U, V, W) is correct.	Application of power to the output terminals (U, V, W) of the inverter will damage the inverter. Never perform such wiring.	37	
No wire offcuts are left from the time of wiring.	Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter clean.  When drilling mounting holes in an enclosure etc., take caution not to allow chips and other foreign matter to enter the inverter.	-	
The main circuit cable gauge is correctly selected.	Use an appropriate cable gauge to suppress the voltage drop to 2% or less.  If the wiring distance is long between the inverter and motor, the voltage drop in the main circuit will cause the motor torque to decrease especially during the output of a low frequency.	41	
The total wiring length is within the specified length.	Keep the total wiring length within the specified length. In long distance wiring, charging currents due to stray capacitance in the wiring may degrade the fast-response current limit operation or cause the equipment on the inverter's output side to malfunction. Pay attention to the total wiring length.	41	
Countermeasures are taken against EMI.	The input/output (main circuit) of the inverter includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the inverter. In such case, activate the EMC filter (turn ON the EMC filter ON/OFF connector) to minimize interference.	76	
On the inverter's output side, there is no power factor correction capacitor, surge suppressor, or radio noise filter installed.	Such installation will cause the inverter to trip or the capacitor and surge suppressor to be damaged. If any of the above devices is connected, immediately remove it.	-	
When performing an inspection or rewiring on the product that has been energized, the operator has waited long enough after shutting off the power supply.	For a short time after the power-OFF, a high voltage remains in the smoothing capacitor, and it is dangerous.  Before performing an inspection or rewiring, wait 10 minutes or longer after the power supply turns OFF, then confirm that the voltage across the main circuit terminals P/+ and N/- of the inverter is low enough using a tester, etc.	-	
The inverter's output side has no short circuit or ground fault occurring.	A short circuit or ground fault on the inverter's output side may damage the inverter module.  Fully check the insulation resistance of the circuit prior to inverter operation since repeated short circuits caused by peripheral circuit inadequacy or a ground fault caused by wiring inadequacy or reduced motor insulation resistance may damage the inverter module.  Fully check the to-earth (ground) insulation and phase-to-phase insulation of the inverter's output side before power-ON. Especially for an old motor or use in hostile atmosphere, make sure to check the motor insulation resistance, etc.	-	
The circuit is not configured to use the inverter's input-side magnetic contactor to start/stop the inverter frequently.	Since repeated inrush currents at power ON will shorten the life of the converter circuit, frequent starts and stops of the magnetic contactor must be avoided. Turn ON/OFF the inverter's start signals (STF, STR) to run/stop the inverter.	81	
The voltage applied to the inverter I/O signal circuits is within the specifications.	Application of a voltage higher than the permissible voltage to the inverter I/O signal circuits or opposite polarity may damage the I/O devices. Especially check the wiring to prevent the speed setting potentiometer from being connected incorrectly to short circuit the terminals 10E and 5.	46	

Checkpoint	Countermeasure	Refer to page	Check by user
When using the electronic bypass operation, electrical and mechanical	When using a switching circuit as shown below, chattering due to misconfigured sequence or arc generated at switching may allow undesirable current to flow in and damage the inverter. Mis-wiring may also damage the inverter.  (The commercial power supply operation is not available with PM motors.)		•
interlocks are provided between the electronic bypass contactors MC1 and MC2.	Power supply    R/L1	363	
A countermeasure is provided for power restoration after a power failure.	If the machine must not be restarted when power is restored after a power failure, provide an MC in the inverter's input side and also make up a sequence which will not switch ON the start signal. If the start signal (start switch) remains ON after a power failure, the inverter will automatically restart as soon as the power is restored.	-	
A magnetic contactor (MC) is installed on the inverter's input side.	On the inverter's input side, connect an MC for the following purposes:  • To disconnect the inverter from the power supply at activation of a protective function or at malfunctioning of the driving system (emergency stop, etc.).  • To prevent any accident due to an automatic restart at power restoration after an inverter stop made by a power failure.  • To separate the inverter from the power supply to ensure safe maintenance and inspection work.  If using an MC for emergency stop during operation, select an MC regarding the inverter input side current as JEM1038-AC-3 class rated current.	81	
The magnetic contactor on the inverter's output side is properly handled.	Switch the magnetic contactor between the inverter and motor only when both the inverter and motor are at a stop.	81	
When using a PM motor, a low-voltage manual contactor is installed on the inverter's output side.	When a failure occurs between the MC2 and motor, make sure to provide a protection circuit, such as using the OH signal input.  In an application, such as fan and blower, where the motor is driven by the load, a low-voltage manual contactor must be connected at the inverter's output side, and wiring and inspection must be performed while the contactor is open. Otherwise you may get an electric shock.	81	
An EMI countermeasure is provided for the frequency setting signals.	If electromagnetic noise generated from the inverter causes frequency setting signal to fluctuate and the motor rotation speed to be unstable when changing the motor speed with analog signals, the following countermeasures are effective:  • Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them.  • Run signal cables as far away as possible from power cables (inverter I/O cables).  • Use shielded cables.  • Install a ferrite core on the signal cable (Example: ZCAT3035-1330 by TDK).	74	
A countermeasure is provided for an overload operation.	When performing frequent starts/stops by the inverter, rise/fall in the temperature of the transistor element of the inverter will repeat due to a repeated flow of large current, shortening the life from thermal fatigue. Since thermal fatigue is related to the amount of current, the life can be increased by reducing current at locked condition, starting current, etc. Reducing current may extend the service life but may also cause torque shortage, which leads to a start failure. Adding a margin to the current can eliminate such a condition. For an induction motor, use an inverter of a higher capacity (up to two ranks). For a PM motor, use an inverter and PM motor of higher capacities.	-	
The specifications and rating match the system requirements.	Make sure that the specifications and rating match the system requirements.	578	

#### 3.7 Failsafe system which uses the inverter

When a fault is detected by the protective function, the protective function activates and outputs a fault signal. However, a fault signal may not be output at an inverter's fault occurrence when the detection circuit or output circuit fails, etc. Although Mitsubishi assures the best quality products, provide an interlock which uses inverter status output signals to prevent accidents such as damage to the machine when the inverter fails for some reason. Also at the same time consider the system configuration where a failsafe from outside the inverter, without using the inverter, is enabled even if the inverter fails.

#### ◆Interlock method which uses the inverter status output signals

By combining the inverter output signals to provide an interlock as shown below, an inverter failure can be detected.


No.	Interlock method	Check method	Used signals	Refer to page
а	Inverter protective function operation	Operation check of an alarm contact. Circuit error detection by negative logic.	Fault output signal (ALM signal)	293
b	Inverter operating status	Operation ready signal check.	Operation ready signal (RY signal)	292
С	Inverter running status	Logic check of the start signal and running signal.	Start signal (STF signal, STR signal) Running signal (RUN signal)	292, 335
d	Inverter running status	Logic check of the start signal and output current.	Start signal (STF signal, STR signal) Output current detection signal (Y12 signal)	296, 335


(a) Checking by the output of the inverter fault signal When the inverter's protective function activates and the inverter trips, the fault output signal (ALM signal) is output. (ALM signal is assigned to terminal A1B1C1 in the initial setting).

With this signal, check that the inverter operates properly.

In addition, negative logic can be set. (ON when the inverter is normal, OFF when the fault occurs.)

- (b) Checking the inverter operating status by the inverter operation ready completion signal Operation ready signal (RY signal) is output when the inverter power is ON and the inverter becomes operative. Check if the RY signal is output after powering ON the inverter.
- (c) Checking the inverter operating status by the start signal input to the inverter and inverter running signal. The inverter running signal (RUN signal) is output when the inverter is running. (RUN signal is assigned to terminal RUN in the initial setting.)
  Check if RUN signal is being output while inputting a start signal to the inverter. (STF signal is a forward rotation signal, and STR is a reverse rotation signal.)
  Even after the start signal is turned OFF, the RUN signal is kept output until the inverter makes the motor to decelerate and to stop. For the logic check, configure a sequence considering the inverter's deceleration time.





#### Failsafe system which uses the inverter

(d) Checking the motor operating status by the start signal input to the inverter and inverter output current detection signal. The output current detection signal (Y12 signal) is output when the inverter operates and currents flows into the motor. Check if Y12 signal is being output while inputting a start signal to the inverter. (STF signal is a forward rotation signal, and STR is a reverse rotation signal.) The Y12 signal is initially set to be output at 120% (FM type) / 110% (CA type) rated inverter current. Adjust the level to around 20% using no load current of the motor as reference with Pr.150 Output current detection level.

Like the inverter running signal (RUN signal), even after the start signal is turned OFF, the Y12 signal is kept output until the inverter stops the output to a decelerating motor. For the logic check, configure a sequence considering the inverter's deceleration time.

Output	Pr.190 to P	r.196 setting
signal	Positive logic	Negative logic
ALM	99	199
RY	11	111
RUN	0	100
Y12	12	112

 When using various signals, assign the functions to Pr.190 and Pr.196 (output terminal function selection) referring to the table on the left.



 Changing the terminal assignment using Pr.190 and Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### **♦**Backup method outside the inverter

Even if the interlock is provided by the inverter status signal, enough failsafe is not ensured depending on the failure status of the inverter itself. For example, if an inverter CPU fails in a system interlocked with the inverter's fault, start, and RUN signals, no fault signal will be output and the RUN signal will be kept ON because the inverter CPU is down.


Provide a speed detector to detect the motor speed and current detector to detect the motor current and consider the backup system such as performing a check as below according to the level of importance of the system.

(a) Start signal and actual operation check

Check the motor running and motor current while the start signal is input to the inverter by comparing the start signal to the inverter and detected speed of the speed detector or detected current of the current detector. Note that the current is flowing through the motor while the motor coasts to stop, even after the inverter's start signal is turned OFF. For the logic check, configure a sequence considering the inverter's deceleration time. In addition, it is recommended to check the three-phase current when using the current detector.

(b) Command speed and actual operation check

Check for a gap between the actual speed and commanded speed by comparing the inverter's speed command and the speed detected by the speed detector.



# 4 BASIC OPERATION


This chapter explains the "BASIC OPERATION" of this product. Always read the instructions before using the equipment.

4.1	Operation panel (FR-DU08)	88
4.2	Monitoring the inverter status	92
4.3	Easy operation mode setting (easy setting mode)	93
4.4	Frequently-used parameters (simple mode parameters)	95
4.5	Basic operation procedure (PU operation)	97
4.6	Basic operation procedure (External operation)	102
4.7	Basic operation procedure (JOG operation)	109

#### **4.1** Operation panel (FR-DU08)

#### 4.1.1 Components of the operation panel (FR-DU08)


To mount the operation panel (FR-DU08) on the enclosure surface, refer to page 60.



No.	Component	Name	Description
(a)	□ PU □ EXT □ NET	Operation mode indicator	PU: ON to indicate the PU operation mode. EXT: ON to indicate the External operation mode. (ON at power-ON in the initial setting.) NET: ON to indicate the Network operation mode. PU and EXT: ON to indicate the External
(b)	□ MON □ PRM	Operation panel status indicator	MON: ON to indicate the monitoring mode. Quickly flickers twice intermittently while the protective function is activated. Slowly flickers in the display-off mode. PRM: ON to indicate the parameter setting mode.
(c)	O IM O PM	Control motor indicator	IM: ON to indicate the induction motor control. PM: ON to indicate the PM motor control. The indicator flickers when test operation is selected.
(d)	Hz	Frequency unit indicator	ON to indicate frequency. (Flickers when the set frequency is displayed in the monitor.)
(e)	BEERE	Monitor (5-digit LED)	Shows the frequency, parameter number, etc. (Using <b>Pr.52</b> , <b>Pr.774 to Pr.776</b> , the monitored item can be changed.)
(f)	□P.RUN	PLC function indicator	ON to indicate that the sequence program can be executed.
(g)	FWD	FWD key, REV key	FWD key: Starts forward rotation. The LED is on during forward operation. REV key: Starts reverse rotation. The LED is on during reverse operation. The LED flickers under the following conditions.  • When the frequency command is not given even if the forward/reverse command is given.  • When the frequency command is the starting frequency or lower.  • When the MRS signal is being input.
(h)	STOP	STOP/RESET key	Stops the operation commands. Resets the inverter when the protection function is activated.
(i)		Setting dial	The setting dial of the Mitsubishi inverters. The setting dial is used to change the frequency and parameter settings.  Press the setting dial to perform the following operations:  To display a set frequency in the monitoring mode (the setting can be changed using Pr.992.)  To display the present setting during calibration  To display a fault history number in the faults history mode
(j)	MODE	MODE key	Switches to different modes.  Switches to the easy setting mode by pressing simultaneously with PU EXT.  Holding this key for 2 seconds locks the operation. The key lock is invalid when Pr.161="0 (initial setting)". (Refer to page 166.)
(k)	SET	SET key	Enters each setting.  If pressed during operation, the monitored item changes.  (Using Pr.52 and Pr.774-Pr.776, the monitored item can be changed.)
(I)	ESC	ESC key	Goes back to the previous display. Holding this key for a longer time changes the mode back to the monitor mode.
(m)	PU EXT	PU/EXT key	Switches between the PU operation mode, the PUJOG operation mode, and the External operation mode.  Switches to the easy setting mode by pressing simultaneously with MODE.  Cancels the PU stop also.

#### 4.1.2 Basic operation of the operation panel

#### **♦**Basic operation



- \*1 For the details of operation modes, refer to page 200.
- \*2 Monitored items can be changed.(Refer to page 263.)
- \*3 For the details of the trace function, refer to page 433. For the details of the PID gain tuning, refer to page 394.
- \*4 For the details of faults history, refer to page 535.
- \*5 The USB memory mode will appear if a USB memory device is connected. (Refer to page 61.)

#### **◆**Parameter setting mode

In the parameter setting mode, inverter functions (parameters) are set.

The following table explains the indications in the parameter setting mode.

Operation panel indication	Function name	Description	Refer to page
P.	Parameter setting mode	Under this mode, the set value of the displayed parameter number is read or changed.	91
Pr.ELR	Parameter clear	Clears and resets parameter settings to the initial values. Calibration parameters and offline auto tuning parameters are not cleared. The communication parameters are not cleared. For the details of the uncleared parameters, refer to page 597.	520
ALLEL	Parameter all clear	Clears and resets parameter settings to the initial values. Calibration parameters and the offline auto tuning parameters are also cleared. The communication parameters are not cleared. For the details of the uncleared parameters, refer to page 597.	520
ErrEL	Faults history clear	Deletes the faults history.	531
PHEPY	Parameter copy	Copies the parameter settings saved in the inverter to the operation panel. The parameters copied to the operation panel can be also copied to other inverters.	521
Pr:CHG	Initial value change list	Identifies the parameters that have been changed from their initial settings.	527
I PM	IPM initialization	Changes the parameters to the settings required to drive an IPM motor (MM-EFS/MM-THE4) as a batch. Also changes the parameters back to the settings required to drive an induction motor.	149
AULO	Automatic parameter setting	Changes parameter settings as a batch. The target parameters include communication parameters for the Mitsubishi's human machine interface (GOT) connection and the parameters for the rated frequency settings of 50 Hz/60 Hz.	173
Pryd	Group parameter setting	Displays parameter numbers by function groups.	133

# 4.1.3 Correspondences between digital and actual characters

There are the following correspondences between the actual alphanumeric characters and the digital characters displayed on the operation panel:

0	1	2	3	4	5	6	7	8	9	Α	B(b)	С	С	D(d)
	1	2	$\exists$	1	II	吕	<u> </u>	日	9	H	占			占
E(e)	F(f)	G(g)	H(h)	l(i)	J(j)	K(k)	L(I)	M(m)	N	n	0	0	P(p)	Q(q)
E	F=	臣	<b>}</b> {			K	1	14	N	1-7			F	
R	r	S(s)	T(t)	U	u	٧	٧	W	w	X(x)	Y(y)	Z(z)		
F	1	5				1.	11	W	M	X	1-1	7		

#### 4.1.4 Changing the parameter setting value

Changing example Change the Pr.1 Maximum frequency.

	Operation —
1.	Screen at power-ON The monitor display appears.
2.	Changing the operation mode  Press PU to choose the PU operation mode. [PU] indicator is on.
3.	Parameter setting mode  Press MODE to choose the parameter setting mode. (The parameter number read previously appears.)
4.	Selecting the parameter number  Turn until P.
5.	Changing the setting value  Turn to change the set value to "fill". Press SET to enter the setting.  "fill to read another parameter.  • Press SET to show the setting again.  • Press SET twice to show the next parameter.  • Press MODE three times to return to the monitor display of the frequency.

#### • NOTE

- E -- 1 to E -- are displayed... Why?
- Er- | appears.....Write disable error
- E = appears.....Write error during operation
- **☐ , - ∃** appears.....Calibration error
- - appears.....Mode designation error

For details, refer to page 535.


#### POINT)

• When **Pr.77 Parameter write selection=**"0 (initial setting)", the parameter setting change is only available while the inverter is stopped under the PU operation mode.

To enable the parameter setting change while the inverter is running or under the operation mode other than PU operation mode, change the **Pr.77** setting. (Refer to **page 169**)

#### **4.2** Monitoring the inverter status

#### 4.2.1 Monitoring of output current and output voltage




#### 4.2.2 First monitored item

The first monitored item to be displayed in the monitor mode is selectable.

To set a monitored item as the first monitored item, display a monitored item, and press set | set | for a while.

Changing example | Set the output current as the first monitored item.





• Use Pr.774 Operation panel monitor selection 1 to change the monitored item. (Refer to page 263.)

#### 4.2.3 Displaying the set frequency

In the PU operation mode or in the External/PU combined operation mode 1(



(Pr.79 Operation mode selection

="3"), select the monitor mode, and then press the setting dial. The present set frequency is displayed.



• Use Pr.992 Operation panel setting dial push monitor selection to change the displayed indication. (Refer to page 263.)

#### 4.3 Easy operation mode setting (easy setting mode)


A required combination of a start command and a frequency command can be easily selected using Pr.79 Operation mode selection.

**Changing example** 

Operate with the external (STF/STR) start command and



frequency command.



Operation penal indication	Operation	Operation made	
Operation panel indication	Start command	Frequency command	Operation mode
Flickering — \$\frac{2}{0} \frac{P}{0} \frac{P}{2} \frac{1}{0} \fra	FWD , PREV	*1	PU operation mode
Flickering $-2$ $0$ $0$ $0$ $0$ $0$ $0$ $0$ $0$ $0$ $0$	External (STF, STR)	Analog voltage input	External operation mode
Flickering $-2$ $\frac{2}{0}$ $\frac{P_{ij}}{0}$ $\frac{MON}{0}$ $\frac{-1M}{PM}$	External (STF, STR)	*1	External/PU combined operation mode 1
Flickering OF 1 PM PM PM	FWD REV	Analog voltage input	External/PU combined operation mode 2

\*1 To use as a potentiometer, refer to page 166.

#### Easy operation mode setting (easy setting mode)



- -Pr.79 may not be included in the user group set by Pr.160 User group read selection ="1".
- E → E is displayed... Why?
- -Setting cannot be changed during operation. Turn the start command (FWD) or REV, STF or STR) OFF.
- If MODE is pressed before pressing SET, the easy setting mode is terminated and the display goes back to the monitor display. If the easy setting mode is terminated while **Pr.79** ="0 (initial value)", the operation mode switches between the PU operation mode and the External operation mode. Check the operation mode.
- Reset by STOP is enabled.
- The priorities of the frequency commands when **Pr.79** = "3" are "Multi-speed operation (RL/RM/RH/REX) > PID control (X14) > terminal 4 analog input (AU) > digital input from the operation panel".

# **4.4** Frequently-used parameters (simple mode parameters)

 $\label{parameters} \mbox{Parameters that are frequently used for the FR-F800 series are grouped as simple mode parameters.}$ 

When Pr.160 User group read selection="9999", only the simple mode parameters are displayed.

This section explains about frequently-used parameters.

#### 4.4.1 Simple mode parameter list

For simple variable-speed operation of the inverter, the initial values of the parameters may be used as they are. Set the necessary parameters to meet the load and operational specifications. Parameter setting, change and check can be performed from the operation panel (FR-DU08).



• **Pr.160 User group read selection** can narrow down the displayed parameters to only the simple mode parameters. Set **Pr.160 User group read selection** as required. (For the parameter change, refer to **page 91**.)

Pr.160 setting	Description
9999 (FM type initial value)	Displays only the simple mode parameters.
0 (CA type initial value)	Displays simple mode + extended parameters.
1	Displays parameters registered in the user group.

	_			Initial	value			Refer
Pr.	Pr.	Name	Unit	*	11	Range	Application	to
	group			FM CA				page
		000 Torque boost		6%*1 4%*2 3%*3			Set this parameter to obtain a higher starting torque under V/F control. Also set this when a	
0	G000		0.1%	2%*4 1.5%*5		0 to 30%	loaded motor cannot be driven and the warning [OL] occurs, then the inverter trips with [OC1].	496
1	H400	Maximum frequency	0.01 Hz	1%*6 120 Hz*7 60 Hz*8		0 to 120 Hz	Sets the upper limit for the output frequency.	245
2	H401	Minimum frequency	0.01 Hz	0Hz		0 to 120 Hz	Sets the lower limit for the output frequency.	1
3	G001	Base frequency	0.01 Hz	60 Hz	50 Hz	0 to 590 Hz	Set this parameter when the rated motor frequency is 50 Hz. Check the rating plate of the motor.	497
4	D301	Multi-speed setting (high speed)	0.01 Hz	60 Hz	50 Hz	0 to 590 Hz		99, 104, 222
5	D302	Multi-speed setting (middle speed)	0.01 Hz	30 Hz		0 to 590 Hz	Pre-sets the speeds that will be switched among by terminals.	
6	D303	Multi-speed setting (low speed)	0.01 Hz	10 Hz		0 to 590 Hz		
7	F010	Acceleration time	0.1 s	5 s*9 15 s*10	1	0 to 3600 s	Sets the acceleration time.	407
8	F011	Deceleration time	0.1 s	10 s*9	1	0 to 3600 s	Sets the deceleration time.	187
9	H000		0.01 A*7	Rated inverter	0 to 500 A*7	Protects the motor from heat.	225	
J	C103		0.1 A*8	current		0 to 3600 A*8	Set the rated motor current.	225
79	D000	Operation mode selection	1	0		0 to 4, 6, 7	Select the start and frequency command sources.	200
125	T022	Terminal 2 frequency setting gain frequency	0.01 Hz	60 Hz	50 Hz	0 to 590 Hz	Allows the frequency at the maximum potentiometer setting (5 V in the initial setting) to be changed.	106, 314
126	T042	Terminal 4 frequency setting gain frequency	0.01 Hz	60 Hz	50 Hz	0 to 590 Hz	Allows the frequency at the maximum current input (20 mA in the initial setting) to be changed.	108, 314

#### Frequently-used parameters (simple mode parameters)

Pr.	Pr.	Name	Name Unit		Unit *11		Application	Refer to
	group			FM	CA			page
160	E440	User group read selection	1	9999	0	0, 1, 9999	Restricts the parameters that are read by the operation panel and the parameter unit.	177
998	E430	PM parameter initialization	1	(	)	0, 12, 112, 8009, 8109, 9009, 9109	Selects the PM sensorless vector control and set the parameters that are required to drive an PM motor.	149
999	E431	Automatic parameter setting	1	99	99	1, 2, 10, 11, 12, 13, 20, 21, 30, 31, 9999	Changes parameter settings as a batch. The target parameters include communication parameters for the Mitsubishi's human machine interface (GOT) connection and the parameters for the rated frequency settings of 50 Hz/60 Hz.	173

- \*1 Initial value for the FR-F820-00046(0.75K) or lower and FR-F840-00023(0.75K) or lower.
- \*2 Initial value for the FR-F820-00077(1.5K) to FR-F820-00167(3.7K) and the FR-F840-00038(1.5K) to FR-F840-00083(3.7K).
- \*3 Initial value for the FR-F820-00250(5.5K), FR-F820-00340(7.5K), FR-F840-00126(5.5K), and FR-F840-00170(7.5K).
- \*4 Initial value for the FR-F820-00490(11K) to FR-F820-01540(37K), FR-F840-00250(11K) to FR-F840-00770(37K).
- \*5 Initial value for the FR-F820-01870(45K), FR-F820-02330(55K), FR-F840-00930(45K), and FR-F840-01160(55K).
- \*6 Initial value for the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.
- \*7 For the FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower.
- \*8 For the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.
- \*9 Initial value for the FR-F820-00340(7.5K) or lower and FR-F840-00170(7.5K) or lower.
- \*10 Initial value for the FR-F820-00490(11K) or higher and FR-F840-00250(11K) or higher.
- \*11 FM denotes the initial value for the FM type inverter that has the terminal FM, and CA denotes the initial value for the CA type inverter that has the terminal CA

#### 4

## 4.5 Basic operation procedure (PU operation)




- · Where is the frequency command source?
  - The frequency set in the frequency setting mode of the operation panel → Refer to 4.5.1. (Refer to page 97.)
- The setting dial used as the potentiometer  $\rightarrow$  Refer to 4.5.2. (Refer to page 98.)
- The ON/OFF switches connected to terminals → Refer to 4.5.3. (Refer to page 99.)
- Voltage input signals → Refer to 4.5.4. (Refer to page 100.)
- Current input signals → Refer to 4.5.5. (Refer to page 101.)

## 4.5.1 Operating at a set frequency (example: operating at 30 Hz)



· Use the operation panel (FR-DU08) to give a start command and a frequency command. (PU operation)



Operation example

Operate at 30 Hz.

Operation Screen at power-ON The monitor display appears. Changing the operation mode 2. Press Press Pu to choose the PU operation mode. [PU] indicator is on. Setting the frequency Turn (2) until the target frequency, "  $\exists \Box \Box \Box \Box$ " (30.00 Hz), appears. The frequency flickers for about 5 s. While the value is flickering, press SET to enter the frequency. "F" and " I like alternately. After about 3 s of 3. flickering, the indication goes back to " [ ] [ ] " (monitor display). is not pressed, the indication of the value goes back to " (0.00 Hz) after about 5 s of flickering.In that case, turn ( again and set the frequency.) Start  $\rightarrow$  acceleration  $\rightarrow$  constant speed to start running. The frequency value on the indication increases in Pr.7 Acceleration time, and " ] [ (30.00 Hz) appears. (To change the set frequency, perform the operation in above step 3. The previously set frequency appears.) Deceleration → stop 5. Press to stop. The frequency value on the indication decreases in Pr.8 Deceleration time, and the motor stops rotating with " (0.00 Hz) displayed.

## • NOTE

• To display the set frequency under PU operation mode or External/PU combined operation mode 1 (**Pr.79** = "3"), press (Refer to page 263.)



can also be used like a potentiometer to perform operation. (Refer to page 98.)

#### Parameters referred to

Pr.7 Acceleration time, Pr.8 Deceleration time page 187 Pr.79 Operation mode selection page 200

## 4.5.2 Using the setting dial like a potentiometer to perform operation



• Set Pr.161 Frequency setting/key lock operation selection ="1" (setting dial potentiometer).

Operation example

Change the frequency from 0 Hz to 60 Hz during operation

	Operation ————
1.	Screen at power-ON
•	The monitor display appears.
	Changing the operation mode
2.	Press PU to choose the PU operation mode. [PU] indicator is on.
3.	Changing the parameter setting
3.	Change Pr.161 setting to "1". (For setting value change, refer to page 91.)
	Start
4.	Press FWD or REV to start the inverter operation.
	Setting the frequency
5.	Turn " until " $\Box\Box\Box\Box$ " appears. The set frequency flickers. (The frequency flickers for about 5 s.)
	SET needs not to be pressed.

## NOTE:

- If the display changes from flickering "60.00" to "0.00", Pr.161 Frequency setting/key lock operation selection may be set to a value other than "1".
- Simply turning (i) will enable frequency setting whether the inverter is running or at a stop.
- The newly-set frequency will be saved as the set frequency in EEPROM after 10 s.
- With the setting dial, the frequency can go up to the setting value of Pr.1 Maximum frequency. Check the Pr.1 Maximum frequency setting, and adjust the setting according to the application.

#### # Parameters referred to

Pr.1 Maximum frequency page 245


Pr.161 Frequency setting/key lock operation selection page 166


# 4.5.3 Setting the frequency by switches (multi-speed setting)

## POINT)

- Use the operation panel (FR-DU08) ( FWD or REV ) to give a start command.
- Turn ON the RH, RM, or RL signal to give a frequency command. (multi-speed setting)
- Set Pr.79 Operation mode selection="4" (External/PU combination operation mode 2).

[Connection diagram]





Operation example

Operate at a low-speed (10 Hz).

#### Operation

1. Screen at power-ON

The monitor display appears

2. Changing the operation mode

Set "4" in Pr.79. [PU] and [EXT] indicators are on. (For setting value change, refer to page 93.)

3. Setting the frequency

Turn ON the low-speed switch (RL).

 $Start \rightarrow acceleration \rightarrow constant \ speed$ 

4. Press FWD or REV to start running. The frequency value on the indication increases in Pr.7 Acceleration time, and

" | [ ] [ ] " (10.00 Hz) appears.

Deceleration → stop

Fress STOP to stop. The frequency value on the indication decreases in **Pr.8 Deceleration time**, and the motor stops rotating with " (0.00 Hz) displayed. Turn OFF the low-speed switch (RL).

## • NOTE

- The terminal RH is initially set to 60 Hz for the FM type inverter, and to 50 Hz for the CA type inverter. The terminal RM is set to 30 Hz, and the RL is set to 10 Hz. (To change, set **Pr.4**, **Pr.5**, **and Pr.6**.)
- In the initial setting, when two or more of multi-speed settings are simultaneously selected, priority is given to the set frequency of the lower signal.

For example, when RH and RM signals turn ON, RM signal (Pr.5) has a higher priority.

• Maximum of 15-speed operation can be performed.

#### Parameters referred to

Pr.4 to Pr.6 (multi-speed setting) page 222

Pr.7 Acceleration time, Pr.8 Deceleration time page 187


Pr.79 Operation mode selection page 200

### 4.5.4 Setting the frequency with analog signals (voltage input)

## POINT


- Use the operation panel (FR-DU08) ( FWD or REV ) to give a start command.
- Use the potentiometer (frequency setting potentiometer) to give a frequency command (by connecting it across terminals 2 and 5 (voltage input)).
- Set Pr.79 Operation mode selection = "4" (External/PU combination operation mode 2).

[Connection diagram] (The inverter supplies 5 V power to the frequency setting potentiometer (terminal 10).)



Operation example

Operate at 60 Hz.



## • NOTE

- To change the frequency (60 Hz) at the maximum voltage input (initial value 5 V), adjust Pr.125 Terminal 2 frequency setting gain frequency.
- To change the frequency (0 Hz) at the minimum voltage input (initial value 0 V), adjust the calibration parameter C2 Terminal 2 frequency setting bias frequency.

#### # Parameters referred to

Pr.7 Acceleration time, Pr.8 Deceleration time page 187

Pr.79 Operation mode selection page 200

Pr.125 Terminal 2 frequency setting gain frequency page 314


C2(Pr.902) Terminal 2 frequency setting bias frequency page 314

## 4.5.5 Using an analog signal (current input) to give a frequency command



- Use the operation panel (FR-DU08) ( FWD or) REV to give a start command.
- Use the outputs from the current signal source (4 to 20 mA) to give a frequency command (by connecting it across terminals 4 and 5 (current input)).
- · Turn ON the AU signal.
- Set Pr.79 Operation mode selection ="4" (External/PU combination operation mode 2).

[Connection diagram]



Operation example

Operate at 60 Hz.

Operation Screen at power-ON The monitor display appears. Changing the operation mode 2. Set "4" in Pr.79. [PU] and [EXT] indicators are on. (For setting value change, refer to page 91.) Terminal 4 input selection 3. Turn ON the terminal 4 input selection signal (AU). Input to the terminal 4 is enabled. Start 4. FWD or REV. [FWD] or [REV] flickers as no frequency command is given. Acceleration → constant speed 5. appears. Deceleration Input 4 mA or less. The frequency value on the indication decreases in Pr.8 Deceleration time, and the motor stops rotating 6.

Stop 7.

. [FWD] or [REV] indicator turns OFF.

with "[][] " (0.00 Hz) displayed. [FWD] or [REV] indicator flickers.

## • NOTE

- Pr.184 AU terminal function selection must be set to "4" (AU signal) (initial value).
- To change the frequency (60 Hz) at the maximum current input (initial value 20 mA), adjust Pr.126 Terminal 4 frequency setting gain frequency.
- · To change the frequency (0 Hz) at the minimum current input (initial value 4 mA), adjust the calibration parameter C5 Terminal 4 frequency setting bias frequency.

#### Parameters referred to

Pr.7 Acceleration time, Pr.8 Deceleration time page 187

Pr.79 Operation mode selection page 200

Pr.126 Terminal 4 frequency setting gain frequency page 314

Pr.184 AU terminal function selection? page 329

C5(Pr.904) Terminal 4 frequency setting bias frequency page 314

## 4.6 **Basic operation procedure (External** operation)




- Where is the frequency command source?
- The frequency set in the frequency setting mode of the operation panel → Refer to 4.6.1. (Refer to page 102.)
- Switches (multi-speed setting) → Refer to 4.6.3. (Refer to page 105.)
- Voltage input signals → Refer to 4.6.4. (Refer to page 106.)
- Current input signals → Refer to 4.6.5. (Refer to page 107.)

#### Using the frequency set by the operation panel 4.6.1



- · Switch ON the STF (STR) signal to give a start command.
- Use the operation panel (FR-DU08) ( ) to give a start command.
- Set Pr.79 ="3" (External/PU combined operation mode 1).

#### [Connection diagram]



Operation example

Operate at 30 Hz.


Operation Changing the operation mode Set "3" in Pr.79. [PU] and [EXT] indicators are on. (For setting value change, refer to page 91.) Setting the frequency Turn to until the target frequency, " - [ ] [ (30.00 Hz), appears. The frequency flickers for about 5 s. While the value is flickering, press SET to enter the frequency. " and " I like alternately. After about 3 s of 2. flickering, the indication goes back to " [ ] [ " (monitor display). is not pressed, the indication of the value goes back to "[[[]]]" (0.00 Hz) after about 5 s of flickering. In that case, turn again and set the frequency.) Start → acceleration → constant speed

Turn ON the start switch (STF or STR). The frequency value on the indication increases in Pr.7 Acceleration time, and 3. " - [ (30.00 Hz) appears. [FWD] indicator is on during the forward rotation, and [REV] indicator is on during the reverse rotation.

(To change the set frequency, perform the operation in above step 2. The previously set frequency appears.)

Deceleration → stop

Turn OFF the start switch (STF or STR). The frequency value on the indication decreases in Pr.8 Deceleration time, and 4. the motor stops rotating with " (0.00 Hz) displayed.



- · When both the forward rotation switch (STF) and the reverse rotation switch (STR) are ON, the motor cannot be started. If both are turned ON while the inverter is running, the inverter decelerates to a stop.
- Pr.178 STF terminal function selection must be set to "60" (or Pr.179 STR terminal function selection must be set to "61"). (All are initial values.)
- Setting Pr.79 Operation mode selection="3" also enables multi-speed operation.
- If stopped using on the operation panel (FR-DU08) during the External operation, the inverter enters the PU stop status.

( 🏳 🛱 appears on the operation panel.)

To reset the PU stop status, turn OFF the start switch (STF or STR), and then press  $\left\| \frac{PU}{EXT} \right\|$ . (Refer to page 163)



#### Parameters referred to

Pr.4 to Pr.6 (multi-speed setting) page 222

Pr.7 Acceleration time, Pr.8 Deceleration time page 187

Pr.178 STF terminal function selection page 329

Pr.179 STR terminal function selection page 329


Pr.79 Operation mode selection page 200


### 4.6.2 Setting the frequency by switches (multi-speed setting) (Pr.4 to Pr.6)

## POINT

- Switch ON the STF (STR) signal to give a start command.
- Turn ON the RH, RM, or RL signal to give a frequency command. (Multi-speed setting)

[Connection diagram]





Changing example

Operate at a high-speed (60 Hz).

Operation

Screen at power-ON 1.

The monitor display appears.

Setting the frequency 2.

Turn ON the high-speed switch (RH).

Start → acceleration → constant speed

Turn ON the start switch (STF or STR). The frequency value on the indication increases in Pr.7 Acceleration time, and " [ (60.00 Hz) appears. [FWD] indicator is on during the forward rotation, and [REV] indicator is on during the reverse rotation.

· When RM is turned ON, 30 Hz is displayed. When RL is turned ON, 10 Hz is displayed.

Deceleration → stop

Turn OFF the start switch (STF or STR). The frequency value on the indication decreases in Pr.8 Deceleration time, and the motor stops rotating with "[][][" (0.00 Hz) displayed. [FWD] or [REV] indicator turns OFF. Turn OFF the high-speed switch (RH).

## NOTE

3.

4.

- · When both the forward rotation switch (STF) and the reverse rotation switch (STR) are ON, the motor cannot be started. If both are turned ON while the inverter is running, the inverter decelerates to a stop.
- The terminal RH is initially set to 60 Hz for the FM type inverter, and to 50 Hz for the CA type inverter. The terminal RM is set to 30 Hz, and the RL is set to 10 Hz. (To change, set Pr.4, Pr.5, and Pr.6.)
- In the initial setting, when two or more of multi-speed settings are simultaneously selected, priority is given to the set frequency of the lower signal.

For example, when RH and RM signals turn ON, RM signal (Pr.5) has a higher priority.

· Maximum of 15-speed operation can be performed.

#### Parameters referred to

Pr.4 to Pr.6 (multi-speed setting) page 222

Pr.7 Acceleration time, Pr.8 Deceleration time page 187


### 4.6.3 Setting the frequency with analog signals (voltage input)

## POINT

- · Switch ON the STF (STR) signal to give a start command.
- Use the potentiometer (frequency setting potentiometer) to give a frequency command. (by connecting it across terminals 2 and 5 (voltage input)).

#### [Connection diagram]

(The inverter supplies 5 V power to the frequency setting potentiometer (terminal 10).)



Operation example

Operate at 60 Hz.

Operation

Screen at power-ON

The monitor display appears.

2.

Turn ON the start switch (STF or STR). [FWD] or [REV] flickers as no frequency command is given.

Acceleration → constant speed

Turn the potentiometer (frequency setting potentiometer) clockwise slowly to full. The frequency value on the indication 3. increases in Pr.7 Acceleration time, and " [ [ [ [ (60.00 Hz) appears. [FWD] indicator is on during the forward rotation, and [REV] indicator is on during the reverse rotation.

Deceleration

- Turn the potentiometer (frequency setting potentiometer) counterclockwise slowly to full. The frequency value on the 4. indication decreases in Pr.8 Deceleration time, and the motor stops rotating with " [ ] [ [ 0.00 Hz ) displayed.
- Stop 5. Turn OFF the start switch (STF or STR). [FWD] or [REV] indicator turns OFF.

## • NOTE

- · When both the forward rotation switch (STF) and the reverse rotation switch (STR) are ON, the motor cannot be started. If both are turned ON while the inverter is running, the inverter decelerates to a stop.
- Pr.178 STF terminal function selection must be set to "60" (or Pr.179 STR terminal function selection must be set to "61"). (All are initial values.)

#### Parameters referred to

Pr.7 Acceleration time, Pr.8 Deceleration time page 187 Pr.178 STF terminal function selection page 329

Pr.179 STR terminal function selection page 329


### 4.6.4 Changing the frequency (60 Hz, initial value) at the maximum voltage input (5 V, initial value)

Change the maximum frequency.

Changing example


With a 0 to 5 VDC input frequency setting potentiometer, change the frequency at 5 V from 60 Hz (initial value) to 50 Hz.

Adjust the setting so that the inverter outputs 50 Hz when 5 V is input. Set "50 Hz" in Pr.125.



## • NOTE

• To set the frequency at 0 V, use the calibration parameter C2.



· Other adjustment methods for the frequency setting voltage gain are the following: adjustment by applying a voltage directly across terminals 2 and 5, and adjustment using a specified point without applying a voltage across terminals 2 and 5.

#### Parameters referred to


Pr.125 Terminal 2 frequency setting gain frequency page 314 C2(Pr.902) Terminal 2 frequency setting bias frequency page 314 C4(Pr.903) Terminal 2 frequency setting gain page 314

### 4.6.5 Using an analog signal (current input) to give a frequency command

## POINT

- · Switch ON the STF (STR) signal to give a start command.
- Turn ON the AU signal.
- Set Pr.79 Operation mode selection="2" (External operation mode).

#### [Connection diagram]



Operation example

Operate at 60 Hz.

Operation

- Screen at power-ON
  - The monitor display appears.
- Terminal 4 input selection 2.
  - Turn ON the terminal 4 input selection signal (AU). Input to the terminal 4 is enabled.
- Start 3.
  - Turn ON the start switch (STF or STR). [FWD] or [REV] flickers as no frequency command is given.

Acceleration → constant speed

- 4. Input 20 mA.The frequency value on the indication increases in Pr.7 Acceleration time, and " [ ] [ [ (60.00 Hz) appears. [FWD] indicator is on during the forward rotation, and [REV] indicator is on during the reverse rotation.
  - Deceleration
- Input 4 mA or less. The frequency value on the indication decreases in Pr.8 Deceleration time, and the motor stops rotating 5. with " (0.00 Hz) displayed. [FWD] or [REV] indicator flickers.
- 6.
  - Turn OFF the start switch (STF or STR). [FWD] or [REV] indicator turns OFF.

## NOTE:

- · When both the forward rotation switch (STF) and the reverse rotation switch (STR) are ON, the motor cannot be started. If both are turned ON while the inverter is running, the inverter decelerates to a stop.
- Pr.184 AU terminal function selection must be set to "4" (AU signal) (initial value).

#### Parameters referred to

Pr.7 Acceleration time, Pr.8 Deceleration time page 187


Pr.184 AU terminal function selection page 329

## 4.6.6 Changing the frequency (60 Hz, initial value) at the maximum current input (at 20 mA, initial value)


Change the maximum frequency.

Changing example With a 4 to 20 mA input frequency setting potentiometer, change the frequency at 20 mA from 60 Hz (initial value) to 50 Hz.

Adjust the setting so that the inverter outputs 50 Hz when 20 mA is input. Set "50 Hz" in Pr.126.



• To set the frequency at 4 mA, use the calibration parameter C5.



· Other adjustment methods for the frequency setting current gain are the following: adjustment by applying a current through terminals 4 and 5, and adjustment using a specified point without applying a current through terminals 4 and 5.

#### # Parameters referred to

Pr.126 Terminal 4 frequency setting gain frequency page 314 C5(Pr.904) Terminal 4 frequency setting bias frequency page 314 C7(Pr.905) Terminal 4 frequency setting gain page 314


## **Basic operation procedure (JOG operation)**

## **Performing JOG operation using external** signals



- · Perform JOG operation only while the JOG signal is ON.
- Use Pr.15 Jog frequency and Pr.16 Jog acceleration/deceleration time for the operation.
- Set Pr.79 Operation mode selection = "2" (External operation mode).

[Connection diagram]



Operation example

Operate at 5 Hz.

Operation

- Screen at power-ON
  - The monitor display appears.
- Turning ON the JOG signal 2.
  - Turn ON the JOG switch (JOG). The inverter is set ready for the JOG operation.
  - Start → acceleration → constant speed
- Turn ON the start switch (STF or STR). The frequency value on the indication increases in Pr.16 Jog acceleration/ 3. deceleration time, and " [] [] " (5.00 Hz) appears. [FWD] indicator is on during the forward rotation, and [REV] indicator is on during the reverse rotation.
  - Deceleration → stop
- Turn OFF the start switch (STF or STR). The frequency value on the indication decreases in Pr.16 Jog acceleration/ 4. deceleration time, and the motor stops rotating with "[] [] (0.00 Hz) displayed. [FWD] or [REV] indicator turns OFF. Turn OFF the JOG switch (JOG).
- Stop 5.
  - Turn OFF the start switch (STF or STR). [FWD] or [REV] indicator turns OFF.

## • NOTE

- To change the running frequency, change Pr.15 Jog frequency (initial value "5 Hz").
- To change the acceleration/deceleration time, change Pr.16 Jog acceleration/deceleration time (initial value "0.5 s").

#### Parameters referred to

Pr.15 Jog frequency page 221

Pr.16 Jog acceleration/deceleration time page 221

Pr.79 Operation mode selection page 200

#### 4.7.2 JOG operation from the operation panel



 Operate only while FWD or

> Operation panel (FR-DU08)



Operation example Operate at 5 Hz.

Operation Screen at power-ON The monitor display appears. Changing the operation mode 2. Press FXT twice to choose the PUJOG operation mode. The monitor displays 155, and [PU] indicator is on. Start → acceleration → constant speed 3. Keep pressing FWD or REV . The frequency value on the indication increases in Pr.16 Jog acceleration/deceleration time, and " \( \sum\_{\infty} \subseteq \sin \subseteq \subseteq \subseteq \subseteq \subseteq \subseteq \s Deceleration → stop Release FWD or REV . The frequency value on the indication decreases in Pr.16 Jog acceleration/deceleration time, 4. and the motor stops rotating with " [ ] [ ] " (0.00 Hz) displayed.

## NOTE

- To change the running frequency, change Pr.15 Jog frequency (initial value "5 Hz").
- To change the acceleration/deceleration time, change Pr.16 Jog acceleration/deceleration time (initial value "0.5 s").

#### Parameters referred to

Pr.15 Jog frequency page 221

Pr.16 Jog acceleration/deceleration time page 221

# 5 PARAMETERS

This chapter explains the function setting for use of this product. Always read this instructions before use.

The following marks are used to indicate the controls as below. (Parameters without any mark are valid for all control.)

Mark	Control method	Applied motor
V/F	V/F control	
Magnetic flux	Advanced magnetic flux vector control	Three-phase induction motor
PM	PM sensorless vector control	IPM motor

The setting range and the initial value of parameters differ depending on the structure or functions of the inverter. The following common designations are used for each type of the inverter models.

Inverter model	Common designation						
FR-F8[ ]0	Standard model						
FR-F8[ ]2	Separated converter type						

## **5.1** Parameter List

## 5.1.1 Parameter list (by parameter number)

For simple variable-speed operation of the inverter, the initial value of the parameters may be used as they are. Set the necessary parameters to meet the load and operational specifications. Parameter setting, change and check can be made from the operation panel (FR-DU08).

## NOTE

- <u>Simple</u> indicates simple mode parameters. Use **Pr.160 User group read selection** to indicate the simple mode parameters only.
- Parameter setting may be restricted in some operating statuses. Use Pr.77 Parameter write selection to change the setting.
- Refer to Appendix 3 (page 597) for instruction codes for communication and availability of parameter clear, all clear, and parameter copy of each parameter.

on		<b>D</b> .			Minimum	Initial	value	Refer	ner
Function	Pr.	Pr. group	Name	Setting range	setting increments	FM	CA	to page	<b>Customer</b> setting
	0	G000	Torque boost Simple	0 to 30%	0.1%	6% *1 4% *1 3% *1 2% *1 1.5% *	1	496	
	1	H400	Maximum frequency Simple	0 to 120 Hz	0.01 Hz	120 Hz		245	
	2	H401	Minimum frequency Simple	0 to 120 Hz	0.01 Hz	0 Hz		245	
ns	3	G001	Base frequency Simple	0 to 590 Hz	0.01 Hz	60 Hz	50 Hz	497	
Basic functions	4	D301	Multi-speed setting (high speed) Simple	0 to 590 Hz	0.01 Hz	60 Hz	50 Hz	222	
Basic f	5	D302	Multi-speed setting (middle speed) Simple	0 to 590 Hz	0.01 Hz	30 Hz		222	
	6	D303	Multi-speed setting (low speed) Simple	0 to 590 Hz	0.01 Hz	10 Hz		222	
	7	F010	Acceleration time Simple	0 to 3600 s	0.1 s	5 s *4 15 s *5		187	
	8	F011	Deceleration time Simple	0 to 3600 s	0.1 s	10 s *4 30 s *5		187	
	1 9 1	H000	Electronic thermal O/L relay  Simple	0 to 500 A	0.01 A *2		nverter	225, 341,	
		C103	Rated motor current Simple	0 to 3600 A	0.1 A *3	current	•	351	
ion	10	G100	DC injection brake operation frequency	0 to 120 Hz, 9999	0.01 Hz	3 Hz		502	
ject ake	11	G101	DC injection brake operation time	0 to 10 s, 8888	0.1 s	0.5 s		502	
DC injection brake	12	G110	DC injection brake operation voltage	0 to 30%	0.1%	4% *6 2% *6 1% *6		502	
_	13	F102	Starting frequency	0 to 60 Hz	0.01 Hz	0.5 Hz		197, 198	
_	14	G003	Load pattern selection	0, 1	1	1		499	
Jog operation	15	D200	Jog frequency	0 to 590 Hz	0.01 Hz	5 Hz		221	
Jo	16	F002	Jog acceleration/deceleration time	0 to 3600 s	0.1 s	0.5 s		221	
_	17	T720	MRS input selection	0, 2, 4	1	0		332	
_	18	H402	High speed maximum frequency	0 to 590 Hz	0.01 Hz	120 Hz 60 Hz •		245	
_	19	G002	Base frequency voltage	0 to 1000 V, 8888, 9999	0.1 V	9999	8888	497	

Pr. Pr. group Name Setting range Minimum setting increments FM    Voite   Pr. group   Pr.		Refer to page 187 187 248 248	Customer setting
20 F000 Acceleration/deceleration reference frequency  21 F001 Acceleration/deceleration time increments  0, 1 1 0 590 Hz 0.01 Hz 60 Hz 0.01 H	z 50 Hz	187 187 248	Custom setting
		187	
	110%	248	
Stall prevention operation level 0 to 400% 0.1% 120% 0.1% 0.1% 0.1% 0.1% 0.1% 0.1% 0.1% 0.	110%		
Stall prevention operation level 23 H610 compensation factor at double 0 to 200%, 9999 0.1% 9999		248	
speed speed			
24 to 27 D304 to D307 Multi-speed setting (4 speed to 7 speed)  Multi-speed setting (4 speed to 7 speed)  0 to 590 Hz, 9999  0.01 Hz		222	
- 28 D300 Multi-speed input compensation selection 0, 1 1 0		222	
- 29 F100 Acceleration/deceleration pattern selection 1 0		191	
- 30 E300 Regenerative function selection 0 to 2, 10, 11, 20, 21, 100 to 102, 110, 111, 1 0 120, 121 *10 2, 10, 11, 102, 110, 1 10		508	
111 *11			
31 H420 Frequency jump 1A 0 to 590 Hz, 9999 0.01 Hz 9999 32 H421 Frequency jump 1B 0 to 590 Hz, 9999 0.01 Hz 9999		246	
		246 246	
33     H422     Frequency jump 2A     0 to 590 Hz, 9999     0.01 Hz     9999       34     H423     Frequency jump 2B     0 to 590 Hz, 9999     0.01 Hz     9999		246	
35 H424 Frequency jump 3A 0 to 590 Hz, 9999 0.01 Hz 9999		246	
<b>36 H425 Frequency jump 3B</b> 0 to 590 Hz, 9999 0.01 Hz 9999		246	
- 37 M000 Speed display 0, 1 to 9998 1 0		261	
41 M441 Up-to-frequency sensitivity 0 to 100% 0.1% 10%		294	
41 M441 Up-to-frequency sensitivity 0 to 100% 0.1% 10%  42 M442 Output frequency detection 0 to 590 Hz 0.01 Hz 6 Hz  43 M443 Output frequency detection for 0 to 590 Hz, 9999 0.01 Hz 9999		294	
43 M443 Output frequency detection for reverse rotation 0 to 590 Hz, 9999 0.01 Hz 9999		294	
44 F020 Second acceleration/deceleration time 0 to 3600 s 0.1 s 5 s		187	
<b>45 F021 Second deceleration time</b> 0 to 3600 s, 9999 0.1 s 9999		187	
<b>46</b> G010 Second torque boost 0 to 30%, 9999 0.1% 9999		496	
9999 47 G011 Second V/F (base frequency) 0 to 590 Hz, 9999 0.01 Hz		497	
46 G010 Second torque boost 0 to 30%, 9999 0.1% 9999 47 G011 Second V/F (base frequency) 0 to 590 Hz, 9999 0.01 Hz 9999 48 H600 Second stall prevention operation level 0 to 400% 0.1% 120% 49 H601 Second stall prevention operation frequency 0 to 590 Hz, 9999 0.01 Hz 0 Hz 50 M444 Second output frequency detection 0 to 590 Hz 0.01 Hz 30 Hz	110%	248	
49 H601 Second stall prevention operation of to 590 Hz, 9999 0.01 Hz 0 Hz		248	
50 M444 Second output frequency detection 0 to 590 Hz 0.01 Hz 30 H	Z	294	
51 H010 Second electronic thermal O/L relay C203 Rated second motor current 0 to 500 A, 9999 *2 0.01 A		225, 341,	
52 M100 Operation panel main monitor Selection Selection 10 South A So		263	
Selection		273	
55 M040 Frequency monitoring reference 0 to 590 Hz 0.01 Hz 60 H		273	
M041         Current monitoring reference         0 to 500 A *2         0.01 A         Rate current	d inverter nt	273	

Ē					Minimum	Initial	value	Refer	er 3
Function	Pr.	Pr. group	Name	Setting range	setting increments	FM	CA	to page	Customer setting
Automatic restart	57	A702	Restart coasting time	0, 0.1 to 30 s, 9999	0.1 s	9999		414, 420	
Auto	58	A703	Restart cushion time	0 to 60 s	0.1 s	1 s		414	
1	59	F101	Remote function selection	0 to 3, 11 to 13	1	0		194	
1	60	G030	Energy saving control selection	0, 4, 9	1	0		500	
1	65	H300	Retry selection	0 to 5	1	0		236	
ı	66	H611	Stall prevention operation reduction starting frequency	0 to 590 Hz	0.01 Hz	60 Hz	50 Hz	248	
try	67	H301	Number of retries at fault occurrence	0 to 10, 101 to 110	1	0		236	
Retry	68	H302	Retry waiting time	0.1 to 600 s	0.1 s	1 s		236	
	69	H303	Retry count display erase	0	1	0		236	
_	70	G107	Parameter for manufacturer setting. Do	not set.					
-	71	C100	Applied motor	0 to 6, 13 to 16, 20, 23, 24, 40, 43, 44, 50, 53, 54, 70, 73, 74, 210, 213, 214, 8090, 8093, 8094, 9090, 9093, 9094	1	0		337, 341, 351	
-	72	E600	DWM fraguency colection	0 to 15 *2	1	2		179	
_	12	E000	PWM frequency selection	0 to 6, 25 *3	1			179	
-	73	T000	Analog input selection	0 to 7, 10 to 17	1	1		306, 311	
_	74	T002	Input filter time constant	0 to 8	1	1		313	
		-	Reset selection/disconnected PU detection/PU stop selection	0 to 3, 14 to 17 *2 0 to 3, 14 to 17, 100 to 103, 114 to 117 *3	1	14			
_	75	E100	Reset selection			0		162	
		E101	Disconnected PU detection	0, 1				4	
		E102	PU stop selection			1		1	
		E107	Reset limit	0 *2 0, 1 *3	1	0			
_	76	M510	<u> </u>	0 to 2	1	0		302	
_	77	E400	Parameter write selection	0 to 2	1	0		169	
_	78	D020	Reverse rotation prevention selection	0 to 2	1	0		217	
_	79	D000	Operation mode selection Simple	0 to 4, 6, 7	1	0		200, 209	

_						Initial	value		<b>5</b> –
tior	D.	Pr.	Nome	Catting range	Minimum	- IIIIciai	, and	Refer	ome ing
Function	Pr.	group	Name	Setting range	setting increments	FM	CA	to page	<b>Customer</b> setting
				0.4 to 55 kW, 9999 *2	0.01 kW *2			143,	
	80	C101	Motor capacity	0 to 3600 kW, 9999 *3	0.1 kW *3	9999		341, 351	
	81	C102	Number of motor poles	2, 4, 6, 8, 10, 12, 9999	1	9999		143, 341,	
				0 to 500 A, 9999 *2	0.01 A *2			351	
	82	C125	Motor excitation current	0 to 3600 A, 9999 *3	0.1 A *3	9999		341	
	83	C104	Rated motor voltage	0 to 1000 V	0.1 V	200 V =		143, 341, 351	
ants	84	C105	Rated motor frequency	10 to 400 Hz, 9999	0.01 Hz	9999		143, 341, 351	
Motor constants	89	G932	Speed control gain (Advanced magnetic flux vector)	0 to 200%, 9999	0.1%	9999		147	
orc	00	0400		0 to 50 Ω, 9999 *2	0.001 Ω *2	0000		341,	
Mot	90	C120	Motor constant (R1)	0 to 400 mΩ, 9999 *3	0.01 mΩ *3	9999		351, 422	
	91	C121	Motor constant (R2)	0 to 50 Ω, 9999 *2	0.001 Ω *2	9999		341	
			Motor constant (L1)/d-axis	0 to 400 mΩ, 9999 *3 0 to 6000mH, 9999 *2	0.01 mΩ *3 0.1 mH *2			341,	
	92	C122	inductance (Ld)	0 to 400mH, 9999 *3	0.01 mH *3			351	
	93	C123	Motor constant (L2)/q-axis	0 to 6000mH, 9999 *2	0.1 mH *2	9999		341,	
			inductance (Lq)	0 to 400mH, 9999 *3	0.01 mH *3 0.1% *2	0000		351	
	94	C124	Motor constant (X)	0 to 100%, 9999	0.01% *3	9999		341	
	95	C111	Online auto tuning selection	0, 1	1	0		359	
	96	C110	Auto tuning setting/status	0, 1, 11, 101	1	0		341, 351, 422	
	100	G040	V/F1 (first frequency)	0 to 590 Hz, 9999	0.01 Hz	9999		501	
V/F	101	G041	V/F1 (first frequency voltage)	0 to 1000 V	0.1 V	0 V		501	
points V/F	102	G042	V/F2 (second frequency)	0 to 590 Hz, 9999	0.01 Hz	9999		501	
Ö	103	G043	V/F2 (second frequency voltage)	0 to 1000 V	0.1 V	0 V		501	
2	104	G044	V/F3 (third frequency)	0 to 590 Hz, 9999	0.01 Hz	9999		501	
ple	105	G045	V/F3 (third frequency voltage)	0 to 1000 V	0.1 V	0 V		501	
stal	106	G046	V/F4 (fourth frequency)	0 to 590 Hz, 9999	0.01 Hz	9999		501	
Adjustable	107	G047	V/F4 (fourth frequency voltage)	0 to 1000 V	0.1 V	0 V		501	
₹	108	G048	V/F5 (fifth frequency)	0 to 590 Hz, 9999	0.01 Hz	9999		501	
	109	G049	V/F5 (fifth frequency voltage)	0 to 1000 V	0.1 V	0 V		501	
	117	N020	PU communication station number	0 to 31 48, 96, 192, 384, 576,	1	0		449	
tion	118	N021	PU communication speed  PU communication stop bit length /	768, 1152	1	192		449	
nica	446	-	data length	0, 1, 10, 11		1			
ınu	119	N022	PU communication data length	0, 1	1	0		449	
m		N023	PU communication stop bit length	0, 1		1		1	
	120	N024	PU communication parity check	0 to 2	1	2		449	
ector	121	N025	Number of PU communication retries	0 to 10, 9999	1	1		449	
PU connector communication	122	N026	PU communication check time interval	0, 0.1 to 999.8 s, 9999	0.1 s	9999		449	
P	123	N027	PU communication waiting time setting	0 to 150 ms, 9999	1 ms	9999		449	
	124	N028	PU communication CR/LF selection	0 to 2	1	1		449	
			Terminal 2 frequency setting gain						
_	125	T022	frequency Simple	0 to 590 Hz	0.01 Hz	60 Hz	50 Hz	314	
_	126	T042	Terminal 4 frequency setting gain frequency Simple	0 to 590 Hz	0.01 Hz	60 Hz	50 Hz	314	
		1	moduling emilia	l		<u> </u>			

_						Initial	value		_
tior	Pr.	Pr.	Name	Cotting range	Minimum	micial		Refer	ome
Function	Pr.	group	Name	Setting range	setting increments	FM	CA	to page	<b>Customer</b> setting
	127	A612	PID control automatic switchover frequency	0 to 590 Hz, 9999	0.01 Hz	9999		378	
PID operation	128	A610	PID action selection	0, 10, 11, 20, 21, 50, 51, 60, 61, 70, 71, 80, 81, 90, 91, 100, 101, 1000, 1001, 1010, 1011, 2000, 2001, 2010, 2011	1	0		378	
0 0	129	A613	PID proportional band	0.1 to 1000%, 9999	0.1%	100%		378	
F	130	A614	PID integral time	0.1 to 3600 s, 9999	0.1 s	1 s		378	
	131	A601	PID upper limit	0 to 100%, 9999	0.1%	9999		378	
	132	A602	PID lower limit	0 to 100%, 9999	0.1%	9999		378	
	133	A611	PID action set point	0 to 100%, 9999	0.01%	9999		378	
	134	A615	PID differential time	0.01 to 10 s, 9999	0.01 s	9999		378	
	135	A000	Electronic bypass sequence selection	0, 1	1	0		363	
Bypass	136	A001	MC switchover interlock time	0 to 100 s	0.1 s	1 s		363	
ура	137	A002	Start waiting time	0 to 100 s	0.1 s	0.5 s		363	
ω	138	A003	Bypass selection at a fault	0, 1	1	0		363	
	139	A004	Automatic switchover frequency from inverter to bypass operation	0 to 60 Hz, 9999	0.01 Hz	9999		363	
	140	F200	Backlash acceleration stopping frequency	0 to 590 Hz	0.01 Hz	1 Hz		191	
dash	141	F201	Backlash acceleration stopping time	0 to 360 s	0.1 s	0.5 s		191	
Backlash measures	142	F202	Backlash deceleration stopping frequency	0 to 590 Hz	0.01 Hz	1 Hz		191	
	143	F203	Backlash deceleration stopping time	0 to 360 s	0.1 s	0.5 s		191	
_	144	M002	Speed setting switchover	0, 2, 4, 6, 8, 10, 12, 102, 104, 106, 108, 110, 112	1	4		261	
PU	145	E103	PU display language selection	0 to 7	1	1		164	
_	147	F022	Acceleration/deceleration time switching frequency	0 to 590 Hz, 9999	0.01 Hz	9999		187	
드	148	H620	Stall prevention level at 0 V input	0 to 400%	0.1%	120%	110%	248	
ctic	149	H621	Stall prevention level at 10 V input	0 to 400%	0.1%	150%	120%	248	
lete	150	M460	Output current detection level	0 to 400%	0.1%	120%	110%	296	
Current detection	151	M461	Output current detection signal delay time	0 to 10 s	0.1 s	0 s		296	
ı.n.	152	M462	Zero current detection level	0 to 400%	0.1%	5%		296	
	153	M463	Zero current detection time	0 to 10 s	0.01 s	0.5 s		296	
_	154	H631	Voltage reduction selection during stall prevention operation	0, 1, 10, 11	1	1		248	
_	155	T730	RT signal function validity condition selection	0, 10	1	0		333	
_	156	H501	Stall prevention operation selection	0 to 31, 100, 101	1	0		248	
_	157	M430	OL signal output timer	0 to 25 s, 9999	0.1 s	0 s		248	
_	158	M301	AM terminal function selection	1 to 3, 5 to 14, 17, 18, 21, 24, 34, 50, 52 to 54, 61, 62, 67, 70, 86 to 96, 98	1	1		273	
_	159	A005	Automatic switchover frequency range from bypass to inverter operation	0 to 10 Hz, 9999	0.01 Hz	9999	T	363	
_	160	E440	User group read selection Simple	0, 1, 9999	1	9999	0	177	
_	161	E200	Frequency setting/key lock operation selection	0, 1, 10, 11	1	0		166	

L.		_			Minimum	Initial value		Refer	er g
Function	Pr.	Pr. group	Name	Setting range	setting increments	FM	CA	to page	<b>Customer</b> setting
Automatic restart functions	162	A700	Automatic restart after instantaneous power failure selection	0 to 3, 10 to 13	1	0		414, 420, 422	
utomati restart inctions	163	A704	First cushion time for restart	0 to 20 s	0.1 s	0 s		414	
\uterian re	164	A705	First cushion voltage for restart	0 to 100%	0.1%	0%		414	
	165	A710	Stall prevention operation level for restart	0 to 400%	0.1%	120%	110%	414	
Current detection	166	M433	Output current detection signal retention time	0 to 10 s, 9999	0.1 s	0.1 s		296	
Cur	167	M464	Output current detection operation selection	0, 1, 10, 11	1	0		296	
_	168	E000 E080	Parameter for manufacturer setting. Do	not set.					
_	169	E001 E081			r	T		ı	
lative itor ar	170	M020	Watt-hour meter clear	0, 10, 9999	1	9999	9999		
Cumulative monitor clear	171	M030	Operation hour meter clear	0, 9999	1	9999		263	
er up	172	E441	User group registered display/ batch clear	9999, (0 to 16)	1	0		177	
User group	173	E442	User group registration	0 to 1999, 9999	1	9999		177	
O,	174	E443	User group clear	0 to 1999, 9999	1	9999		177	
ıt	178	T700	STF terminal function selection	0 to 8, 10 to 14, 16, 18, 24, 25, 28, 37 to 40, 46 to 48, 50, 51, 60, 62, 64 to 67, 70 to 73, 77 to 81, 84, 94 to 98, 9999	1	60		329	
Input terminal function assignment	179	T701	STR terminal function selection	0 to 8, 10 to 14, 16, 18, 24, 25, 28, 37 to 40, 46 to 48, 50, 51, 61, 62, 64 to 67, 70 to 73, 77 to 81, 84, 94 to 98, 9999	1	61		329	
Jun	180	T702	RL terminal function selection		1	0		329	
al fı	181	T703	RM terminal function selection		1	1		329	
nin	182	T704	RH terminal function selection		1	2		329	
ern	183	T705	RT terminal function selection	0 to 8, 10 to 14, 16,	1	3		329	
ut t	184	T706	AU terminal function selection	18, 24, 25, 28, 37 to 40, 46 to 48, 50,	1	4		329	
u	185	T707	JOG terminal function selection	51, 62, 64 to 67,	1	5		329	
_	186	T708	CS terminal function selection	70 to 73, 77 to 81, 84,	1	9999		329	
	187	T709	MRS terminal function selection	94 to 98, 9999	1	24 *10 10 *11		329	
	188	T710	STOP terminal function selection		1	25		329	
	189	T711	RES terminal function selection		1	62	_	329	

ڌ					Minimo	Initial value	Defer	er 3
Function	Pr.	Pr. group	Name	Setting range	Minimum setting increments	FM CA	Refer to page	Customer setting
	190	M400	RUN terminal function selection	0 to 5, 7, 8, 10 to 19, 25, 26, 35, 39, 40,	1	0	288	
	191	M401	SU terminal function selection	45 to 54, 57, 64 to 68, 70 to 79, 82, 85, 90 to 96, 98 to 105,	1	1	288	
‡-	192	M402	IPF terminal function selection	107, 108, 110 to 116, 125, 126, 135, 139, 140, 145 to 154, 157, 164 to 168,	1	2 *10*12 9999 *11	288	
assignme	193	M403	OL terminal function selection	170 to 179, 182, 185, 190 to 196, 198 to 208, 211 to 213, 215,	1	3	288	
function	194	M404	FU terminal function selection	300 to 308, 311 to 313, 315, 9999	1	4	288	
Output terminal function assignment	195	M405	ABC1 terminal function selection	0 to 5, 7, 8, 10 to 19, 25, 26, 35, 39, 40, 45 to 54, 57, 64 to 68, 70 to 79, 82, 85, 90, 91, 94 to 96, 98 to 105, 107, 108, 110 to 116, 125, 126,	1	99	288	
	196	M406	ABC2 terminal function selection	135, 139, 140, 145 to 154, 157, 164 to 168, 170 to 179, 182, 185, 190, 191, 194 to 196, 198 to 208, 211 to 213, 215, 300 to 308, 311 to 313, 315, 9999	1	9999	288	
Multi-speed setting	232 to 239	D308 to D315	Multi-speed setting (8 speed to 15 speed)	0 to 590 Hz, 9999	0.01 Hz	9999	222	
_	240	E601	Soft-PWM operation selection	0, 1	1	1	179	
_	241	M043	Analog input display unit switchover	0, 1	1	0	314	
_	242	T021	Terminal 1 added compensation amount (terminal 2)	0 to 100%	0.1%	100%	311	
_	243	T041	Terminal 1 added compensation amount (terminal 4)	0 to 100%	0.1%	75%	311	
_	244	H100	Cooling fan operation selection	0, 1, 101 to 105	1	1	233	
tion	245	G203	Rated slip	0 to 50%, 9999	0.01%	9999	518	
Slip compensation	246	G204	Slip compensation time constant	0.01 to 10 s	0.01 s	0.5 s	518	
сошр	247	G205	Constant-power range slip compensation selection	0, 9999	1	9999	518	
_	248	A006	Self power management selection	0 to 2	1	0	370	
_	249	H101	Earth (ground) fault detection at start	0, 1	1	0	234	
_	250	G106	Stop selection	0 to 100 s, 1000 to 1100 s, 8888, 9999	0.1 s	9999	507	
_	251	H200	Output phase loss protection selection	0, 1	1	1	235	

Pr. Lis	

드	ijon				Minimum	Initial	value	Refer	ner g
Function	Pr.	Pr. group	Name	Setting range	setting increments	FM	CA	to page	Customer setting
Frequency compensation function	252	T050	Override bias	0 to 200%	0.1%	50%		311	
Freque comper func	253	T051	Override gain	0 to 200%	0.1%	150%		311	
_	254	A007	Main circuit power OFF waiting time	0 to 3600 s, 9999	1 s	600 s		370	
	255	E700	Life alarm status display	(0 to 15)	1	0		180	
Life check	256 *12	E701	Inrush current limit circuit life display	(0 to 100%)	1%	100%		180	
당	257	E702	Control circuit capacitor life display	(0 to 100%)	1%	100%		180	
-ife	258 *12	E703	Main circuit capacitor life display	(0 to 100%)	1%	100%		180	
	259 *12	E704	Main circuit capacitor life measuring	0, 1	1	0		180	
_	260	E602	PWM frequency automatic switchover	0, 1	1	1		179	
۵	261	A730	Power failure stop selection	0 to 2, 11, 12, 21, 22	1	0		426	
Power failure stop	262	A731	Subtracted frequency at deceleration start	0 to 20 Hz	0.01 Hz	3 Hz		426	
I≣	263	A732	Subtraction starting frequency	0 to 590 Hz, 9999	0.01 Hz	60 Hz	50 Hz	426	
r fa	264	A733	Power-failure deceleration time 1	0 to 3600 s	0.1 s	5 s		426	
×e	265	A734	Power-failure deceleration time 2	0 to 3600 s, 9999	0.1 s	9999		426	
Ро	266	A735	Power failure deceleration time switchover frequency	0 to 590 Hz	0.01 Hz	60 Hz	50 Hz	426	
_	267	T001	Terminal 4 input selection	0 to 2	1	0		306	
_	268	M022	Monitor decimal digits selection	0, 1, 9999	1	9999		263	
_	269	E023	Parameter for manufacturer setting. Do		1	ı		1	
_	289	M431	Inverter output terminal filter	5 to 50 ms, 9999	1 ms	9999		288	
_	290	M044	Monitor negative output selection	0 to 7	1	0		263, 273	
_	291	D100	Pulse train I/O selection	[FM Type] 0, 1, 10, 11, 20, 21, 100 [CA Type] 0, 1	1	0		218, 273	
_	294	A785	UV avoidance voltage gain	0 to 200%	0.1%	100%		426	
_	295	E201	Frequency change increment amount setting	0, 0.01, 0.1, 1, 10	0.01	0		167	
word	296	E410	Password lock level	0 to 6, 99, 100 to 106, 199, 9999	1	9999		171	
Password function	297	E411	Password lock/unlock	(0 to 5), 1000 to 9998, 9999	1	9999		171	
_	298	A711	Frequency search gain	0 to 32767, 9999	1	9999		422	
_	299	A701	Rotation direction detection selection at restarting	0, 1, 9999	1	9999		414	

_						Initial	value		
Function	Pr.	Pr. group	Name	Setting range	Minimum setting increments	FM	CA	Refer to page	Customer setting
	331	N030	RS-485 communication station number	0 to 31 (0 to 247)	1	0		449	
	332	N031	RS-485 communication speed	3, 6, 12, 24, 48, 96, 192, 384, 576, 768, 1152	1	96		449	
	222	-	RS-485 communication stop bit length / data length	0, 1, 10, 11	1	1		440	
	333	N032	PU communication data length	0, 1	1	0		449	
		N033	PU communication stop bit length	0, 1	1	1			
ation	334	N034	RS-485 communication parity check selection	0 to 2	1	2		449	
nic	335	N035	RS-485 communication retry count	0 to 10, 9999	1	1		449	
n m m	336	N036	RS-485 communication check time interval	0 to 999.8 s, 9999	0.1 s	0 s		449	
RS-485 communication	337	N037	RS-485 communication waiting time setting	0 to 150 ms, 9999	1 ms	9999		449	
RS-4	338	D010	Communication operation command source	0, 1	1	0		210	
	339	D011	Communication speed command source	0 to 2	1	0		210	
	340	D001	Communication startup mode selection	0 to 2, 10, 12	1	0		209	
	341	N038	RS-485 communication CR/LF selection	0 to 2	1	1		449	
	342	N001	Communication EEPROM write selection	0, 1	1	0		446	
	343	N080	Communication error count	_	1	0		465	
_	374	H800	Overspeed detection level	0 to 590 Hz, 9999	0.01 Hz	9999		259	
	384	D101	Input pulse division scaling factor	0 to 250	1	0		218	
Pulse train input	385	D110	Frequency for zero input pulse	0 to 590 Hz	0.01 Hz	0 Hz		218	
및 # i	386	D111	Frequency for maximum input pulse	0 to 590 Hz	0.01 Hz	60 Hz	50 Hz	218	
_	390	N054	% setting reference frequency	1 to 590 Hz	0.01 Hz	60 Hz	50 Hz	480	
	414	A800	PLC function operation selection	0 to 2	1	0		431	
PLC function	415	A801	Inverter operation lock mode setting	0, 1	1	0		431	
fg P	416	A802	Pre-scale function selection	0 to 5	1	0		431	
	417	A803	Pre-scale setting value	0 to 32767	1	1		431	

_					B.A.L.	Initial value	Defer	a a
Function	Pr.	Pr. group	Name	Setting range	Minimum setting increments	FM CA	Refer to page	Customer setting
	450	C200	Second applied motor	0, 1, 3 to 6, 13 to 16, 20, 23, 24, 40, 43, 44, 50, 53, 54, 70, 73, 74, 210, 213, 214, 8093, 8094, 9090, 9093, 9094, 9999	1	9999	337	
	453	C201	Second motor capacity	0.4 to 55 kW, 9999 *2 0 to 3600 kW, 9999 *3	0.01 kW *2 0.1 kW *3	9999	341, 351	
	454	C202	Number of second motor poles	2, 4, 6, 8, 10, 12, 9999	1	9999	341, 351	
ants	455	C225	Second motor excitation current	0 to 500 A, 9999 *2 0 to 3600 A, 9999 *3	0.01 A *2 0.1 A *3	9999	341	
onst	456	C204	Rated second motor voltage	0 to 1000 V	0.1 V	200 V 400 V	341, 351	
otor (	457	C205	Rated second motor frequency	10 to 400 Hz, 9999	0.01 Hz	9999	341, 351	
Second motor constants	458	C220	Second motor constant (R1)	0 to 50 Ω, 9999 *2 0 to 400 mΩ, 9999 *3	0.001 Ω *2 0.01 mΩ *3	9999	341, 351, 422	
Sei	459	C221	Second motor constant (R2)	0 to 50 Ω, 9999 *2 0 to 400 mΩ, 9999 *3	0.001 Ω*2 0.01 mΩ *3	9999	341	
	460	C222	Second motor constant (L1) / d-axis inductance (Ld)	0 to 6000mH, 9999 *2 0 to 400mH, 9999 *3	0.1 mH *2 0.01 mH *3	9999	341, 351	
	461	C223	Second motor constant (L2) / q-axis inductance (Lq)	0 to 6000mH, 9999 *2 0 to 400mH, 9999 *3	0.1 mH *2 0.01 mH *3	9999	341, 351	
	462	C224	Second motor constant (X)	0 to 100%, 9999	0.1% *2 0.01% *3	9999	341	
	463	C210	Second motor auto tuning setting/ status	0, 1, 11, 101	1	0	341, 351, 422	
te ut	495	M500	Remote output selection	0, 1, 10, 11	1	0	298	
Remote output	496	M501	Remote output data 1	0 to 4095	1	0	298	
χ°	497	M502	Remote output data 2	0 to 4095	1	0	298	
_	498	A804	PLC function flash memory clear	0 to 9999	1	0	431	
-	502	N013	Stop mode selection at communication error	0 to 3	1	0	446	
Maintenance	503	E710	Maintenance timer 1	0 (1 to 9998)	1	0	184	
Mainte	504	E711	Maintenance timer 1 warning output set time	0 to 9998, 9999	1	9999	184	
_	505	M001	Speed setting reference	1 to 590 Hz	0.01 Hz	60 Hz 50 Hz	261	
_	514 *12	H324	Emergency drive dedicated waiting time	0.1 to 600 s, 9999	0.1 s	9999	238	
-	515 *12	H322	Emergency drive dedicated retry count	1 to 200, 9999	1	1	238	
_	522 523 *12	G105 H320	Output stop frequency  Emergency drive mode selection	0 to 590 Hz, 9999 100, 111, 112, 121 to 124, 200, 211, 212, 221 to 224, 300, 311, 312, 321 to 324, 400, 411, 412, 421 to 424, 9999	0.01 Hz	9999	238	
_	524 *12	H321	Emergency drive running speed	0 to 590 Hz, 9999	0.01 Hz	9999	238	
_	539	N002	Modbus-RTU communication check time interval	0 to 999.8 s, 9999	0.1 s	9999	465	
USB	547	N040	USB communication station number	0 to 31	1	0	493	
SN NS	548	N041	USB communication check time interval	0 to 999.8 s, 9999	0.1 s	9999	493	

Ē					Minimum	Initial	value	Dofor	a e
Function	Pr.	Pr. group	Name	Setting range	Minimum setting increments	FM	CA	Refer to page	<b>Customer</b> setting
ation	549	N000	Protocol selection	0, 1, 2	1	0		446	
Communication	550	D012	NET mode operation command source selection	0, 1, 9999	1	9999		210	
Com	551	D013	PU mode operation command source selection	1 to 3, 9999	1	9999	9999		
_	552	H429	Frequency jump range	0 to 30 Hz, 9999	0.01 Hz	9999		246	
PID	553	A603	PID deviation limit	0 to 100%, 9999	0.1%	9999		378	
. 8	554	A604	PID signal operation selection	0 to 3, 10 to 13	1	0		378	
age :or	555	E720	Current average time	0.1 to 1 s	0.1 s	1 s		185	
aver	556	E721	Data output mask time	0 to 20 s	0.1 s	0 s		185	
Current average value monitor	557	E722	Current average value monitor	0 to 500 A*2	0.01 A *2		nverter	185	
ว >			signal output reference current	0 to 3600 A*3	0.1 A *3	current			
_	560	A712	Second frequency search gain	0 to 32767, 9999	1	9999		422	
_	561	H020	PTC thermistor protection level	0.5 to 30 kΩ, 9999	0.01 kΩ	9999		225	
_	563	M021	Energization time carrying-over times	(0 to 65535)	1	0		263	
_	564	M031	Operating time carrying-over times	(0 to 65535)	1	0		263	
Second motor constants	569	G942	Second motor speed control gain	0 to 200%, 9999	0.1%	9999		147	
Multiple rating	570	E301	Multiple rating setting	0, 1	1	1	0	168	
_	571	F103	Holding time at a start	0 to 10 s, 9999	0.1 s	9999	•	197	
-	573	A680 T052	4 mA input check selection	1 to 4, 9999	1	9999		325	
_	574	C211	Second motor online auto tuning	0, 1	1	0		359	
2 <u>5</u>	575	A621	Output interruption detection time	0 to 3600 s, 9999	0.1 s	1 s		378	
PID	576	A622	Output interruption detection level	0 to 590 Hz	0.01 Hz	0 Hz		378	
Ö	577	A623	Output interruption cancel level	900 to 1100%	0.1%	1000%	1	378	
	578 579	A400 A401	Auxiliary motor operation selection  Motor connection function	0 to 3 0 to 3	1	0		406 406	
	580	A402	selection MC switching interlock time	0 to 100 s	0.1 s	1 s		406	
	581	A403	Start waiting time	0 to 100 s	0.1 s	1 s		406	
	582	A404	Auxiliary motor connection-time deceleration time	0 to 3600 s, 9999	0.1 s	1 s		406	
_	583	A405	Auxiliary motor disconnection-time acceleration time	0 to 3600 s, 9999	0.1 s	1 s		406	
Pump function	584	A406	Auxiliary motor 1 starting frequency	0 to 590 Hz	0.01 Hz	60 Hz	50 Hz	406	
np fu	585	A407	Auxiliary motor 2 starting frequency	0 to 590 Hz	0.01 Hz	60 Hz	50 Hz	406	
Pun	586	A408	Auxiliary motor 3 starting frequency	0 to 590 Hz	0.01 Hz	60 Hz	50 Hz	406	
	587	A409	Auxiliary motor 1 stopping frequency	0 to 590 Hz	0.01 Hz	0 Hz	•	406	
	588	A410	Auxiliary motor 2 stopping frequency	0 to 590 Hz	0.01 Hz	0 Hz		406	
	589	A411	Auxiliary motor 3 stopping frequency	0 to 590 Hz	0.01 Hz	0 Hz		406	
	590	A412	Auxiliary motor start detection time	0 to 3600 s	0.1 s	5 s		406	
	591	A413	Auxiliary motor stop detection time	0 to 3600 s	0.1 s	5 s		406	

						Initial va	مبراد		_
Function	D.	Pr.	Nome	Cotting range	Minimum	IIIIIIai Va	iiue	Refer	Customer setting
ŭ.	Pr.	group	Name	Setting range	setting increments	FM	CA	to page	uste
	592	A300	Traverse function selection	0 to 2	1	0		373	0 "
u o	593	A301	Maximum amplitude amount	0 to 25%	0.1%	10%		373	
nncti	594	A302	Amplitude compensation amount	0 to 50%	0.1%	10%		373	
Traverse function	595	A303	Amplitude compensation amount	0 to 50%	0.1%	10%		373	
ave	596	A304	during acceleration  Amplitude acceleration time	0.1 to 3600 s	0.1 s	5 s		373	
F	597	A305	Amplitude acceleration time  Amplitude deceleration time	0.1 to 3600 s	0.1 s	5 s		373	
_	598 *13	H102	Undervoltage level	350 to 430 V, 9999	0.1 V	9999		234	
_	599	T721	X10 terminal input selection	0, 1	1	0 *10*12 1 *11		508	
la	600	H001	First free thermal reduction frequency 1	0 to 590 Hz, 9999	0.01 Hz	9999		225	
ern y	601	H002	First free thermal reduction ratio 1	1 to 100%	1%	100%		225	
Electronic thermal O/L relay	602	H003	First free thermal reduction frequency 2	0 to 590 Hz, 9999	0.01 Hz	9999		225	
ort O/I	603	H004	First free thermal reduction ratio 2	1 to 100%	1%	100%		225	
Elec	604	H005	First free thermal reduction frequency 3	0 to 590 Hz, 9999	0.01 Hz	9999		225	
_	606	T722	Power failure stop external signal input selection	0, 1	1	1		426	
_	607	H006	Motor permissible load level	110 to 250%	1%	150%		225	
_	608	H016	Second motor permissible load level	110 to 250%, 9999	1%	9999		225	
PID	609	A624	PID set point/deviation input selection	1 to 5	1	2		378	
F S	610	A625	PID measured value input selection	1 to 5, 101 to 105	1	3		378	
_	611	F003	Acceleration time at a restart	0 to 3600 s, 9999	0.1 s	9999		414, 420	
Speed smoothing control	653	G410	Speed smoothing control	0 to 200%	0.1%	0%		519	
Spinoc	654	G411	Speed smoothing cutoff frequency	0 to 120 Hz	0.01 Hz	20 Hz		519	
요드	655	M530	Analog remote output selection	0, 1, 10, 11	1	0		300	
Analog remote output function	656	M531	Analog remote output 1	800 to 1200%	0.1%	1000%		300	
fun	657	M532	Analog remote output 2	800 to 1200%	0.1%	1000%		300	
alog	658	M533	Analog remote output 3	800 to 1200%	0.1%	1000%		300	
ort S	659	M534	Analog remote output 4	800 to 1200%	0.1%	1000%		300	
netic ration	660	G130	Increased magnetic excitation deceleration operation selection	0, 1	1	0		517	
Increased magnetic excitation deceleration	661	G131	Magnetic excitation increase rate	0 to 40%, 9999	0.1%	9999		517	
Incre	662	G132	Increased magnetic excitation current level	0 to 300%	0.1%	100%		517	
_	663	M060	Control circuit temperature signal output level	0 to 100°C	1°C	0°C		304	
_	665	G125	Regeneration avoidance frequency gain	0 to 200%	0.1%	100%		514	
_	668	A786	Power failure stop frequency gain	0 to 200%	0.1%	100%		426	
_	673	G060	SF-PR slip amount adjustment operation selection	2, 4, 6, 9999	1	9999		502	
_	674	G061	SF-PR slip amount adjustment gain	0 to 500%	0.1%	100%		502	
_	684	C000	Tuning data unit switchover	0, 1	1	0		341,	
	304	2000	ranning data dilit Switchover	V, 1				351	

_					National Control	Initial value	D.C.	a n
Function	Pr.	Pr. group	Name	Setting range	Minimum setting increments	FM CA	Refer to page	Customer setting
Φ	686	E712	Maintenance timer 2	0 (1 to 9998)	1	0	184	
Maintenance	687	E713	Maintenance timer 2 warning output set time	0 to 9998, 9999	1	9999	184	
l te	688	E714	Maintenance timer 3	0 (1 to 9998)	1	0	184	
Mair	689	E715	Maintenance timer 3 warning output set time	0 to 9998, 9999	1	9999	184	
_	692	H011	Second free thermal reduction frequency 1	0 to 590 Hz, 9999	0.01 Hz	9999	225	
erma	693	H012	Second free thermal reduction ratio	1 to 100%	1%	100%	225	
ronic the O/L relay	694	H013	Second free thermal reduction frequency 2	0 to 590 Hz, 9999	0.01 Hz	9999	225	
Electronic thermal O/L relay	695	H014	Second free thermal reduction ratio	1 to 100%	1%	100%	225	
ū	696	H015	Second free thermal reduction frequency 3	0 to 590 Hz, 9999	0.01 Hz	9999	225	
_	699	T740	Input terminal filter	5 to 50 ms, 9999	1 ms	9999	329	
	702	C106	Maximum motor frequency	0 to 400 Hz, 9999	0.01 Hz	9999	351	
	706	C130	Induced voltage constant (phi f)	0 to 5000 mV/(rad/s), 9999	0.1 mV/ (rad/s)	9999	351	
र्	707	C107	Motor inertia (integer)	10 to 999, 9999	1	9999	351	
tan	711	C131	Motor Ld decay ratio	0 to 100%, 9999	0.1%	9999	351	
ns	712	C132	Motor Lq decay ratio	0 to 100%, 9999	0.1%	9999	351	
Motor constants	717	C182	Starting resistance tuning compensation	0 to 200%, 9999	0.1%	9999	351	
Mo	721	C185	Starting magnetic pole position detection pulse width	0 to 6000 μs, 10000 to 16000 μs, 9999	1 μs	9999	351	
	724	C108	Motor inertia (exponent)	0 to 7, 9999	1	9999	351	
	725	C133	Motor protection current level	100 to 500%, 9999	0.1%	9999	351	
Ġ.	726	N050	Auto Baudrate/Max Master	0 to 255	1	255	480	
S/I	727	N051	Max Info Frames	1 to 255	1	1	480	
BACnet MS/TP protocol	728	N052	Device instance number (Upper 3 digits)	0 to 419 (0 to 418)	1	0	480	
BACr	729	N053	Device instance number (Lower 4 digits)	0 to 9999 (0 to 4302)	1	0	480	
	738	C230	Second motor induced voltage constant (phi f)	0 to 5000 mV/(rad/s), 9999	0.1 mV/ (rad/s)	9999	351	
-	739	C231	Second motor Ld decay ratio	0 to 100%, 9999	0.1%	9999	351	
ဟ	740	C232	Second motor Lq decay ratio	0 to 100%, 9999	0.1%	9999	351	
stant	741	C282	Second starting resistance tuning compensation	0 to 200%, 9999	0.1%	9999	351	
Motor constants	742	C285	Second motor magnetic pole detection pulse width	0 to 6000 μs, 10000 to 16000 μs, 9999	1 μs	9999	351	
otc	743	C206	Second motor maximum frequency	0 to 400 Hz, 9999	0.01 Hz	9999	351	
Σ	744	C207	Second motor inertia (integer)	10 to 999, 9999	1	9999	351	
	745	C208	Second motor inertia (exponent)	0 to 7, 9999	1	9999	351	
	746	C233	Second motor protection current level	100 to 500%, 9999	0.1%	9999	351	
trol	753	A650	Second PID action selection	0, 10, 11, 20, 21, 50, 51, 60, 61, 70, 71, 80, 81, 90, 91, 100, 101, 1000, 1001, 1011, 2000, 2001, 2010, 2011	1	0	378	
PID control	754	A652	Second PID control automatic switchover frequency	0 to 590 Hz, 9999	0.01 Hz	9999	378	
PIC	755	A651	Second PID action set point	0 to 100%, 9999	0.01%	9999	378	
	756	A653	Second PID proportional band	0.1 to 1000%, 9999	0.1%	100%	378	
	757	A654	Second PID integral time	0.1 to 3600 s, 9999	0.1 s	1 s	378	
	758	A655	Second PID differential time	0.01 to 10 s, 9999	0.01 s	9999	378	
	759	A600	PID unit selection	0 to 43, 9999	1	9999	399	
			1	,	l	l		

E					Minimum	Initial v	alue	Refer	ner g
Function	Pr.	Pr.	Name	Setting range	setting			to	Customer setting
ᇤ		group		3 . 3	increments	FM	CA	page	Sus
_	760	A616	Dro charge fault calestian	0, 1	1	0		402	)
_	761	A617	Pre-charge fault selection  Pre-charge ending level	0 to 100%, 9999	0.1%	9999		402	
pre-charge function	762	A618	Pre-charge ending time	0 to 3600 s, 9999	0.1 % 0.1 s	9999		402	
nct	763	A619	Pre-charge upper detection level	0 to 100%, 9999	0.1%	9999		402	
) i	764	A620	Pre-charge time limit	0 to 3600 s, 9999	0.1 % 0.1 s	9999		402	
Ę.	765	A656	Second pre-charge fault selection	0, 1	1	0		402	
cha	766	A657	Second pre-charge ending level	0 to 100%, 9999	0.1%	9999		402	
ē	767	A658	Second pre-charge ending time	0 to 3600 s, 9999	0.1 x	9999		402	
d C			Second pre-charge upper detection	·					
PD	768	A659	level	0 to 100%, 9999	0.1%	9999		402	
	769	A660	Second pre-charge time limit	0 to 3600 s, 9999	0.1 s	9999		402	
	774	M101	Operation panel monitor selection 1	1 to 3, 5 to 14,	1	9999		263	
5 5				17, 18, 20, 23 to 25,					
Monitor function	775	M102	Operation panel monitor selection 2	34, 38, 40 to 45,	1	9999		263	
M L L	776	M402	Operation panel monitor selection 3	50 to 57, 61, 62, 64, 67, 68, 81 to 96, 98,	1	0000		262	
_	776	M103	Operation panel monitor selection 3	100, 9999	1	9999		263	
		A681	4 mA input fault operation						
_	777	T053	frequency	0 to 590 Hz, 9999	0.01 Hz	9999		325	
	_	A682							
_	778	T054	4 mA input check filter	0 to 10 s	0.01 s	0 s		325	
	7-0		Operation frequency during	0.1. 500.11. 0000	0.041:	0000		446	
_	779	N014	communication error	0 to 590 Hz, 9999	0.01 Hz	9999		446	
	791	F070	Acceleration time in low-speed	0 to 3600 s, 9999	0.1 s	9999		187	
	731	1070	range	0 10 3000 8, 9999	0.13	3333		107	
_	792	F071	Deceleration time in low-speed	0 to 3600 s, 9999	0.1 s	9999		187	
			range	·					
_	799	M520	Pulse increment setting for output power	0.1, 1, 10, 100, 1000 kWh	0.1 kWh	1 kWh		303	
_	800	G200	Control method selection	9, 20	1	20		143	
	820	G211	Speed control P gain 1	0 to 1000%	1%	25%		154	
	821	G212	Speed control integral time 1	0 to 20 s	0.001 s	0.333 s		154	
	822	T003	Speed setting filter 1	0 to 5 s, 9999	0.001 s	9999		313	
			Torque control P gain 1 (current						
o	824	G213	loop proportional gain)	0 to 500%	1%	50%		154	
Adjustment functi	825	G214	Torque control integral time 1	0 to 500 ms	0.1 ms	40 ms		154	
Ē			(current loop integral time)						
ent	827	G216	-	0 to 0.1 s	0.001 s	0 s		158	
Ĕ	828	G224			1	1			
sní	830	G311	Speed control P gain 2	0 to 1000%, 9999	1%	9999		154	
Ad	831	G312	-	0 to 20 s, 9999	0.001 s	9999		154	
	832	T005	Speed setting filter 2	0 to 5 s, 9999	0.001 s	9999		313	
	834	G313	-	0 to 500%, 9999	1%	9999		154	
	835	G314	Torque control integral time 2	0 to 500 ms, 9999	0.1 ms	9999		154	
	837	G316	Torque detection filter 2	0 to 0.1 s, 9999	0.001 s	9999		158	
L C	849	T007	Analog input offset adjustment	0 to 200%	0.1%	100%		313	
Additional function	858	T040	Terminal 4 function assignment	0, 4, 9999	1	0		248,	
Ę.			<u> </u>	· · ·				310	
<u>a</u>	859	C126	Torque current/Rated PM motor current	0 to 500 A, 9999 *2 0 to 3600 A, 9999 *3	0.01 A *2 0.1 A *3	9999		341, 351	
io			Second motor torque current/Rated	0 to 500 A, 9999 *3	0.1 A *3 0.01 A *2			341,	
ldit	860	C226	PM motor current	0 to 3600 A, 9999 *3	0.01 A *2	9999		351	
0	864	M470	Torque detection	0 to 400%	0.1%	150%		298	
⋖		<del></del>						-	
	866	M042	Torque monitoring reference	0 to 400%	0.1%	150%		273	
Indication function	866								
	866 867	M321	AM output filter	0 to 5 s	0.01 s	0.01 s		279	
Indication function	866								
Indication function	866 867	M321	AM output filter	0 to 5 s	0.01 s	0.01 s	0.02 s	279 248,	

5					Minimum	Initial	value	Refer	er G
Function	Pr.	Pr. group	Name	Setting range	setting increments	FM	CA	to page	Customer setting
_	870	M440	Speed detection hysteresis	0 to 5 Hz	0.01 Hz	0 Hz		294	
Protective Functions	872 *12	H201	Input phase loss protection selection	0, 1	1	0		235	
Prote Func	874	H730	OLT level setting	0 to 400%	0.1%	120%	110%	248	
ance	882	G120	Regeneration avoidance operation selection	0 to 2	1	0		514	
Regeneration avoidance function	883	G121	Regeneration avoidance operation level	300 to 800 V	0.1V	DC380 DC760		514	
ation ave	884	G122	Regeneration avoidance at deceleration detection sensitivity	0 to 5	1	0		514	
enera	885	G123	Regeneration avoidance compensation frequency limit value	0 to 590 Hz, 9999	0.01 Hz	6 Hz		514	
Reg	886	G124	Regeneration avoidance voltage gain	0 to 200%	0.1%	100%		514	
Free parameters	888	E420	Free parameter 1	0 to 9999	1	9999		173	
Fr	889	E421	Free parameter 2	0 to 9999	1	9999		173	
	891	M023	Cumulative power monitor digit shifted times	0 to 4, 9999	1	9999		263, 283	
	892	M200	Load factor	30 to 150%	0.1%	100%		283	
ō	893	M201	Energy saving monitor reference	0.1 to 55 kW *2	0.01 kW *2	Rated i		283	
oni			(motor capacity)	0 to 3600 kW *3	0.1 kW *3	capacit	у		
Energy saving monitor	894	M202	Control selection during commercial power-supply operation	0 to 3	1	0		283	
sav	895	M203	Power saving rate reference value	0, 1, 9999	1	9999		283	
g	896	M204	Power unit cost	0 to 500, 9999	0.01	9999		283	
ner	897	M205	Power saving monitor average time	0 to 1000 h, 9999	1 h	9999		283	
Ш	898	M206	Power saving cumulative monitor clear	0, 1, 10, 9999	1	9999		283	
	899	M207	Operation time rate (estimated value)	0 to 100%, 9999	0.1%	9999		283	

_						Initial	value		
Function	Pr.	Pr. group	Name	Setting range	Minimum setting increments	FM	CA	Refer to page	<b>Customer</b> setting
	C0 (900) *9	M310	FM/CA terminal calibration	-	_	_		279	
	C1 (901) *9	M320	AM terminal calibration	_	_	_		279	
	C2 (902) *9	T200	Terminal 2 frequency setting bias frequency	0 to 590 Hz	0.01 Hz	0 Hz		314	
	C3 (902) *9	T201	Terminal 2 frequency setting bias	0 to 300%	0.1%	0%		314	
	125 (903) *9	T202	Terminal 2 frequency setting gain frequency	0 to 590 Hz	0.01 Hz	60 Hz	50 Hz	314	
	C4 (903) *9	T203	Terminal 2 frequency setting gain	0 to 300%	0.1%	100%		314	
	C5 (904)	T400	Terminal 4 frequency setting bias frequency	0 to 590 Hz	0.01 Hz	0 Hz		314	
v	C6 (904)	T401	Terminal 4 frequency setting bias	0 to 300%	0.1%	20%	Γ	314	
Calibration parameters	126 (905) *9	T402	Terminal 4 frequency setting gain frequency	0 to 590 Hz	0.01 Hz	60 Hz	50 Hz	314	
tion par	C7 (905)	T403	Terminal 4 frequency setting gain	0 to 300%	0.1%	100%		314	
Calibra	C12 (917) *9	T100	Terminal 1 bias frequency (speed)	0 to 590 Hz	0.01 Hz	0 Hz		314	
	C13 (917) *9	T101	Terminal 1 bias (speed)	0 to 300%	0.1%	0%		314	
	C14 (918) *9	T102	Terminal 1 gain frequency (speed)	0 to 590 Hz	0.01 Hz	60 Hz	50 Hz	314	
	C15 (918)	T103	Terminal 1 gain (speed)	0 to 300%	0.1%	100%		314	
	C16 (919) *9	T110	Terminal 1 bias command (torque)	0 to 400%	0.1%	0%		320	
	C17 (919) *9	T111	Terminal 1 bias (torque)	0 to 300%	0.1%	0%		320	
	C18 (920) *9	T112	Terminal 1 gain command (torque)	0 to 400%	0.1%	150%		320	
	C19 (920) *9	T113	Terminal 1 gain (torque)	0 to 300%	0.1%	100%		320	
	C8 (930) *9	M330	Current output bias signal	0 to 100%	0.1%	_		279	

r.					Minimum	Initial	value	Refer	ler g
Function	Pr.	Pr. group	Name	Setting range	setting increments	FM	CA	to page	Customer setting
	C9 (930) *9	M331	Current output bias current	0 to 100%	0.1%	_	0%	279	
	C10 (931) *9	M332	Current output gain signal	0 to 100%	0.1%	_	100%	279	
	C11 (931) *9	M333	Current output gain current	0 to 100%	0.1%	_	100%	279	
10	C38 (932) *9	T410	Terminal 4 bias command (torque)	0 to 400%	0.1%	0%		320	
ameters	C39 (932)	T411	Terminal 4 bias (torque)	0 to 300%	0.1%	20%		320	
Calibration parameters	C40 (933)	T412	Terminal 4 gain command (torque)	0 to 400%	0.1%	150%		320	
Calibra	C41 (933) *9	T413	Terminal 4 gain (torque)	0 to 300%	0.1%	100%		320	
	C42 (934) *9	A630	PID display bias coefficient	0 to 500, 9999	0.01	9999		399	
	C43 (934)	A631	PID display bias analog value	0 to 300%	0.1%	20%		399	
	C44 (935)	A632	PID display gain coefficient	0 to 500, 9999	0.01	9999		399	
	C45 (935) *9	A633	PID display gain analog value	0 to 300%	0.1%	100%		399	
_	977	E302	Input voltage mode selection	0, 1	1	0		168	
_	989	E490	Parameter copy alarm release	10 *2 100 *3	1	10 *2		521	
<b>D</b>	990	E104	PU buzzer control	0, 1	1	1		164	
PU	991	E105	PU contrast adjustment	0 to 63	1	58		165	
Monitor function	992	M104	Operation panel setting dial push monitor selection	0 to 3, 5 to 14, 17, 18, 20, 23 to 25, 34, 38, 40 to 45, 50 to 57, 61, 62, 64, 67, 68, 81 to 96, 98, 100	1	0		263	
_	997	H103	Fault initiation	0 to 255, 9999	1	9999		235	
_	998	E430	PM parameter initialization Simple	0, 12, 112, 8009, 8109, 9009, 9109	1	0		149	
_	999	E431	Automatic parameter setting Simple	1, 2, 10, 11, 12, 13, 20, 21, 9999	1	9999		173	
_	1000	E108	Parameter for manufacturer setting.	Do not set.	1	ı		1	
_	1002	C150	Lq tuning target current adjustment coefficient	50 to 150%, 9999	0.1%	9999		351	
A C	1006	E020	Clock (year)	2000 to 2099	1	2000		160	
Clock function	1007	E021	Clock (month, day)	1/1 to 12/31	1	101		160	
ပည်	1008	E022	Clock (hour, minute)	0:00 to 23:59	1	0		160	
_	1013 *12	H323	Emergency drive running speed after retry reset	0 to 590 Hz	0.01 Hz	1 1		238	
_	1015	A607	Integral stop selection at limited frequency	0, 1, 10, 11	1	0		378	
_	1016	H021	PTC thermistor protection detection time	0 to 60 s	1 s	0		225	

г		i
L	_	1

Function	Pr.	Pr. group	Name		Minimum	Initial value		Refer	e G
				Setting range	setting increments	FM	CA	to page	Customer setting
	1020	A900	Trace operation selection	0 to 4	1	0		433	
	1021	A901	Trace mode selection	0 to 2	1	0		433	
	1022	A902	Sampling cycle	0 to 9	1	2		433	
	1023	A903	Number of analog channels	1 to 8	1	4		433	
	1024	A904	Sampling auto start	0, 1	1	0		433	
	1025	A905	Trigger mode selection	0 to 4	1	0		433	
	1026	A906	Number of sampling before trigger	0 to 100%	1%	90%		433	
	1027	A910	Analog source selection (1ch)			201		433	
	1028	A911	Analog source selection (2ch)	1 to 3, 5 to 14,		202		433	
	1029	A912	Analog source selection (3ch)	17, 18, 20, 23, 24, 34,		203		433	
	1030	A913	Analog source selection (4ch)	40 to 42, 52 to 54, 61,		204		433	
	1031	A914	Analog source selection (5ch)	62, 64, 67, 68, 81 to 96, 98,	3, 1		205		
tion	1032	A915	Analog source selection (6ch)	201 to 213,		206		433	
Trace function	1033	A916	Analog source selection (7ch)	230 to 232, 237, 238		207		433	
	1034	A917	Analog source selection (8ch)	]		208		433	
	1035	A918	Analog trigger channel	1 to 8	1	1		433	
	1036	A919	Analog trigger operation selection	0, 1	1	0		433	
	1037	A920	Analog trigger level	600 to 1400	1	1000		433	
	1038	A930	Digital source selection (1ch)			1		433	
	1039	A931	Digital source selection (2ch)			2		433	
	1040	A932	Digital source selection (3ch)		1	3		433	
	1041	A933	Digital source selection (4ch)	4.4- 055		4		433	
	1042	A934	Digital source selection (5ch)	1 to 255		5		433	
	1043	A935	Digital source selection (6ch)			6		433	
	1044	A936	Digital source selection (7ch)			7		433	
	1045	A937	Digital source selection (8ch)	7		8		433	
	1046	A938	Digital trigger channel	1 to 8	1	1		433	
	1047	A939	Digital trigger operation selection	0, 1	1	0		433	
_	1048	E106	Display-off waiting time	0 to 60 min	1 min	0		165	
_	1049	E110	USB host reset	0, 1	1	0		540	
or	1106	M050	Torque monitor filter	0 to 5 s, 9999	0.01 s	9999		263	
Monitor function	1107	M051	Running speed monitor filter	0 to 5 s, 9999	0.01 s	9999		263	
Mo fun	1108	M052	Excitation current monitor filter	0 to 5 s, 9999	0.01 s	9999		263	

						Initial	alue		_		
Function	Pr.	Pr. group	Name		Minimum	Initial value		Refer	ome		
				Setting range	setting increments	FM	CA	to page	<b>Customer</b> setting		
	1132	A626	Pre-charge change increment amount	0 to 100%, 9999	0.01%	9999		402			
	1133	A666	Second pre-charge change increment amount	0 to 100%, 9999	0.01%	9999		402			
	1134	A605	Parameter for manufacturer setting. Do	not not							
	1135	A606	rarameter for manufacturer setting. Do	not set.							
	1136	A670	Second PID display bias coefficient	0 to 500, 9999	0.01	9999		399			
	1137	A671	Second PID display bias analog value	0 to 300%	0.1%	20%		399			
	1138	A672	Second PID display gain coefficient	0 to 500, 9999	0.01	9999		399			
_	1139	A673	Second PID display gain analog value	0 to 300%	0.1%	100%		399			
PID control	1140	A664	Second PID set point/deviation input selection	1 to 5	1	2		378			
PID c	1141	A665	Second PID measured value input selection	1 to 5, 101 to 105	1	3		378			
	1142	A640	Second PID unit selection	0 to 43, 9999	1	9999		378			
	1143	A641	Second PID upper limit	0 to 100%, 9999	0.1%	9999		378			
	1144	A642	Second PID lower limit	0 to 100%, 9999	0.1%	9999		378			
	1145	A643	Second PID deviation limit	0 to 100%, 9999	0.1%	9999		378			
	1146	A644	Second PID signal operation selection	0 to 3, 10 to 13	1	0		378			
	1147	A661	Second output interruption detection time	0 to 3600 s, 9999	0.1 s	1		378			
	1148	A662	Second output interruption detection level	0 to 590 Hz	0.01 Hz	0 Hz		378			
	1149	A663	Second output interruption cancel level	900 to 1100%	0.1%	1000%		378			
PLC function	1150 to 1199	A810 to A859	PLC function user parameters 1 to 50	0 to 65535	1	0		431			
	1211	A690	PID gain tuning timeout time	1 to 9999 s	1 s	100 s		394			
	1212	A691	Step manipulated amount	900 to 1100%	0.1%	1000%		394			
	1213	A692	Step responding sampling cycle	0.01 to 600 s	0.01 s	1 s		394			
ing	1214	A693	Timeout time after the maximum slope	1 to 9999 s	1 s	10 s		394			
PID gain tuning	1215	A694	Limit cycle output upper limit	900 to 1100%	0.1%	1100%		394			
	1216	A695	Limit cycle output lower limit	900 to 1100%	0.1%	1000%		394			
	1217	A696	Limit cycle hysteresis	0.1 to 10%	0.1%	1%		394			
	1218	A697	PID gain tuning setting	0, 100 to 102, 111, 112, 121, 122, 200 to 202, 211, 212, 221, 222	1	0		394			
	1219	A698	PID gain tuning start/status	(0), 1, 8, (9, 90 to 96)	1	0		394			
_	1300 to 1343, 1350 to	N500 to N543, N550 to	Communication option parameters. For details, refer to the Instruction Manual of the option.								
	1359	N559									

_						Initial value			<u> </u>
Function	Pr.	Pr. group	Name	Setting range	Minimum setting increments	FM	CA	Refer to page	<b>Customer</b> setting
PID gain tuning	1460	A683	PID multistage set point 1	0 to 100%, 9999	0.01%	9999		378	
	1461	A684	PID multistage set point 2	0 to 100%, 9999	0.01%	9999		378	
	1462	A685	PID multistage set point 3	0 to 100%, 9999	0.01%	9999		378	
	1463	A686	PID multistage set point 4	0 to 100%, 9999	0.01%	9999		378	
	1464	A687	PID multistage set point 5	0 to 100%, 9999	0.01%	9999		378	
	1465	A688	PID multistage set point 6	0 to 100%, 9999	0.01%	9999		378	
	1466	A689	PID multistage set point 7	0 to 100%, 9999	0.01%	9999		378	
	1469	A420	Number of cleaning times monitor	0 to 255	1	0		375	
	1470	A421	Number of cleaning times setting	0 to 255	1	0		375	
	1471	A422	Cleaning trigger selection	0 to 15	1	0		375	
	1472	A423	Cleaning reverse rotation frequency	0 to 590 Hz	0.01 Hz	30 Hz		375	
lg.	1473	A424	Cleaning reverse rotation operation time	0 to 3600 s	0.1 s	5 s		375	
Cleaning	1474	A425	Cleaning forward rotation frequency	0 to 590 Hz, 9999	0.01 Hz	9999		375	
O	1475	A426	Cleaning forward rotation operation time	0 to 3600 s, 9999	0.1 s	9999		375	
	1476	A427	Cleaning stop time	0 to 3600 s	0.1 s	5 s		375	
	1477	A428	Cleaning acceleration time	0 to 3600 s, 9999	0.1 s	9999		375	
	1478	A429	Cleaning deceleration time	0 to 3600 s, 9999	0.1 s	9999		375	
	1479	A430	Cleaning time trigger	0 to 6000 h	0.1 h	0 h		375	
	1480	H520	Load characteristics measurement mode	0, 1 (2 to 5, 81 to 85)	1	0		255	
	1481	H521	Load characteristics load reference	0 to 400%, 8888, 9999	0.1%	9999		255	
ion	1482	H522	Load characteristics load reference	0 to 400%, 8888, 9999	0.1%	9999		255	
fault detection	1483	H523	Load characteristics load reference	0 to 400%, 8888, 9999	0.1%	9999		255	
ult d	1484	H524	Load characteristics load reference 4	0 to 400%, 8888, 9999	0.1%	9999		255	
	1485	H525	Load characteristics load reference 5	0 to 400%, 8888, 9999	0.1%	9999		255	
terist	1486	H526	Load characteristics maximum frequency	0 to 590 Hz	0.01 Hz	60 Hz	50 Hz	255	
Load characteristics	1487	H527	Load characteristics minimum frequency	0 to 590 Hz	0.01 Hz	6 Hz		255	
	1488	H530	Upper limit warning detection width	0 to 400%, 9999	0.1%	20%		255	
	1489	H531	Lower limit warning detection width	0 to 400%, 9999	0.1%	20%		255	
	1490	H532	Upper limit fault detection width	0 to 400%, 9999	0.1%	9999		255	
	1491	H533	Lower limit fault detection width	0 to 400%, 9999	0.1%	9999		255	
	1492	H534	Load status detection signal delay time / load reference measurement waiting time	0 to 60 s	0.1 s	1 s		255	
ers	Pr.C	LR	Parameter clear	(0), 1	1	0		520	
Clear parameters	ALL.CL		All parameter clear	(0), 1	1	0		520	
par	Err.	CL	Fault history clear	(0), 1	1	0		531	

#### **Parameter List**

#### Parameter list (by parameter number)

۶	Ę					Minimum	Initial	value	/alue Refer	
Pr.	Pr.	Pr. group	Name	Setting range	setting increments	FM	CA	to page	Customer setting	
-	-	Pr.C	PY	Parameter copy	(0), 1 to 3	1	0		521	
_	-	Pr.C	HG	Initial value change list	_	1	0		527	
_	_	IP	М	IPM initialization	0, 12	1	0		149	
_	_	AU.	ТО	Automatic parameter setting	_	_	_		173	
_	_	Pr.N	ИD	Group parameter setting	(0), 1, 2	1	0		133	

- Differ according to capacities.
  6%: FR-F820-00046(0.75K), FR-F840-00023(0.75K)
  4%: FR-F820-00077(1.5K) to FR-F820-00167(3.7K), FR-F840-00038(1.5K) to FR-F840-00083(3.7K)
  - 3%: FR-F820-00250(5.5K), FR-F820-00340(7.5K), FR-F840-00126(5.5K), FR-F840-00170(7.5K) 2%: FR-F820-00490(11K) to FR-F820-01540(37K), FR-F840-00250(11K) to FR-F840-00770(37K) 1.5%: FR-F820-01870(45K), FR-F820-02330(55K), FR-F840-00930(45K), FR-F840-01160(55K)

  - 1%: FR-F820-03160(75K) or higher, FR-F840-01800(75K) or higher
- The setting range or initial value for the FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower. The setting range or initial value for the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.
- The initial value for the FR-F820-00340(7.5K) or lower and FR-F840-00170(7.5K) or lower.
- The initial value for the FR-F820-00490(11K) or higher and FR-F840-00250(11K) or higher. Differ according to capacities.
- - 4%: FR-F820-00340(7.5K) or lower, FR-F840-00170(7.5K) or lower
  - 2%: FR-F820-00490(11K) to FR-F820-02330(55K), FR-F840-00250(11K) to FR-F840-01160(55K) 1%: FR-F820-03160(75K) or higher, FR-F840-01800(75K) or higher
- The value for the 200 V class.
- The value for the 400 V class.

  The parameter number in parentheses is the one for use with the LCD operation panel and the parameter unit.
- \*10 The setting range or initial value for the standard model.
- \*11 The setting range or initial value for the separated converter type.
  \*12 The setting is available for the standard model only.
- \*13 The setting is available only with the 400 V class.

#### 5.1.2 **Group parameter display**


Parameter numbers can be changed to grouped parameter numbers. Parameters are grouped by their functions. The related parameters can be set easily.

#### Changing to the grouped parameter numbers

Pr.MD setting value	Description
0	Default parameter display method
1	Parameter display by parameter number
2	Parameter display by function group

	Operation ————
1.	Screen at power-ON The monitor display appears.
	Parameter setting mode
2.	Press MODE to choose the parameter setting mode. (The parameter number read previously appears.)
	Selecting the parameter number
3.	Turn until (parameter display method) appears.
	Press SET . " [ " (initial value) will appear.
	Changing to the group parameter display
4.	Turn to change the set value to "," (group parameter display). Press SET to select the group parameter setting.
	" and "   flicker alternately after the setting is completed.

#### Changing parameter settings in the group parameter display



5

# Parameter list (by function group)

#### **♦** E: Environment setting parameters

Parameters that set the inverter operation characteristics.

	is that set	the inverter operation characteristics.	1
Pr. group	Pr.	Name	Refer to page
E000	168	Parameter for manufacturer setting. Do not	•
E001	169	Parameter for manufacturer setting. Do not	set.
E020	1006	Clock (year)	160
E021	1007	Clock (month, day)	160
E022	1008	Clock (hour, minute)	160
E023	269	Parameter for manufacturer setting. Do not	set.
E080	168	Parameter for manufacturer setting. Do not	
E081	169	Parameter for manufacturer setting. Do not	
E100	75	Reset selection	162
E101	75	Disconnected PU detection	162
E102	75	PU stop selection	162
E103	145	PU display language selection	164
E104	990	PU buzzer control	164
E105	991	PU contrast adjustment	165
E106	1048	Display-off waiting time	165
E107	75	Reset limit	162
E108	1000	Parameter for manufacturer setting. Do not	ı
E110	1049	USB host reset	540
E200	161	Frequency setting/key lock operation selection	166
E201	295	Frequency change increment amount setting	167
E300	30	Regenerative function selection	508
E301	570	Multiple rating setting	168
E302	977	Input voltage mode selection	168
E400	77	Parameter write selection	169
E410	296	Password lock level	171
E411	297	Password lock/unlock	171
E420	888	Free parameter 1	173
E421	889	Free parameter 2	173
E430	998	PM parameter initialization Simple	149
E431	999	Automatic parameter setting Simple	173
E440	160	User group read selection Simple	177
E441	172	User group registered display/batch clear	177
E442	173	User group registration	177
E443	174	User group clear	177
E490	989	Parameter copy alarm release	521
E600	72	PWM frequency selection	179
E601	240	Soft-PWM operation selection	179
E602	260	PWM frequency automatic switchover	179
E700	255	Life alarm status display	180
E701 E702	256 +2 257	Inrush current limit circuit life display	180 180
E702	257 258 *2	Control circuit capacitor life display  Main circuit capacitor life display	180
E703	250 ±2 259 ±2	Main circuit capacitor life display	180
E710	503	Maintenance timer 1	184
E710	503	Maintenance timer 1 warning output set	184
E712		time	
	686	Maintenance timer 2  Maintenance timer 2 warning output set	184
E713	687	time	184
<b>⊏</b> /14	688	Maintenance timer 3	184

Pr. group	Pr.	Name	Refer to page
E715	689	Maintenance timer 3 warning output set time	184
E720	555	Current average time	185
E721	556	Data output mask time	185
E722	557	Current average value monitor signal output reference current	185

#### ◆ F: Setting of acceleration/deceleration time and acceleration/deceleration pattern

Parameters that set the motor acceleration/deceleration characteristics.

Pr. group	Pr.	Name	Refer to page
F000	20	Acceleration/deceleration reference frequency	187
F001	21	Acceleration/deceleration time increments	187
F002	16	Jog acceleration/deceleration time	221
F003	611	Acceleration time at a restart	414, 420
F010	7	Acceleration time Simple	187
F011	8	Deceleration time Simple	187
F020	44	Second acceleration/deceleration time	187
F021	45	Second deceleration time	187
F022	147	Acceleration/deceleration time switching frequency	187
F040	1103	Deceleration time at emergency stop	187
F070	791	Acceleration time in low-speed range	187
F071	792	Deceleration time in low-speed range	187
F100	29	Acceleration/deceleration pattern selection	191
F101	59	Remote function selection	194
F102	13	Starting frequency	197, 198
F103	571	Holding time at a start	197
F200	140	Backlash acceleration stopping frequency	191
F201	141	Backlash acceleration stopping time	191
F202	142	Backlash deceleration stopping frequency	191
F203	143	Backlash deceleration stopping time	191

#### ◆ D: Operation command and frequency command

Parameters that specify the inverter's command source, and parameters that set the motor driving frequency and torque.

Pr. group	Pr.	Name	Refer to page
D000	79	Operation mode selection Simple	200, 209
D001	340	Communication startup mode selection	209
D010	338	Communication operation command source	210
D011	339	Communication speed command source	210
D012	550	NET mode operation command source selection	210
D013	551	PU mode operation command source selection	210
D020	78	Reverse rotation prevention selection	217
D100	291	Pulse train I/O selection	218, 273
D101	384	Input pulse division scaling factor	218
D110	385	Frequency for zero input pulse	218

Pr. group	Pr.	Name	Refer to page
D111	386	Frequency for maximum input pulse	218
D200	15	Jog frequency	221
D300	28	Multi-speed input compensation selection	222
D301	4	Multi-speed setting (high speed) Simple	222
D302	5	Multi-speed setting (middle speed) Simple	222
D303	6	Multi-speed setting (low speed) Simple	222
D304 to D307	24 to 27	Multi-speed setting (4 speed to 7 speed)	222
D308 to D315	232 to 239	Multi-speed setting (8 speed to 15 speed)	222

# ◆ H: Protective function parameter Parameters to protect the motor and the inverter.

Pr. group	Pr.	Name	Refer to page
H000	9	Electronic thermal O/L relay Simple	225, 341, 351
H001	600	First free thermal reduction frequency 1	225
H002	601	First free thermal reduction ratio 1	225
H003	602	First free thermal reduction frequency 2	225
H004	603	First free thermal reduction ratio 2	225
H005	604	First free thermal reduction frequency 3	225
H006	607	Motor permissible load level	225
H010	51	Second electronic thermal O/L relay	225, 341, 351
H011	692	Second free thermal reduction frequency 1	225
H012	693	Second free thermal reduction ratio 1	225
H013	694	Second free thermal reduction frequency 2	225
H014	695	Second free thermal reduction ratio 2	225
H015	696	Second free thermal reduction frequency 3	225
H016	608	Second motor permissible load level	225
H020	561	PTC thermistor protection level	225
H021	1016	PTC thermistor protection detection time	225
H100	244	Cooling fan operation selection	233
H101	249	Earth (ground) fault detection at start	234
H102	598	Undervoltage level	234
H103	997	Fault initiation	235
H200	251	Output phase loss protection selection	235
H201	872 *2	Input phase loss protection selection	235
H300	65	Retry selection	236
H301	67	Number of retries at fault occurrence	236
H302	68	Retry waiting time	236
H303	69	Retry count display erase	236
H320	<b>523</b> *2	Emergency drive mode selection	238
H321	<b>524</b> *2	Emergency drive running speed	238
H322	<b>515</b> *2	Emergency drive dedicated retry count	238
H323	1013 *2	Emergency drive running speed after retry reset	238
H324	<b>514 *</b> 2	Emergency drive dedicated waiting time	238
H400	1	Maximum frequency Simple	245
H401	2	Minimum frequency Simple	245

Pr. group	Pr.	Name	Refer to page
H402	18	High speed maximum frequency	245
H420	31	Frequency jump 1A	246
H421	32	Frequency jump 1B	246
H422	33	Frequency jump 2A	246
H423	34	Frequency jump 2B	246
H424	35	Frequency jump 3A	246
H425	36	Frequency jump 3B	246
H429	552	Frequency jump range	246
H500	22	Stall prevention operation level (Torque limit level)	248
H501	156	Stall prevention operation selection	248
H520	1480	Load characteristics measurement mode	255
H521	1481	Load characteristics load reference 1	255
H522	1482	Load characteristics load reference 2	255
H523	1483	Load characteristics load reference 3	255
H524	1484	Load characteristics load reference 4	255
H525	1485	Load characteristics load reference 5	255
H526	1486	Load characteristics maximum frequency	255
H527	1487	Load characteristics minimum frequency	255
H530	1488	Upper limit warning detection width	255
H531	1489	Lower limit warning detection width	255
H532	1490	Upper limit fault detection width	255
H533	1491	Lower limit fault detection width	255
H534	1492	Load status detection signal delay time / load reference measurement waiting time	255
H600	48	Second stall prevention operation level	248
H601	49	Second stall prevention operation frequency	248
H610	23	Stall prevention operation level compensation factor at double speed	248
H611	66	Stall prevention operation reduction starting frequency	248
H620	148	Stall prevention level at 0 V input	248
H621	149	Stall prevention level at 10 V input	248
H631	154	Voltage reduction selection during stall prevention operation	248
H730	874	OLT level setting	248
H800	374	Overspeed detection level	259

### ◆ M: Monitor display and monitor output signal

Parameters regarding the inverter's operating status. These parameters are used to set the monitors and output signals.

Pr. group	Pr.	Name	Refer to page
M000	37	Speed display	261
M001	505	Speed setting reference	261
M002	144	Speed setting switchover	261
M020	170	Watt-hour meter clear	263
M021	563	Energization time carrying-over times	263
M022	268	Monitor decimal digits selection	263
M023	891	Cumulative power monitor digit shifted times	263, 283
M030	171	Operation hour meter clear	263
M031	564	Operating time carrying-over times	263
M040	55	Frequency monitoring reference	273
M041	56	Current monitoring reference	273
M042	866	Torque monitoring reference	273
M043	241	Analog input display unit switchover	314
M044	290	Monitor negative output selection	263, 273
M050	1106	Torque monitor filter	263

Pr.	Pr.	Name	Refer
group			to page
M051 M052	1107 1108	Running speed monitor filter	263
		Excitation current monitor filter  Control circuit temperature signal	263
M060	663	output level	304
M100	52	Operation panel main monitor selection	263
M101	774	Operation panel monitor selection 1	263
M102	775	Operation panel monitor selection 2	263
M103	776	Operation panel monitor selection 3	263
M104	992	Operation panel setting dial push	263
		monitor selection	
M200	892	Load factor  Energy saving monitor reference (motor	283
M201	893	capacity)	283
M202	894	Control selection during commercial power-supply operation	283
M203	895	Power saving rate reference value	283
M204	896	Power unit cost	283
M205	897	Power saving monitor average time	283
M206	898	Power saving cumulative monitor clear	283
M207	899	Operation time rate (estimated value)	283
M300	54	FM/CA terminal function selection	273
M301	158	AM terminal function selection	273
	CO		
M310	(900)	FM/CA terminal calibration	279
	*1		
	C1		
M320	(901)	AM terminal calibration	279
	*1		
M321	867	AM output filter	279
	C8		
M330	(930)	Current output bias signal	279
	*1		
	C9		
M331	(930)	Current output bias current	279
	*1		
MAGGA	C10		070
M332	(931)	Current output gain signal	279
	*1 C11		
M333	(931)	Current output gain current	279
WISSS	, ,	Current output gain current	213
M334	*1 869	Current output filter	279
M400	190	RUN terminal function selection	288
M401	191	SU terminal function selection	288
M402	192	IPF terminal function selection	288
M403	193	OL terminal function selection	288
M404	194	FU terminal function selection	288
M405	195	ABC1 terminal function selection	288
M406	196	ABC2 terminal function selection	288
M430	157	OL signal output timer	248
M431	289	Inverter output terminal filter	288
		Output current detection signal	
M433	166	retention time	296
M440	870	Speed detection hysteresis	294
M441	41	Up-to-frequency sensitivity	294
M442	42	Output frequency detection	294
M443	43	Output frequency detection for reverse rotation	294
M444	50	Second output frequency detection	294
M460	150	Output current detection level	296
M461	151	Output current detection signal delay	
		time	296
M462	152	Zero current detection level	296

Pr. group	Pr.	Name	Refer to page
M463	153	Zero current detection time	296
M464	167	Output current detection operation selection	296
M470	864	Torque detection	298
M500	495	Remote output selection	298
M501	496	Remote output data 1	298
M502	497	Remote output data 2	298
M510	76	Fault code output selection	302
M520	799	Pulse increment setting for output power	303
M530	655	Analog remote output selection	300
M531	656	Analog remote output 1	300
M532	657	Analog remote output 2	300
M533	658	Analog remote output 3	300
M534	659	Analog remote output 4	300

◆ T: Multi-function input terminal parameters
Parameters for the input terminals where inverter commands are received through.

Pr. group	Pr.	Name	Refer to page
T000	73	Analog input selection	306, 311
T001	267	Terminal 4 input selection	306
T002	74	Input filter time constant	313
T003	822	Speed setting filter 1	313
T005	832	Speed setting filter 2	313
T007	849	Analog input offset adjustment	313
T010	868	Terminal 1 function assignment	248, 310
T021	242	Terminal 1 added compensation amount (terminal 2)	311
T022	125	Terminal 2 frequency setting gain frequency Simple	314
T040	858	Terminal 4 function assignment	248, 310
T041	243	Terminal 1 added compensation amount (terminal 4)	311
T042	126	Terminal 4 frequency setting gain frequency Simple	314
T050	252	Override bias	311
T051	253	Override gain	311
T052	573	4 mA input check selection	325
T053	777	4 mA input fault operation frequency	325
T054	778	4 mA input check filter	325
T100	C12 (917) *1	Terminal 1 bias frequency (speed)	314
T101	C13 (917) *1	Terminal 1 bias (speed)	314
T102	C14 (918) *1	Terminal 1 gain frequency (speed)	314
T103	C15 (918) *1	Terminal 1 gain (speed)	314
T110	C16 (919) *1	Terminal 1 bias command (torque)	320
T111	C17 (919) *1	Terminal 1 bias (torque)	320

	<b>.</b>	<u> </u>	
Pr. group	Pr.	Name	Refer to page
9.00.0	C18		to page
T112	(920)	Terminal 1 gain command (torque)	320
	*1		
	C19		
T113	(920)	Terminal 1 gain (torque)	320
	*1		
	C2		
T200	(902)	Terminal 2 frequency setting bias frequency	314
	*1	nequency	
	C3		
T201	(902)	Terminal 2 frequency setting bias	314
	*1		
	125	Terminal 2 frequency setting gain	
T202	(903)	frequency	314
	*1	. ,	
	C4		
T203	(903)	Terminal 2 frequency setting gain	314
	*1		
T 460	C5	Terminal 4 frequency setting bias	64:
T400	(904)	frequency	314
	*1		
T401	C6	Towning A fraguency action him	244
1401	(904) *1	Terminal 4 frequency setting bias	314
	126		
T402	(905)	Terminal 4 frequency setting gain	314
1402	*1	frequency	• • • • • • • • • • • • • • • • • • • •
	C7		
T403	(905)	Terminal 4 frequency setting gain	314
	*1	33.	
	C38		
T410	(932)	Terminal 4 bias command (torque)	320
	*1		
	C39		
T411	(932)	Terminal 4 bias (torque)	320
	*1		
	C40		
T412	(933)	Terminal 4 gain command (torque)	320
	*1		
T440	C41		000
T413	(933)	Terminal 4 gain (torque)	320
T700	*1 178	STF terminal function selection	220
T700 T701	178		329 329
		STR terminal function selection	
T702	180	RL terminal function selection	329
T703	181	RM terminal function selection	329
T704	182	RH terminal function selection	329
T705	183	RT terminal function selection	329
T706	184	AU terminal function selection	329
T707	185	JOG terminal function selection	329
T708	186	CS terminal function selection	329
T709	187	MRS terminal function selection	329
T710 T711	188	STOP terminal function selection	329
T720	189 17	RES terminal function selection	329 332
		MRS input selection	
T721	599	X10 terminal input selection  Power failure stop external signal input	508
T722	606	selection	426
T730	155	RT signal function validity condition	333
		selection	
T740	699	Input terminal filter	329

# ◆ C: Motor constant parameters Parameters for the applied motor setting.

Pr.	Pr.	Name	Refer
group	C0.4		to page 341,
C000	684	Tuning data unit switchover	351
C100	71	Applied motor	337, 341,
0100		Applied motor	351
0404			143,
C101	80	Motor capacity	341, 351
			143,
C102	81	Number of motor poles	341,
			351 225.
C103	9	Rated motor current Simple	341,
			351
C104	83	Rated motor voltage	143, 341,
0104	03	Rated motor voltage	351
			143,
C105	84	Rated motor frequency	341, 351
C106	702	Maximum motor frequency	351
C107	707	Motor inertia (integer)	351
C108	724	Motor inertia (exponent)	351
0440			341,
C110	96	Auto tuning setting/status	351, 422
C111	95	Online auto tuning selection	359
		-	341,
C120	90	Motor constant (R1)	351, 422
C121	91	Motor constant (R2)	341
		Motor constant (L1)/d-axis inductance	341,
C122	92	(Ld)	351
C123	93	Motor constant (L2)/q-axis inductance (Lq)	341, 351
C124	94	Motor constant (X)	341
C125	82	Motor excitation current	341
C126	859	Torque current/Rated PM motor current	341,
C130			351
C130	706 711	Induced voltage constant (phi f)  Motor Ld decay ratio	351 351
C132	712	Motor Lq decay ratio	351
C133	725	Motor protection current level	351
C150	1002	Lq tuning target current adjustment	351
		coefficient Starting resistance tuning	
C182	717	compensation	351
C185	721	Starting magnetic pole position detection pulse width	351
C200	450	Second applied motor	337
C201	453	Second motor capacity	341,
-201	,00		351
C202	454	Number of second motor poles	341, 351
			225,
C203	51	Rated second motor current	341, 351
0001	4=0		341.
C204	456	Rated second motor voltage	351
C205	457	Rated second motor frequency	341,
C206	743	Second motor maximum frequency	351 351
C207	744	Second motor inertia (integer)	351
C208	745	Second motor inertia (exponent)	351
	-	. , ,	·

Pr. group	Pr.	Name	Refer to page
C210	463	Second motor auto tuning setting/ status	341, 351, 422
C211	574	Second motor online auto tuning	359
C220	458	Second motor constant (R1)	341, 351, 422
C221	459	Second motor constant (R2)	341
C222	460	Second motor constant (L1) / d-axis inductance (Ld)	341, 351
C223	461	Second motor constant (L2) / q-axis inductance (Lq)	341, 351
C224	462	Second motor constant (X)	341
C225	455	Second motor excitation current	341
C226	860	Second motor torque current/Rated PM motor current	341, 351
C230	738	Second motor induced voltage constant (phi f)	351
C231	739	Second motor Ld decay ratio	351
C232	740	Second motor Lq decay ratio	351
C233	746	Second motor protection current level	351
C282	741	Second starting resistance tuning compensation	351
C285	742	Second motor magnetic pole detection pulse width	351

# ◆ A: Application parameters Parameters to set a specific application.

Pr. group	Pr.	Name	Refer to page
A000	135	Electronic bypass sequence selection	363
A001	136	MC switchover interlock time	363
A002	137	Start waiting time	363
A003	138	Bypass selection at a fault	363
A004	139	Automatic switchover frequency from inverter to bypass operation	363
A005	159	Automatic switchover frequency range from bypass to inverter operation	363
A006	248	Self power management selection	370
A007	254	Main circuit power OFF waiting time	370
A300	592	Traverse function selection	373
A301	593	Maximum amplitude amount	373
A302	594	Amplitude compensation amount during deceleration	373
A303	595	Amplitude compensation amount during acceleration	373
A304	596	Amplitude acceleration time	373
A305	597	Amplitude deceleration time	373
A400	578	Auxiliary motor operation selection	406
A401	579	Motor connection function selection	406
A402	580	MC switching interlock time	406
A403	581	Start waiting time	406
A404	582	Auxiliary motor connection-time deceleration time	406
A405	583	Auxiliary motor disconnection-time acceleration time	406
A406	584	Auxiliary motor 1 starting frequency	406
A407	585	Auxiliary motor 2 starting frequency	406
A408	586	Auxiliary motor 3 starting frequency	406
A409	587	Auxiliary motor 1 stopping frequency	406
A410	588	Auxiliary motor 2 stopping frequency	406
A411	589	Auxiliary motor 3 stopping frequency	406
A412	590	Auxiliary motor start detection time	406
A413	591	Auxiliary motor stop detection time	406
A420	1469	Number of cleaning times monitor	375
A421	1470	Number of cleaning times setting	375

Pr. group	Pr.	Name	Refer to page
A422	1471	Cleaning trigger selection	375
A423	1472	Cleaning reverse rotation frequency	375
A424	1473	Cleaning reverse rotation operation time	375
A425	1474	Cleaning forward rotation frequency	375
A426	1475	Cleaning forward rotation operation time	375
A427	1476	Cleaning stop time	375
A428	1477	Cleaning acceleration time	375
A429	1478	Cleaning deceleration time	375
A430	1479	Cleaning time trigger	375
A600	759	PID unit selection	399
A601	131	PID upper limit	378
A602	132	PID lower limit	378
A603	553	PID deviation limit	378
A604	554	PID signal operation selection	378
A605	1134		
A606	1135	Parameter for manufacturer setting. Do not	set.
A607	1015	Integral stop selection at limited frequency	378
A610	128	PID action selection	378
A611	133	PID action set point	378
A612	127	PID control automatic switchover frequency	378
A613	129	PID proportional band	378
A614	130	PID integral time	378
A615	134	PID differential time	378
A616	760	Pre-charge fault selection	402
A617	761	Pre-charge ending level	402
A618	762	Pre-charge ending time	402
A619	763	Pre-charge upper detection level	402
A620	764	Pre-charge time limit	402
A621	575	Output interruption detection time	378
A622	576	Output interruption detection level	378
A623	577	Output interruption cancel level	378
A624	609	PID set point/deviation input selection	378
A625	610	PID measured value input selection	378
A626	1132	Pre-charge change increment amount	402
A630	C42 (934) *1	PID display bias coefficient	399
A631	C43 (934) *1	PID display bias analog value	399
A632	C44 (935) *1	PID display gain coefficient	399
A633	C45 (935) *1	PID display gain analog value	399
A640	1142	Second PID unit selection	378
A641	1143	Second PID upper limit	378
A642	1144	Second PID lower limit	378
A643	1145	Second PID deviation limit	378
A644	1146	Second PID signal operation selection	378
A650	753	Second PID action selection	378
A651 A652	755 754	Second PID action set point Second PID control automatic	378 378
		switchover frequency	
A653	756	Second PID proportional band	378
A654	757	Second PID integral time	378

Pr.	D	Nama	Refer
group	Pr.	Name	to page
A655	758	Second PID differential time	378
A656	765	Second pre-charge fault selection	402
A657	766	Second pre-charge ending level	402
A658	767	Second pre-charge ending time	402
A659	768	Second pre-charge upper detection level	402
A660	769	Second pre-charge time limit	402
A661	1147	Second output interruption detection time	378
A662	1148	Second output interruption detection level	378
A663	1149	Second output interruption cancel level	378
A664	1140	Second PID set point/deviation input selection	378
A665	1141	Second PID measured value input selection	378
A666	1133	Second pre-charge change increment amount	402
A670	1136	Second PID display bias coefficient	399
A671	1137	Second PID display bias analog value	399
A672	1138	Second PID display gain coefficient	399
A673	1139	Second PID display gain analog value	399
A680	573	4 mA input check selection	325
A681	777	4 mA input fault operation frequency	325
A682	778	4 mA input check filter	325
A683	1460	PID multistage set point 1	378
A684	1461	PID multistage set point 2	378
A685	1462	PID multistage set point 3	378
A686	1463	PID multistage set point 4	378
A687	1464	PID multistage set point 5	378
A688	1465	PID multistage set point 6	378
A689	1466	PID multistage set point 7	378
A690	1211	PID gain tuning timeout time	394
A691	1212	Step manipulated amount	394
A692	1213	Step responding sampling cycle	394
A693	1214	Timeout time after the maximum slope	394
A694	1215	Limit cycle output upper limit	394
A695	1216	Limit cycle output lower limit	394
A696	1217	Limit cycle hysteresis	394
A697	1218	PID gain tuning setting	394
A698	1219	PID gain tuning start/status	394
7.000	.2.0		414.
A700	162	Automatic restart after instantaneous power failure selection	420, 422
A701	299	Rotation direction detection selection at restarting	414
A702	57	Restart coasting time	414, 420
A703	58	Restart cushion time	414
A704	163	First cushion time for restart	414
A705	164	First cushion voltage for restart	414
A710	165	Stall prevention operation level for restart	414
A711	298	Frequency search gain	422
A712	560	Second frequency search gain	422
A730	261	Power failure stop selection	426
A731	262	Subtracted frequency at deceleration start	426
A732	263	Subtraction starting frequency	426
A733	264	Power-failure deceleration time 1	426
A734	265	Power-failure deceleration time 2	426
A735	266	Power failure deceleration time switchover frequency	426
A785	294	UV avoidance voltage gain	426

Pr.	Pr.	Name	Refer
group A786	668	Power failure stop frequency gain	to page
A800	414	PLC function operation selection	431
A801	415	Inverter operation lock mode setting	431
A802	416	Pre-scale function selection	431
A803	417	Pre-scale setting value	431
A804	498	PLC function flash memory clear	431
A810	1150	DI O formation and a second day 50	404
to A859	to 1199	PLC function user parameters 1 to 50	431
A900	1020	Trace operation selection	433
A901	1021	Trace mode selection	433
A902	1022	Sampling cycle	433
A903	1023	Number of analog channels	433
A904	1024	Sampling auto start	433
A905	1025	Trigger mode selection	433
A906	1026	Number of sampling before trigger	433
A910	1027	Analog source selection (1ch)	433
A911	1028	Analog source selection (2ch)	433
A912	1029	Analog source selection (3ch)	433
A913	1030	Analog source selection (4ch)	433
A914	1031	Analog source selection (5ch)	433
A915	1032	Analog source selection (6ch)	433
A916	1033	Analog source selection (7ch)	433
A917	1034	Analog source selection (8ch)	433
A918	1035	Analog trigger channel	433
A919	1036	Analog trigger operation selection	433
A920	1037	Analog trigger level	433
A930	1038	Digital source selection (1ch)	433
A931	1039	Digital source selection (2ch)	433
A932	1040	Digital source selection (3ch)	433
A933	1041	Digital source selection (4ch)	433
A934	1042	Digital source selection (5ch)	433
A935	1043	Digital source selection (6ch)	433
A936	1044	Digital source selection (7ch)	433
A937	1045	Digital source selection (8ch)	433
A938	1046	Digital trigger channel	433
A939	1047	Digital trigger operation selection	433

# ♦ N: Operation via communication and its

Parameters for communication operation. These parameters set the communication specifications and operation.

Pr. group	Pr.	Name	Refer to page
N000	549	Protocol selection	446
N001	342	Communication EEPROM write selection	446
N002	539	Modbus-RTU communication check time interval	465
N013	502	Stop mode selection at communication error	446
N014	779	Operation frequency during communication error	446
N020	117	PU communication station number	449
N021	118	PU communication speed	449
N022	119	PU communication data length	449
N023	119	PU communication stop bit length	449

Pr. group	Pr.	Name	Refer to page
N024	120	PU communication parity check	449
N025	121	Number of PU communication retries	449
N026	122	PU communication check time interval	449
N027	123	PU communication waiting time setting	449
N028	124	PU communication CR/LF selection	449
N030	331	RS-485 communication station number	449
N031	332	RS-485 communication speed	449
N032	333	PU communication data length	449
N033	333	PU communication stop bit length	449
N034	334	RS-485 communication parity check selection	449
N035	335	RS-485 communication retry count	449
N036	336	RS-485 communication check time interval	449
N037	337	RS-485 communication waiting time setting	449
N038	341	RS-485 communication CR/LF selection	449
N040	547	USB communication station number	493
N041	548	USB communication check time interval	493
N050	726	Auto Baudrate/Max Master	480
N051	727	Max Info Frames	480
N052	728	Device instance number (Upper 3 digits)	480
N053	729	Device instance number (Lower 4 digits)	480
N054	390	% setting reference frequency	480
N080	343	Communication error count	465
N500	1300		
to	to	Communication entire personate	
N543, N550	1343, 1350	Communication option parameters.  For details, refer to the Instruction Manual or option.	f the
to	to	οριιστί.	
N559	1359		

#### **♦** G: Control Parameter

Parameters for motor control.

Pr. group	Pr.	Name	Refer to page
G000	0	Torque boost Simple	496
G001	3	Base frequency Simple	497
G002	19	Base frequency voltage	497
G003	14	Load pattern selection	499
G010	46	Second torque boost	496
G011	47	Second V/F (base frequency)	497
G030	60	Energy saving control selection	500
G040	100	V/F1 (first frequency)	501
G041	101	V/F1 (first frequency voltage)	501
G042	102	V/F2 (second frequency)	501
G043	103	V/F2 (second frequency voltage)	501
G044	104	V/F3 (third frequency)	501
G045	105	V/F3 (third frequency voltage)	501
G046	106	V/F4 (fourth frequency)	501
G047	107	V/F4 (fourth frequency voltage)	501
G048	108	V/F5 (fifth frequency)	501
G049	109	V/F5 (fifth frequency voltage)	501
G060	673	SF-PR slip amount adjustment operation selection	502
G061	674	SF-PR slip amount adjustment gain	502
G100	10	DC injection brake operation frequency	502
G101	11	DC injection brake operation time	502
G105	522	Output stop frequency	505
G106	250	Stop selection	507
G107	70	Parameter for manufacturer setting. Do not	set.

Pr. group	Pr.	Name	Refer to page
G110	12	DC injection brake operation voltage	502
G120	882	Regeneration avoidance operation selection	514
G121	883	Regeneration avoidance operation level	514
G122	884	Regeneration avoidance at deceleration detection sensitivity	514
G123	885	Regeneration avoidance compensation frequency limit value	514
G124	886	Regeneration avoidance voltage gain	514
G125	665	Regeneration avoidance frequency gain	514
G130	660	Increased magnetic excitation deceleration operation selection	517
G131	661	Magnetic excitation increase rate	517
G132	662	Increased magnetic excitation current level	517
G200	800	Control method selection	143
G203	245	Rated slip	518
G204	246	Slip compensation time constant	518
G205	247	Constant-power range slip compensation selection	518
G211	820	Speed control P gain 1	154
G212	821	Speed control integral time 1	154
G213	824	Torque control P gain 1 (current loop proportional gain)	154
G214	825	Torque control integral time 1 (current loop integral time)	154
G216	827	Torque detection filter 1	158
G224	828	Parameter for manufacturer setting. Do not	set.
G311	830	Speed control P gain 2	154
G312	831	Speed control integral time 2	154
G313	834	Torque control P gain 2	154
G314	835	Torque control integral time 2	154
G316	837	Torque detection filter 2	158
G410	653	Speed smoothing control	519
G411	654	Speed smoothing cutoff frequency	519
G932	89	Speed control gain (Advanced magnetic flux vector)	147
G942	569	Second motor speed control gain	147

The parameter number in parentheses is the one for use with the LCD operation panel and the parameter unit.

Setting can be made only for the standard model.

#### **5.2 Control method**

V/F control (initial setting), Advanced magnetic flux vector control, and PM motor control are available with this inverter.

#### ♦V/F control

• It controls the frequency and voltage so that the ratio of frequency (F) to voltage (V) is constant while changing the frequency.

#### Advanced magnetic flux vector control

• This control performs vector calculation and divide the inverter's output current into an excitation current and into a torque current. The frequency and the voltage are then compensated to flow the motor current that meets the load torque. This control methods improves the torque generation at a low speed. The output frequency is further compensated (slip compensation) to bring the actual motor speed closer to the commanded speed. This function is useful when the load fluctuates are severe.




- · Advanced magnetic flux vector control requires the following conditions. If the conditions are not satisfied, select V/F control. Otherwise, malfunctions such as insufficient torque, uneven rotation may
- For the motor capacity, the rated motor current should be equal to or less than the rated inverter current. (It must be 0.4 kW
  - Using a motor with the rated current substantially lower than the rated inverter current will cause torque ripples, etc. and degrade the speed and torque accuracies. As a reference, select the motor with the rated motor current that is about 40% or higher of the rated inverter current.
- The motor described in the table below is used.

Motor	Condition
Mitsubishi standard motor (SF-JR)	
Mitsubishi high-efficiency motor (SF-HR)	Offline auto tuning is not required
Mitsubishi constant-torque motor (SF-JRCA 4P, SF-HRCA)	
Mitsubishi high-performance energy-saving motor (SF-PR)	
Other motors (other manufacturers, SF-TH, etc.)	Offline auto tuning is required

- Single-motor operation (one motor to one inverter) is preformed.
- The wiring length from inverter to motor is 30 m or less. (When the wiring length exceeds 30 m, perform offline auto tuning in a wired state.)
- · A sine wave filter (MT-BSL/BSC) is not used.

#### ◆PM motor control

- · Highly efficient motor control and highly accurate motor speed control can be performed by using the inverter with a PM (permanent magnet embedded) motor, which is more efficient than an induction motor.
- The motor speed is calculated based on the output voltage and current from the inverter. It does not require a speed detector such as an encoder. The inverter drives the PM motor with the least required current when a load is applied in order to achieve the highest motor efficiency.
- · Performing the IPM parameter initialization makes the IPM motor MM-EFS or MM-THE4 ready for the PM motor control.





- The PM motor control requires the following conditions.
- · The motor used are described in the table below.

Motor	Condition
Mitsubishi IPM motor (MM-EFS, MM-THE4)	Offline auto tuning is not required
IPM motor (other than MM-EFS, MM-THE4), SPM motor	Offline auto tuning is required

- For the motor capacity, the rated motor current should be equal to or less than the rated inverter current. (It must be 0.4 kW or higher.)
- Using a motor with the rated current substantially lower than the rated inverter current will cause torque ripples, etc. and degrade the speed and torque accuracies. As a reference, select the motor with the rated motor current that is about 40% or higher of the rated inverter current.
- · Single-motor operation (one motor to one inverter) is preformed.
- The overall wiring length with the motor is 100 m or less. (Refer to page 44.) (Even with the IPM motor MM-EFS/MM-THE4, when the wiring length exceeds 30 m, perform offline auto tuning.)
- A surge voltage suppression filter (FR-ASF/FR-BMF) or sine wave filter (MT-BSL/BSC) is not used.

# 5.2.1 Changing the control method

Set the control method.

V/F control, Advanced magnetic flux vector control, and PM motor control are the control methods available for selection.

When using an IPM motor MM-EFS or MM-THE4, simply performing the IPM parameter initialization enables the PM motor control

• The PM motor test operation can be performed by setting Pr.800 Control method selection.

Pr.	Name	Initial value	Setting range	Description
71 C100	Applied motor	0*1	0 to 6, 13 to 16, 20, 23, 24, 40, 43, 44, 50, 53, 54, 70, 73, 74, 210, 213, 214, 8090, 8093, 8094, 9090, 9093, 9094	By selecting a standard motor or constant-torque motor, the thermal characteristic and motor constant of each motor are set.
80 C101	Motor capacity	9999	0.4 to 55 kW*1 0 to 3600 kW*2 9999	Set the applied motor capacity.  V/F control
81 C102	Number of motor poles	9999	2, 4, 6, 8, 10, 12 9999	Set the number of motor poles.  V/F control
83 C104	Rated motor voltage	200/400V*3	0 to 1000 V	Set the rated motor voltage (V).
84 C105	Rated motor frequency	9999	10 to 400Hz 9999	Set the rated motor frequency (Hz).  The setting value of <b>Pr.3 Base frequency</b> is used. *4
800 G200	Control method selection	20	9	PM motor test operation (Motor is not driven even if it is connected.)
	00.000.00		20	Normal operation (Motor can be driven.)

- $*1 \quad \text{For theFR-F820-02330(55K) or lower, and theFR-F840-01160(55K)} or lower. \\$
- \*2 For theFR-F820-03160(75K) or higher and theFR-F840-01800(75K)or higher.
- \*3 The initial value differs according to the voltage class. (200V class/400V class)
- \*4 When the IPM motor MM-EFS or MM-THE4 is selected by **Pr.71** Applied motor, the rated frequency of the MM-EFS or MM-THE4 is used. When a PM motor other than the MM-EFS or MM-THE4 is selected by **Pr.71**, 75 Hz (for the motor capacity 15 kW or lower) or 100 Hz (18.5 kW or higher) is used.

#### ◆ Setting the motor capacity and the number of motor poles (Pr.80, Pr.81)

- Motor specifications (the motor capacity and the number of motor poles) must be set to select Advanced magnetic flux vector control, or PM motor control.
- Set the motor capacity (kW) in Pr.80 Motor capacity and set the number of motor poles in Pr.81 Number of motor poles.

• Setting the number of motor poles in Pr.81 changes the Pr.144 Speed setting switchover setting automatically. (Refer to page 261.)

### **◆PM** motor control test operation (Pr.800="9")

• Test operation in the speed control is available without connecting a motor. The speed calculation changes to track the speed command, and such speed changes can be checked on the operation panel or by outputting it as analog signals to the terminal FM, AM, or CA.

· Since current is not detected and voltage is not output, monitors related to current and voltage such as output current and output voltage, etc. and output signals do not function.

#### ◆I/O signal operation during the test operation

- During the test operation, the following signals are invalid.
- 1) Input terminal function selection (Pr.178 to Pr.189)
  - V/F switchover signal (X18)
  - Start-time tuning start external input signal (X28)
- 2) Output terminal function selection (Pr.190 to Pr.196)
  - Electronic thermal O/L relay pre-alarm signal (THP)
  - Start time tuning completion signal (Y39)

#### Parameters referred to

Pr.178 to Pr.189 (input terminal function selection) page 329 Pr.190 to Pr.196 (output terminal function selection) page 288

# ◆Valid/invalid status of monitor outputs during the test run

: Invalid (always displays 0)

 $\boldsymbol{\Delta}\;$  : Displays accumulated value before the test

- : Not monitored

Types of monitor	DU/PU Monitor display	FM/AM/CA Output
Output frequency	0	0
Fault display	0	_
Frequency setting value	0	0
Running speed	0	0
Converter output voltage	0	0
Electric thermal relay load factor	× *2	× *2
Output current peak value	× *2	× *2
Converter output voltage peak value	0	0
Load meter	0	0
Cumulative energization time	0	_
Reference voltage output	_	0
Actual operation time	0	_
Cumulative power	Δ	_
Trace status	0	×
Station number (RS-485 terminals)	0	_
Station number (PU connector)	0	_
Station number (CC-Link)	0	_
Energy saving effect	0	0
Cumulative energy saving	Δ	_
PID set point	0	0
PID measured value	0	0
PID deviation	0	O*3
Input terminal status	0	_
Output terminal status	0	_
Option input terminal status	0	_

Types of monitor	DU/PU Monitor display	FM/AM/CA Output
Option output terminal status	0	_
Motor thermal load factor	O*4	O*4
Inverter thermal load factor	O*4	O*4
PTC thermistor value	0	_
PID measured value 2	0	0
Remote output 1	0	0
Remote output 2	0	0
Remote output 3	0	0
Remote output 4	0	0
PID manipulated amount	0	O*3
Second PID set point	0	0
Second PID measured value	0	0
Second PID deviation	0	O*3
Second PID measured value 2	0	0
Second PID manipulated amount	0	O*3

- \*1 Different output interface (operation panel, parameter unit, terminal FM/CA or terminal AM) can output different monitored items. For details, refer to page 273.
- \*2 When the operation is switched to the test run, "0" is displayed. When PM sensorless vector control is selected again after a test run, the output current peak value and the electronic thermal relay load factor from the last operation are displayed.
- \*3 The monitored status can be output via the terminal AM only.
- \*4 When the operation is switched to the test run, accumulated thermal value is reduced by considering the output current is "0".

#### Parameters referred to >>>

Pr.52 Operation panel main monitor selection page 263

Pr.158 AM terminal function selection page 273

# ◆Changing the control method with external terminals (RT signal, X18 signal)

- Control method (V/F control, Advanced magnetic flux vector control) can be switched among using external terminals. The control method can be either switched using the Second function selection (RT) signal or the V/F switchover (X18)
- · When using the RT signal, set the second motor in Pr.450 Second applied motor. Turning ON the RT signal enables the second function, enabling the switchover of the control method.
- · When using the X18 signal, turning ON the X18 signal switches the presently-selected control method (Advanced magnetic flux vector control) to the V/F control. At this time, the second functions including electronic thermal characteristic are not changed. Use this method to switch the control method for one motor. (To switch the second functions, use the RT signal.) To input the X18 signal, set "18" in any of Pr.178 to Pr.189 (input terminal function selection) to assign the function.

First motor control method	Second motor control method (RT signal-ON)	Pr.450 setting value	Pr.453, Pr.454 setting value	
	V/F control	9999	_	
	VI CONTO	_	9999*2	
V/F control	Advanced magnetic flux vector control	Induction motor	Other than 9999	
	PM motor control	IPM/SPM motor		
	Same control as the first motor*1	9999	_	
Advanced magnetic flux vector	V/F control	_	9999*2	
control PM motor control *1	Advanced magnetic flux vector control	Induction motor	Other than 9999	
	PM motor control	IPM/SPM motor		

- \*1 V/F control is set by turning ON the X18 signal. If the X18 signal is unassigned, RT signal performs the same function; Turning ON the RT signal selects V/F control.
- \*2 V/F control is set when Pr.453 or Pr.454 = "9999". When Pr.450 is set to the IPM motor MM-EFS or MM-THE4. PM motor control is enabled even if **Pr.453** ≠ "9999" or **Pr.454** = "9999".

#### NOTE !

- RT signal is assigned to the terminal RT in the initial status. Set "3" in one of Pr.178 to Pr.189 (input terminal function selection) to assign the RT signal to another terminal.
- The RT signal is a second function selection signal. The RT signal also enables other second functions. (Refer to page 333.)
- The control method could be changed by external terminals (RT signal, X18 signal) while the inverter is stopped. If a signal is switched during the operation, the control method changes after the inverter stops.

#### # Parameters referred to

Pr.178 to Pr.189 (input terminal function selection) page 329 Pr.450 Second applied motor page 337

#### 5.2.2 Selecting the Advanced magnetic flux vector control Magnetic flux



· To use the Advanced magnetic flux vector control, set the motor capacity, the number of motor poles, and the motor type using Pr.80 and Pr.81.

#### Advanced magnetic flux vector control

Perform secure wiring. (Refer to page 33.)



Make the motor setting. (Pr.71)

Mo	otor	Pr.71 setting*1	Remarks
	SF-JR	0 (initial value) (3, 4)	
Mitsubishi standard motor Mitsubishi	SF-JR 4P 1.5 kW or lower	20	
high-efficiency motor	SF-HR	40	
Ingit emoletroy motor	Others	0 (3)	Offline auto tuning is required.*2
A44 1 1 1 1	SF-JRCA 4P	1	
Mitsubishi constant-torque motor	SF-HRCA	50	
constant-torque motor	Other (SF-JRC, etc.)	1 (13)	Offline auto tuning is required.*2
Mitsubishi high-performance energy-saving motor	SF-PR	70	
Other manufacturer's standard motor	_	0 (3)	Offline auto tuning is required.*2
Other manufacturer's constant-torque motor	_	1 (13)	Offline auto tuning is required.*2

<sup>\*1</sup> For the other setting values of Pr.71, refer to page 337.

<sup>\*2</sup> For offline auto tuning, refer to page 341.



Set the motor overheat protection. (Pr.9) (Refer to page 225)



Set the rated motor current (A) in Pr.9 Electronic thermal O/L relay.

Setting the motor capacity and the number of motor poles.

(Pr.80, Pr.81) (Refer to page 143.)



Set the motor capacity (kW) in Pr.80 Motor capacity, and set the number of motor poles in Pr.81 Number of motor poles.

(V/F control is performed when the setting is "9999" (initial value).)

Set the rated motor voltage and frequency. (Pr.83, Pr.84) (Refer to page 341.)



Set the rated motor voltage (V) in Pr.83 Rated motor voltage, and set the rated motor frequency (Hz) in Pr.84 Rated motor frequency.

Set the operation command. (Refer to page 200.)



Select the start command and speed command.

**Test run** 

#### As required

- Perform offline auto tuning. (Pr.96) (Refer to page 341.)
- Select the online auto tuning. (Pr.95) (Refer to page 359.)

## NOTE :


- · Under this control, rotations are more likely to be uneven than under V/F control. (This control method is not suitable for grinder, wrapping machine, etc., which require even rotation at a low speed.)
- For FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower, the operation with a surge voltage suppression filter (FR-ASF-H/FR-BMF-H) installed between the inverter and the motor may reduce the output torque.
- The optional sine wave filter (MT-BSL/BSC) cannot be used between the inverter and the motor.
- · Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

# Keeping the motor speed constant when the load fluctuates (speed control gain)

Pr.	Name	Initial value	Setting range	Description
89 G932	Speed control gain (Advanced magnetic flux	9999	0 to 200%	Makes adjustments to keep the motor speed constant during variable load operation under Advanced magnetic flux vector control. The reference value is 100%.
	vector)		9999	The gain set by <b>Pr.71.</b> (The gain set in accordance with the motor.)
569 G942	Second motor speed		0 to 200%	Makes adjustments to keep the second motor speed constant during variable load operation under Advanced magnetic flux vector control. The reference value is 100%.
			9999	The gain set by <b>Pr.450.</b> (The gain set in accordance with the motor.)

• Use Pr.89 to keep the motor speed constant during variable load operation.

(This parameter is useful to make adjustments on the motor speed.)



## Driving two motors under Advanced magnetic flux vector control

- Turning ON the Second function selection (RT) signal enables the second motor operation.
- Set a second motor in Pr.450 Second applied motor. (In the initial setting, "9999 (no second motor)" is selected. Refer to page 337.)

Function	RT signal ON (second motor)	RT signal OFF (first motor)
Applied motor	Pr.450	Pr.71
Motor capacity	Pr.453	Pr.80
Number of motor poles	Pr.454	Pr.81
Speed control gain (Advanced magnetic flux vector)	Pr.569	Pr.89

## NOTE

- The RT signal is a second function selection signal. The RT signal also enables other second functions. (Refer to page 333.) RT signal is assigned to the terminal RT in the initial status. Set "3" in any of Pr.178 to Pr.189 (input terminal function selection) to assign the RT signal to another terminal.
- · Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### # Parameters referred to

Pr.71, Pr.450 Applied motor page 337

Pr.800 Control method selection page 143

#### 5.2.3 Selecting the PM motor control M

# ◆ Selecting the PM motor control by performing parameter initialization on the operation panel (! PM)



- The parameters required to drive an IPM motor MM-EFS or MM-THE4 are automatically changed as a batch. (Refer to page
- [PM] on the operation panel (FR-DU08) is on when the PM motor control is set.

#### Operation example

Initialize the parameter settings for an IPM motor MM-EFS or MM-THE4 by selecting IPM parameter initialization on the operation panel.

	Operation
1.	Screen at power-ON
1.	The monitor display appears.
	Changing the operation mode
2.	Press PU to choose the PU operation mode.
	[PU] indicator is on.
	Parameter setting mode
3.	Press MODE to choose the parameter setting mode.
	[PRM] indicator is on.
	IPM parameter initialization
4.	Turn until   ¬¬¬ (IPM parameter initialization) appears.
	Setting value display
5.	Press SET to read the present set value.
	"[]" (initial value) appears.
	Changing the setting value
6.	Turn to change the set value to " ( set ).
	"   ind   in

Setting	Description
0	Parameter settings for an induction motor
12	Parameter settings for an IPM motor MM-EFS/MM-THE4 (rotations per minute)

# NOTE

- If parameters are initialized for a PM motor in the IPM initialization mode, the Pr.998 PM parameter initialization setting is automatically changed.
- To set a speed or to display monitored items in frequency, Pr.998. (Refer to page 150.)

#### Initializing the parameters required for the PM motor control (Pr.998)

- PM parameter initialization sets parameters required for driving an IPM motor MM-EFS or MM-THE4.
- The offline auto tuning enables the operation with an IPM motor other than MM-EFS/MM-THE4 and with SPM motors.
- Two MM-EFS/MM-THE4 IPM parameter initialization methods are available; setting **Pr.998 PM parameter initialization**, and selecting | PM (IPM parameter initialization) mode on the operation panel.

Pr.	Name	Initial value	Setting range	Description		
			0	Parameter settings for an induction motor (frequency)	The parameter settings required to drive an induction motor are set.	
			12	For IPM motor MM-EFS/MM-THE4. Parameter setting (rotations per minute)	The parameters settings required to drive an IPM motor	
			112	For IPM motor MM-EFS/MM-THE4. Parameter setting (frequency)	are set.	
998 E430	PM parameter initialization	83	8009	The parameters settings required to drive an IPM motor other than MM-EFS/MM- THE4 are set. (rotations per minute)(after tunning)	The parameters settings required to drive an IPM motor are set.	
			8109	The parameters settings required to drive an IPM motor other than MM-EFS/MM-THE4 are set. (frequency)(after tunning)	(Set <b>Pr.71 Applied motor</b> and perform offline auto tuning in advance. (Refer to <b>page 351</b> .))	
			9009	The parameters settings required to drive an SPM motor are set. (rotations per minute)(after tunning)	The parameters settings required to drive an SPM motor are set.	
			9109	The parameters settings required to drive an SPM motor are set. (frequency)(after tunning)	(Set <b>Pr.71 Applied motor</b> and perform offline auto tuning in advance. (Refer to <b>page 351</b> .))	

- To use a motor capacity that is one rank lower than the inverter capacity, set Pr.80 Motor capacity before performing IPM
  parameter initialization.
- When **Pr.998**="12, 8009, or 9009", the monitor is displayed and the frequency is set using the motor rotations per minute. To use frequency to display or set, set **Pr. 998**="112, 8109, or 9109".
- Set **Pr.998**="0" to change the PM motor control parameter settings to the parameter settings required to drive an induction motor.
- When using an IPM motor other than MM-EFS/MM-THE4, set **Pr.998** = "8009, 8109, 9009, or 9109". The setting can be made after performing offline auto tuning.

## • NOTE

- Make sure to set **Pr.998** before setting other parameters. If the **Pr.998** setting is changed after setting other parameters, some of those parameters will be initialized too. (Refer to "(3) PM parameter initialization list" for the parameters that are initialized.)
- To change back to the parameter settings required to drive an induction motor, perform parameter clear or all parameter clear
- If the setting of **Pr.998 PM parameter initialization** is changed between "12, 8009, 9009 (rotations per minute)" ⇔ "112, 8109, 9109 (frequency)", the target parameters are respectively set to their initial values. The purpose of **Pr.998** is not to change the display units. Use **Pr.144 Speed setting switchover** to change the display units between rotations per minute and frequency. **Pr.144** enables switching of display units between rotations per minute and frequency without initializing the parameter settings.
- Example) Changing the **Pr.144** setting between "6" and "106" switches the display units between frequency and rotations per minute
- For an inverter out of the capacity range of the IPM motor MM-EFS/MM-THE4, "12 or 112" cannot be set. (Refer to page 583 for the capacities of MM-EFS/MM-THE4 motors.)

# **◆PM** parameter initialization list

- The parameter settings in the following table are changed to the settings required to perform PM motor control by selecting PM motor control with the IPM parameter initialization mode on the operation panel or with **Pr.998 PM parameter** initialization.
- Performing parameter clear or all parameter clear sets back the parameter settings to the settings required to drive an induction motor.

						Setting			Sot	ting
			Indu	ction	PM m	PM motor (trequency)				ments
				tor	(rotations p		T III III OLOT (		1 1101100	
Pr.	Name		`	0		8009		8109		
• • •	Hamo		•	itial	12	9009	112	9109	12,	0, 112,
		Pr.998	val	ue)	(MM-EFS,	(other than	(MM-EFS,	(other than	8009,	8109,
			FM	CA	MM-THE4)	MM-EFS,	MM-THE4)	MM-EFS,	9009	9109
						MM-THE4)		MM-THE4)		
			120 Hz	*1	Maximum motor	Maximum	Maximum	Maximum		
1	Maximum frequency		60 Hz*	2	rotations per	motor	motor	motor	1 r/min	0.01 Hz
					minute Rated motor	frequency*6	frequency	frequency*6		
4	Multi-speed setting (high	speed)	60 Hz	50 Hz	rotations per	Pr.84	Rated motor	Pr.84	1 r/min	0.01 Hz
-					minute		frequency			
				•	Rated motor		Rated motor		0.01 A*1	
9	Electronic thermal O/L rel	av	Rated i		current	_	current	_	0.01 A*I	
		y	current		(Refer to page		(Refer to page		0.1 A*2	
					583.)		583.)			1
13	Starting frequency		0.5 Hz		Minimum rotations per	<b>Pr.84</b> ×10%	Minimum	<b>Pr.84</b> ×10%	1 r/min	0.01 Hz
13	Starting frequency		0.5112		minute	F1.04 × 10 /6	frequency	F1.04 × 10 /0	1 1/111111	0.01112
					Minimum					
15	Jog frequency		5 Hz		rotations per	<b>Pr.84</b> ×10%	Minimum	Pr.84 ×10%	1 r/min	0.01 Hz
					minute		frequency			
			120 Hz	*1	Maximum motor		Maximum			
18	High speed maximum fre	quency	60 Hz*2		rotations per	_	motor	_	1 r/min	0.01 Hz
				1	minute Rated motor		frequency			
120	Acceleration/deceleration		60 Hz	50 Hz	rotations per	Pr.84	Rated motor	Pr.84	1 r/min	0.01 Hz
20	reference frequency		00112	00112	minute	11.04	frequency	11.04	17111111	0.01112
22	Stall prevention operation	lovol	120%	110%	Short-time motor	torquo			0.1%	1
	<u> </u>	levei	*5	*5		torque				
37	Speed display		0	1	0		T	T	1	1
55	Frequency monitoring ref	oronco	60 Hz	50 Hz	Rated motor rotations per	Pr.84	Rated motor	Pr.84	1 r/min	0.01 Hz
55	r requericy monitoring re-	erence	00 112	30 112	minute	F1.0 <del>4</del>	frequency	F1.04	1 1/111111	0.01112
					Rated motor		Rated motor		0.04.4	
56	Current monitoring refere	nce	Rated i	nverter	current	Pr.859	current	Pr.859	0.01 A*1	
50	Ourient monitoring refere	1100	current		(Refer to page	11.000	(Refer to page	11.000	0.1 A*2	
74	A 1!1 4		0		583.)		583.)			
71	Applied motor		0		210*3	_	210*3	<del>_</del>	1	
80	Motor capacity		9999		Inverter	_	Inverter	_	0.01 kW	*1
	Wotor Supusity		0000		capacity*4		capacity*4		0.1 kW*2	!
81	Number of motor poles		9999		Number of motor		Number of		1	
01	Truttibel of filotol poles		9999		poles*4	_	motor poles*4		'	
	5				Rated motor		Rated motor		l	
84	Rated motor frequency		9999		rotations per	_	frequency*4	_	1 r/min	0.01 Hz
					minute*4 Rated motor					
	Terminal 2 frequency setti	ng gain	60 Hz	50 Hz	rotations per	Pr.84	Rated motor	Pr.84	1 r/min	0.01 Hz
(903)	frequency			001.2	minute		frequency		,	0.0
126	Terminal 4 frequency setti	na aoin			Rated motor		Rated motor			
	frequency	iig gaiii	60 Hz	50 Hz	rotations per	Pr.84	frequency	Pr.84	1 r/min	0.01 Hz
(555)					minute				<u> </u>	<u> </u>
144	Speed setting switchover		4		Number of motor	<b>Pr.81</b> +100	Number of	Pr.81	1	
240	Soft-PWM operation sele	ction	1		poles + 100 0		motor poles		1	
270	Cont-1 VVIVI Operation Sele	0.1011	'		Rated motor				<del> </del>	
263	Subtraction starting frequ	ency	60 Hz	50 Hz	rotations per	Pr.84	Rated motor	Pr.84	1 r/min	0.01 Hz
			<u></u>	<u> </u>	minute		frequency			

			Setting						ting	
				ction	PM m		PM motor (	frequency)	incre	•
			motor		(rotations per minute)		<u> </u>			
Pr.	Name		0			8009		8109		
	Nume		(in	itial	12	9009	112	9109	12,	0, 112,
		Pr.998	val	ue)	(MM-EFS,	(other than	(MM-EFS,	(other than	8009,	8109,
			FM	CA	MM-THE4)	MM-EFS,	MM-THE4)	MM-EFS,	9009	9109
					D ( )	MM-THE4)		MM-THE4)		
266	Power failure deceleratio switchover frequency	n time	60 Hz	50 Hz	Rated motor rotations per minute	Pr.84	Rated motor frequency	Pr.84	1 r/min	0.01 Hz
					Overspeed	Maximum	Overspeed	Maximum		
374	Overspeed detection leve	اد	9999		detection level,	motor	detection	motor	1 r/min	0.01 Hz
					rotations per	frequency	level,	frequency		0.01.12
					minute	+10 Hz*6	frequency	+10 Hz*6		
390	% setting reference frequ	onov	60 Hz	50 Hz	Rated motor rotations per	Pr.84	Rated motor	Pr.84	1 r/min	0.01 Hz
390	70 Setting reference frequ	Спсу	00 112	30 112	minute	· · · · · · · · · · · · · · · · · · ·		ency F1.04		0.01112
505	Canad notting reference		60 Hz	50 LI=	Rated motor	Pr.84	Rated motor	Pr.84	0.01 Hz	
505	Speed setting reference		60 HZ	Iz 50 Hz frequency		Pr.84	frequency	Pr.84	U.UT HZ	
					Rated motor		Rated motor		0.01 A*1	
557	Current average value m			nverter	current	Pr.859	current	Pr.859	0.01701	
	signal output reference c	urrent	current		(Refer to page 583.)		(Refer to page 583.)		0.1 A*2	
					Speed detection		Speed			
070					hysteresis	0.511	detection	0.511		0.04.11
870	Speed detection hysteres	SIS	0 Hz		rotations per	0.5 Hz	hysteresis	0.5 Hz	1 r/min	0.01 Hz
					minute		frequency			
	Regeneration avoidance				Minimum		Minimum			
885	compensation frequency	limit	6 Hz		rotations per	Pr.84 ×10%	frequency	<b>Pr.84</b> ×10%	1 r/min	0.01 Hz
	value Energy saving monitor re	foronco	Rated i	inverter	minute				0.01 kW	.1
893	(motor capacity)	IEIEIICE	capacit		Motor capacity (Pr.80)			0.01 kW*1 0.1 kW*2		
	• • •		Japaon	.,	Rated motor				J. 1 KVV*2	
C14	Terminal 1 gain frequency	y	60 Hz	50 Hz	rotations per	Pr.84	Rated motor	Pr.84	1 r/min	0.01 Hz
(918)	(speed)				minute		frequency			

—: Not changed

- \*1 Initial value for the FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower.
- \*2 Initial value for the FR-F820-03160(75K) or higher and FR-F840-01800(75K) and higher.
- \*3 Setting Pr.71 Applied motor ="213, 214, 8093, 8094, 9093, or 9094" does not change the Pr.71 setting.
- \*4 When a value other than "9999" is set, the set value is not changed.
- \*5 110% for SLD, 120% for LD (Refer to **Pr.570 Multiple rating setting page 168**.)
- \*6 The Pr.702 Maximum motor frequency is used as the maximum motor frequency. When Pr.702 ="9999 (initial value)", the Pr.84 Rated motor frequency is used as the maximum motor frequency.

# • NOTE

• If PM parameter initialization is performed in rotations per minute (Pr.998 = "12, 8009, or 9009"), the parameters not listed in the table and the monitored items are also set and displayed in rotations per minute.

#### ◆IPM motor specification list

	MM-EFS (15 kW or lower)	MM-EFS (18.5 kW to 55 kW)	MM-THE4 (75 kW to 160 kW)		
Rated motor frequency (rotations per minute)	75 Hz (1500 r/min)	100 Hz (1500 r/min)	75 Hz (1500 r/min)		
Maximum motor frequency (rotations per minute)	112.5 Hz (2250 r/min)	150 Hz (2250 r/min)	90 Hz (1800 r/min)		
Number of motor poles	6	8	6		
Short-time motor torque	110% for SLD, 120% for LD				
Minimum frequency (rotations per minute)	7.5 Hz (150 r/min)	10 Hz (150 r/min)	7.5 Hz (150 r/min)		
Speed detection hysteresis frequency (rotations per minute)	0.5 Hz (10 r/min)	0.5 Hz (8 r/min)	0.5 Hz (10 r/min)		
Overspeed detection level, frequency (rotations per minute)	122.5 Hz (2450 r/min)	160 Hz (2400 r/min)	100 Hz (2000 r/min)		


# **Speed control under PM motor control**

Purpose	Parameter to set					
To adjust the gain during PM motor control	Speed control gain adjustment	P.G211 to P.G214, P.G311 to P.G314	Pr.820, Pr.821, Pr.824, Pr.825, Pr.830, Pr.831, Pr.834, Pr.835	154		
To stabilize torque feedback signal	Torque detection filter	P.G216, P.G316	Pr.827, Pr.837	158		

Speed control performs control so that the speed command and the actual motor rotation speed match.

#### 5.3.1 Setting procedure of PM motor control M

This inverter is set for a general-purpose motor in the initial setting. Follow the following procedure to change the setting for the PM motor control.



## • NOTE

- To change to the PM motor control, perform PM parameter initialization at first. If parameter initialization is performed after setting other parameters, some of those parameters will be initialized too. (Refer to page 151 for the parameters that are
- Constant-speed operation cannot be performed in the low-speed range of 150 r/min or less.
- During PM motor control, the RUN signal is output about 100 ms after turning ON the start command (STF, STR). The delay is due to the magnetic pole detection.
- · During PM motor control, the automatic restart after instantaneous power failure function operates only when an MM-EFS or MM-THE4 IPM motor is connected.

When a regeneration unit is used, the frequency search may not be available if the rotation speed is about 10% higher than the rating.


#### 5.3.2 Performing high-accuracy, fast-response control (gain adjustment for PM motor control)

Manual gain adjustment is useful for achieving optimum machine performance or improving unfavorable conditions, such as vibration and acoustic noise during operation with high load inertia or gear backlash.


Pr.	Name	Initial	Setting	Description
		value	range	·
820 G211	Speed control P gain 1	25%	0 to 1000%	The proportional gain during speed control is set. (Setting this parameter higher improves the trackability for speed command changes. It also reduces the speed fluctuation caused by external disturbance.)
821 G212	Speed control integral time 1	0.333 s	0 to 20 s	The integral time during speed control is set. (Setting this parameter lower shortens the return time to the original speed when the speed fluctuates due to external disturbance.)
824 G213	Torque control P gain 1 (current loop proportional gain)	50%	0 to 500%	The proportional gain of the current controller is set.
825 G214	Torque control integral time 1 (current loop integral time)	40 ms	0 to 500 ms	The integral time of the current controller is set.
830	Speed control P gain 2	9999	0 to 1000%	Second function of <b>Pr.820</b> (valid when RT signal is ON)
G311	Speed Control F gain 2	9999	9999	The <b>Pr.820</b> setting is applied to the operation.
831	Speed control integral	9999	0 to 20 s	Second function of Pr.821 (valid when RT signal is ON)
G312	time 2	3333	9999	The <b>Pr.821</b> setting is applied to the operation.
834	Torque control P gain 2	9999	0 to 500%	Second function of Pr.824 (valid when RT signal is ON)
G313	Torque control P gain 2	3333	9999	The <b>Pr.824</b> setting is applied to the operation.
835	Torque control integral	9999	0 to 500 ms	Second function of <b>Pr.825</b> (valid when RT signal is ON)
G314	time 2	3333	9999	The Pr.825 setting is applied to the operation.

#### Adjusting the speed control gain manually

- The speed control gain can be adjusted for the conditions such as abnormal machine vibration, acoustic noise, slow response, and overshoot.
- Pr.820 Speed control P gain 1="25% (initial value)" is equivalent to 50 rad/s (speed response of a single motor). (Equivalent to the half the rad/s value with the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.) Setting this parameter higher speeds up the response, but setting this too high causes vibration and acoustic noise.
- Setting Pr.821 Speed control integral time 1 lower shortens the return time to the original speed during speed fluctuation, but setting it too low causes overshoot.



- \*1 The value in parentheses is applicable with the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.
- · Actual speed gain is calculated as below when load inertia is applied.



JM: Motor inertia Actual speed gain = Speed gain of a single motor  $\times$ JM + JL JL: Load inertia converted as the motor axis inertia

- · Adjust in the following procedure:
  - 1) Change the Pr.820 setting while checking the conditions.
  - 2) If it cannot be adjusted well, change Pr.821 setting, and perform 1) again.

No.	Movement / condition	Adjustment method				
		Set Pr.820 and Pr.821 higher.				
1	Load inertia is high.	Pr.820	If acceleration is slow, raise the setting by 10%s and then set the value to 0.8 to $0.9 \times 10^{-2}$ the setting immediately before vibration/noise starts occurring.			
		Pr.821	If overshoots occur, raise the setting by double the setting and then set the value to $0.8$ to $0.9 \times$ the setting where overshoots stop occurring.			
		Set Pr.820	D lower and <b>Pr.821</b> higher.			
2	Vibration or acoustic noise are generated from machines.	Pr.820	Lower the setting by 10%s and then set the value to 0.8 to 0.9 × the setting immediately before vibration/noise starts occurring.			
		Pr.821	If overshoots occur, raise the setting by double the setting and then set the value to $0.8$ to $0.9 \times$ the setting where overshoots stop occurring.			
		Set <b>Pr.820</b>	) higher.			
3	Response is slow.	Pr.820	If acceleration is slow, raise the setting by 5%s and then set the value to 0.8 to $0.9 \times 10^{-2}$ the setting immediately before vibration/noise starts occurring.			
	Deture time (necessary times)	Set <b>Pr.821</b>	lower.			
4	i is ioria.		Lower <b>Pr.821</b> by half the current setting and then set the value to 0.8 to 0.9 × the setting immediately before overshoots or unstable movements stop occurring.			
	Overshoots or unstable	Set Pr.821 higher.				
5	Overshoots or unstable movements occur.	Raise <b>Pr.821</b> by double the current setting and then set the value to 0.8 to 0.9 × the setting immediately before overshoots or unstable movements stop occurring.				

· Pr.830 Speed control P gain 2 and Pr.831 Speed control integral time 2 are valid when terminal RT is ON. In this case, replace them for Pr.820 and Pr.821 in the description above.

#### ◆Gain adjustment of current controllers for the d axis and the q axis

- Use Pr.824 Torque control P gain 1 (current loop proportional gain) to adjust the proportional gain of current controllers for the d axis and the q axis. The 100% gain is equivalent to 1000 rad/s. Setting this parameter higher improves the trackability for current command changes. It also reduces the current fluctuation caused by external disturbance.
- Use Pr.825 Torque control integral time 1 (current loop integral time) to set the integral time of current controllers for the d axis and the q axis. If the setting value is small, it produces current fluctuation toward disturbance, decreasing time until it returns to original current value.

# NOTE:

Pr.834 Torque control P gain 2 and Pr.835 Torque control integral time 2 are valid when terminal RT is ON. In this case, replace them for Pr.824 and Pr.825 in the description above.

#### 5.3.3 Troubleshooting in the speed control PM

No.	Condition	Cause	Countermeasure			
1	Motor does not run at the correct speed. (Command speed and	Speed command from the controller is different from the actual speed. The speed command is affected by noise.	Check that the speed command sent from the controller is correct. (Take EMC measures.)     Set Pr.72 PWM frequency selection lower.			
	actual speed differ.)	The command speed and the speed recognized by the inverter are different.	Adjust the bias and gain (Pr.125, Pr.126, C2 to C7, C12 to C15) of the speed command again.			
2	The speed does not accelerate to the	Torque shortage. The stall prevention operation level is operating.	Raise the stall prevention operation level. (Refer to page 248.) Increase the capacity.			
	command speed.	Only P (proportional) control is performed.	Speed deviation occurs under P (proportional) control when the load is heavy. Select PI control.			
		Speed command varies.	Check that the speed command sent from the controller is correct. (Take EMC measures.) Set Pr.72 lower. Set Pr.822 Speed setting filter 1 higher. (page 313)			
3	Motor speed fluctuates.	Torque shortage.	Raise the stall prevention operation level. (Refer to page 248.)			
		Speed control gain is not suitable for the machine. (Resonance occurs.)	Adjust Pr.820 Speed control P gain 1 and Pr.821 Speed control integral time 1.			
	Hunting (vibration or	Speed control gain is too high.	Set Pr.820 lower and Pr.821 higher.			
4	acoustic noise) occurs in the motor or the machine.	Torque control gain is too high.	Set Pr.824 Torque control P gain 1 (current loop proportional gain) lower.			
	macrime.	Motor wiring is incorrect.	Check the wiring.			
5	Acceleration/ deceleration time is	Torque shortage.	Raise the stall prevention operation level. (Refer to page 248.)			
	different from the setting.	Load inertia is too high.	Set acceleration/deceleration time suitable for the load.			
		Speed control gain is not suitable for the machine.	Adjust Pr.820 and Pr.821.			
6	Machine movement is unstable.	Response is slow because of the inverter's acceleration/deceleration time setting.	Set the optimum acceleration/deceleration time.			
7	Rotation ripple occurs	High carrier frequency is affecting the motor rotation.	• Set Pr.72 lower.			
	during the low-speed operation.	Speed control gain is too low.	Set Pr.820 higher.			

#### Parameters referred to >>>

Pr.3 Base frequency, Pr.19 Base frequency voltage page 497

Pr.72 PWM frequency selection page 179

Pr.80 Motor capacity, Pr.81 Number of motor poles page 143

Pr.125 Terminal 2 frequency setting gain frequency, Pr.126 Terminal 4 frequency setting gain frequency 🎏 page 314

Pr.822 Speed setting filter 1 \* page 313

#### 5.3.4

Set the time constant of primary delay filter for torque feedback signal. Speed loop response is reduced. Under ordinary circumstances, therefore, use the initial value as it is.

Pr.	Name	Initial value	Setting range	Description
827	27		0	Without filter
G216	Torque detection filter 1	0 s	0.001 to 0.1 s	Set the time constant of primary delay filter torque feedback signal.
837	837 Torque detection filter 2		0 to 0.1 s	Second function of Pr.827 (enabled when RT signal ON)
G316	Torque detection filter 2	9999	9999	Same as Pr.827 setting

#### ◆Stabilizing torque detection (Pr.827, Pr.837)

• Current loop response is reduced. Under ordinary circumstances, therefore, use the initial value as it is. If there is torque ripple due to high frequency disturbance, adjust until speed stabilizes by gradually raising the setting. Speed is oppositely destabilized if the setting value is too large.

#### Employing multiple primary delay filters

• Use Pr.833, Pr.837 if changing filter according to application. Pr.833, Pr.837: Second function selection (RT) signal

# • NOTE

- The RT signal is a second function selection signal. The RT signal also enables other second functions. (Refer to page 333.)
- The RT signal is assigned to the terminal RT in the initial setting. Set "3" in any of Pr.178 to Pr.189 (input terminal function selection) to assign the RT signal to another terminal.

#### **5.4** (E) Environment setting parameters

Purpose	Par	Refer to page		
To set the time	Simple clock function	P.E020 to P.E022	Pr.1006 to Pr.1008	160
To set a limit for the reset function  To shut off output if the operation panel disconnects  To force deceleration to a stop on the operation panel	Reset selection/ disconnected PU detection/PU stop selection/Reset limit	P.E100 to P.E102, P.E107	Pr.75	162
To select the display language of the parameter unit	PU display language selection	P.E103	Pr.145	164
To control the buzzer of the parameter unit and operation panel	PU buzzer control	P.E104	Pr.990	164
To adjust the LCD contrast of the parameter unit	PU contrast adjustment	P.E105	Pr.991	165
To turn OFF the operation panel when not using it for a certain period of time	Display-off mode	P.E106	Pr.1048	165
To use the USB memory	USB host reset	P.E110	Pr.1049	165
To use the setting dial of the operation panel like a potentiometer to set the frequency.  To disable the operation panel.	Operation panel operation selection	P.E200	Pr.161	166
To change the frequency change increments which changes when using the setting dial of the operation panel	Frequency change increment amount setting	P.E201	Pr.295	167
To use the regeneration unit to increase the motor braking torque	Regenerative brake selection	P.E300	Pr.30	508
To change the overload current rating specification	Multiple rating setting	P.E301	Pr.570	168
To input a voltage between 480 V and 500 V	Input voltage mode selection	P.E302	Pr.977	168
To prevent parameter rewriting	Parameter write disable selection	P.E400	Pr.77	169
To restrict parameters with a password	Password function	P.E410, P.E411	Pr.296, Pr.297	171
To use parameters freely	Free parameter	P.E420, P.E421	Pr.888, Pr.889	173
To change parameter settings for an IPM motor as a batch	PM parameter initialization	P.E430	Pr.998	150
To set multiple parameters as a batch	Automatic parameter setting	P.E431	Pr.999	173
To display the required parameters	Applicable parameter display and user group function	P.E440 to P.E443	Pr.160, Pr.172 to Pr.174	177
To release the parameter copy warning (CP)	Parameter copy alarm release	P.E490	Pr.989	521
To reduce the motor noise and EMI	PWM carrier frequency changing	P.E600 to P.E602	Pr.72, Pr.240, Pr.260	179
To understand the maintenance time	Inverter parts life display	P.E700 to P.E704	Pr.255 to Pr.259	180
To understand the maintenance time of inverter parts and peripheral device	Maintenance output function	P.E710 to P.E715	Pr.503, Pr.504, Pr.686 to Pr.689	184
	Current average value monitor signal	P.E720 to P.E722	Pr.555 to Pr.557	185

# 5.4.1 Real time clock function

The time can be set. The time can only be updated while the inverter power is ON. The real time clock function is enabled using an optional LCD operation panel (FR-LU08).

Pr.	Name	Initial value	Setting range	Description
1006 E020	Clock (year)	2000	2000 to 2099	Set the year.
1007 E021	Clock (month, day)	101 (January 1)	101 to 131, 201 to 228, (229), 301 to 331, 401 to 430, 501 to 531, 601 to 630, 701 to 731, 801 to 831, 901 to 930, 1001 to 1031, 1101 to 1130, 1201 to 1231	Set the month and day. 1000 and 100 digits: January to December 10 and 1 digits: 1 to end of month (28, 29, 30 or 31) For December 31, set "1231".
1008 E022	Clock (hour, minute)	0 (00:00)	0 to 59, 100 to 159, 200 to 259, 300 to 359, 400 to 459, 500 to 559, 600 to 659, 700 to 759, 800 to 859, 900 to 959, 1000 to 1059, 1100 to 1159, 1200 to 1259,1300 to 1359, 1400 to 1459, 1500 to 1559, 1600 to 1659, 1700 to 1759, 1800 to 1859,1900 to 1959, 2000 to 2059, 2100 to 2159, 2200 to 2259, 2300 to 2359	Set the hour and minute using the 24-hour clock. 1000 and 100 digits: 0 to 23 hours 10 and 1 digits: 0 to 59 minutes For 23:59, set "2359".


### **♦**Simple clock function

• When the year, month, day, time and minute are set in the parameters, the inverter counts the date and time. The date and time can be checked by reading the parameters.

## NOTE

- The clock's count-up data is saved in the inverter's EEPROM every 10 minutes.
- Because the date and time are cleared after turning OFF the control circuit power supply, the clock function must be reset after turning ON the power supply. Use a separate power supply, such as an external 24 V power supply, for the control circuit of the simple clock function, and supply power continuously to this control circuit.
- In the initial setting, inverter reset is performed if supplying power to the main circuit is started when power is supplied only to the control circuit. Then, the clock information stored in EEPROM is restored. Reset at the start of supplying power to the main circuit can be disabled by setting **Pr.30 Regenerative function selection**. (Refer to **page 508**)
- The set clock is also used for functions such as faults history.

#### ◆Real time clock function



• When the FR-LU08 is connected to the inverter, the internal clock of the inverter can be synchronized with the clock of FR-LU08. (Real time clock function)

With a battery (CR1216), the FR-LU08 time count continues even if the main power of the inverter is turned OFF. (The time count of the inverter internal clock does not continue when the inverter power is turned OFF.

• To adjust the clock of FR-LU08, use the FR-LU08 and set Pr.1006 to Pr.1008.

### NOTE

- Time adjustment between the inverter internal clock and the FR-LU08 is performed every one minute.
- When the FR-LU08 clock is initialized after the battery is exhausted for example, the inverter internal clock is valid.

#### 5.4.2 Reset selection/disconnected PU detection/PU stop selection

The reset input acceptance, disconnected PU (operation panel/paprameter unit) connector detection function and PU stop function (PU stop) can be selected.

Pr.	Name	Initial value	Setting range	Description
	Reset selection/disconnected		0 to 3, 14 to 17*1	For the initial setting, reset is always
75	PU detection/PU stop selection	14	0 to 3, 14 to 17, 100 to 103, 114 to 117*2	enabled, without disconnected PU detection, and with the PU stop function.
			0	Reset input is always enabled.
E100	Reset selection	0	1	Reset input is enabled only when the protective function is activated.
E101	Disconnected PU detection	0	0	Operation continues even when the PU is disconnected.
EIVI	Disconnected PO detection	0	1	The inverter output is shut off when the PU is disconnected.
			0	Decelerates to a stop when the STOP key is pressed in PU operation mode only.
E102	PU stop selection	1	1	Decelerates to a stop when the STOP key for PU is pressed in any of the PU, external and communication operation modes.
E107	Reset limit	0	0	Reset limit disabled
L107	iveset iiiiit	U	1 *2	Reset limit enabled

The parameters above will not return to their initial values even if parameter (all) clear is executed.

<sup>\*2</sup> The setting range for the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.

Pr.75 Setting*3	Reset selection	Disconnected PU detection	PU stop selection	
0, 100	Reset input always enabled	Operation continues even when PU		
1, 101	Reset input enabled only when protective function activated	is disconnected.	Decelerates to a stop when RESET is	
2, 102	Reset input always enabled	Inverter output shut off when PU	input in PU operation mode only.	
3, 103	Reset input enabled only when protective function activated	disconnected.	input in a operation mode only.	
14 (Initial value), 114	Reset input always enabled	Operation continues even when PU	Decelerates to a stop when RESET is input in any of the PU, external and communication operation modes.	
15, 115	Reset input enabled only when protective function activated	is disconnected.		
16, 116	Reset input always enabled	Inverter output shut off when PU		
17, 117	Reset input enabled only when protective function activated	disconnected.	, samman spanaron notation	

<sup>\*3</sup> Setting Pr.75 = any of "100 to 103 and 114 to 117" will enable the reset limit function. The setting is available for the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.

# ◆Reset selection (P.E100)

• When P.E100="1" or Pr.75="1, 3, 15, 17, 100, 103, 115, or 117" is set, reset (reset command via RES signal or communication) input is enabled only when the protective function is activated.

# • NOTE

- · When the reset signal (RES) is input during operation, the motor coasts since the inverter being reset shuts off the output. Also, the cumulative values of electronic thermal O/L relay and regenerative brake duty are cleared.
- The input of the PU reset key is only enabled when the protective function is activated, regardless of the P.E100 and Pr.75 settings.

<sup>\*1</sup> The setting range for the FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower.

• If the PU (FR-DU08/FR-PU07) is detected to be disconnected from the inverter for 1 s or longer while P.E101 ="1" or Pr.75 = "2, 3, 16, 17, 102, 103, 116, or 117", PU disconnection (E.PUE) is displayed and the inverter output is shut off.

#### • NOTE

- When the PU has been disconnected since before power-ON, the output is not shut off.
- · To restart, confirm that the PU is connected and then reset.
- When P.E101="0" or Pr.75 = "0, 1, 14, 15, 100, 101, 114, or 115" (operation continues even when PU disconnected), decelerates to a stop when PU is disconnected during PU JOG operation.
- When RS-485 communication operation is performed through the PU connector, the reset selection/PU stop selection function is valid but the disconnected PU detection function is invalid. (The communication is checked according to Pr.122 PU communication check time interval.)

## ◆PU stop selection (P.E102)

- Stop can be performed by inputting from the PU in any of the operation modes of PU operation, External operation and network operation.
- When stop is performed by the PU stop function, " " is displayed on the PU. A fault output is not provided.
- When **P.E102**="0" or **Pr.75**="0 to 3, 100 to 103" is set, deceleration stop using is valid only in the PU operation mode.

## NOTE:

When Pr.551 PU mode operation command source selection="1" (PU mode RS-485 terminal), deceleration stop is performed even when stop is input during operation in PU mode via RS-485 communication.


# ◆How to restart after stopping with property input from the PU during External operation (PU stop (PS) release method)

- PU stop release method for operation panel (FR-DU08)
  - 1)After completion of deceleration to a stop, switch OFF the STF and STR signal.

(When Pr.79 Operation mode selection = "0 (initial value) or 6")

When **Pr.79** = "2, 3, or 7", PU stop can be released by pressing one time.

- PU stop release method for parameter unit (FR-PU07)
  - 1) After completion of deceleration to a stop, switch OFF the STF or STR signal.



Stop/restart example for External operation

The motor can be restarted by resetting the power supply or resetting with a RES signal.

# NOTE:

• Even when Pr.250 Stop selection ≠ "9999" is set and coasting stop is selected, deceleration stop and not coasting stop is performed in the PU stop function during External operation.

#### ◆Reset limit function (P.E107)

- When P.E107 = "1" or Pr.75 = any of "100 to 103 and 114 to 117", if an electronic thermal O/L relay or an overcurrent protective function (E.THM, E.THT, E.OC[]) is activated while one of them has been already activated within 3 minutes, the inverter will not accept any reset command (RES signal, etc.) for about 3 minutes from the second activation.
- The reset limit function is available with the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.

# NOTE >

- · Resetting the inverter power (turning OFF the control power) will clear the accumulated thermal value.
- When the retry function is set enabled (Pr.67 Number of retries at fault occurrence ≠ "0"), the reset limit function is

# Caution

• Do not perform a reset while a start signal is being input. Doing so will cause a sudden start of the motor, which is dangerous.

#### # Parameters referred to

Pr.67 Number of retries at fault occurrence page 236 Pr.79 Operation mode selection page 200 Pr.250 Stop selection page 507 Pr.551 PU mode operation command source selection page 210

#### 5.4.3 PU display language selection

The display language of the parameter unit (FR-PU07) can be selected.

Pr.	Name	Initial value	Setting range	Description
	PU display language selection	1	0	Japanese
			1	English
145 E103			2	German
			3	French
			4	Spanish
			5 Italian	Italian
			6	Swedish
			7	Finnish

#### 5.4.4 **Buzzer control**

The buzzer can be set to "beep" when the keys of the operation panel and the parameter unit are operated.

Pr.	Name	Initial value	Setting range	Description	
990	PU buzzer control	1	0	Without buzzer	
E104	PO buzzer control	1	1 With buzzer	With buzzer	



· When with buzzer is set, the buzzer sounds if an inverter fault occurs.

# 5.4.5 PU contrast adjustment

Contrast adjustment of the LCD of the LCD operation panel (FR-LU08) and the parameter unit (FR-PU07) can be performed.

Decreasing the setting value lowers the contrast.

Pr.	Name	Initial value	Setting range	Description
991 E105	PU contrast adjustment	58	0 to 63	0: Low → 63: High

The above parameter is displayed as a simple mode parameter only when the LCD operation panel (FR-LU08) and the parameter unit (FR-PU07) are connected.

# 5.4.6 Display-off mode

The LED of the operation panel (FR-DU08) can be turned OFF when it has not been used for a certain period of time.

Pr.	Name	Initial value	Setting range	Description
1048		0	0	Display-off mode disabled
E106	Display-off waiting time		1 to 60 min	Set time until the LED of the operation panel is turned OFF.

- If the operation panel has not been operated for the time set in **Pr.1048**, the display-off mode is enabled and its LED is turned OFF.
- In the display-off mode, the "MON" LED flickers slowly.
- The count to display off is reset at installation/removal of the operation panel, power-ON/OFF of the inverter, or inverter reset.
- · Display-off mode end condition
  - Operation of the operation panel
  - Occurrence of a warning, alarm, or fault
  - Installation/removal of the operation panel, power-ON/OFF of the inverter, or inverter reset
  - Connection/disconnection of the USB A connector



• The "P.RUN" LED is on in the display-off mode (when the PLC function is operating).

# 5.4.7 Resetting USB host errors

When a USB device is connected to the USB connector (connector A), the USB host error can be canceled without performing an inverter reset.

Pr.	Name	Initial value	Setting range	Description	
1049	USB host reset	0	0	Read only	
E110			1	Resets the USB host.	

- Parameter copy (refer to page 521) and the trace function (refer to page 433) can be used when a USB device (such as a USB memory) is connected to the USB connector (connector A).
- When a device such as a USB charger is connected to the USB connector and an excessive current (500 mA or higher) flows, USB host error LF (UF warning) is displayed on the operation panel.
- If a UF warning occurs, disconnect the USB device and set **Pr.1049=**"1" to cancel the USB error. (The UF warning can also be canceled by resetting the inverter power or resetting with the RES signal.)

5

GROUP **E** 

# 5.4.8 Setting dial potentiometer mode/key lock operation selection

The setting dial of the operation panel (FR-DU08) can be used for setting like a potentiometer. The key operation of the operation panel can be disabled.

Pr.	Name	Initial value	Setting range	Description	
161 E200	Frequency setting/key lock operation selection		0	Setting dial frequency setting mode	Key lock mode
			1	Setting dial potentiometer mode	disabled
		0	Setting dial frequency setting mode	Karria ale manda a mahind	
			11	Setting dial potentiometer mode	Key lock mode enabled

#### **◆**Using the setting dial like a potentiometer to set the frequency

• The frequency can be set by simply turning the setting dial of the operation panel (FR-DU08) during operation.

needs not to be pressed. (For the details of the operation method, refer to page 98.)



- If the display changes from flickering "60.00" to "0.00", the setting value of Pr.161 may not be "1".
- The newly-set frequency will be saved as the set frequency in EEPROM after 10 s.
- When setting the frequency by turning the setting dial, the frequency goes up to the set value of **Pr.1 Maximum frequency** (initial value: 200 Hz). Be aware of what frequency **Pr.1** is set to, and adjust the setting of **Pr.1** according to the application.

# ◆Disabling the setting dial and key operation of the operation panel (Press and hold [MODE] (2 s))

- Operation using the setting dial and keys of the operation panel (FR-DU08) can be disabled to prevent parameter changes, unexpected starts or frequency changes.
- Set **Pr.161** to "10 or 11" and then press MODE for 2 s to disable setting dial or key operations.
- When setting dial and key operations are disabled, \( \frac{1}{2} \) \( \frac{1}{2} \) appears on the operation panel. If setting dial or key operation is attempted while dial and key operations are disabled, \( \frac{1}{2} \) \( \frac{1}{2} \) appears. (When a setting dial or key operation is not performed for 2 s, the monitor display appears.)
- To enable the setting dial and key operation again, press MODE for 2 s.



- Even if setting dial and key operations are disabled, the monitor indicator and are enabled.
- The PU stop cannot be released with key operations unless the operation lock is released first.

« Parameters referred to »

Pr.1 Maximum frequency page 245

#### 5.4.9 Frequency change increment amount setting


When setting the set frequency with the setting dial of the operation panel (FR-DU08), the frequency changes in 0.01 Hz increments in the initial status. Setting this parameter to increase the frequency increment amount that changes when the setting dial is rotated can improve usability.

Pr.	Name	Initial value	Setting range	Description	
295 E201	Frequency change increment amount setting	0	0	Function invalid	
			0.01		
			0.10	The minimum change width when the set	
			1.00	frequency is changed with the setting dial can be set.	
			10.00	dan be set.	

#### Basic operation

• When Pr.295≠"0", the minimum increment when the set frequency is changed with the setting dial can be set. For example, when Pr.295="1.00 Hz", one click (one dial gauge) of the setting dial changes the frequency in increments of 1.00 Hz, such as 1.00 Hz  $\rightarrow$  2.00 Hz  $\rightarrow$  3.00 Hz.

When Pr.295="1"



## NOTE:

- · When machine speed display is selected in Pr.37 Speed display, the minimum increments of change are determined by Pr.295 as well. Note that the setting value may differ because the speed setting performs frequency conversion for the set machine speed, and then reverse-converts it to the speed display again.
- · For Pr.295, the increments are not displayed.
- The Pr.295 setting is enabled only for changes to the set frequency. It does not apply to the settings of other parameters related to frequency.
- When 10 is set, the frequency setting changes in 10 Hz increments. Be cautious of excessive speed (in potentiometer mode).

#### Parameters referred to

Pr.37 Speed display page 261

# 5.4.10 Multiple rating setting

Four rating types of different rated current and permissible load can be selected. The optimal inverter rating can be chosen in accordance with the application, enabling equipment size to be reduced.

Pr.	Name	Initial value		Setting	Description (overload current rating,	
PI.		FM	CA	range	surrounding air temperature)	
570	Multiple rating setting		0	0	SLD rating 110% 60 s, 120% 3 s (inverse-time characteristics) Surrounding air temperature 40°C	
E301				1	LD rating 120% 60 s, 150% 3 s (inverse-time characteristics) Surrounding air temperature 50°C	

# ◆Changing the parameter initial values and setting ranges

• When inverter reset and all parameter clear are performed after setting **Pr.570**, the parameter initial values are changed according to each rating, as shown below.

Pr.	Name	Pr.570 s	Refer	
FI.	Name	0	1	to
9	Electronic thermal O/L relay	SLD rated current*1	LD rated current*1	225
22	Stall prevention operation level	110%	120%	248
48	Second stall prevention operation level	110%	120%	248
56	Current monitoring reference	SLD rated current*1	LD rated current*1	273
148	Stall prevention level at 0 V input	110%	120%	248
149	Stall prevention level at 10 V input	120%	150%	248
150	Output current detection level	110%	120%	296
165	Stall prevention operation level for restart	110%	120%	414
557	Current average value monitor signal output reference current	SLD rated current*1	LD rated current*1	185
874	OLT level setting	110%	120%	248
893	Energy saving monitor reference (motor capacity)	SLD rated motor capacity*1	LD rated motor capacity*1	283

<sup>\*1</sup> The rated current and motor capacity differ depending on the inverter capacity. Refer to the inverter rated specifications (page 578).

# • NOTE

 When Pr.570="0" (SLD rating), carrier frequency automatic reduction is enabled regardless of the setting in Pr.260 PWM frequency automatic switchover.

#### Parameters referred to >>>

Pr.260 PWM frequency automatic switchover page 179

# 5.4.11 Using the power supply exceeding 480 V

To input a voltage between 480 V and 500 V to the 400 V class inverter, change the voltage protection level.

Pr.	Name	Initial value	Setting range	Description
977	Innut voltage made calcution	0	0	400 V class voltage protection level
E302	Input voltage mode selection		1	500 V class voltage protection level

- To use a voltage between 480 V and 500 V, set Pr.977 Input voltage mode selection = "1". The setting is applied after a reset.
- Setting **Pr.977** = "1" will change the voltage protection level to the one for the 500 V class.
- The increased magnetic excitation deceleration level is changed to 740 V. (Use **Pr.660 Increased magnetic excitation** deceleration operation selection to select the increased magnetic excitation deceleration.)

# • NOTE

- $\bullet$  Stand-alone options (except line noise filter) cannot be used when inputting a voltage between 480 and 500 V.
- The voltage protection level of the 200 V class inverters is not affected by the Pr.977 setting.

#### « Parameters referred to »

Pr.660 Increased magnetic excitation deceleration operation selection page 517

#### 5.4.12 **Parameter write selection**

Whether to enable the writing to various parameters or not can be selected. Use this function to prevent parameter values from being rewritten by misoperation.

Pr.	Name	Initial value	Setting range	Description
			0	Writing is enabled only during stop.
77	Parameter write selection	0	1 Parameter writing is disable	Parameter writing is disabled.
E400	Talameter write selection		2	Parameter writing is enabled in any operation mode regardless of the operation status.

<sup>•</sup> Pr.77 can be set at any time regardless of the operation mode or operation status. (Setting through communication is unavailable.)

# **♦**Writing parameters only during stop (Pr.77 = "0" initial value)

- Parameters can be written only during a stop in the PU operation mode.
- The following parameters can always be written regardless of the operation mode or operation status.

Pr.	Name
4 to 6	(Multi-speed setting high-speed, middle-speed, low-speed)
22	Stall prevention operation level
24 to 27	(Multi-speed setting speed 4 to speed 7)
52	Operation panel main monitor selection
54	FM/CA terminal function selection
55	Frequency monitoring reference
56	Current monitoring reference
72*1	PWM frequency selection
75	Reset selection/disconnected PU detection/PU stop selection
77	Parameter write selection
79*2	Operation mode selection
129	PID proportional band
130	PID integral time
133	PID action set point
134	PID differential time
158	AM terminal function selection
160	User group read selection
232 to 239	(Multi-speed setting speed 8 to speed 15)
240*1	Soft-PWM operation selection
241	Analog input display unit switchover
268	Monitor decimal digits selection
290	Monitor negative output selection
295	Frequency change increment amount setting
296, 297	(Password setting)
306	Analog output signal selection
310	Analog meter voltage output selection
340*2	Communication startup mode selection
345, 346	(DeviceNet communication)
416, 417	(PLC function)
434, 435	(CC-Link communication)
496, 497	(Remote output)
498	PLC function flash memory clear

Pr.	Name	
550*2	NET mode operation command source selection	
551*2	PU mode operation command source selection	
555 to 557	(Current average value monitor)	
656 to 659	(Analog remote output)	
663	Control circuit temperature signal output level	
755 to 758	(Second PID control)	
759	PID unit selection	
774 to 776	(PU/DU monitor selection)	
866	Torque monitoring reference	
888, 889	(Free parameter)	
891 to 899	(Energy saving monitor)	
C0 (900)	FM/CA terminal calibration	
C1 (901)	AM terminal calibration	
C8 (930)	Current output bias signal	
C9 (930)	Current output bias current	
C10 (931)	Current output gain signal	
C11 (931)	Current output gain current	
990	PU buzzer control	
991	PU contrast adjustment	
992	Operation panel setting dial push monitor selection	
997	Fault initiation	
998*2	PM parameter initialization	
999*2	Automatic parameter setting	
1006	Clock (year)	
1007	Clock (month, day)	
1008	Clock (hour, minute)	
1019	Analog meter voltage negative output selection	
1048	Display-off waiting time	
1142	Second PID unit selection	
1150 to 1199	(PLC function user parameters)	
1211 to 1219	(PID gain tunig)	
1460 to 1466	(PID multistage set points 1 to 7)	
1480 to 1485	(Load characteristics fault detection)	

<sup>\*1</sup> Writing during operation is enabled in PU operation mode, but disabled in External operation mode.

<sup>\*2</sup> Writing during operation is disabled. To change the parameter setting value, stop the operation.

#### **◆**Disabling parameter write (Pr.77="1")

- Parameter write, parameter clear and all parameter clear are disabled. (Parameter read is enabled.)
- The following parameters can be written even if **Pr.77**="1".

Pr.	Name
22	Stall prevention operation level
75	Reset selection/disconnected PU detection/ PU stop selection
77	Parameter write selection
79	Operation mode selection*1
160	User group read selection
296	Password lock level

Pr.	Name	
297	Password lock/unlock	
345, 346	(DeviceNet communication)	
496, 497	(Remote output)	
656 to 659	(Analog remote output)	
805	Torque command value (RAM)	
997	Fault initiation	

<sup>\*1</sup> Writing during operation is disabled. To change the parameter setting value, stop the operation.

#### **♦**Writing parameters during operation (Pr.77="2")

- These parameters can always be written.
- The following parameters cannot be written during operation if **Pr.77**="2". To change the parameter setting value, stop the operation.

Pr.	Name		
23	Stall prevention operation level compensation		
23	factor at double speed		
48	Second stall prevention operation level		
49	Second stall prevention operation frequency		
60	Energy saving control selection		
66	Stall prevention operation reduction starting frequency		
71	Applied motor		
79	Operation mode selection		
80	Motor capacity		
81	Number of motor poles		
82	Motor excitation current		
83	Rated motor voltage		
84	Rated motor frequency		
90 to 94	(Motor constant)		
95	Online auto tuning selection		
96	Auto tuning setting/status		
135 to 139	(Electronic bypass sequence parameter)		
178 to 196	(Input and output terminal function selection)		
248	Self power management selection		
254	Main circuit power OFF waiting time		
261	Power failure stop selection		
289	Inverter output terminal filter		
291	Pulse train I/O selection		
298	Frequency search gain		
313 to 322	(Extended output terminal function selection)		
329	Digital input unit selection		
414	PLC function operation selection		
415	Inverter operation lock mode setting		
418	Extension output terminal filter		
450	Second applied motor		
453	Second motor capacity		
454	Number of second motor poles		

Pr.	Name	
455	Second motor excitation current	
456	Rated second motor voltage	
457	Rated second motor frequency	
458 to 462	(Second motor constant)	
463	Second motor auto tuning setting/status	
541	Frequency command sign selection	
560	Second frequency search gain	
561	PTC thermistor protection level	
570	Multiple rating setting	
574	Second motor online auto tuning	
578	Auxiliary motor operation selection	
579	Motor connection function selection	
598	Undervoltage level	
606	Power failure stop external signal input selection	
660 to 662	(Increased magnetic excitation deceleration)	
673	SF-PR slip amount adjustment operation selection	
699	Input terminal filter	
702	Maximum motor frequency	
706, 707, 711, 712, 717, 721, 724, 725	(PM motor tuning)	
738 to 746	(Second PM motor tuning)	
800	Control method selection	
858	Terminal 4 function assignment	
859	Torque current/Rated PM motor current	
860	Second motor torque current/Rated PM motor current	
868	Terminal 1 function assignment	
977	Input voltage mode selection	
998	PM parameter initialization	
999	Automatic parameter setting	
1002	Lq tuning target current adjustment coefficient	

Registering a 4-digit password can restrict parameter reading/writing.

Pr.	Name	Initial value	Setting range	Description
296 E410	Password lock level	9999	0 to 6, 99, 100 to 106, 199	Select restriction level of parameter reading/ writing when a password is registered.
E410			9999	No password lock
			1000 to 9998	Register a 4-digit password
297 E411	Password lock/unlock	9999	(0 to 5) *1 Displays password unlock error count only) (Valid when <b>Pr.296</b> = "100 to 10")	
			9999 *1	No password lock

The above parameters can be set when Pr.160 User group read selection = "0". However, when Pr.296 ≠ 9999 (password lock is set), Pr.297 can always be set, regardless of the setting in Pr.160.

\*1 When Pr.297 = "0, 9999", writing is always enabled, but setting is disabled. (The display cannot be changed.)

#### ◆Parameter reading/writing restriction level (Pr.296)

• The level of the reading/writing restriction using the PU/Network (NET) operation mode operation command can be selected with Pr.296.

Pr.296 setting	DII operatio	n made eneration	NE.	NET operation mode operation command•4			
	PU operation mode operation command+3			erminals / PLC nction*7	Communication option		
	Read*1	Write*2	Read	Write*2	Read	Write*2	
9999	0	0	0	0	0	0	
0, 100*6	×	×	×	×	×	×	
1, 101	0	×	0	×	0	×	
2, 102	0	×	0	0	0	0	
3, 103	0	0	0	×	0	×	
4, 104	×	×	×	×	0	×	
5, 105	×	×	0	0	0	0	
6, 106	0	0	×	×	0	×	
99 to 199	,	rs registered in the user s not registered in the u	• .		104" applies.)		

- \*1 If the parameter reading is restricted by the Pr.160 User group read selection setting, those parameters are unavailable for reading even when
- \*2 If the parameter writing is restricted by the Pr.77 Parameter write selection setting, those parameters are unavailable for writing even when "O" is indicated.
- \*3 This restricts parameter access from the command source that can write a parameter under the PU operation mode (initially the operation panel (FR-DU08) or the parameter unit). (For the PU operation mode command source selection, refer to page 210.)
- \*4 This restricts parameter access from the command source that can write a parameter under the Network operation mode (initially the RS-485 terminals or a communication option). (For the NET operation mode command source selection, refer to page 210.)
- \*5 Read/write is enabled only for the simple mode parameters registered in the user group when Pr.160="9999". Pr.296 and Pr.297 are always read/write enabled whether registered to a user group or not.
- \*6 If a communication option is installed, an option fault Option fault (E.OPT) occurs, and the inverter output shuts off. (Refer to page 546.)
- \*7 The PLC function user parameters (Pr.1150 to Pr.1199) can be written and read by the PLC function regardless of the Pr.296 setting.

# ◆Registering a password (Pr.296, Pr.297)

- · The following section describes how to register a password.
  - 1)Set the parameter reading/writing restriction level. (Pr.296 ≠ "9999")

Pr.296 setting	Password unlock error restriction	Pr.297 display
0 to 6, 99	No restriction	Always displays 0
100 to 106, 199*1	Restricted at fifth error	Displays the error count (0 to 5)

- During Pr.296 = any of "100 to 106, 199", if password unlock error has occurred 5 times, correct password will not unlock the restriction. All parameter clear can unlock the restriction. (In this case, the parameters are returned to their initial values.)
- 2)Write a four-digit number (1000 to 9998) in Pr.297 as a password. (Writing is disabled when Pr.296="9999".) When a password is registered, parameter reading/writing is restricted with the restriction level set in Pr.296 until unlocking.



- After registering a password, the read value of Pr.297 is always one of "0 to 5".
- | | | appears when a password restricted parameter is read/written.
- Even if a password is registered, the parameters, which the inverter itself writes, such as inverter parts life are overwritten as needed
- Even if a password is registered, reading/writing is enabled for Pr.991 PU contrast adjustment when the parameter unit (FR-PU07) is connected.

#### ◆Unlocking a password (Pr.296, Pr.297)

- · There are two ways of unlocking the password.
- Enter the password in **Pr.297**. If the password matches, it unlocks. If the password does not match, an error occurs and the password does not unlock. When any of "100 to 106, or 199" is set in **Pr.296** and a password unlock error occurs five times, the restriction will not be unlocked even if the correct password is subsequently input. (Password lock in operation.)
- · Perform all parameter clear.

#### • NOTE

- If the password is forgotten, it can be unlocked with all parameter clear, but doing so will also clear the other parameters.
- · All parameter clear cannot be performed during the operation.
- During the conditions where parameter reading is disabled (**Pr.296** = any of "0, 4, 5, 99, 100, 104, 105, or 199"), do not use FR Configurator2. It may not operate correctly.
- The password unlocking method differs between the operation panel, parameter unit, RS-485 communication and communication option.

	Operation panel/ parameter unit	RS-485 communication	Communication option
All parameter clear	0	0	0
Parameter clear	×	×	0

O: Password can be unlocked, x: Password cannot be unlocked

• For the parameter clear and parameter all clear methods for the communication option and parameter unit, refer to the Instruction Manual of each option. (For the operation panel (FR-DU08), refer to page 520, for the Mitsubishi inverter protocol of RS-485 communication, refer to page 451, and for the Modbus-RTU communication protocol, refer to page 465.)

# ◆Parameter operations during password locking/unlocking

		Password	l unlocked	Password locked	Password lock in operation
Operation		Pr.296 = 9999 Pr.296 ≠ 9999		Pr.296 ≠ 9999	Pr.296 = 100 to 106, 199
		Pr.297 = 9999	Pr.297 = 9999	Pr.297 = 0 to 4 (read value)	Pr.297 = 5 (read value)
Read Read		O*1	0	0	0
Pr.296 Write		O*1	O*1	×	×
Pr.297	Read	O*1	0	0	0
P1.291	Write	×	0	0	O*3
Paramete execution		0	0	X*4	×*4
All parameter clear execution		0	0	O*2	O*2
Paramete execution		0	0	×	×

O: Enabled, x: Disabled

- \*1 Reading/writing is disabled if reading is restricted by the **Pr.160** setting. (Reading is available in the Network operation mode regardless of the **Pr.160** setting.)
- \*2 All parameter clear cannot be performed during the operation.
- \*3 Correct password will not unlock the restriction.
- \*4 Parameter clear can only be performed from the communication option.

# • NOTE

- When **Pr.296** = "4, 5, 104, or 105" (password lock), the setting screen for PU JOG frequency is not displayed in the parameter unit (FR-PU07).
- When the password is being locked, parameter copy using the operation panel, parameter unit and USB memory is not enabled.

#### Parameters referred to

Pr.77 Parameter write selection page 169

Pr.160 User group read selection page 177

Pr.550 NET mode operation command source selection page 210

Pr.551 PU mode operation command source selection page 210

#### 5.4.14 Free parameter

Any number within the setting range of 0 to 9999 can be input.

For example, these numbers can be used:

- · As a unit number when multiple units are used.
- As a pattern number for each operation application when multiple units are used.
- As the year and month of introduction or inspection.

Pr.	Name	Initial value	Setting range	Description
888 E420	Free parameter 1	9999	0 to 9999	Any value can be input. The settings are retained even if the inverter power is
889 E421	Free parameter 2	9999	0 to 9999	turned OFF.



<sup>•</sup> Pr.888 and Pr.889 do not influence the operation of the inverter.

#### 5.4.15 Setting multiple parameters as a batch

Parameter settings are changed as a batch. Those include communication parameter settings for the Mitsubishi's human machine interface (GOT) connection and the parameter setting for the rated frequency settings of 50 Hz/60 Hz and acceleration/deceleration time.

Multiple parameters are changed automatically. Users do not have to consider each parameter number. (Automatic parameter setting mode)

Pr.	Name	Initial value	Setting range	Description		
			1	Standard PID display setting		
			2	Extended PID display setting	_	
			10	GOT initial setting (PU connector)	"Controller Type" in GOT: FREQROL	
999 E431			11	GOT initial setting (RS485 terminals)	500/700/800, SENSORLESS SERVO	
	Automatic parameter setting	9999*1	12	GOT initial setting (PU connector)	"Controller Type" in GOT: FREQROL	
			13	GOT initial setting (RS-485 terminal)	800 (Automatic Negotiation)	
			20	50 Hz rated frequency	L	
			21	60 Hz rated frequency		
			9999	No action		

<sup>\*1</sup> The read value is always "9999".

#### **◆**Automatic parameter setting (Pr.999)

• Select which parameters to automatically set from the table below, and set them in Pr.999. Multiple parameter settings are changed automatically. Refer to page 175 for the list of parameters that are changed automatically.

Pr.999 Setting	Description		Operation in the automatic parameter setting mode		
1	Sets the standard monit	or indicator setting of PID control.	$\square$ (AUTO) $\rightarrow$ $\square$ (PID) $\rightarrow$ Write "1"		
2	Automatically sets the n	nonitor indicator for PID control.	$\square$ (AUTO) $\rightarrow \square$ (PID) $\rightarrow$ Write "2"		
10	connection with a PU co	ommunication parameters for the GOT onnector ("Controller Type" in GOT: 0, SENSORLESS SERVO)	$A \subseteq A \subseteq$		
11	connection with RS-485	ommunication parameters for the GOT terminals ("Controller Type" in GOT: 0, SENSORLESS SERVO)	_		
12	,	ommunication parameters for the GOT onnector ("Controller Type" in GOT: atic Negotiation))			
13	Automatically sets the communication parameters for the GOT connection with RS-485 terminals ("Controller Type" in GOT: FREQROL 800 (Automatic Negotiation))		_		
20	50 Hz rated frequency	Sets the related parameters of the rated frequency according to the power supply	$\square$ (AUTO) $\rightarrow$ $\square$ (F50) $\rightarrow$ Write "1"		
21	60 Hz rated frequency	frequency	_		

# • NOTE

• If the automatic setting is performed with Pr.999 or the automatic parameter setting mode, the settings including the changed parameter settings (changed from the initial setting) will be automatically changed. Before performing the automatic setting, confirm that changing the parameters will not cause any problem.

# ◆PID monitor indicator setting (Pr.999 = "1 or 2")

Pr.	Name	Initial value	Pr.999="1"	Pr.999="2"	Refer to page
759	PID unit selection	9999	9999	4	399
1142	Second PID unit selection	9999	9999	4	355
774	Operation panel monitor selection 1	9999	9999	52	
775	Operation panel monitor selection 2	9999	9999	53	263
776	Operation panel monitor selection 3	9999	9999	54	-
C42 (934)	PID display bias coefficient	9999	9999	0	
C44 (935)	PID display gain coefficient	9999	9999	100	399
1136	Second PID display bias coefficient	9999	9999	0	399
1138	Second PID display gain coefficient	9999	9999	100	
_	3-step monitor setting	_	Disabled	Enabled*1	_
_	Extended direct setting	_	Disabled	Enabled*1	_
_	Dedicated parameter list function	_	Disabled	Enabled*1	_

<sup>\*1</sup> Enabled when the FR-PU07-01 is used.

· 3-line monitor setting

The 3-line monitor is used as the first monitor.

· Extended direct setting

Pressing the [FUNC] key of the FR-PU07-01 displays the extended direct setting screen. The PID action set point can be directly set regardless of the operation mode or Pr.77 Parameter write selection setting.

Pressing the [FUNC] key on the extended direct setting screen displays the function menu.

Extended direct setting	Parameter to be set
Extended direct setting 1	Pr.133 PID action set point
Extended direct setting 2	Pr.755 Second PID action set point

· Dedicated parameter list function

Pressing the [PrSET] key of the FR-PU07-01 displays the dedicated parameter list. Parameters that need to be set first for the PID extended display setting are listed.

Dedicated parameter list	Parameter to be set
No.1	Pr.999 Automatic parameter setting
No.2	Pr.934 PID display bias coefficient
No.3	Pr.935 PID display gain coefficient

# • NOTE

• The display of parameters other than the above may be changed due to changes in C42 or C44. Set the PID monitor indicator before changing the settings of other parameters.

#### ◆GOT initial setting (PU connector) (Pr.999 = "10, 12")

Pr.	Name	Initial value	Pr.999="10"	Pr.999="12"	Refer to page
79	Operation mode selection	0	1	1	200
118	PU communication speed	192	192	1152	
119	PU communication stop bit length	1	10	0	
120	PU communication parity check	2	1	1	
121	Number of PU communication retries	1	9999	9999	449
122	PU communication check time interval	9999	9999	9999	
123	PU communication waiting time setting	9999	0 ms	0 ms	
124	PU communication CR/LF selection	1	1	1	
340	Communication startup mode selection	0	0	0	209
414	PLC function operation selection	0	_	2*1	431

- \*1 When **Pr.414=**"1", the setting value is not changed.
- Initial setting with the GOT2000 series
  - When "FREQROL 500/700/800, SENSORLESS SERVO" is selected for "Controller Type" in the GOT setting, set Pr.999="10" to configure the GOT initial setting.
  - When "FREQROL 800 (Automatic Negotiation)" is selected for "Controller Type" in the GOT setting, the GOT automatic connection can be used. When "FREQROL 800 (Automatic Negotiation)" is selected for "Controller Type" in the GOT setting and the GOT automatic connection is not used, set Pr.999="12" to configure the GOT initial setting. (Refer to page 494)
- Initial setting with the GOT1000 series
  - Set Pr.999="10" to configure the GOT initial setting.

- · Always perform an inverter reset after the initial setting.
- For the details of connection with GOT, refer to the Instruction Manual of GOT.

#### ◆GOT initial setting (RS-485 terminals) (Pr.999 = "11, 13")

Pr.	Name	Initial value	Pr.999="11"	Pr.999="13"	Refer to page
79	Operation mode selection	0	0	0	200
332	RS-485 communication speed	96	192	1152	
333	RS-485 communication stop bit length	1	10	0	
334	RS-485 communication parity check selection	2	1	1	449
335	RS-485 communication retry count	1	9999	9999	445
336	RS-485 communication check time interval	0 s	9999	9999	
337	RS-485 communication waiting time setting	9999	0 ms	0 ms	
340	Communication startup mode selection	0	1	1	209
341	RS-485 communication CR/LF selection	1	1	1	449
414	PLC function operation selection	0	_	2*1	431
549	Protocol selection	0	0	0	465

- \*1 When **Pr.414=**"1", the setting value is not changed.
- Initial setting with the GOT2000 series
  - When "FREQROL 500/700/800, SENSORLESS SERVO" is selected for "Controller Type" in the GOT setting, set **Pr.999**="11" to configure the GOT initial setting.
  - When "FREQROL 800 (Automatic Negotiation)" is selected for "Controller Type" in the GOT setting, the GOT automatic connection can be used. When "FREQROL 800 (Automatic Negotiation)" is selected for "Controller Type" in the GOT setting and the GOT automatic connection is not used, set **Pr.999=**"13" to configure the GOT initial setting. (Refer to page 494)
- · Initial setting with the GOT1000 series
  - Set Pr.999="11" to configure the GOT initial setting.

#### NOTE

- Always perform an inverter reset after the initial setting.
- For the details of connection with GOT, refer to the Instruction Manual of GOT.

# **♦**Rated frequency (Pr.999 = "20 (50 Hz), 21 (60 Hz)")

Pr.	Name	Initial	value	Pr.999 = "21"	Pr.999 = "20"	Refer to
Pr.	Name	FM type	CA type	F1.999 - 21		page
3	Base frequency	60 Hz	50 Hz	60 Hz	50 Hz	497
4	Multi-speed setting (high speed)	60 Hz	50 Hz	60 Hz	50 Hz	222
20	Acceleration/deceleration reference frequency	60 Hz	50 Hz	60 Hz	50 Hz	187
37	Speed display	0	•	0		261
55	Frequency monitoring reference	60 Hz	50 Hz	60 Hz	50 Hz	273
66	Stall prevention operation reduction starting frequency	60 Hz	50 Hz	60 Hz	50 Hz	248
125 (903)	Terminal 2 frequency setting gain frequency	60 Hz	50 Hz	60 Hz	50 Hz	314
126 (905)	Terminal 4 frequency setting gain frequency	60 Hz	50 Hz	60 Hz	50 Hz	
263	Subtraction starting frequency	60 Hz	50 Hz	60 Hz	50 Hz	
266	Power failure deceleration time switchover frequency	60 Hz	50 Hz	60 Hz	50 Hz	426
386	Frequency for maximum input pulse	60 Hz	50 Hz	60 Hz	50 Hz	218
390	% setting reference frequency	60 Hz	50 Hz	60 Hz	50 Hz	480
505	Speed setting reference	60 Hz	50 Hz	60 Hz	50 Hz	261
584	Auxiliary motor 1 starting frequency	60 Hz	50 Hz	60 Hz	50 Hz	
585	Auxiliary motor 2 starting frequency	60 Hz	50 Hz	60 Hz	50 Hz	406
586	Auxiliary motor 3 starting frequency	60 Hz	50 Hz	60 Hz	50 Hz	
C14 (918)	Terminal 1 gain frequency (speed)	60 Hz	50 Hz	60 Hz	50 Hz	314
1013	Emergency drive running speed after retry reset	60 Hz	50 Hz	60 Hz	50 Hz	238

#### 5.4.16 Extended parameter display and user group **function**

This function restricts the parameters that are read by the operation panel and the parameter unit.

Pr.	Name	Initial value		Cotting range	Description	
PI.	Name	FM	CA	Setting range	Description	
	User group read selection	9999		9999	Only simple mode parameters can be displayed.	
160 E440			0	0	Simple mode and extended parameters can be displayed.	
				1	Only parameters registered in user groups can be displayed.	
172 E441	User group registered	0		0	(0 to 16)	Displays the number of groups that are registered as user groups. (Read-only)
E441	display/batch clear			9999	Batch clear of user group registrations	
173 E442	User group registration	9999*1		0 to 1999, 9999	Sets the parameter number to register for the user group.	
174 E443	User group clear	9999*1		0 to 1999, 9999	Sets the parameter number to clear from the user group.	

<sup>\*1</sup> The read value is always "9999".

#### Display of simple mode parameters and extended parameters (Pr.160)

- When Pr.160 = "9999", only the simple mode parameters can be displayed on the operation panel and the parameter unit. (For the simple mode parameters, refer to the parameter list page 112.)
- With the initial value (Pr.160 = "0"), simple mode parameters and extended parameters can be displayed.

#### • NOTE

- When a plug-in option in installed on the inverter, the option parameters can also be read.
- Every parameter can be read regardless of the Pr.160 setting when reading parameters via a communication option.
- When reading the parameters using the RS-485 terminals, all parameters can be read regardless of the Pr.160 setting by setting Pr.550 NET mode operation command source selection and Pr.551 PU mode operation command source selection.

Pr.551	Pr.550	Pr.160 enabled/disabled	
1 (RS-485)	-	Enabled	
0 (DL)	0 (Communication option)	Enabled	
2 (PU) 3 (USB)	1 (RS-485)	Disabled (All can be read)	
9999 (Automatic determination)	0000 (Automatic determination)	With communication option: Enabled	
(Initial value)	9999 (Automatic determination) (Initial value)	Without communication option: Disabled (All can be read)	

• When the LCD operation panel (FR-LU08) or the parameter unit (FR-PU07) is installed, Pr.15 Jog frequency, Pr.16 Jog acceleration/deceleration time, C42(Pr.934) PID display bias coefficient, C43(Pr.934) PID display bias analog value, C44(Pr.935) PID display gain coefficient, C45(Pr.935) PID display gain analog value and Pr.991 PU contrast adjustment are displayed as simple mode parameters.

# ◆User group function (Pr.160, Pr.172 to Pr.174)

- The user group function is a function for displaying only the parameters required for a setting.
- A maximum of 16 parameters from any of the parameters can be registered in a user group. When **Pr.160**="1", reading/ writing is enabled only for the parameters registered in user groups. (Parameters not registered in user groups can no longer be read.)
- To register a parameter in a user group, set the parameter number in Pr.173.
- To clear a parameter from a user group, set the parameter number in Pr.174. To batch clear all the registered parameters, set Pr.172 = "9999".

#### ◆Registering a parameter in a user group (Pr.173)

• To register Pr.3 in a user group

	Operation —
1	Power ON
١.	Make sure the motor is stopped.
	Changing the operation mode
2.	Press PU to choose the PU operation mode. [PU] indicator is on.
	Parameter setting mode
3.	Press MODE to select the parameter setting mode. (The parameter number read previously appears.)
	Selecting the parameter number
4.	Turn 🕄 until 🟳 🖂 [Pr.173) appears.
	Selecting the parameter number
5.	Press SET to display " 9999 ".
	Parameter registration
6.	Turn  until  (Pr.3) appears. Press  to register the parameter.  173 and  flicker alternately.
	To continue adding parameters, repeat steps 5 and 6.

#### **◆**Clearing a parameter from a user group (Pr.174)

• To delete Pr.3 from a user group

1 Po	ower ON
•	Make sure the motor is stopped.
	hanging the operation mode
2.	Press PU to choose the PU operation mode. [PU] indicator is on.
	arameter setting mode
3.	Press MODE to select the parameter setting mode. (The parameter number read previously appears.)
Se	electing the parameter number
4.	Turn until — (Pr.174) appears.
	electing the parameter number
5.	Press SET to display " 9999 ".
CI	learing the parameter
6.	Turn until $\exists$ (Pr.3) appears. Press SET to delete the parameter. $\Box$ $\Box$ and $\Box$ flicker alternately.
	To continue deleting parameters, repeat steps 5 and 6.

#### • NOTE

- Pr.77 Parameter write selection, Pr.160, Pr.296 Password lock level, Pr.297 Password lock/unlock and Pr.991 PU
  contrast adjustment can always be read regardless of the user group setting. (For Pr.991, only when the FR-LU08 or the
  FR-PU07 is connected.)
- Pr.77, Pr.160, Pr.172 to Pr.174, Pr.296, Pr.297 cannot be registered in a user group.
- When Pr.174 is read, "9999" is always displayed. "9999" can be written, but it does not function.
- Pr.172 is disabled if set to a value other than "9999".

#### # Parameters referred to

Pr.15 Jog frequency, Pr.16 Jog acceleration/deceleration time page 221
Pr.77 Parameter write selection page 169
Pr.296 Password lock level, Pr.297 Password lock/unlock page 171
Pr.550 NET mode operation command source selection page 210
Pr.551 PU mode operation command source selection page 210
Pr.991 PU contrast adjustment page 165

#### 5.4.17 **PWM** carrier frequency and Soft-PWM control

The motor sound can be changed.

Pr.	Name	Initial value	Setting range	Description	
72			0 to 15*1	The PWM carrier frequency can be changed. The setting displayed is in [kHz]. Note that 0 indicates 0.7	
E600	PWM frequency selection   2		0 to 6, 25*2	kHz, 15 indicates 14.5 kHz, and 25 indicates 2.5 kHz. (The setting value "25" is for the sine wave filter.)	
240	Soft-PWM operation	1	0	Soft-PWM disabled	
E601	selection		1	The soft-PWM is enabled.	
260 E602	PWM frequency automatic switchover	1	0	The PWM carrier frequency is constant regardless of the load.  When the carrier frequency is set to 3 kHz or higher (Pr.72 ≥ 3), perform continuous operation at less than 85% of the inverter rated current.	
			1	When the load increases, the PWM carrier frequency is reduced.	

- \*1 The setting range for the FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower.
- \*2 The setting range for the FR-F820-03160(75K) or higher and FR-F840-01800(75K) and higher.

# Changing the PWM carrier frequency (Pr.72)

- The PWM carrier frequency of the inverter can be changed.
- · Changing the PWM carrier frequency can be effective for avoiding the resonance frequency of the mechanical system or motor, as a countermeasure against EMI generated from the inverter, or for reducing leakage current caused by PWM
- · Under PM motor control, the following carrier frequencies are used.

Pr.72 setting	Carrier frequency (kHz)
0 to 5	2
6 to 9	6*1
10 to 13	10*1
14, 15	14*1

- \*1 In the low-speed range (slower than 10% of the rated motor frequency), the carrier frequency is automatically changed to 2 kHz. (For FR-F820-00490(11K) or lower and FR-F840-00250(11K) or lower)
- When using the optional sine wave filter (MT-BSL/BSC), set Pr.72 = "25" (2.5 kHz). (FR-F820-03160(75K) or higher, FR-F840-01800(75K) or higher.)

- When Pr.72="25", the following limitations apply.
- V/F control is forcibly set.
- Soft-PWM control is disabled.
- The maximum output frequency is 60 Hz.

# ◆Soft-PWM control (Pr.240)

- Soft-PWM control is a control method that changes the motor noise from a metallic sound into an inoffensive, complex tone.
- Setting Pr.240 = "1" will enable the Soft-PWM control.
- To enable the Soft-PWM control for the FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower, set Pr.72 to "5

To enable it for the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher, set Pr.72 to "4 kHz or less".

# NOTE

• While a sine wave filter (Pr.72 = "25") is being used, the Soft-PWM control is disabled.

#### **♦PWM** carrier frequency automatic reduction function (Pr.260)

- Setting Pr.260="1 (initial value)" will enable the PWM carrier frequency auto-reduction function. If a heavy load is continuously applied while the inverter carrier frequency is set to 3 kHz or higher (Pr.72 ≥ "3"), the carrier frequency is automatically reduced to prevent occurrence of the inverter overload trip (electronic thermal O/L relay function) (E.THT). The carrier frequency is reduced to as low as 2 kHz. (Motor noise increases, but not to the point of failure.)
- The auto-reduction function is activated for a continuous operation with the 85% or higher rated inverter current.
- When continuous operation with FR-F840-02600(110K) or higher is performed at 85% of the rated inverter current or higher, the automatic reduction function is activated regardless of the **Pr.570** setting.
- When **Pr.260**="0", the carrier frequency becomes constant (**Pr.72** setting) regardless of the load, making the motor sound uniform. However, when the SLD rating is selected, (**Pr.570**="0"), the operation is the same as **Pr.260**="1".

# NOTE

- Reducing the PWM carrier frequency is effective as a countermeasure against EMI from the inverter or for reducing leakage current, but doing so increases the motor noise.
- When the PWM carrier frequency is set to 1 kHz or lower (Pr.72 ≤ 1), the increase in the harmonic current causes the fast-response current limit to activate before the stall prevention operation, which may result in torque shortage. In this case, disable the fast-response current limit in Pr.156 Stall prevention operation selection.

#### # Parameters referred to

Pr.156 Stall prevention operation selection page 248
Pr.570 Multiple rating setting page 168
Pr.800 Control method selection page 143

# 5.4.18 Inverter parts life display

The degree of deterioration of the control circuit capacitor, main circuit capacitor, cooling fan, and inrush current limit circuit can be diagnosed on the monitor.

When a part approaches the end of its life, an alarm can be output by self diagnosis to prevent a fault. (Note that the life diagnosis of this function should be used as a guideline only, because with the exception of the main circuit capacitor, the life values are theoretical calculations.)


Pr.	Name	Initial value	Setting range	Description
255 E700	Life alarm status display	0	(0 to 15)*1	Displays whether or not the parts of the control circuit capacitor, main circuit capacitor, cooling fan, and inrush current limit circuit have reached the life alarm output level. Read-only.
256 E701 *2	Inrush current limit circuit life display	100%	(0 to 100%)	Displays the deterioration degree of the inrush current limit circuit. Read-only.
257 E702	Control circuit capacitor life display	100%	(0 to 100%)	Displays the deterioration degree of the control circuit capacitor. Read-only.
258 E703 *2	Main circuit capacitor life display	100%	(0 to 100%)	Displays the deterioration degree of the main circuit capacitor. Read-only.  The value measured by <b>Pr.259</b> is displayed.
259 E704 *2	Main circuit capacitor life measuring	0	0, 1 (2, 3, 8, 9)	Setting "1" and turning the power supply OFF starts the mea surement of the main circuit capacitor life. If the setting value of <b>Pr.259</b> becomes "3" after turning the power supply ON again, it means that the measurement is completed. The deterioration degree is read to <b>Pr.258</b> .

- \*1 The setting range (reading only) for separated converter types is "0, 1, 4, or 5".
- \*2 The setting is available only for standard models.

#### ◆Life alarm display and signal output (Y90 signal, Pr.255)

# POINT

- In the life diagnosis of the main circuit capacitor, the alarm signal (Y90) is not output unless measurement by turning OFF the power supply is performed.
- Use Pr.255 Life alarm status display and the life alarm signal (Y90) to check whether or not the parts of the control circuit capacitor, main circuit capacitor, cooling fan or inrush current limit circuit have reached the life alarm output level.



Pr.	255	bit3	h:40	bi44	h:40
Decimal	Binary	DITS	bit2	bit1	bit0
15	1111	0	0	0	0
14	1110	0	0	0	×
13	1101	0	0	×	0
12	1100	0	0	×	×
11	1011	0	×	0	0
10	1010	0	×	0	×
9	1001	0	×	×	0
8	1000	0	×	×	×
7	0111	×	0	0	0
6	0110	×	0	0	×
5	0101	×	0	×	0
4	0100	×	0	×	×
3	0011	×	×	0	0
2	0010	×	×	0	×
1	0001	×	×	×	0
0	0000	×	×	×	×

O: With warnings, x: Without warnings

- The life alarm signal (Y90) turns ON when any of the control circuit capacitor, main circuit capacitor, cooling fan or inrush current limit circuit reaches the life alarm output level.
- For the terminal used for the Y90 signal, set "90" (positive logic) or "190" (negative logic) in any of Pr.190 to Pr.196 (output terminal function selection).

# NOTE

- · When using an option (FR-A8AY, FR-A8AR, FR-A8NC, FR-A8NCE), the life can be output separately to the control circuit capacitor life signal (Y86), main circuit capacitor life signal (Y87), cooling fan life signal (Y88), and inrush current limit circuit life signal (Y89).
- · Changing the terminal assignment using Pr.190 to Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

# Life display of the inrush current limit circuit (Pr.256) (Standard models)

- The life of the inrush current limit circuit (relay, contactor and inrush resistor) is displayed in Pr.256.
- The number of contact (relay, contactor, thyristor) ON times is counted, and it is counted down from 100% (0 time) every 1%/10,000 times. As soon as 10% (900,000 times) is reached, Pr.255 bit 3 is turned ON and also a warning is output to the Y90 signal.

#### ◆Life display of the control circuit capacitor (Pr.257)

- The deterioration degree of the control circuit capacitor is displayed in Pr.257.
- · In the operating status, the control circuit capacitor life is calculated from the energization time and temperature, and is counted down from 100%. As soon as the control circuit capacitor life falls below 10%, Pr.255 bit 0 is turned ON and also a warning is output to the Y90 signal

# **♦Life display of the main circuit capacitor (Pr.258, Pr.259) (Standard** models)



- · For accurate life measurement of the main circuit capacitor, wait three hours or longer after turning OFF. The temperature left in the main circuit capacitor affects measurement.
- The deterioration degree of the main circuit capacitor is displayed in Pr.258.
- With the main circuit capacitor capacity at factory shipment as 100%, the capacitor life is displayed in Pr.258 every time measurement is made. When the measured value falls to 85% or lower, Pr.255 bit 1 is turned ON and also a warning is output to the Y90 signal.
- · Measure the capacitor capacity according to the following procedure and check the deterioration degree of the capacitor capacity.
  - 1) Check that the motor is connected and at a stop.
  - 2) Set "1" (measuring start) in Pr.259.
  - 3) Switch the power OFF. The inverter applies DC voltage to the motor to measure the capacitor capacity while the inverter is OFF.
  - 4) After confirming that the power lamp is OFF, turn ON the power again.
  - 5) Check that "3" (measurement complete) is set in Pr.259, read Pr.258, and check the deterioration degree of the main circuit capacitor.

Pr.259	Description	REMARKS
0	No measurement	Initial value
1	Measurement start	Measurement starts when the power supply is switched OFF
2	During measurement	
3	Measurement complete	Only displayed and connot be set
8	Forced end	Only displayed and cannot be set
9	Measurement error	

# NOTE:

- When the main circuit capacitor life is measured under the following conditions, "forced end" (Pr.259 ="8") or", easurement error" (Pr.259 ="9") may occur, or the status may remain in "measurement start" (Pr.259 ="1"). To perform measurement, first eliminate the following conditions. Under the following conditions, even if "measurement complete" (Pr.259 ="3") is reached, measurement cannot be performed correctly.
- FR-HC2, FR-CV, MT-RC, or a sine wave filter is connected.
- Terminals R1/L11, S1/L21 or DC power supply is connected to terminals P/+ and N/-.
- The power supply is switched ON during measurement.
- The motor is not connected to the inverter.
- The motor is running (coasting).
- The motor capacity is smaller than the inverter capacity by two ranks or more.
- The inverter is tripped or a fault occurred while the power was OFF.
- The inverter output is shut off with the MRS signal.
- The start command is given while measuring.
- The applied motor setting is incorrect.
- Operation environment: surrounding air temperature (annual average of 40°C (free from corrosive gas, flammable gas, oil mist, dust and dirt)).
- Output current (80% of the inverter rating)
- · Since repeated inrush currents at power ON will shorten the life of the converter circuit, frequent starts and stops of the magnetic contactor must be avoided.

#### WARNING

When measuring the main circuit capacitor capacity (Pr.259 ="1"), the DC voltage is applied to the motor for about 1 s at power OFF. Never touch the motor terminal, etc. right after powering OFF to prevent an electric shock.

#### **♦**Life display of the cooling fan

- If a cooling fan speed of less than the specified speed (refer below) is detected, Fan alarm F 🖔 (FN) is displayed on the operation panel and the parameter unit. As an alarm display, Pr.255 bit 2 is turned ON and also a warning is output to the Y90 signal and Alarm (LF) signal.
- For the terminal used for the LF signal, set "98" (positive logic) or "198" (negative logic) in any of Pr.190 to Pr.196 (output terminal function selection).

Capacity	Warning level
FR-F820-00250(5.5K) or lower, FR-F820-03160(75K) or higher FR-F840-00126(5.5K) or lower	Less than 50% of the rated rotations per minute
FR-F820-00340(7.5K) to FR-F820-02330(55K) FR-F840-00170(7.5K) to FR-F840-03610(160K)	Less than 70% of the rated rotations per minute
FR-F840-04320(185K) or higher FR-F842-07700(355K) or higher	Approx. less than 1700 r/min

#### • NOTE


- · When the inverter is mounted with two ore more cooling fans, "FN" is displayed with one or more fans with speed of 50% or
- Changing the terminal assignment using Pr.190 to Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.
- For replacement of each part, contact the nearest Mitsubishi FA center.

#### 5.4.19 Maintenance timer alarm

The maintenance timer output signal (Y95) is output when the inverter's cumulative energization time reaches the time period set with the parameter. MT1, MT2 or MT3 is displayed on the operation panel.

This can be used as a guideline for the maintenance time of peripheral devices.

Pr.	Name	Initial value	Setting range	Description
503 E710	Maintenance timer 1	0	0(1 to 9998)	Displays the inverter's cumulative energization time in increments of 100 h (read-only).  Writing the setting of "0" clears the cumulative energization time while Pr.503 = "1 to 9998". (Writing is disabled when Pr.503 = "0".)
504 E711	Maintenance timer 1 warning output set time	9999	0 to 9998	Set the time until the maintenance timer signal (Y95) is output. MT1 is displayed on the operation panel.
	•		9999	No function
686 E712	Maintenance timer 2	0	0(1 to 9998)	The same function as <b>Pr.503</b> .
687	Maintenance timer 2 warning	0000	0 to 9998	The same function as <b>Pr.504</b> .
E713	output set time	9999	9999	MT2 is displayed on the operation panel.
688 E714	Maintenance timer 3	0	0(1 to 9998)	The same function as <b>Pr.503</b> .
689	Maintenance timer 3 warning	9999	0 to 9998	The same function as <b>Pr.504</b> .
E715	output set time	3333	9999	MT3 is displayed on the operation panel.



Operation example of the maintenance timer 1 (Pr.503, Pr.504) (with both MT2 and MT3 OFF)

- The cumulative energization time of the inverter is stored in the EEPROM every hour and displayed in Pr.503 (Pr.686, Pr.688) in 100 h increments. Pr.503 (Pr.686, Pr.688) is clamped at 9998 (999800 h).
- When the value in Pr.503 (Pr.686, Pr.688) reaches the time (100 h increments) set in Pr.504 (Pr.687, Pr.689), Maintenance timer signal (Y95) is output, and also | (MT1), | (MT1), | (MT2), or | (MT3) is displayed on the operation panel.
- For the terminal used for Y95 signal output, assign the function by setting "95 (positive logic)" or "195 (negative logic)" in any of Pr.190 to Pr.196 (output terminal function selection).

# NOTE :

- The Y95 signal turns ON when any of MT1, MT2 or MT3 is activated. It does not turn OFF unless all of MT1, MT2 and MT3
- If all of MT1, MT2 and MT3 are activated, they are displayed in the priority of "MT1 > MT2 > MT3".
- MT is displayed on the FR-PU07 parameter unit if any of MT1, MT2 or MT3 is activated.
- The cumulative energization time is counted every hour. Energization time of less than 1 h is not counted.
- · Changing the terminal assignment using Pr.190 to Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.


#### # Parameters referred to

Pr.190 to Pr.196 (output terminal function selection) page 288

#### 5.4.20 **Current average value monitor signal**

The output current average value during constantspeed operation and the maintenance timer value are output to the current average value monitor signal (Y93) as a pulse. The output pulse width can be used in a device such as the I/O unit of a programmable controller as a guideline for the maintenance time for mechanical wear, belt stretching, or deterioration of devices with age.

The pulse is repeatedly output during constant-speed operation in cycles of 20 s to the Current average monitor signal (Y93).




Pr.	Name	Initial value	Setting range	Description
555 E720	Current average time	1 s	0.1 to 1 s	Set the time for calculating the average current during start pulse output (1 s).
556 E721	Data output mask time	0 s	0 to 20 s	Set the time for not obtaining (masking) transitional state data.
557 E722	Current average value monitor signal output reference current Rated inverter current		0 to 500 A*1	Set the reference (100%) for outputting
		0 to 3600 A*2	the output current average value signal.	

- \*1 Initial value for the FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower.
- \*2 Initial value for the FR-F820-03160(75K) or higher and FR-F840-01800(75K) and higher.

#### Operation example

- The pulse output of Current average monitor signal (Y93) is indicated below.
- For the terminal used for Y93 signal output, assign the function by setting "93 (positive logic)" or "193 (negative logic)" in any of Pr.190 to Pr.194 (output terminal function selection). (This cannot be assigned by setting in Pr.195 ABC1 terminal function selection or Pr.196 ABC2 terminal function selection.)



# ◆Pr.556 Data output mask time setting

· Immediately after acceleration/deceleration is shifted to constant-speed operation, the output current is unstable (transitional state). Set the time for not obtaining (masking) transitional state data in Pr.556.

# Pr.555 Current average time setting

· The output current average is calculated during start pulse (1 s) HIGH output. Set the time for calculating the average current during start pulse output in Pr.555.


# ◆Pr.557 Current average value monitor signal output reference current setting

• Set the reference (100%) for outputting the output current average value signal. The signal output time is calculated with the following formula.

The output time range is 0.5 to 9 s. When the output current average value is less than 10% of the setting value in **Pr.557**, the output time is 0.5 s, and when it is more than 180%, the output time is 9 s.

For example, when **Pr.557** = "10 A" and the output current average value is 15 A:

15 A/10 A  $\times$  5 s = 7.5 s, thus the current average value monitor signal is Low output in 7.5 s intervals.




#### ♦ Pr.503 Maintenance timer 1 output

• After LOW output of the output current value is performed, HIGH output of the maintenance timer value is performed. The maintenance timer value output time is calculated with the following formula.


$$\frac{\text{Pr.503} \times 100}{40000 \text{ h}} \times 5 \text{ s} \quad \text{(Maintenance timer value } 100\%/5 \text{ s)}$$

The output time range is 2 to 9 s. When **Pr.503** is less than 16000 h, the output time is 2 s, and when it is more than 72000 h, the output time is 9 s.



#### • NOTE

- · Masking of the data output and sampling of the output current are not performed during acceleration/deceleration.
- If constant speed changes to acceleration or deceleration during start pulse output, it is judged as invalid data, and HIGH
  output in 3.5 s intervals is performed for the start pulse and LOW output in 16.5 s intervals is performed for the end signal.
  After the start pulse output is completed, minimum 1-cycle signal output is performed even if acceleration/deceleration is
  performed.



- If the output current value (inverter output current monitor) is 0 A at the completion of the 1-cycle signal output, no signal is output until the next constant-speed state.
- · Under the following conditions, the Y93 signal is output with Low output in 20 s intervals (no data output).
  - When acceleration or deceleration is operating at the completion of the 1-cycle signal output
  - When automatic restart after instantaneous power failure (**Pr.57 Restart coasting time** ≠ "9999") is set, and the 1-cycle signal output is completed during the restart operation
  - When automatic restart after instantaneous power failure (**Pr.57** ≠ "9999") is set, and the restart operation was being performed at the completion of data output masking
- Pr.686 Maintenance timer 2 and Pr.688 Maintenance timer 3 cannot be output.
- Changing the terminal assignment using Pr.190 to Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### # Parameters referred to

Pr.57 Restart coasting time page 414, page 420

Pr.190 to Pr.196 (output terminal function selection) page 288

Pr.503 Maintenance timer 1, Pr.686 Maintenance timer 2, Pr.688 Maintenance timer 3 \* page 184

# (F) Setting of acceleration/deceleration time and acceleration/deceleration pattern

Purpose	Parameter to set			
To set the motor acceleration/ deceleration time	Acceleration/ deceleration time	P.F000 to P.F003, P.F010, P.F011, P.F020 to P.F022, P.F070, P.F071	Pr.7, Pr.8, Pr.16, Pr.20, Pr.21, Pr.44, Pr.45, Pr.147, Pr.611, Pr.791, Pr.792	187
To set the acceleration/ deceleration pattern suitable for an application	Acceleration/ deceleration pattern and backlash measures	P.F100, P.F200 to P.F203	Pr.29, Pr.140 to Pr.143	191
To command smooth speed transition with terminals	Remote setting function	P.F101	Pr.59	194
To set the starting frequency	Starting frequency and start-time hold	P.F102, P.F103	Pr.13, Pr.571	197, 198

#### 5.5.1 Setting the acceleration and deceleration time

The following parameters are used to set motor acceleration/deceleration time.

Set a larger value for a slower acceleration/deceleration, and a smaller value for a faster acceleration/deceleration. For the acceleration time at automatic restart after instantaneous power failure, refer to Pr.611 Acceleration time at a restart (page 414, page 420).


D.	Nome	Initial	value	Cotting rounds	_	) an avietie e	
Pr.	Name	FM	CA	Setting range	L	Description	
20 F000	Acceleration/ deceleration reference frequency	60 Hz	50 Hz	1 to 590 Hz	Set the frequency that will be the basis of acceleration/ deceleration time. As acceleration/deceleration time, set the frequency change time from a stop status to <b>Pr.20</b> .		
21	Acceleration/ deceleration time	0		0	Increment: 0.1 s Range: 0 to 3600 s  Select the increment for the acceleration/deceleration time		
F001	increments	O		1	Increment: 0.01 s Range: 0 to 360 s	setting and the setting range.	
16 F002	Jog acceleration/ deceleration time	0.5 s		0 to 3600 s (360 s*1)	Set the acceleration/dece stop status to <b>Pr.20</b> ). Refer to <b>page 221</b>	leration time for JOG operation (from	
611 F003	Acceleration time at a restart	9999		0 to 3600 s, 9999	Set the acceleration time for restart (from stop status to Pr.20 When "9999" is set, standard acceleration time (like Pr.7) is applied as the acceleration time at restart.  Refer to page 414, page 420.		
7 F010	Acceleration time	5 S*2 15 S*3		0 to 3600 s (360 s*1)	Set the motor acceleration time (from stop status to <b>Pr.20</b> ).		
8 F011	Deceleration time	10 s*2 30 s*3		0 to 3600 s (360 s*1)	Set the motor deceleration	n time (from <b>Pr.20</b> to stop status).	
44 F020	Second acceleration/ deceleration time	5 s		0 to 3600 s (360 s*1)	Set the acceleration/dece ON.	leration time when the RT signal is	
45	Second deceleration	9999		0 to 3600 s (360 s*1)	Set the deceleration time	when the RT signal is ON.	
F021	time	3333		9999	Acceleration time = decel	eration time	
147 F022	Acceleration/ deceleration time	9999		0 to 590 Hz	Set the frequency where to switches to the time set in	the acceleration/deceleration time  Pr.44 and Pr.45.	
FUZZ	switching frequency			9999	No function		
791	Acceleration time in	9999		0 to 3600 s (360 s*1)	Set the acceleration time in a low-speed range (less than 10% of the rated motor frequency).		
F070	low-speed range	3333		9999	The acceleration time set in <b>Pr.7</b> is applied. (While RT signal ON, the second function is enabled.)		
792	Deceleration time in	9999		0 to 3600 s (360 s*1)	of the rated motor frequency).		
F071	low-speed range	9999 -		9999	The deceleration time set in <b>Pr.8</b> is applied. (While RT signal ON, the second function is enabled.)		

<sup>\*1</sup> Depends on the Pr.21 Acceleration/deceleration time increments setting. The initial value for the setting range is "0 to 3600 s", and for the setting increment is "0.1 s".

Initial value for the FR-F820-00340(7.5K) or lower and FR-F840-00170(7.5K) or lower.

Initial value for the FR-F820-00490(11K) or higher and FR-F840-00250(11K) and higher.

#### **◆**Control block diagram





#### ◆Acceleration time setting (Pr.7, Pr.20)

- Use Pr.7 Acceleration time to set the acceleration time required to reach Pr.20 Acceleration/deceleration reference frequency from stop status.
- · Set the acceleration time according to the following formula.

Acceleration time setting = **Pr.20** × Acceleration time from stop status to maximum frequency / (maximum frequency - **Pr.13**)

• For example, the following calculation is performed to find the setting value for **Pr.7** when increasing the output frequency to the maximum frequency of 50 Hz in 10 s with **Pr.20** = "60 Hz (initial value)" and **Pr.13** = "0.5 Hz".





# **◆**Deceleration time setting (Pr.8, Pr.20)

- Use **Pr.8 Deceleration time** to set the deceleration time required to reach a stop status from to **Pr.20 Acceleration/ deceleration reference frequency**.
- · Set the deceleration time according to the following formula.

Deceleration time setting = Pr.20 × deceleration time from maximum frequency to stop / (maximum frequency - Pr.10)

• For example, the following calculation is used to find the setting value for **Pr.8** when increasing the output frequency to the maximum frequency of 50 Hz in 10 s with **Pr.20** = 120 Hz and **Pr.10** = 3 Hz.

# • NOTE

- If the acceleration/deceleration time is set, the actual motor acceleration/deceleration time cannot be made shorter than the shortest acceleration/deceleration time determined by the mechanical system J (moment of inertia) and motor torque.
- If the **Pr.20** setting is changed, the **Pr.125** and **Pr.126** (frequency setting signal gain frequency) settings do not change. Set **Pr.125** and **Pr.126** to adjust the gains.
- Under PM motor control, if the protective function (E.OLT) is activated due to insufficient torque in the low-speed range, set longer acceleration/deceleration times only in the low-speed range in **Pr.791 Acceleration time in low-speed range** and **Pr.792 Deceleration time in low-speed range**.

#### Changing the setting range and increments of the acceleration/ deceleration time (Pr.21)

• Use Pr.21 to set the acceleration/deceleration time and minimum setting range. Setting value "0" (initial value): 0 to 3600 s (minimum setting increments 0.1 s) Setting value "1": 0 to 360 s (minimum setting increments 0.01 s)


# NOTE

 Changing the Pr.21 setting changes the acceleration/deceleration time setting (Pr.7, Pr.8, Pr.16, Pr.44, Pr.45, Pr.264, Pr.265, Pr.582, Pr.583, Pr.791, Pr.792, Pr.1477, Pr.1478). (The Pr. 611 Acceleration time at a restart setting is not affected.)

#### ◆ Setting multiple acceleration/deceleration times (RT signal, Pr.44, Pr.45, Pr.147)

- Pr.44 and Pr.45 are valid when the RT signal is ON or when the output frequency is equal to or higher than the frequency set in Pr.147 Acceleration/deceleration time switching frequency.
- Even at the frequency lower than the Pr.147 setting, turning ON the RT signal will switch the acceleration/deceleration time to the second acceleration/deceleration time. The priority of the signals and settings is RT signal > Pr.147 setting.
- When "9999" is set in Pr. 45, the deceleration time becomes equal to the acceleration time (Pr. 44).
- If the Pr.147 setting is equal to or less than the Pr.10 DC injection brake operation frequency or the Pr.13 Starting frequency setting, the acceleration/deceleration time switches to the Pr.44 (Pr.45) when the output frequency reaches or exceeds the Pr.10 or Pr.13 setting.

Pr.147 setting	Acceleration/deceleration time	Description
9999 (initial value)	Pr.7, Pr.8	Acceleration/deceleration time is not automatically changed.
0.00 Hz	Pr.44, Pr.45	Second acceleration/deceleration time is applied from the start.
0.01 Hz ≤ <b>Pr.147</b> ≤ set frequency	Output frequency < Pr.147: Pr.7, Pr.8 Pr.147 ≤ output frequency: Pr.44, Pr.45	Acceleration/deceleration time is automatically changed.
Set frequency < Pr.147	Pr.7, Pr.8	Not changed as the frequency has not reached the switchover frequency.




· Switching frequency for each control method

Control method	Switching frequency
V/F control	Output frequency
Advanced magnetic flux vector control	Output frequency before the slip compensation.
PM motor control	Estimated speed converted as frequency

- · The reference frequency during acceleration/deceleration depends on the Pr.29 Acceleration/deceleration pattern selection setting. (Refer to page 191.)
- The RT signal can be assigned to an input terminal by setting Pr.178 to Pr.189 (input terminal function selection). Changing the terminal assignment may affect other functions. Set parameters after confirming the function of each terminal.
- The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 333.)
- RT signal is assigned to the terminal RT in the initial status. Set "3" in any of Pr.178 to Pr.189 (input terminal function selection) to assign the RT signal to another terminal.

# ◆ Setting the acceleration/deceleration time in the low-speed range (Pr.791, Pr.792)

• If torque is required in the low-speed range (less than 10% of the rated motor frequency) under PM motor control, set the Pr.791 Acceleration time in low-speed range and Pr.792 Deceleration time in low-speed range settings higher than the Pr.7 Acceleration time and Pr.8 Deceleration time settings so that the mild acceleration/deceleration is performed in the low-speed range. (When RT signal is turned ON, the second acceleration/deceleration time setting is prioritized.)





- Set Pr.791 higher than Pr.7, and Pr.792 higher than Pr.8. If set as Pr.791 < Pr.7, the operation is performed as Pr.791 = Pr.7. If set as Pr.792 < Pr.8, the operation is performed as Pr.792 = Pr.8.
- Refer to page 583 for the rated motor frequency of MM-EFS/MM-THE4.

#### # Parameters referred to

Pr.3 Base frequency page 497

Pr.10 DC injection brake operation frequency page 502

Pr.29 Acceleration/deceleration pattern selection page 191

Pr.125, Pr.126 (frequency setting gain frequency) page 314

Pr.178 to Pr.182 (input terminal function selection) page 329

Pr.264 Power-failure deceleration time 1, Pr.265 Power-failure deceleration time 2 page 426


#### 5.5.2 **Acceleration/deceleration pattern**

The acceleration/deceleration pattern can be set according to the application. In addition, the backlash measures that stop acceleration/deceleration by the frequency or time set with parameters at acceleration/deceleration can be set.

Pr.	Name	Initial value	Setting range	Description
			0	Linear acceleration/deceleration
20	A cooleration/decoleration nottorn		1	S-pattern acceleration/deceleration A
	Acceleration/deceleration pattern selection	0 2 S-pattern acceleration 3 Backlash measures		S-pattern acceleration/deceleration B
	Selection			Backlash measures
			6	Variable-torque acceleration/deceleration
140 F200	Backlash acceleration stopping frequency	1 Hz	0 to 590 Hz	
141 F201	Backlash acceleration stopping time	0.5 s	0 to 360 s	Set the stopping frequency and time during backlash measures.
142 F202	Backlash deceleration stopping frequency	1 Hz	0 to 590 Hz	Valid by backlash measures ( <b>Pr.29=</b> "3").
143 F203	Backlash deceleration stopping time	0.5 s	0 to 360 s	

#### **♦**Linear acceleration/deceleration (Pr.29 = "0" initial value)


• When the frequency is changed for acceleration, deceleration, etc. during inverter operation, the output frequency is changed linearly (linear acceleration/deceleration) to reach the set frequency without straining the motor and inverter. Linear acceleration/deceleration has a uniform frequency/time slope.



#### (F) Setting of acceleration/deceleration time and acceleration/deceleration pattern

#### ◆S-pattern acceleration/deceleration A (Pr.29 = "1")

- Use this when acceleration/deceleration is required for a short time until a high-speed area equal to or higher than the base frequency, such as for the main shaft of the machine.
- The acceleration/deceleration pattern has the **Pr.3 Base frequency** (**Pr.84 Rated motor frequency** under PM motor control) (fb) as the point of inflection in an S-pattern curve, and the acceleration/deceleration time can be set to be suitable for the motor torque reduction in the constant-power operation range at the base frequency (fb) or more.



• Acceleration/deceleration time calculation method when the set frequency is equal to or higher than the base frequency

Acceleration time  $t = (4/9) \times (T/fb^2) \times f^2 + (5/9) \times T$ 

Where T is the acceleration/deceleration time (s), f is the set frequency (Hz), and fb is the base frequency (rated motor frequency)

• Reference (0 Hz to set frequency) of acceleration/deceleration time when Pr.3 = "60 Hz"


Acceleration/deceleration time	Set frequency (Hz)			
(s)	60	120	200	400
5	5	12	27	102
15	15	35	82	305



• For the acceleration/deceleration time setting of the S-pattern acceleration/deceleration A, set the time to **Pr.3** (**Pr.84** under PM motor control) instead of **Pr.20 Acceleration/deceleration reference frequency**.


# ◆S-pattern acceleration/deceleration B (Pr.29 = "2")

• This is useful for preventing collapsing stacks such as on a conveyor. S-pattern acceleration/deceleration B can reduce the impact during acceleration/deceleration by accelerating/decelerating while maintaining an S-pattern from the present frequency (f2) to the target frequency (f1).



#### **◆**Backlash measures (Pr.29 = "3", Pr.140 to Pr.143)

- Reduction gears have an engagement gap and have a dead zone between forward rotation and reverse rotation. This dead zone is called backlash, and this gap disables a mechanical system from following motor rotation. More specifically, a motor shaft develops excessive torque when the direction of rotation changes or when constant-speed operation shifts to deceleration, resulting in a sudden motor current increase or regenerative status.
- To avoid backlash, acceleration/deceleration is temporarily stopped. Set the acceleration/deceleration stopping frequency and time in Pr.140 to Pr.143.




#### • NOTE

· Setting the backlash measures increases the acceleration/deceleration time by the stopping time.

#### ◆Variable-torque acceleration/deceleration (Pr.290 = "6")

• This function is suitable to accelerate/decelerate a variable torque load such as a fan and blower in a short time. Linear acceleration/deceleration is performed in the area where the output frequency > base frequency.



# NOTE

- When the base frequency is out of the range 45 to 65 Hz, the linear acceleration/deceleration is performed even if Pr.29 = "6".
- Even if Pr.14 Load pattern selection = "1 (variable torque load)", variable torque acceleration/deceleration setting is prioritized and the inverter operates as Pr.14 = "0 (constant torque load)".
- · For the variable torque acceleration/deceleration time setting, set the time period to reach Pr.3 Base frequency. (Not the time period to reach Pr.20 Acceleration/deceleration reference frequency.)
- · The variable torque acceleration/deceleration is disabled during PM motor control. (Linear acceleration/deceleration is performed.)

#### Parameters referred to

Pr.3 Base frequency page 497

Pr.7 Acceleration time, Pr.8 Deceleration time, Pr.20 Acceleration/deceleration reference frequency page 187

Pr.10 DC injection brake operation frequency page 502

Pr.178 to Pr.182 (input terminal function selection) page 329

#### 5.5.3 **Remote setting function**


Even if the operation panel is located away from the enclosure, contact signals can be used to perform continuous variable-speed operation, without using analog signals.

By simply setting this parameter, the acceleration, deceleration and setting clear functions of the remote speed setter (FR-FK) become available.

					Description	
Pr.	Name	Initial value	Setting range	RH, RM, RL signal function	Frequency setting storage function	Deceleration to the frequency lower than the set frequency
			0	Multi-speed setting	-	
			1	Remote setting	With	
		ion time 0	2	Remote setting	Without	
59 Restart cushion	Restart cushion time		3	Remote setting	Without (Turning STF/STR OFF clears remotely- set frequency.)	Disabled
F101			11	Remote setting	With	
			12	Remote setting	Without	
			13	Remote setting	Without (Turning STF/STR OFF clears remotely- set frequency.)	Enabled

#### ◆Remote setting function

- Use Pr.59 to enable/disable the remote setting function and enable/disable the frequency setting storage function during remote setting.
- When Pr. 59≠"0" (remote setting function valid), the functions of the RH, RM and RL signals are changed to acceleration (RH), deceleration (RM) and clear (RL).




\*1 External operation frequency (other than multi-speed) or PU running frequency

GROUF

#### **◆**Acceleration/deceleration operation

- When the acceleration signal (RH) is turned ON, the set frequency increases. The increased speed at this time is determined by the setting of **Pr.44 Second acceleration/deceleration time**. Turning OFF the RH signal will stop increasing the set frequency and run the motor at the frequency at that time.
- When the deceleration signal (RM) is turned ON, the set frequency decreases. The decreased speed at this time is determined by the setting of **Pr.45 Second deceleration time**. When **Pr.45** = "9999", the deceleration speed is the same as **Pr.44** setting. Turning OFF the RM signal will stop decreasing the set frequency and runs the motor at the frequency at that time.
- When **Pr.59** = any of "11, 12, or 13", deceleration can be performed to a frequency equal to or lower than the main speed (External operation mode frequency except multi-speed or PU operation mode frequency).



# • NOTE

While the RT signal is OFF, Pr.44 Second acceleration/deceleration time and Pr.45 Second deceleration time are used as the set frequency accelerating/decelerating time at turn ON of the acceleration/deceleration signal. If the Pr.7 and Pr.8 settings are longer, the acceleration/deceleration time set by Pr.7 and Pr.8 are applied.
 While the RT signal is ON, Pr.44 and Pr.45 settings are used as the acceleration/deceleration time regardless of the Pr.7 and Pr.8 settings.

#### **♦**Output frequency

- During External operation, the remotely-set frequency set with RH and RM signals is added to the terminal 4 input and External operation mode frequency (PU operation mode frequency when Pr.79 = "3" (External and PU combined operation)) except multi-speed setting. (When compensating analog input, set Pr.28 Multi-speed input compensation selection = "1". If the RH and RM signals are used for acceleration/deceleration while the frequency is set by analog voltage input (terminal 2 or 4, selected by Pr.28 = "0"), the auxiliary input via the terminal 1 is disabled.)
- During PU operation, the remotely-set frequency set with RH and RM signal operation is added to the PU running frequency.

# **♦**Frequency setting storage

- When **Pr.59** = "1, 11", the remotely-set frequency (frequency set by RH/RM operation) is stored to the memory (EEPROM). When power is switched OFF once, then ON, operation is resumed with the stored set frequency.
- When **Pr.59** = "2, 3, 12, 13", the set frequency is not stored, so when switching the power ON again after being switched OFF, the remotely-set frequency becomes 0 Hz.
- The remotely-set frequency is stored at the point when the start signal (STF or STR) turns OFF. Remotely-set frequency is stored every minute after turning OFF (ON) the RH and RM signals together. Each minute, the frequency is overwritten in the EEPROM if the latest frequency is different from the previous one when comparing the two. This cannot be written with RL signals.

# NOTE

• When switching the start signal from ON to OFF, or changing frequency by the RH or RM signal frequently, set the frequency setting value storage function (write to EEPROM) invalid (**Pr.59** = "2, 3, 12, 13"). If the frequency setting value storage function is valid (**Pr.59** = "1, 11"), the frequency is written to EEPROM frequently, and this will shorten the life of the EEPROM.

# **◆**Clearing the settings


• When **Pr.59** = "1, 2, 11, 12" and the clear signal (RL) is turned ON, the remotely-set frequency is cleared. When **Pr.59** = "3, 13" and the STF (STR) signal is turned OFF, the remotely-set frequency is cleared.

405

#### (F) Setting of acceleration/deceleration time and acceleration/deceleration pattern

#### • NOTE

• The range of frequency changeable by acceleration signal (RH) and deceleration signal (RM) is 0 to maximum frequency (**Pr.1** or **Pr.18** setting). Note that the maximum value of set frequency is (main speed + maximum frequency).




- Even if the start signal (STF or STR) is OFF, turning ON the RH or RM signal varies the preset frequency.
- The RH, RM, or RL signal can be assigned to an input terminal by setting Pr.178 to Pr.189 (input terminal function selection).


Changing the terminal assignment may affect other functions. Set parameters after confirming the function of each terminal.

- The inverter can be used in the Network operation mode.
- The remote setting function is invalid during JOG operation and PID control operation.
- The multi-speed operation function is invalid when remote setting function is selected.

#### Setting frequency is "0".

- Even when the remotely-set frequency is cleared by turning ON the RL (clear) signal after turning OFF (ON) both the RH and RM signals, the inverter operates at the remotely-set frequency stored in the last operation if power is reapplied before one minute has elapsed since turning OFF (ON) both the RH and RM signals.
- When the remotely-set frequency is cleared by turning ON the RL (clear) signal after turning OFF (ON) both the RH and RM signals, the inverter operates at the frequency in the remotely-set frequency cleared state if power is reapplied before one minute has elapsed since turning OFF (ON) both the RH and RM signals.







#### Caution

 When using the remote setting function, set the maximum frequency again according to the machine.

#### Parameters referred to

Pr.1 Maximum frequency, Pr.18 High speed maximum frequency page 245

Pr.7 Acceleration time, Pr.8 Deceleration time, Pr.44 Second acceleration/deceleration time, Pr.45 Second deceleration time page 187

Pr.28 Multi-speed input compensation selection page 222

Pr.178 to Pr.182 (input terminal function selection) page 329

# 5

#### 5.5.4 Starting frequency and start-time hold function


Magnetic flux

It is possible to set the starting frequency and hold the set starting frequency for a certain period of time. Set these functions when a starting torque is needed or the motor drive at start needs smoothing.

Pr.	Name	Initial value	Setting range	Description
13 F102	Starting frequency	0.5 Hz	0 to 60 Hz	Set the starting frequency at which the start signal is turned ON.
571	Holding time at a start	9999	0 to 10 s	Set the holding time of <b>Pr.13</b> .
F103		9999	9999	The holding function at a start is invalid.

# Starting frequency setting (Pr.13)

- The frequency at start can be set in the range of 0 to 60 Hz.
- Set the starting frequency at which the start signal is turned ON.




#### NOTE

• The inverter does not start if the frequency setting signal is less than the value set in Pr.13. For example, while Pr.13 = 5 Hz, the inverter output starts when the frequency setting signal reaches 5 Hz.

# ◆Start-time hold function (Pr.571)

- This function holds during the period set in Pr.571 and the output frequency set in Pr.13 Starting frequency.
- This function performs initial excitation to smooth the motor drive at a start.



# NOTE:

- When Pr.13 ="0 Hz", the starting frequency is held at 0.01 Hz.
- · When the start signal was turned OFF during start-time hold, deceleration is started at that point.
- · At switching between forward rotation and reverse rotation, the starting frequency is valid but the start-time hold function is invalid.

# Caution

 Note that when Pr.13 is set to any value equal to or lower than Pr.2 Minimum frequency, simply turning ON the start signal will run the motor at the preset frequency even if the command frequency is not input.

#### Parameters referred to

Pr.2 Minimum frequency page 245

GROUP


#### 5.5.5 Minimum motor speed frequency PM

Set the frequency where the PM motor starts running. Set the deadband in the low-speed range to eliminate noise and offset deviation when setting a frequency with analog input.

Pr.	Name	Initial value	Setting range	Description
13 F102	Starting frequency	Minimum frequency/ Minimum rotations per minute	0 to 60 Hz	Set the frequency where the motor starts running.

#### Starting frequency setting (Pr.13)

- The frequency where the PM motor starts running can be set in the range of 0 to 60 Hz.
- · While the frequency command is less than the Pr.13 Starting frequency setting, the PM motor is stopped. When the frequency command reaches the set frequency or higher, the PM motor accelerates according to the Pr.7 Acceleration time setting.



#### NOTE:

- · Under induction motor control (under V/F control and Advanced magnetic flux vector control), the output starts at the frequency set in Pr.13. Under PM motor control, the output always starts at 0.01 Hz.
- The inverter output does not start when the frequency-setting signal is less than Pr.13. For example, while Pr.13 = "20 Hz", the inverter output starts when the frequency setting signal reaches 20 Hz.



 Note that when Pr.13 is set to any value equal to or lower than Pr.2 Minimum frequency, simply turning ON the start signal will run the motor at the preset frequency even if the command frequency is not input.

#### # Parameters referred to

Pr.2 Minimum frequency page 245 Pr.7 Acceleration time page 187

#### **5.6** (D) Operation command and frequency command

Purpose	Par	ameter to set		Refer to page
To select the operation mode	Operation mode selection	P.D000	Pr.79	200
To start up in Network operation mode at power-ON	Communication startup mode selection	P.D000, P.D001	Pr.79, Pr.340	209
To select the command source during communication operation	Operation and speed command sources during communication operation, command source selection	P.D010 to P.D013	Pr.338, Pr.339, Pr.550, Pr.551	210
To prevent motor from rotating reversely	Reverse rotation prevention selection	P.D020	Pr.78	217
To set the frequency by pulse train input	Pulse train input	P.D100, P.D101, P.D110, P.D111	Pr.291, Pr.384 to Pr.386	218
To perform JOG operation	JOG operation	P.D200, P.F002	Pr.15, Pr.16	221
To control frequency with combinations of terminals	Multi-speed operation	P.D300 to P.D315	Pr.28, Pr.4 to Pr.6, Pr.24 to Pr.27, Pr.232 to Pr.239	222

# 5.6.1 Operation mode selection

Select the operation mode of the inverter.

The mode can be changed among operations using external signals (External operation), operation by operation panel or the parameter unit (PU operation), combined operation of PU operation and External operation (External/PU combined operation), and Network operation (when RS-485 terminals or communication option is used).

Pr.	Name	Initial value	Setting range	Description
79 D000	Operation mode selection	0	0 to 4, 6, 7	Selects the operation mode.

The following table lists valid and invalid commands in each operation mode.

Pr.79 setting		Description		LED display :OFF :ON	Refer to page	
0 (initial value)	mode.	e the External/PU switchover mode (PU EXT)) to switch between the PU and External operation de.  bower ON, the inverter is in the External operation mode.  Operation mode Frequency command Start command				
	Operation mode	Frequency command	Start command			
1	PU operation mode fixed	Operation panel or parameter unit.	operation panel or parameter unit	PU operation mode	204	
2	External operation mode fixed. The operation can be performed by switching between the External and NET operation modes.	External signal input (terminal 2 and 4, JOG, multi-speed selection, etc.)	External signal input (terminal STF, STR)	External operation mode  PU EXT NET NET operation mode  PU EXT NET	204	
3	External/PU combined operation mode 1	Operation panel/ parameter unit or external signal input (multi- speed setting, terminal 4) *1	External signal input (terminal STF, STR)	External/PU combined operation mode	205	
4	External/PU combined operation mode 2	External signal input (terminal 2 and 4, JOG, multi-speed selection, etc.)	operation panel or parameter unit	— PU — EXT — NET	205	
6	Switchover mode Switching of PU, External, a	nd NET operation modes can be pe	erformed during operation.	PU operation mode	205	
7	shutoff)	U operation interlock) to PU operation mode enabled (duri to PU operation mode disabled	ing External operation, output	External operation mode  PU EXT NET NET NET OPERATION MODE	206	

<sup>\*1</sup> The priority of frequency commands when **Pr.79** = "3" is "multi-speed operation (RL/RM/RH/REX) > PID control (X14) > terminal 4 analog input (AU) > digital input by operation panel".

#### Operation mode basics


- The operation mode specifies the source of the start command and the frequency command for the inverter.
- · Basically, there are following operation modes.

External operation mode: For inputting a start command and a frequency command with an external potentiometer and switches which are connected to the control circuit terminal.

PU operation mode: For inputting a start command and a frequency command with the operation panel (FR-DU08), parameter unit, or the RS-485 communication via PU connector.

Network operation mode (NET operation mode): For inputting a start command and a frequency command using the RS-485 terminals or communication option.


• The operation mode can be selected from the operation panel or with the communication instruction code.



# NOTE

- · There are two settings of "3" and "4" with PU/External combined operation. The startup method differs according to the setting value.
- In the initial setting, the stop function (PU stop selection) by the operation panel or the parameter unit modes other than the PU operation mode. (Refer to Pr.75 Reset selection/disconnected PU detection/PU stop selectionon page 162.)

# **♦**Operation mode switching method



- - · For details on switching by external terminals, refer to the following pages.
  - PU operation external interlock signal (X12) page 206
  - PU-External operation switchover signal (X16) page 207
  - External-NET operation switchover signal (X65), NET-PU operation switchover signal (X66) 🕮 page 207
  - Pr.340 Communication startup mode selection Page 209


# **♦**Operation mode selection flow

Referring to the following table, select the basic parameter settings or terminal wiring related to the operation mode.

Start command input method	Frequency setting method	Terminal wiring	Parameter setting	Operation method
External signal input (terminal STF, STR)	External (terminal 2 and 4, JOG, multi-speed, etc.)	STF (forward rotation)/STR (reverse rotation) (Refer to page 335.) Terminal 2 and 4 (analog) RL, RM, RH, JOG, etc.	Pr.79 = "2" (External operation mode fixed)	Frequency setting     Frequency setting terminal ON     Start command     STF(STR)-ON
	PU (digital setting)	STF (forward rotation)/STR (reverse rotation) (Refer to page 335.)	Pr.79 = "3" (External/PU combined operation 1)	Frequency setting     DU digital setting     Start command     STF(STR)-ON
	Communication (RS-485 terminals)	STF (forward rotation)/STR (reverse rotation) (Refer to page 335.) RS-485 terminals (Refer to page 443.)	Pr.338 = "1" Pr.340 = "1, 2"	Frequency setting     Transmit a frequency command     via communication.     Start command     STF(STR)-ON
	Communication (communication option)	Terminals for communication option (Refer to the Instruction Manual of the communication option.)	Pr.338 = "1" Pr.340 = "1"	Frequency setting     Transmit a frequency command     via communication.     Start command     STF(STR)-ON
PU (FWD/REV key)	External (terminal 2 and 4, JOG, multi-speed, etc.)	Terminal 2 and 4 (analog) RL, RM, RH, JOG, etc.	Pr.79 = "4" (External/PU combined operation 2)	Frequency setting     Frequency setting terminal ON     Start command     FWD/REV key ON
	PU (digital setting)	_	Pr.79 = "1" (PU operation mode fixed)	Frequency setting     Digital setting     Start command     FWD/REV key ON
	Communication (RS-485 terminals/ communication option)	N/A		
Communication (RS-485 terminals)	External (terminal 2 and 4, JOG, multi- speed, etc.)	RS-485 terminals (Refer to page 443.) Terminal 2 and 4 (analog) RL, RM, RH, JOG, etc.	Pr.339 = "1" Pr.340 = "1, 2"	Frequency setting     Frequency setting terminal ON     Start command     Transmit a start command via     communication
	PU (digital setting)	N/A	_	
	Communication RS-485 terminals	RS-485 terminals (Refer to page 443.)	<b>Pr.340</b> = "1, 2"	Frequency setting     Transmit a frequency command     via communication.     Start command     Transmit a start command via     communication
Communication (Communication option)	External (terminal 2 and 4, JOG, multispeed, etc.)	Terminals for communication option (Refer to the Instruction Manual of the communication option.) Terminal 2 and 4 (analog) RL, RM, RH, JOG, etc.	Pr.339 = "1" Pr.340 = "1"	Frequency setting     Frequency setting terminal ON     Start command     Transmit a start command via communication
	PU (digital setting)	N/A	Т	
	Communication (communication option)	Terminals for communication option (Refer to the Instruction Manual of the communication option.)	Pr.340 = "1"	Frequency setting     Transmit a frequency command     via communication.     Start command     Transmit a start command via     communication


### ◆External operation mode (Pr.79 = "0" (initial value), "2")

- Select the External operation mode when the start command and the frequency command are applied from a frequency setting potentiometer, start switch, etc. which are provided externally and connected to the control circuit terminals of the inverter.
- Generally, parameter change cannot be performed in the External operation mode. (Some parameters can be changed. Refer to **Pr.77 Parameter write selection page 169**.)
- When **Pr.79** = "0 or 2", the inverter starts up in the External operation mode at power-ON. (When using the Network operation mode, refer to **page 209**.)
- When parameter changing is seldom necessary, setting "2" fixes the operation mode to the External operation mode.
   When frequent parameter changing is necessary, setting "0" (initial value) allows the operation mode to be changed easily to the PU operation mode by pressing PU of the operation panel. After switching to the PU operation mode, always return to the External operation mode.
- The STF and STR signal are used as a start command, and the voltage to terminal 2 and 4, current signal, multi-speed signal, and JOG signal are used as a frequency command.




### **♦PU** operation mode (Pr.79 = "1")

- Select the PU operation mode when applying start and frequency commands by only the key operation of the operation panel or the parameter unit. Also select the PU operation mode when making communication using the PU connector.
- When **Pr.79** ="1", the inverter starts up in the PU operation mode at power-ON. The mode cannot be changed to other operation modes.
- The setting dial of the operation panel can be used for setting like a potentiometer. (Pr.161 Frequency setting/key lock operation selection page 166)
- When the PU operation mode is selected, the PU operation mode signal (PU) can be output.
   For the terminal used for the PU signal, set "10 (positive logic)" or "110 (negative logic)" in any of Pr.190 to Pr.196 (output terminal function selection) to assign the function.




### ◆PU/External combined operation mode 1 (Pr.79 = "3")

- Select the PU/External combined operation mode 1 when applying a frequency command from the operation panel or the parameter unit and inputting a start command with the external start switches.
- Set "3" in **Pr.79**. The mode cannot be changed to other operation modes.
- · When a frequency is input from the external signal by multi-speed setting, it has a higher priority than the frequency command from the PU. Also, when AU is set to "ON", the command signal is output to the terminal 4.



### ◆PU/External combined operation mode 2 (Pr.79 = "4")

- · Select the PU/External combined operation mode 2 when applying a frequency command from the external potentiometer, or multi-speed and JOG signals, and inputting a start command by key operation of the operation panel or the parameter
- Set "4" in Pr.79. The mode cannot be changed to other operation modes.



### ◆Switchover mode (Pr.79 = "6")

• PU, External and Network operation (when RS-485 terminals or communication option is used) can be switched among during operation.

Operation mode switchover	Operation switchover/Operating status
External operation→PU operation	Set to the PU operation mode on the operation panel and the parameter unit.  •As the direction of rotation, the direction that was active by External operation is continued.  •For the setting frequency, the setting of the potentiometer (frequency command) is continued. (Note, however, that the setting disappears when the power is turned OFF or when the inverter is reset.)
External operation→NET operation	The switchover command to the Network operation mode is transmitted via communication.  • As the direction of rotation, the direction that was active by External operation is continued.  • The setting by the setting potentiometer (frequency command) is kept. (Note, however, that the setting disappears when the power is turned OFF or when the inverter is reset.)
PU operation→External operation	Press the External operation key on the operation panel and the parameter unit.  • The direction of operation is determined by the External operation input signal.  • The setting frequency is determined by the external frequency command signal.
PU operation→NET operation	The switchover command to the Network operation mode is transmitted via communication.  • For the direction of operation and setting frequency, the status during PU operation is continued.
NET operation→External operation	The switchover command to the External operation mode is transmitted via communication.  • The direction of operation is determined by the External operation input signal.  • The setting frequency is determined by the external frequency command signal.
NET operation→PU operation	Switch to the PU operation mode on the operation panel and the parameter unit.  • For the direction of operation and frequency, the status during Network operation is continued.

### ◆PU operation interlock (Pr.79 = "7")

- The operation mode can be forcibly switched to the External operation mode by input of the PU operation interlock (X12) signal. This function prevents the operation mode from being accidentally unswitched from the PU operation mode. If the operation mode left unswitched from the PU operation mode, the inverter does not reply to the commands sent through external commands.
- To input the X12 signal, set "12" in any of Pr.178 to Pr.189 (input terminal function selection) to assign the function to a terminal. (For details on Pr.178 to Pr.189, refer to page 329.)
- Set Pr.79="7" (PU operation interlock).
- · If the X12 signal is not assigned, the function of the MRS signal is switched to PU operation internal signal from MRS (output stop).

X12 (MRS)	Function/Operation					
signal	Operation mode	Parameter writing*1				
ON	Switching of the operation mode (External, PU, and NET) is enabled. Output is stopped during External operation.	Parameter writing enabled				
OFF	Operation mode is forcefully changed to the External operation mode.  External operation is enabled.  Switching to the PU or NET operation mode from the External operation mode is disabled.	Writing of parameters other than <b>Pr.79</b> is disabled.				

- \*1 Depends on the Pr.77 Parameter write selection setting and the writing conditions of each parameter. (Refer to page 169.)
- Functions/operations by X12 (MRS) signal ON/OFF

Operating status			Operation		Switching to
Operation mode	Status	X12 (MRS) signal	mode	Operating status	PU or NET operation mode
PU/NET	during a stop	ON→OFF*1	External*2	If frequency and start commands are input from external source, the inverter runs by those	Not available
	Running	ON→OFF*1	]	commands.	Not available
	during a	OFF→ON		during a stop	Available
External	stop	ON→OFF	External*2	during a stop	Not available
LAIGIIIAI	Running	OFF→ON	LAIGIIIdI*2	Running→Output shutoff	Not available
	Rulling	ON→OFF		Output shutoff→Running	Not available

- \*1 The mode is switched to the External operation mode regardless of the ON/OFF state of the start signals (STF, STR). Thus, the motor runs under the External operation mode when the X12 (MRS) signal turns OFF with either of STF or STR in an ON state.
- \*2 When a fault occurs, the inverter can be reset by pressing on the operation panel.





- The operation mode cannot switched to the PU operation mode with the start signal (STF, STR) in an ON state even if the X12 (MRS) signal is ON.
- If the MRS signal is ON and Pr.79 is written to a value other than "7" when the MRS signal is used as the PU interlock signal during PU operation mode, the MRS signal will act as a regular MRS function (output stop). Also, when Pr.79="7", the MRS signal becomes the PU interlock signal.
- The logic of the signal follows the Pr.17 MRS input selection setting also when the MRS signal is used as the PU operation interlock signal. When Pr.17 ="2", ON and OFF in the above explanation are reversed.
- Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

### ◆Switching operation mode by external signal (X16 signal)

- When External operation and the operation from the operation panel are used together, the PU operation mode and External operation mode can be switched during a stop (during motor stop, start command OFF) by using the PU-External operation switchover signal (X16).
- When Pr.79="0", "6" or "7", switching between the PU operation mode and External operation mode is possible. (When **Pr.79**="6", the switchover can also be made during operation.)
- To input the X16 signal, set "16" in any of Pr.178 to Pr.189 (input terminal function selection) to assign the function to a terminal.

	Pr.79	_	s and operation	REMARKS		
	setting	ON (External) OFF (PU)				
0 (	() (initial value)		PU operation mode	Switching among the External, PU, and NET operation modes is enabled.		
	1	PU operation mode		PU operation mode fixed		
	2 External operation mode		ode	External operation mode fixed. (Switching to NET operation mode is enabled.)		
	3, 4	External/PU combine	ed operation mode	External/PU combined operation mode fixed		
	6	External operation mode PU operation mode		Switching among the External, PU, and NET operation mode is enabled while running.		
7	X12 (MRS) External operation ON mode PU operation mode		PU operation mode	Switching among the External, PU, and NET operation mode is enabled. (In the External operation mode, output shutoff.)		
X12 (MRS) OFF		External operation mode		External operation mode fixed. (Forcibly switched to External operation mode.)		

### • NOTE

- · The status of the operation mode follows the Pr.340 Communication startup mode selection setting and the ON/OFF state of the X65 and X66 signals. (For details, refer to page 207.)
- The priority among Pr.79 and Pr.340 and signals is Pr.79 > X12 > X66 > X65 > X16 > Pr.340.
- · Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

## ◆Switching the operation mode by external signals (X65, X66 signals)

- When Pr.79 ="0, 2 or 6", the PU operation mode and External operation modes can be changed to the Network operation mode during a stop (during motor stop, start command OFF) by the PU/NET operation switchover (X65) signal, the External/NET operation switchover (X66) signal. (When Pr.79 ="6", switchover is enabled during operation.)
- To switch between the Network operation mode and the PU operation mode
  - 1) Set Pr.79 = "0 (initial value) or 6".
  - 2) Set Pr.340 Communication startup mode selection="10 or 12".
  - 3) Set "65" in any of Pr.178 to Pr.189 to assign the NET-PU operation switching signal(X65) to a terminal.
  - 4) When the X65 signal is ON, the PU operation mode is selected. When the X65 signal is OFF, the Network operation mode is selected.

Pr.340		Pr.79	X65 sig	nal state	REMARKS		
setting		setting	ON (PU)	OFF (NET)	REWARKS		
	0 (	initial value)	PU operation mode*1	NET operation mode*2	_		
	1 2 3, 4		PU operation mode		PU operation mode fixed		
			NET operation mode		NET operation mode fixed		
			External/PU combined	operation mode	External/PU combined operation mode fixed		
10, 12		6	PU operation mode*1 NET operation mode*2		Switching between operation modes is enabled while running.		
		X12 (MRS)	Switching between the External operation mode and PU operation mode is enabled.*2		Output is shutoff in the External operation mode.		
	7	ON			Output is struton in the External operation mode.		
	,		External operation mod	40	The operation mode is forcibly switched to the		
	OFF		External operation mod	ie –	External operation mode.		

- \*1 When the X66 signal is ON, the NET operation mode is selected.
- \*2 When the X16 signal is OFF, the PU operation mode is selected. Also, when "0" is set for Pr.550 NET mode operation command source selection and the communication option is not connected (communication option is the command source), the PU operation mode is selected.

### (D) Operation command and frequency command

- To switch between the Network operation mode and the External operation mode
  - 1) Set **Pr.79**="0" (initial value) or "2, "6" or "7". (When **Pr.79** ="7" and the X12 (MRS) signal is ON, the operation mode can be switched.)
  - 2) Set Pr.340 Communication startup mode selection ="0" (initial value), "1" or "2".
  - 3) Set "66" in one of Pr.178 to Pr.189 to assign the NET-External operation switching signal (X66) to a terminal.
  - 4) When the X66 signal is ON, Network operation mode is selected. When the X66 signal is OFF, the External operation mode is selected.

Pr.340			X66 si	gnal state	REMARKS		
setting			ON (NET) OFF (External)		REWARKS		
	0 (i	nitial value)	NET operation mode*1 External operation mode*2		_		
		1	PU operation mode		PU operation mode fixed		
	0 3, 4 (initial value), 6		NET operation mode*1 External operation mode		Switching to PU operation mode is disabled.		
0			External/PU combined of	peration mode	External/PU combined operation mode fixed		
(initial value),			NET operation mode*1 External operation mode*2		Switching between operation modes is enabled while running.		
1, 2		X12 (MRS)	NET operation mode*1	External operation mode*2	Output is shutoff in the External operation		
	7	ON	NET operation mode*1	External operation mode*2	mode.		
	,	X12 (MRS)	External operation mode		The operation mode is forcibly switched to the		
	OFF		LAternal operation mode	<del>,</del>	External operation mode.		

- When "Pr.550 NET mode operation command source selection = "0" (communication option control source)" and no communication option is connected, the External operation mode is selected.
- \*2 When the X16 signal is OFF, the PU operation mode is selected. Also, when the X65 signal is assigned, the operation mode follows the ON/OFF state of the X65 signal.

### NOTE

- The priority of Pr.79 and Pr.340 and signals is Pr.79 > X12 > X66 > X65 > X16 > Pr.340.
- Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

### Parameters referred to

Pr.15 Jog frequency page 221

Pr.4 to Pr.6, Pr.24 to 27, Pr.232 to Pr.239 multi-speed operation page 222

Pr.75 Reset selection/disconnected PU detection/PU stop selection page 162

Pr.161 Frequency setting/key lock operation selection page 166

Pr.178 to Pr.182 (input terminal function selection) page 329

Pr.190 to Pr.196 (output terminal function selection) \*page 288

Pr.340 Communication startup mode selection page 209

Pr.550 NET mode operation command source selection page 210

# 5.6.2 Startup in Network operation mode at power-ON

When power is switched ON or when power comes back ON after an instantaneous power failure, the inverter can be started up in the Network operation mode. After the inverter starts up in the Network operation mode, parameter writing and operation can be commanded from programs.

Set this mode when performing communication operation using the RS-485 terminals or a communication option.

Pr.	Name	Initial value	Setting range	Description
79 D000	Operation mode selection	0	0 to 4, 6, 7	Selects the operation mode. (Refer to page 200.)
			0	Follows the <b>Pr.79</b> setting.
340	Communication startup		1, 2	The inverter starts up in the Network operation mode.  If an instantaneous power failure occurs when "2" is set, the operating status before the instantaneous power failure is maintained.
340 D001	Communication startup mode selection	0	10, 12	The inverter starts up in the Network operation mode. The operation mode can be changed between the PU operation mode and Network operation mode from the operation panel.  If an instantaneous power failure occurs when "12" is set, running is continued at the condition before the instantaneous power failure.

### ◆Selecting the operation mode for power-ON (Pr.340)

• Depending on the Pr.79 and Pr.340 settings, the operation mode at power-ON (reset) changes as described below.

Pr.340 setting	Pr.79 setting	Operation mode at power-ON, at power restoration, or after a reset	Operation mode switching			
	0(initial value)	External operation mode	Switching among the External, PU, and NET operation modes is enabled.*2			
0 (initial value)	1	PU operation mode	PU operation mode fixed			
	2	External operation mode	Switching between the External and NET operation modes is enabled. Switching to PU operation mode is disabled			
	3, 4	External/PU combined operation mode	Operation mode switching is disabled			
	6	External operation mode	Switching among the External, PU, and NET operation mode is enabled while running.			
	7	X12 (MRS) signal ON External operation mode	Switching among the External, PU, and NET operation modes is enabled.*2			
	<b>'</b>	X12 (MRS) signal OFF External operation mode	External operation mode fixed. (Forcibly switched to External operation mode.)			
	0	NET operation mode				
	1	PU operation mode	Same as <b>Pr.340=</b> "0" setting			
	2	NET operation mode				
1, 2*1	3, 4	External/PU combined operation mode				
	6	NET operation mode				
	7	X12(MRS) signal ON NET operation mode				
	<b>'</b>	X12 (MRS) signal OFF External operation mode				
	0	NET operation mode	Switching between the PU and NET operation mode is enabled*3			
	1	PU operation mode	Same as Pr.340="0" setting			
10, 12*1	2	NET operation mode	NET operation mode fixed			
10, 12*1	3, 4	External/PU combined operation mode	Same as <b>Pr.340</b> ="0" setting			
	6	NET operation mode	Switching between the PU and NET operation mode is enabled while running.*3			
	7	External operation mode	Same as Pr.340="0" setting			

- 1 Use Pr.340="2 or 12" setting to perform communication with the RS-485 terminals. Even if an instantaneous power failure occurs while Pr.57 Restart coasting time ≠ "9999" (with automatic restart after instantaneous power failure), inverter continues operation at the condition before the instantaneous failure.
- \*2 The operation mode cannot be directly changed between the PU operation mode and Network operation mode.
- \*3 Switching between the PU and NET operation modes is available with the PU key on the operation panel or the X65 signal.

### Parameters referred to

# 5.6.3 Start command source and frequency command source during communication operation

The start and frequency commands from an external device can be made valid when using the RS-485 terminals or the communication option. The command source in the PU operation mode can also be selected.

Pr.	Name	Initial value	Setting range	Description
338	Communication operation	0	0	Start command source is communication.
D010	command source	O	1	Start command source is external.
			0	Frequency command source is communication.
			1	Frequency command source is external.
339 D011	Communication speed command source	0	2	Frequency command source is external. (When there is no external input, the frequency command via communication is valid, and the frequency command from terminal 2 is invalid.)
			0	The communication option is the command source when in the NET operation mode.
			1	The RS-485 terminals are the command source when in the NET operation mode.
550 D012	NET mode operation command source selection	9999	9999	Communication option is recognized automatically.  Normally, the RS-485 terminals are the command source. When the communication option is mounted, the communication option is the command source.
			1	The RS-485 terminals are the command source when in the PU operation mode.
			2	The PU connector is the command source when in the PU operation mode.
551 D013	PU mode operation command source selection	9999	3	The USB connector is the command source when in the PU operation mode.
5013	332.33 30.031.011		9999	USB automatic recognition Normally, the PU connector is the command source. When the USB is connected, the USB connector is the command source.

## ◆ Selection of command source in Network operation mode (Pr.550)

- Either of the RS-485 terminals or the communication option can be specified for the command source in the Network operation mode.
- For example, whether or not the communication option is mounted, set **Pr.550** ="1" to write parameters from or input the start and frequency commands via RS-485 terminals in the Network operation mode.

## • NOTE

• In the initial setting, "9999" (communication option automatic recognition) is set for **Pr.550**. Thus, if the communication option is mounted, parameters cannot be written or the start and frequency commands cannot be sent by communications that use the RS-485 terminals. (Monitoring or parameter reading can be performed.)

## ◆ Selection of the command source of the PU operation mode (Pr.551)

- Any of the PU connector, RS-485 terminals, or USB connector can be specified as the command source in the PU operation mode.
- Set Pr.551="1" to use communication connected to the RS-485 terminals to write parameters or execute start and frequency commands in the PU operation mode. Set Pr.551="3" or "9999" to use the USB connector.

## NOTE:

- When Pr.550 ="1" (NET mode RS-485 terminals) and Pr.551 ="1" (PU mode RS-485 terminals), the PU operation mode has a precedence. For this reason, if the communication option is not mounted, switching to the Network operation mode is not longer possible.
- Changed setting values are enabled at power-ON or inverter reset.

Pr.550	Pr.551					
setting	setting	PU connector	USB connector	RS-485 terminals	Communication option	REMARKS
	1	×	×	PU operation mode*1	NET operation mode*2	
	2	PU operation mode	×	×	NET operation mode*2	
0	3	×	PU operation mode	×	NET operation mode*2	
	9999 (initial value)	PU operation mode*3	PU operation mode*3	×	NET operation mode*2	
	1	×	×	PU operation mode*1	×	Switching to NET operation mode disabled
	2	PU operation mode	×	NET operation mode	×	
1	3	×	PU operation mode	NET operation mode	×	
	9999 (initial value)	PU operation mode*3	PU operation mode*3	NET operation mode	×	
	1	×	×	PU operation mode*1	NET operation mode*2	
	2	PLI operation mode	×	×	NET operation mode*2	With communication option
9999	2	PU operation mode	X	NET operation mode	×	Without communication option
(initial value)	3	×	DI Longration mode	×	NET operation mode*2	With communication option
value)		^	PU operation mode	NET operation mode	×	Without communication option
	9999 (initial	PU operation	PU operation	×	NET operation mode*2	With communication option
	value)	mode*3	mode*3	NET operation mode	×	Without communication option

- \*1 The Modbus-RTU protocol cannot be used in the PU operation mode. To use the Modbus-RTU protocol, set Pr.551="2".
- \*2 If the communication option is not mounted, switching to the Network operation mode is not longer possible.
- \*3 When **Pr.551=** "9999", the priority of the PU command source is USB connector > PU connector.

# **♦**Controllability through communication

Command Source   Condition (Pr.551 setting)   Item   PU operation   External (PU combined operation operation (start) (when the command operation (start) (command operation)   Operation (command operation)   Oper			Controllability in each operation mode							
Control by RS-485 terminals   Control by Command   Control by RS-485 terminals   Control by Command   Control by RS-485 terminals   Control by Command   Control by C		(Pr.551	ltem	_		PU combined operation mode 1	PU combined operation mode 2	operation (when RS-485 terminals are	operation (when communication option is	
Control by RS-485 communication via PU connector by RS-485 terminals   Control by RS-485 terminals   Command				0	×	×	0	×		
Control by RS-485 connection   Firequency   Control by RS-485 connection   Parameter read   Control by RS-485 co		(PU connector)		0	Δ*3	Δ*3	0	Δ*3		
Mithout USB connection   Parameter writing   O-4		(automatic	_	0	×	0	×	×		
Control by RS-485 communication on via PU connector			Monitor	0	0	0	0	0		
Parameter read   O   O   O   O   O   O   O   O   O			Parameter writing	O*4	X*5	O*4	O*4	X*5		
Inverter reset		,	Parameter read	0	0	0	0	0		
On via PU connector         Operation (start) command         x <td></td> <td></td> <td>Inverter reset</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td></td>			Inverter reset	0	0	0	0	0		
Other than the above	on via PU			×	×	×	×	×		
Control by communication or via RS-485 terminals   Other than the above   Other than the				Δ*3	Δ*3	Δ*3	Δ*3	Δ*3		
Monitor			_	×	×	×	×	×		
Parameter read   O   O   O   O   O   O   O   O   O			Monitor	0	0	0	0	0		
Inverter reset			Parameter writing	X*5	X*5	X*5	X*5	X*5		
1			Parameter read	0	0	0	0	0		
1			Inverter reset	0	0	0	0	0		
Control by communication via RS-485 terminals   Other than the above   Control by communication via RS-485 terminals   Other than the above   Frequency   Other than the above   Ot			command	0	×	×	0	×		
Control by communication via RS-485 terminals   Monitor   O   O   O   O   O   O   O   O   O				0	×	0	×	×		
Parameter read   O   O   O   O   O   O   O   O   O		*	Monitor	0	0	0	0	0		
Inverter reset			Parameter writing	O*4	X*5	O*4	O*4	X*5		
communication via RS-485 terminals         Inverter reset         O         O         O         O         O           Other than the above         Other than the above         Running frequency         X <td>Control by</td> <td></td> <td>Parameter read</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td></td>	Control by		Parameter read	0	0	0	0	0		
Other than the above         Command (start, stop)         X         X         X         X         X         O*1         X           Monitor         O         O         O         O         O         O         O           Parameter writing         X*5         X*5         X*5         X*5         O*4         X*5			Inverter reset	0	0	0	0	0		
Other than the above         frequency         X         X         X         X         C*I         X           Monitor         O         O         O         O         O         O         O           Parameter writing         X*5         X*5         X*5         X*5         O*4         X*5           Parameter read         O         O         O         O         O         O			command	×	×	×	×	O*1	×	
Parameter writing         X+5         X+5         X+5         O*4         X+5           Parameter read         O         O         O         O         O         O		Other than the		×	×	×	×	O*1	×	
Parameter read O O O O O		above	Monitor	0	0	0	0	0	0	
			Parameter writing	X*5	X*5	X*5	X*5	O*4	X*5	
Inverter reset X X X X O*2 X			Parameter read	0	0	0	0	0	0	
			Inverter reset	×	×	×	×	O*2	×	

			Controllability in each operation mode							
Command source	Condition (Pr.551 setting)	Item	PU operation	External operation	External/ PU combined operation mode 1 (Pr.79 =3)	External/ PU combined operation mode 2 (Pr.79 =4)	NET operation (when RS-485 terminals are used) *6	NET operation (when communication option is used) *7		
	3 (USB	Operation command (start, stop)	0	×	×	0	×			
	connector) 9999	Running frequency	0	×	0	×	×			
	(automatic	Monitor	0	0	0	0	0			
	recognition, with USB	Parameter writing	O*4	X*5	X*5	X*5	X*5			
	connection)	Parameter read	0	0	0	0	0			
Control via USB		Inverter reset	0	0	0	0	0			
connector	Other than the above	Operation command (start, stop)	×	×	×	×	×			
		Running frequency	×	×	×	×	×			
		Monitor	0	0	0	0	0			
		Parameter writing	X*5	X*5	X*5	X*5	X*5			
		Parameter read	0	0	0	0	0			
		Inverter reset	0	0	0	0	0			
		Operation command (start, stop)	×	×	×	×	×	O*1		
Communicati on option (via	_	Running frequency	×	×	×	×	×	O*1		
communicati		Monitor	0	0	0	0	0	0		
on)		Parameter writing	X*5	X*5	X*5	X*5	X*5	O*4		
		Parameter read	0	0	0	0	0	0		
		Inverter reset	×	×	×	×	×	O*2		
		Inverter reset	0	0	0	0	0			
External terminal at the control circuit	_	Operation command (start, stop)	×	0	0	×	X*1			
		Frequency setting	×	0	×	0	X*1			

O: Valid  $\times$ : Invalid  $\Delta$ : Partially valid

- \*1 Follows the Pr.338 Communication operation command source and Pr.339 Communication speed command source settings. (Refer to page 210.)
- \*2 At occurrence of RS-485 communication error, the inverter cannot be reset from the computer.
- \*3 PU stop is only enabled. PS is displayed on the operation panel during PU stop. Follows the **Pr.75 Reset selection/disconnected PU detection/PU stop selection** setting. (Refer to **page 162**.)
- \*4 Writing of some parameters may be disabled by the Pr.77 Parameter write selection setting and the operating condition. (Refer to page 169.)
- \*5 Some parameters are write-enabled independently of the operation mode and command source presence/absence. Writing is also enabled when **Pr.77=**"2". (Refer to **page 169**.) Parameter clear is disabled.
- \*6 When **Pr.550 NET mode operation command source selection=**"1" (RS-485 terminals enabled), or **Pr.550 NET mode operation command source selection=**"9999" with no communication option connected.
- \*7 When **Pr.550 NET mode operation command source selection=**"0" (communication option enabled), or **Pr.550 NET mode operation command source selection=**"9999" with communication option connected.

D

## **♦**Operation at fault

		Operation in each operation mode at error occurrences								
Fault record	Conditions (Pr.551 setting)	PU operation	External operation	External/PU combined operation mode 1 (Pr.79 =3)	External/PU combined operation mode 2 (Pr.79 =4)	NET operation (when RS-485 terminals are used)*5	NET operation (when communication option is used)*6			
Inverter fault	_	Stop								
PU connector disconnection	2 (PU connector) 9999 (automatic recognition)	Stop/continued *1*4								
Other than 2 Stop/continued *1										
Communication error at PU	2 (PU connector)	Stop/continued *2	Continued I I Cont			Continued	ontinued			
connector	Other than 2	Continued								
Communication error at RS-485	1 (RS-485 terminals)	Stop/continued *2	Continued Stop/ continued *2			Continued				
terminals	Other than 1	Continued				Stop/continued *2	Continued			
Communication error at USB connector	3 (USB connector) 9999 (automatic recognition)	Stop/continued continued								
	Other than 3	Continued								
Communication error at communication option	_	Continued					Stop/continued *3			

- \*1 Selectable with Pr.75 Reset selection/disconnected PU detection/PU stop selection
- \*2 Selectable with Pr.122 PU communication check time interval, Pr.336 RS-485 communication check time interval, and Pr.548 USB communication check time interval
- \*3 Follows the communication option
- \*4 In the PU JOG operation mode, operation always stops when the PU is disconnected. The operation of PU disconnection (E.PUE) follows the Pr.75 Reset selection/disconnected PU detection/PU stop selection setting.
- \*5 When **Pr.550 NET mode operation command source selection=** "1" (RS-485 terminals enabled), or **Pr.550 NET mode operation command source selection=**"9999" with no communication option connected.
- \*6 When **Pr.550 NET mode operation command source selection=**"0" (communication option enabled), or **Pr.550 NET mode operation command source selection=**"9999" with communication option connected.

## ◆ Selection of control source in Network operation mode (Pr.338, Pr.339)

- There are two control sources: the start command source, which controls the signals related to the inverter stand command and function selection, and the speed command source, which controls signals related to frequency setting.
- The table below shows the commands from the external terminals and communication (RS-485 terminals or communication option) in the Network operation mode.

Op	oerat	ion	Pı	r.338 Communication ration command source		0: NET			1: EXT		
	catio		•	9 Communication speed command source	0: NET	1: EXT	2: EXT	0: NET	1: EXT	2: EXT	- REMARKS
	Running frequency from communication		NET	_	NET	NET	_	NET			
`	nınaı- valent		Termina	12	_	External	_	_	_	_	
func			Termina	14	_	External		_	Externa		
	,		Termina	11	Comper	nsation					
		0	RL Low-speed operation command/remote setting Clear/Stop-on-contact selection 0		NET External		NET External		l	<b>Pr.59</b> ="0" (multi-speed)	
		1	RM	Middle-speed operation command/remote setting deceleration	NET	External		NET	External	l	Pr.59 ≠"0" (remote) Pr.270 ="1, 3, 11, or 13" (stop-on-contact)
		2	RH	High-speed operation command/remote setting acceleration	NET	External		NET	Externa	l	,
		3	RT	Second function selection/ stop-on-contact selection 1	NET	_		Externa	l		<b>Pr.270</b> ="1, 3, 11, or 13" (stop-on-contact)
		4	AU	Terminal 4 input selection	_	Combine	b	_	Combin	ed	
		5	JOG	Jog operation selection	_			Externa	I		
		6	CS	No function	Externa	l					
		7	OH	External thermal relay input	External						
		8	REX	15-speed selection	NET External			NET	External	I	<b>Pr.59</b> ="0" (multispeed)
		10	X10	Inverter run enable signal	External						
tion	setting	11	X11	FR-HC2/FR-CC2 connection, instantaneous power failure detection	Externa	I					
Selectable function	Pr.189 s	12	X12	PU operation external interlock	Externa	I					
table	o Pr.′	13	X13	External DC injection brake operation start	NET			External			
ec	'8 t	14	X14	PID control valid terminal	NET	External		NET	Externa		
Se	Pr.178 to	16	X16	PU/External operation switchover	Externa	l					
		18	X18	V/F switchover	NET			Externa	l		
				Output stop	Combin	ed		Externa	l		Pr.79 ≠ "7"
		24	MRS	PU operation interlock	Externa	I					Pr.79 = "7" When X12 signal is not assigned.
		25	STP (STOP)	Start self-holding selection	-			Externa	1		
		28	X28	Start-time tuning start external input	NET			Externa	I		
		37	X37	Traverse function selection	NET		Externa	I			
		38	PDI1	PID multistage set point setting 1	NET External		NET	Externa			
		39	PDI2	PID multistage set point setting 2	NET	External		NET	Externa	I	
		40	PDI3	PID multistage set point setting 3	NET	External		NET	Externa	l	
		46	TRG	Trace trigger input	NET			External			
		47	TRC	Trace sampling start/end	NET			Externa	External		
		48	X48	Power failure stop external	Externa	I					

### (D) Operation command and frequency command

-	erat			r.338 Communication eration command source		0: NET			1: EXT		- REMARKS
	selection Pr.339 Communication speed command source		0: NET	1: EXT	2: EXT	0: NET	1: EXT	2: EXT	REMARKS		
		50	SQ	Sequence start	External, NET		External			Pr.414="1": Valid when there is external or network input Pr.414="2": External	
		51	X51	Fault clear	Combin	ed		Externa	l		
		60	STF	Forward rotation command	NET			Externa	l		
		61	STR	Reverse rotation command	NET			Externa	I		
		62	RES	Inverter reset	Externa	I					
		64	X64	PID forward/reverse action switchover	NET	External		NET	External		
		65	X65	PU/NET operation switchover	Externa	İ		•			
		66	X66	External/NET operation switchover	Externa	I					
		67	X67	Command source switchover	Externa						
	5	70	X70	DC feeding operation permission	NET		External				
on	setting	71	X71	DC feeding cancel	NET			External			
cti		72	X72	PID integral value reset	NET	External		NET	External		
Selectable function	Pr.189	73	X73	Second PID P control switchover	NET	External		NET	External		
tab	to P	77	X77	Pre-charge end command	NET	External		NET	External		
Select	Pr.178 t	78	X78	Second pre-charge end command	NET	External		NET	External		
	P.	79	X79	Second PID forward/reverse action switchover	NET	External		NET	External		
		80	X80	Second PID control valid terminal	NET	External		NET	External		
		81	PGT	PID gain tuning start/forced end	NET	External		NET	External		
		84	X84	Emergency drive execution command	Combined						
		94	X94	Control signal input for main circuit power supply MC	External						
		95	X95	Converter unit fault input	Externa						
		96	X96	Converter unit fault input (E.CPU, E.OUT)	External						
		97	X97	Cleaning valid	NET			External			
		98	X98	Cleaning trigger	NET			Externa	I		

### [Explanation of terms in table]

External (EXT) : Commands from external terminal are only valid.

NET : Commands via communication are only valid.

Combined : Command from both external terminal and communication is valid.

— : Command from either of external terminal and communication is invalid.

Compensation : Commands are valid only from external terminal signals when Pr.28 Multi-speed input compensation

selection ="1".

## NOTE

- $\bullet$  The command source of communication follows the Pr.550 and Pr.551 settings.
- The **Pr.338** and **Pr.339** settings can be changed while the inverter is running when **Pr.77** = "2". Note that the setting change is applied after the inverter has stopped. Until the inverter has stopped, communication operation command source and communication speed command source before the setting change are valid.

- In the Network operation mode, the start command source and speed command source can be switched over by the command source switchover signal (X67). This can be used to control signal inputs from both the external terminals and via communication.
- For the X67 signal, set "67" to any of Pr.178 to Pr.189 (input terminal function selection) to assign the function to a control terminal.
- When the X67 signal is OFF, the start command source and speed command source are given via control terminals.

X67 signal state	Start command source	Speed command source				
Signal not assigned	According to Pr.338	According to Pr.339				
ON	According to F1.336	According to F1.339				
OFF	Commands from external terminals are only valid.					

- The ON/OFF state of the X67 signal is applied only during a stop. When the terminals are switched during operation, the ON/ OFF state is applied after a stop.
- When the X67 is OFF, a reset via communication is disabled.
- · Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

### Parameters referred to

Pr.28 Multi-speed input compensation selection page 222

Pr.59 Remote function selection page 194

Pr.79 Operation mode selection page 200

### 5.6.4 **Reverse rotation prevention selection**

This function can prevent reverse rotation fault resulting from the incorrect input of the start signal.

Pr.	Name	Initial value	Setting range	Description
78	Reverse rotation prevention selection		0	Both forward and reverse rotations allowed
D020		0	1	Reverse rotation disabled
			2	Forward rotation disabled

- Set this parameter to limit the motor rotation to only one direction.
- · This parameter is valid for all of the reverse rotation and forward rotation keys of the operation panel and of the parameter unit, the start signals (STF, STR signals) via external terminals, and the forward and reverse rotation commands through communication.

## 5.6.5 Frequency setting via pulse train input


A pulse train input to the terminal JOG can be used to set the inverter's speed command. Moreover, speed synchronized operation of an inverter can be performed by using the pulse train output together with the terminal JOG.

D.:	Name	Initial	value	Setting	_		
Pr.	Name	FM	CA	range	Description		
					Pulse train input (terminal JOG)	Pulse train output (terminal FM)	
				0	JOG signal∗ı	FM output*2	
				1	Pulse train input	FM output*2	
				10*2	JOG signal∗ı	High-speed pulse train output (50% duty)	
291 D100	Pulse train I/O selection	0		11*2	Pulse train input	High-speed pulse train output (50% duty)	
				20*2	JOG signal∗ı	High-speed pulse train output (ON width is fixed)	
				21*2	Pulse train input	High-speed pulse train output (ON width is fixed)	
				100*2	Pulse train input	High-speed pulse train output (ON width is fixed) Output of pulse train input as is	
384	Input pulse division			0	Pulse train input disabled		
D101	Input pulse division scaling factor	0		1 to 250	Division ratio on the input pulse. The frequency resolution on the input pulse changes according to this setting.		
385 D110	Frequency for zero input pulse	0 Hz		0 to 590 Hz	0 Hz Sets the frequency when the input pulse is zero (bias).		
386 D101	Frequency for maximum input pulse	60 Hz	50 Hz	0 to 590 Hz	Sets the frequency when the input pulse is maximum (gain).		

- \*1 Function assigned to Pr.185 JOG terminal function selection.
- \*2 Valid only for the FM type inverters.

## ◆ Selection of pulse train input(Pr.291)

- Setting Pr.291 Pulse train I/O selection = "1, 11, 21, 100" and Pr.384 Input pulse division scaling factor ≠ "0" changes the function of terminal JOG to a pulse train input so that the frequency can be set to the inverter. In the initial setting, the JOG signal is assigned to terminal JOG. A maximum pulse train of 100k pulses/s can be input.
- · Connection with an open collector output system pulse generator




\*1 When the wiring length is long with open collector outputs, the influence of stray capacitance causes the pulse to flatten out and prevents the input pulse from being recognized.

When the wiring length is long (10 m or longer of shielded twisted pair cable with a recommended cable gauge of 0.75 mm²), connect the open collector output signal to the power supply by an external pull-up resistance. The table below shows the reference resistance values for wiring length. The stray capacitance of the wiring changes considerably according to how the cable is laid, thus the above wiring lengths are not guaranteed values. When using a pull-up/down resistance, check the permissible load of the resistor and the permissible load current of the output transistor, and use within the permissible range.

Wiring length	Less than 10 m	10 to 50 m	50 to 100 m	
Pull-up/down resistance	Not required	1 kΩ	470 Ω	
Load current (reference)	10 mA	35 mA	65 mA	

· Connection with a complementary output system pulse generator



### NOTE:

- When pulse train input is selected, the function assigned to terminal JOG by Pr.185 JOG terminal function selection is invalid
- Pr.291 is the selection parameter for pulse train output/FM output. Thus, before changing the setting, check the specifications of the device connected to the terminal FM. (For the pulse train output, refer to page 277.)


### Pulse train input specification

	Item	Specification			
Supported pulse method		Open collector output. Complementary output. (24 V power supply voltage)			
HIGH input level		20 V or more (voltage between JOG and SD)			
LOW input level		5 V or less (voltage between JOG and SD)			
Maximum input pulse rat	е	100 kpps			
Minimum input pulse wid	th	2.5 us			
Input resistance/load cur	rent	2 kΩ (typ)/10 mA (typ)			
Maximum wiring length	Open collector output method	10 m (0.75 mm <sup>2</sup> /twisted pair)			
(reference value)	Complementary output method	100 m (output resistance 50 Ω)*1			
Detection resolution		1/3750			

The wiring length of complementary output is dependent on the output wiring specification of the complementary output unit. The stray capacitance of the wiring changes considerably according to how the cable is laid, thus the maximum wiring length is not a guaranteed value.

## ◆Adjustment of pulse train and frequency (Pr.385, Pr.386)

· The frequency during zero input pulse and maximum input pulse can be set with Pr.385 Frequency for zero input pulse and Pr.386 Frequency for maximum input pulse, respectively.



Limit value = (Pr.386 - Pr.385) × 1.1 + Pr.385

## ♦ How to calculate the input pulse division scaling factor (Pr.384)

· The maximum number of pulses can be calculated by the following formula with Pr.384Input pulse division scaling factor:

Maximum number of pulses (pulse/s) = Pr.384 × 400 (maximum 100k pulses/s) (number of detectable pulses = 11.45 pulses/s)

• For example, to run the invert at 0 Hz when pulse train input is zero and at 30 Hz when pulse train is 4000 pulses/sec, set the inverter as follows:


**Pr.384** = 10 (maximum number of input pulses 4000 pulses/s)

**Pr.385** = 0 Hz, **Pr.386** = 30 Hz (pulse train limit value 33 Hz)



• The priority of the frequency command by the external signals is "Jog operation > multi-speed operation > terminal 4 analog input". When pulse train input is enabled (**Pr.291** = "1, 11, 21, 100" and **Pr.384** ≠ "0"), terminal 2 analog input becomes invalid.

### Speed synchronized operation by pulse input/output



\*1 When the wiring length between FM and JOG is long, the influence of stray capacitance causes the pulse to flatten out and prevents the input pulse from being recognized. When the wiring length is long (10 m or longer of shielded twisted pair cable with a recommended cable size of 0.75 mm²), connect the terminal JOG to the terminal PC by an external pull-up resistance. The table below shows the reference resistance values for wiring length.

Wiring length	Less than 10 m	10 to 50 m	50 to 100 m
Pull-up resistance	Not required	1 kΩ	470 Ω
Load current (reference)	10 mA	35 mA	65 mA

The stray capacitance of the wiring changes considerably according to how the cable is laid, thus the above wiring lengths are not guaranteed values

When using a pull-up/down resistance, check the permissible load of the resistor and the permissible load current (terminal PC: 100 mA, high-speed pulse train output: 85 mA), and use within the permissible range.

- Setting "100" to **Pr.291** enables out of the pulse train input as it is to the pulse train output (terminal FM). Connecting in a daisy chain enables speed synchronized operation of multiple inverters.
- Set Pr.384 to "125" for inverters that receive pulse train since the maximum pulse train output is 50k pulses/s.
- The maximum number of input pulses should be 50k pulses/s.
- When performing synchronized operation, wire according to the following procedure. (This is to prevent contact input of 24 V from being applied to the terminal FM.)
  - 1) Set pulse train output (setting other than "0, 1") to Pr.291 on the master side inverter.
  - 2) Turn the inverter power supply OFF.
  - 3) Wire the slave side terminal JOG-SD to the master side terminal FM-SD.
  - 4) Turn the inverter power supply ON.

## • NOTE

- After changing the **Pr.291** setting, connect the JOG terminal to the terminal FM-SD. When FM output (voltage output) is taken as the pulse train, take caution to prevent voltage from being applied to the terminal FM.
- Use the sink logic (factory setting) for the slave side inverter. The inverter does not operate properly with source logic.

## **♦** Speed synchronized operation specification

Item	Specification
Output pulse format	Pulse width fixed (10 μs)
Pulse rate	0 to 50 kpps
Pulse propagation delay	1 to 2 μs/1 unit∗ι

\*1 A pulse transmission delay of about 1 to 2  $\mu s$  in the slave occurs and further increases when the wiring length is long.

### Parameters referred to

Pr.291 (Pulse train output) \*page 273

### 5.6.6 **JOG** operation

The frequency and acceleration/deceleration time for JOG operation can be set. JOG operation is possible in both External operation and PU.

JOG operation can be used for conveyor positioning, test run, etc.


Pr.	Name	Initial value	Setting range	Description
15 D200	Jog frequency	5 Hz	0 to 590 Hz	Sets the frequency during JOG operation.
16 F002	Jog acceleration/ deceleration time	0.5 s	0 to 3600 s (360 s*1)	Sets motor acceleration/deceleration time during JOG operation. For the acceleration/deceleration time, set the time until the frequency*2 set to Pr.20 Acceleration/deceleration reference frequency is reached.  The acceleration/deceleration times cannot be set separately.

The above parameter is displayed as a simple mode parameter when the LCD operation panel (FR-LU08) or the parameter unit (FR-PU07) is mounted. Setting of this parameter is enabled when the operation panel (FR-DU08) is connected and "0" is set to Pr.160 User group read selection. (Refer to page 177.)

- When Pr.21 Acceleration/deceleration time increments = "0" (initial value), the setting range is "0 to 3600 s" and the setting increment is "0.1 s". When Pr.21 = "1" is set, this means a setting range of "0 to 360 s" and the setting increment is "0.01 s".
- \*2 The Pr.20 initial value is set to 60 Hz for the FM type and to 50 Hz for the CA type.

### JOG operation in the External operation

- · Operation can be started and stopped by the start signals (STF and STR signals) when the Jog operation selection (JOG) signal is ON. (For the operation method, refer to page 109.)
- In the initial setting, the JOG signal is assigned to the terminal JOG.



## JOG operation in PU

· When the operation panel or the parameter unit is in the JOG operation mode, the motor jogs only while the start button is pressed. (For the operation method, refer to page 110.)

- · The reference frequency of the acceleration/deceleration time differs according to the Pr.29 Acceleration/deceleration pattern selectionsetting. (Refer to page 191.)
- The Pr.15 setting should be equal to or higher than the Pr.13 Starting frequency setting.
- The JOG signal can be assigned to an input terminal by setting Pr.178 to Pr.189 (input terminal function selection). Changing the terminal assignment may affect other functions. Set parameters after confirming the function of each terminal.
- During JOG operation, the second acceleration/deceleration cannot be selected with the RT signal. (Other second functions are enabled. (Refer to page 333.))
- When Pr.79 Operation mode selection="4", JOG operation is started by one push of REV on the operation panel and stopped by
- This function is invalid when Pr.79= "3".

### Parameters referred to

Pr.13 Starting frequency page 197

Pr.20 Acceleration/deceleration reference frequency, Pr.21 Acceleration/deceleration time increments page 187

Pr.29 Acceleration/deceleration pattern selection page 191

Pr.79 Operation mode selection page 200

Pr.178 to Pr.182 (input terminal function selection) Pr.178 to Pr.182 (input terminal function selection)

# 5.6.7 Operation by multi-speed setting


Use these parameters to change among pre-set operation speeds with the terminals. The speeds are pre-set with parameters.


Any speed can be selected by simply turning ON/OFF the contact signals (RH, RM, RL, and REX signals).

Pr.	Neme	Initia	value	Setting	Decembrish
Pr.	Name	FM	CA	range	Description
28	Multi-speed input compensation	0		0	Without compensation
D300	selection	U		1	With compensation
4 D301	Multi-speed setting (high speed)	60 Hz	50 Hz	0 to 590 Hz	Sets the frequency when RH is ON.
5 D302	Multi-speed setting (middle speed)	30 Hz		0 to 590 Hz	Sets the frequency when RM is ON.
6 D303	Multi-speed setting (low speed)	10 Hz		0 to 590 Hz	Sets the frequency when RL is ON.
24 D304	Multi-speed setting (speed 4)				
25 D305	Multi-speed setting (speed 5)				
26 D306	Multi-speed setting (speed 6)				
27 D307	Multi-speed setting (speed 7)				
232 D308	Multi-speed setting (speed 8)				
233 D309	Multi-speed setting (speed 9)	9999		0 to 590 Hz,	Frequency from 4th speed to 15th speed can be set according to the combination
234 D310	Multi-speed setting (speed 10)	9999		9999	of the RH, RM, RL and REX signals. 9999: Not selected
235 D311	Multi-speed setting (speed 11)				
236 D312	Multi-speed setting (speed 12)				
237 D313	Multi-speed setting (speed 13)				
238 D314	Multi-speed setting (speed 14)				
239 D315	Multi-speed setting (speed 15)				

## ♦ Multi-speed setting (Pr.4 to Pr.6)

• The inverter operates at frequencies set in **Pr.4** when RH signal is ON, **Pr.5** when RM signal is ON and **Pr.6** when RL signal is ON.







## • NOTE

- In the initial setting, when two or more of multi-speed settings are simultaneously selected, priority is given to the set frequency of the lower signal.
- For example, when RH and RM signals turn ON, RM signal (Pr.5) has a higher priority.
- The RH, RM and RL signals are assigned to the terminals RH, RM and RL in the initial status.
   Set "0 (RL)", "1 (RM)", and "2 (RH)" in any of Pr.178 to Pr.189 (input terminal function selection) to assign the signals to other terminals.

## ◆Multi-speed setting for 4th speed or more (Pr.24 to Pr.27, Pr.232 to Pr.239)

- The frequency from 4th speed to 15th speed can be set by the combination of the RH, RM, RL, and REX signals. Set the running frequencies in Pr.24 to Pr.27, Pr.232 to Pr.239. (In the initial status, 4th to 15th speeds are invalid.)
- For the terminal used for REX signal input, set "8" in any of Pr.178 to Pr.189 (input terminal function selection) to assign the function.





When RH, RM and RL is set to OFF and REX is set to ON when "9999" is set to Pr.232 Multi-speed setting (speed 8), the inverter runs by the frequency set to Pr.6.

### ◆Input compensation of multi-speed setting (Pr.28)

• Speed (frequency) compensation can be applied for the multi-speed setting and the remote setting by inputting the frequency setting compensation signal (terminals 1, 2).

## NOTE

- The priority of the frequency commands by the external signals are "Jog operation > multi-speed operation > terminal 4 analog input > pulse train input > terminal 2 analog input". (For details on frequency commands by analog input, refer to page 314.)
- Valid in the External operation mode or PU/External combined operation mode (Pr.79= "3" or "4").
- Multi-speed parameters can also be set during PU operation or External operation.
- The Pr.24 to Pr.27 and Pr.232 to Pr.239 settings have no priority among them.
- When Pr.59 Remote function selection ≠ "0", the multi-speed setting is invalid since the RH, RM, and RL signals are for
- · When performing analog input compensation, set Pr.28 Multi-speed input compensation selection to "1".
- Select the terminals (terminals 1, 2) to use for compensation input voltage (0 to ± 5 V, 0 to ± 10 V) at Pr.73 Analog input
- When using terminal 1 for compensation input, set Pr.868 Terminal 1 function assignment "0" (initial value).
- · Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

### Parameters referred to

Pr.15 Jog frequency page 221

Pr.59 Remote function selection page 194

Pr.73 Analog input selection page 306

Pr.79 Operation mode selection page 200

Pr.178 to Pr.189 (input terminal function selection) page 329

Pr.868 Terminal 1 function assignment page 310

# (H) Protective function parameter

Purpose	F	arameter to set		Refer to page
To protect the motor from overheating	Electronic thermal O/L relay	P.H000, P.H006, P.H010, P.H016, P.H020, P.H021	Pr.9, Pr.51, Pr.561, Pr.607, Pr.608, Pr.1016	225
To set the overheat protection characteristics for the motor	Free thermal O/L relay setting	P.H001 to P.H005, P.H011 to P.H015	Pr.600 to Pr.604, Pr.692 to Pr.696	232
To extend the life of the cooling fan	Cooling fan operation selection	P.H100	Pr.244	233
To detect ground fault at start	Ground fault at start enable/disable	P.H101	Pr.249	234
To vary the operating level of the undervoltage protective function	Undervoltage level	P.H102	Pr.598	234
To initiate an inverter protective function	Fault initiation	P.H103	Pr.997	235
To disable the I/O phase loss protective function	I/O phase loss protection selection	P.H200, P.H201	Pr.251, Pr.872	235
To restart using the retry function when the protective function is activated	Retry operation	P.H300 to P.H303	Pr.65, Pr.67 to Pr.69	236
To operate without activating protective functions in case of emergency	Emergency drive	P.H320 to P.H324	Pr.514, Pr.515, Pr.523, Pr.524, Pr.1013	238
To set the upper and lower limits of the output frequency	Maximum/minimum frequency	P.H400 to P.H402	Pr.1, Pr.2, Pr.18	245
To operate by avoiding resonance points	Frequency jump	P.H420 to P.H425, P.H429	Pr.31 to Pr.36, Pr.552	246
To limit the output current so that the inverter protective function does not activate	Stall prevention	P.H500, P.H501, P.H600, P.H601, P.H610, P.H611, P.H620, P.H621, P.H631, P.M430, P.T010, P.T040	Pr.22, Pr.23, Pr.48, Pr.49, Pr.66, Pr.148, Pr.149, Pr.154, Pr.156, Pr.157, Pr.858, Pr.868	248
To monitor for load faults	Load characteristics fault detection	P.H520 to P.H527, P.H530 to P.H534	Pr.1480 to Pr.1492	255
To shut off the output during acceleration	Overspeed detection level	P.H800	Pr.374	259

### 5.7.1 Motor overheat protection (electronic thermal O/L relay)


Set the current of the electronic thermal O/L relay function to protect the motor from overheating. Such settings will provide the optimum protective characteristic considering the low cooling capability of the motor during low-speed operation.

Pr.	Name	Initial value	Setting range	Description
9	Electronic thermal O/L	Rated inverter	0 to 500 A*1	Set the rated motor current.
H000	relay	current	0 to 3600 A*2	- Set the rated motor current.
600	First free thermal reduction	9999	0 to 590 Hz	
H001	frequency 1	9999	9999	
601	First free thermal reduction	100%	1 to 100%	
H002	ratio 1	100 70	9999	The electronic thermal O/L relay operation level can be
602	First free thermal reduction	9999	0 to 590 Hz	changed to match the motor temperature characteristics with the combination of these three
H003	frequency 2	3333	9999	points (Pr.600, Pr.601), (Pr.602, Pr.603), (Pr.604, Pr.9).
603	First free thermal reduction	100%	1 to 100%	9999: Free thermal O/L relay invalid
H004	ratio 2	10070	9999	
604	First free thermal reduction	9999	0 to 590 Hz	
H005	frequency 3	3333	9999	
607 H006	Motor permissible load level	150%	110 to 250%	Set the permissible load according to the motor characteristics.
51	Second electronic thermal	9999	0 to 500 A*1	Enabled when the RT signal is ON.
H010			0 to 3600 A*2	Set the rated motor current.
11010	3/2 relay		9999	Second electronic thermal O/L relay invalid
692	Second free thermal	9999	0 to 590 Hz	
H011	reduction frequency 1	3333	9999	
693	Second free thermal	100%	1 to 100%	The electronic thermal O/L relay operation level can be
H012	reduction ratio 1	10070	9999	changed to match the second motor temperature
694	Second free thermal	9999	0 to 590 Hz	characteristics with the combination of these three
H013	reduction frequency 2	3333	9999	points (Pr.692, Pr.693), (Pr.694, Pr.695), (Pr.696,
695	Second free thermal	100%	1 to 100%	Pr.51). 9999: Second free thermal O/L relay invalid
H014	reduction ratio 2	10070	9999	9999. Second free thermal O/L relay invalid
696	Second free thermal	9999	0 to 590 Hz	]
H015	reduction frequency 3		9999	
608	Second motor permissible		110 to 250%	Set the permissible load when the RT signal is ON.
H016	load level	9999	9999	The <b>Pr.607</b> setting is applied even when the RT signal is ON.
561	PTC thermistor protection	9999	0.5 to 30 kΩ	Set the PTC thermistor protection level (resistance).
H020	level	שטטט	9999	PTC thermistor protection disabled
1016 H021	PTC thermistor protection detection time	0 s	0 to 60 s	Set the time from when the resistance of the PTC thermistor reaches the protection level until the protective function is activated.

- \*1 The setting range for FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower. The minimum setting increment is "0.01 A".
- \*2 The setting range for FR-F820-03160(75K) or higher, and FR-F840-01800(75K) or higher. The minimum setting increment is "0.1 A".

## ◆Electronic thermal O/L relay operation characteristic for induction motor (Pr.9, E.THM)

- This function detects the overload (overheat) of the motor and trips the inverter by stopping the operation of the transistor at the inverter output side.
- Set the rated current (A) of the motor in Pr.9. (If the motor has both 50 Hz and 60 Hz ratings and the Pr.3 Base frequency is set to 60 Hz, set to 1.1 times the 60 Hz rated motor current.)
- Set "0" in Pr.9 to avoid activating the electronic thermal O/L relay function; for example, when using an external thermal relay for the motor. (Note that the output transistor protection of the inverter is activated. (E.THT))
- When using the Mitsubishi constant-torque motor, set Pr.71 Applied motor = "1, 13 to 16, 50, 53, 54". (This will set a 100% continuous torque characteristic in the low-speed range.)



- \*1 When setting **Pr.9** to a value (current value) of 50% of the inverter rated current
- The % value denotes the percentage to the rated inverter current. It is not the percentage to the rated motor current.
- When the electronic thermal O/L relay of the Mitsubishi constant-torque motor is set, the characteristic curve is as shown in this diagram at 6 Hz or higher. (For selection of the operation characteristic, refer to page 337.)
- Transistor protection is activated depending on the temperature of the heatsink. The protection may be activated even with less than 120% depending on the operating conditions.


### NOTE

- The internal accumulated heat value of the electronic thermal relay function is reset to the initial value by the inverter's power reset and reset signal input. Avoid unnecessary reset and power-OFF.
- · Install an external thermal relay (OCR) between the inverter and motors to operate several motors, a multi-pole motor or a dedicated motor with one inverter. When setting an external thermal relay, note that the current indicated on the motor rating plate is affected by the line-to-line leakage current. (Refer to page 72.) The cooling effect of the motor drops during low-speed operation. Use a thermal protector or a motor with built-in thermistor.
- · The protective characteristic of the electronic thermal O/L relay is degraded when there is a large difference in capacity between the inverter and motor, and when the set value is small. In such case, use an external thermal relay.
- · A dedicated motor cannot be protected by an electronic thermal O/L relay. Use an external thermal relay.
- If the electronic thermal O/L relay is set to 3% or lower of the rated inverter current, the electronic thermal O/L relay may not
- The transistor protection thermal O/L relay is activated early when the Pr.72 PWM frequency selection setting is increased.

- This function detects the overload (overheat) of the motor and trips the inverter by stopping the operation of the transistor at the inverter output side. (The operation characteristic is shown below.)
- Set the rated current (A) of the motor in **Pr.9**. Performing IPM parameter initialization automatically sets the rated current of the IPM motor. (Refer to page 151.)
- Set "0" in **Pr.9** to avoid activating the electronic thermal O/L relay function; for example, when using an external thermal relay for the motor.

(Note that the output transistor protection of the inverter is activated. (E.THT))

• MM-EFS, MM-THE4



- \*1 The % value denotes the percentage to the rated motor current.
- · Protective function activated area: the area right of the characteristic curve
- · Normal operation area: the area left of the characteristic curve


## • NOTE

- The internal accumulated heat value of the electronic thermal relay function is reset to the initial value by the inverter's power reset and reset signal input. Avoid unnecessary reset and power-OFF.
- When using a PM motor other than MM-EFS/MM-THE4, set the free thermal parameters (**Pr.600** to **Pr.604**) in accordance with the motor characteristic.
- The transistor protection thermal O/L relay is activated early when the Pr.72 PWM frequency selection setting is increased.

5

GROUP **H** 

## ◆Set two types of electronic thermal O/L relays (Pr.51)



- These settings are used when rotating two motors with different rated current separately by a single inverter. (When rotating two motors together, use an external thermal relay.)
- Set the rated motor current for the second motor in Pr.51.
- When the RT signal is ON, thermal protection is provided based on the Pr.51 setting.

Pr.450 Pr.9		Pr.51	RT-	OFF	RT-ON	
Second applied motor	Electronic thermal O/L relay	Second electronic thermal O/L relay	No.1 Motor	No.2 Motor	No.1 motor	No.2 motor
		9999	×	×	×	×
9999	0	0	×	×	×	×
		0.01 to 500 (0.1 to 3600)	×	Δ	×	0
		9999	0	×	0	×
9999	Other than 0	0	0	×	Δ	×
		0.01 to 500 (0.1 to 3600)	0	Δ	Δ	0
		9999	×	×	×	×
Other than 9999	0	0	×	×	×	×
		0.01 to 500 (0.1 to 3600)	×	Δ	×	0
		9999	0	Δ	Δ	0
Other than 9999	Other than 0	0	0	×	Δ	×
		0.01 to 500 (0.1 to 3600)	0	Δ	Δ	0


- O: Values are accumulated by using the output current.
- Δ: Values are accumulated by assuming the output current is "0 A" (cooling processing).
- x: Electronic thermal O/L relay does not operate.

## • NOTE

- The RT signal is a second function selection signal. The RT signal also enables other second functions. (Refer to page 333.)
- The RT signal is assigned to the terminal RT in the initial setting. Set "3" in any of Pr.178 to Pr.189 (input terminal function selection), to assign the RT signal to another terminal.

### ◆Motor permissible load level setting (Pr.607, Pr.608)


The electronic thermal O/L relay operation characteristic can be changed by setting the permissible load level according to the motor characteristics.



Example of motor permissible load setting (when Pr.9="100% of the inverter rating")

## ◆Electronic thermal O/L relay pre-alarm (TH) and warning signal (THP) signal)

- If the accumulated electronic thermal value reaches 85% of the Pr.9 or Pr.51 setting, electronic thermal O/L relay function pre-alarm (TH) is displayed and the electronic thermal O/L relay pre-alarm (THP) signal is output. If the value reaches 100% of the Pr.9 setting, the motor thermal protection (E.THM/E.THT) is activated to shut off the inverter output. The inverter output is not shut off with the TH display. The inverter output is not shut off with the warning signal (THP).
- For the terminal used for THP signal output, set "8 (positive logic)" or "108 (negative logic)" in any of Pr.190 to Pr.196 (output terminal function selection) to assign the function.




100%: Electronic thermal O/L relay activation value

## NOTE :

· Changing the terminal assignment using Pr.190 to Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

## External thermal relay input (OH signal, E.OHT)




External thermal relay input connection diagram

- The external thermal relay input (OH) signal is used when using an external thermal relay or a thermal protector built into the motor to protect the motor from overheating.
- When the thermal relay function is activated, the external thermal operation (E.OHT) shuts off the inverter output.
- For the terminal used for the OH signal input, set "7" in any of Pr.178 to Pr.189 (input terminal function selection) to assign the function.

## NOTE :

• Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.


### ◆PTC thermistor input (Pr.561, Pr.1016, E.PTC)



### **Example of PTC thermistor characteristics**

- · Output from the PTC thermistor, which is built into the motor, can be input to the terminals 2 and 10. If the input from the PTC thermistor reaches the resistor value set in Pr.561 PTC thermistor protection level, the PTC thermistor operation (E.PTC) shuts off the inverter output.
- · Confirm the characteristic of the PTC thermistor to be used, and set the resistance for Pr.561 around the center of the R1 and R2 values shown on the figure above so that it does not deviate from the protective function activating temperature TN. If the Pr.561 setting becomes too close to R1 or R2, the protective function activating temperature may be too hot (protection is delayed), or too cold (too much protection).
- When the PTC thermistor protection is enabled (Pr.561 ≠ "9999"), the resistance value for the PTC thermistor can be displayed on the operation panel (FR-DU08) or via RS-485 communication. (Refer to page 263.)

If the resistance of the PTC thermistor falls below the protection level within the protection detection time, the elapsed time count is cleared.





## NOTE

- When using terminal 2 for PTC thermistor input (Pr.561 ≠ "9999"), the terminal 2 will not operate as an analog frequency command terminal. The PID and dancer control functions assigned to the terminal 2 will be also disabled. Use Pr.133 PID action set point to set the set point for the PID function.
- To input power to the PTC thermistor power supply, always use the terminal 10. Do not use any other terminals or an external power supply Otherwise, the PTC thermistor protection (E.PTC) does not operate properly.
- When E.PTC is activated, the alarm display, "External protection (AU terminal)", may appear on the parameter unit (FR-PU07), but it is not a fault.


## ◆Overheat protection to match the characteristic of the motor (Pr.600 to Pr.604, Pr.692 to Pr.696)

- The activation level of the electronic thermal O/L relay can be varied to match the motor temperature characteristic.
- The electronic thermal O/L relay's activation level can be set using the combination of three points (Pr.600, Pr.601), (Pr.602, Pr.603), (Pr.604, Pr.9). Two or more points are required for setting.
- The electronic thermal O/L relay's activation level can be set to using the combination of three points (Pr.692, Pr.693), (Pr.694, Pr.695), (Pr.696, Pr.51) when the RT signal is ON.





• When setting Pr.600, Pr.602, Pr.604 (Pr.692, Pr.694, Pr.696) to the same frequency, the following graph's upper level will be applied.





· Make sure to set the parameters according to the motor temperature characteristic used.

### # Parameters referred to

Pr.71 Applied motor page 337

Pr.72 PWM frequency selection page 179

Pr.178 to Pr.189 (input terminal function selection) page 329

Pr.190 to Pr.196 (output terminal function selection) Pr.196 page 288

### 5.7.2 **Cooling fan operation selection**

A cooling fan is built into the inverter and its operation can be controlled.

Pr.	Name	Initial value	Setting range	Description	
	3			0	A cooling fan operates at power ON. Cooling fan ON/OFF control is invalid. (The cooling fan is always ON at power ON)
244 H100		1	1	Cooling fan ON/OFF control is valid.  The fan is always ON while the inverter is running. During a stop, the inverter status is monitored and the fan switches ON/OFF according to the temperature.	
			101 to 105	Cooling fan ON/OFF control is valid. Set the cooling fan stop waiting time within 1 to 5 s.	

## ◆Cooling fan always ON (Pr.244 = "0")

- When Pr.244 = "0", the cooling fan operates at power ON. If the fan stops at this time, fan operation is regarded as faulty, Fan alarm F [5] [FN] is displayed on the operation panel, and the fan fault (FAN) and alarm (LF) signals are output.
- For the terminal used for the FAN signal output, set "25 (positive logic)" or "125 (negative logic)" in any of Pr.190 to Pr.196 (output terminal function selection). For the LF signal, set "98 (positive logic)" or "198 (negative logic)".

## ◆Cooling fan operation control (Pr.244 = "1" (initial value), "101 to 105")

- The cooling fan operation is controlled when Pr.244 = "1". When the inverter is running, the cooling fan operates; and when it is stopped, the cooling fan operates according to the temperature of the inverter heatsink. If the fan stops although it meets the conditions for running, fan operation is regarded as faulty, [FN] is displayed on the operation panel, and the fan signal and LF signals are output.
- To prevent the cooling fan from turning ON and OFF repeatedly during frequent starts/stops (inching), the cooling fan stop waiting time can be set. The waiting time when Pr.244 = "101 to 105" is Pr.244-100 (or 1 s, if the Pr.244 = "101").

## Cooling fan operation command signal (Y206 signal)

- The cooling fan operation command signal (Y206 signal) can be output when the inverter cooling fan meets the conditions for running. The function can be used when the fan installed on the enclosure is synchronized with the inverter cooling fan.
- Y206 signal indicates the operating command condition of the inverter cooling fan depending on the power supply ON/OFF or the Pr.244 settings. The signal does not indicate the actual operation of the cooling fan. (The signal is output even if the cooling fan is stopped due to a fault.)
- To use the Y206 signal, set "206 (positive logic) or 306 (negative logic)" in one of Pr.190 to Pr.196 (output terminal function selection) to assign function to an output terminal.

## NOTE:

- The cooling fan is installed on the FR-F820-00105(2.2K) or higher and FR-F840-00083(3.7K) or higher.
- · Changing the terminal assignment using Pr.190 to Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

### Parameters referred to

Pr.190 to Pr.196 (output terminal function selection) page 288

### 5.7.3 Earth (ground) fault detection at start Magnetic flux

Select whether to enable/disable earth (ground) fault detection at start. When enabled, earth (ground) fault detection is performed immediately after a start signal input to the inverter.

Pr.	Name	Initial value	Setting range	Description
249	Earth (ground) fault	0	0	Without the earth (ground) fault detection at start
H101	detection at start		1	With the earth (ground) fault detection at start

- If a ground fault is detected at start while Pr.249 = "1", the output-side earth (ground) fault overcurrent (E.GF) is displayed and the outputs are shut off. (Refer to page 545)
- The Pr.249 setting is enabled during V/F control and Advanced magnetic flux vector control
- When the Pr.72 PWM frequency selection selection setting is high, enable the ground fault detection at start.

### NOTE

- · Because of the detection performed at start, the output is delayed by approximately 20 ms at every start.
- · Use Pr.249 to enable/disable ground fault detection at operation start. Ground faults are detected always during operation regardless of the Pr.249 setting.
- If a smaller-capacity motor is used with the FR-F820-00250(5.5K) or higher and FR-F840-00126(5.5K) or higher, ground fault protection may be insufficient.

### 5.7.4 Varying the activation level of the undervoltage protective function

If the undervoltage protection (E.UVT) activates due to unstable voltage in the power supply, the undervoltage level (DC bus voltage value) can be changed. (only available for 400 V class)

Pr.	Name	Initial value	Setting range	Description
598		9999	350 to 430 VDC	Set the DC voltage value at which E.UVT occurs.
H102			9999	E.UVT occurs at 430 VDC

## NOTE

- · Do not use this function when switching to an external battery, since the inrush current when power is restored increases, as the undervoltage level is decreased.
- The Pr.598 settings are only valid for 400 V class inverters.
- The Pr.598 setting is disabled during PM motor control. The Pr.598 setting is also invalid during PM motor control for the first or second functions.

### 5.7.5 **Initiating a protective function**

A fault (protective function) is initiated by setting the parameter.

This function can be used to check how the system operates at activation of a protective function.

Pr.	Name	Initial value	Setting	Description	
		value	range		
997	997 H103 Fault initiation	16 to 253		The setting range is same with the one for fault data codes of the inverter (which can be read through communication).  Written data is not stored in EEPROM.	
H103			9999	The read value is always "9999". With this setting, the protective function does not activate.	

- To initiate a fault (protective function), set the assigned number of the protective function you want to initiate in Pr.997.
- The value set in Pr.997 is not stored in EEPROM.
- · When a protective function activates, the inverter trips, a fault is displayed, and a fault signal (ALM, ALM2) is output.
- The latest fault in the faults history is displayed while the fault initiation function is in operation. After a reset, the faults history goes back to the previous status. (The protective function generated by the fault is not saved in the faults history.)
- Perform inverter reset to cancel the protective function.
- For the selectable parameter by Pr.997 and the corresponding protective functions, refer to page 535.

### NOTE :

- If a protective function is already operating, no fault can be activated by Pr.997.
- The retry function is disabled when a protective function has been initiated by the fault initiation function.
- If a fault occurs after a protective function has been activated, the protective function indication does not change. The fault is not saved in the faults history either.

### 5.7.6 I/O phase loss protection selection

The output phase loss protection function, which stops the inverter output if one of the three phases (U, V, W) on the inverter's output side (load side) is lost, can be disabled.

The input phase loss protective function on the inverter input side (R/L1, S/L2, T/L3) can be enabled.

Pr.	Name	Initial value	Setting range	Description
251	Output phase loss		0	Without output phase loss protection
H200	H200 protection selection	'	1	With output phase loss protection
872	Input phase loss	0	0	Without input phase loss protection
H201 *1	H201 *1 protection selection	U	1	With input phase loss protection

<sup>\*1</sup> The setting is available only for standard models.

## ◆Output phase loss protection selection (Pr.251)

• When Pr.251 = "0", output phase loss (E.LF) protection is disabled.

## ◆Input phase loss protection selection (Pr.872) (Standard models)

• When Pr. 872 = "1", input phase loss (E.ILF) protection will be activated if one of three phases is detected to be lost for 1 s continuously.



- · When several motors are connected, output phase loss cannot be detected even if the wiring to one motor loses phase.
- If an input phase is lost while Pr.872 = "1" (with input phase loss protection), Pr.261 Power failure stop selection ≠ "0" (power failure stop function enabled), the motor decelerates to stop without outputting E.ILF.
- In the case of R/L1, S/L2 phase loss, the input phase loss protection will not operate, and the inverter will trip.
- · If an input phase loss continues for a long time, the converter section and capacitor lives of the inverter will be shorter.

### Parameters referred to

Pr.261 Power failure stop selection page 426

# 5.7.7 Retry function

This function allows the inverter to reset itself and restart at activation of the protective function (fault indication). The retry generating protective functions can be also selected.

When the automatic restart after instantaneous power failure function is selected (**Pr.57 Restart coasting time** ≠ 9999), the restart operation is also performed after a retry operation as well as after an instantaneous power failure. (Refer to page 414 and page 420 for the restart operation.)

Pr.	Name	Initial value	Setting range	Description		
65 H300	Retry selection	0	0 to 5	A retry-making fault can be selected. (Refer to the table <b>on the next page</b> .)		
			0	No retry function		
67	Number of retries at	0	1 to 10	Set the number of retries at a fault occurrence.  A fault output is not provided during the retry operation.		
H301 fault occurrence	O	101 to 110	Set the number of retries at a fault occurrence. (The setting value minus 100 is the number of retries.) A fault output is provided during the retry operation.			
68 H302	Retry waiting time	1 s	0.1 to 600 s	Set the waiting time from a fault occurrence to a retry.		
69 H303	Retry count display erase	0	0	Clears the number of successful restarts made by retries.		

### ◆Setting the retry function (Pr.67, Pr.68)


- When the inverter protective function is operating (fault indication), the retry function automatically cancels (resets) the protective function after the time set in **Pr.68**. The retry function then restarts the operation from the starting frequency.
- Retry operation is enabled when **Pr.67** ≠ "0". For **Pr.67**, set the number of retries at activation of the protective function.

Pr.67 setting	Fault output during retry operation	Retry count
0	_	No retry function
1 to 10	Not provided	1 to 10 times
101 to 110	Provided	1 to 10 times

- When retries fail consecutively more than the number of times set in **Pr.67**, a retry count excess (E.RET) occurs, resulting in an inverter retries. (Refer to the retry failure example.)
- Use **Pr.68** to set the waiting time from a protective function activation to a retry in the range of 0.1 to 600 s.
- During retry operation, the during retry (Y64) signal is ON. For the Y64 signal, set "64 (positive operation)" or "164 (negative operation)" in any of **Pr.190** to **Pr.196** (output terminal function selection) to assign the function.

## ◆Retry count check (Pr.69)

- Reading the **Pr.69** value provides the cumulative number of successful restart times made by retries. The cumulative count in **Pr.69** increases by 1 when a retry is successful. Retry is regarded as successful when normal operation continues without a fault for the **Pr.68** setting multiplied by four or longer (3.1 s at the shortest). (When retry is successful, the cumulative number of retry failures is cleared.)
- · Writing "0" in Pr.69 clears the cumulative count.



## Selecting retry generating faults (Pr.65)

• Using Pr.65, you can select the fault that will cause a retry. No retry will be made for the fault not indicated. (For the fault details, refer to page 535.) ● indicates the faults selected for retry.

Retry-making	Pr.65 setting					
fault	0	1	2	3	4	5
E.OC1	•	•		•	•	•
E.OC2	•	•		•	•	
E.OC3	•	•		•	•	•
E.OV1	•		•	•	•	
E.OV2	•		•	•	•	
E.OV3	•		•	•	•	
E.THM	•					
E.THT	•					
E.IPF	•				•	
E.UVT	•				•	
E. BE	•				•	
E. GF	•				•	
E.OHT	•					
E.OLT	•				•	
E.OPT	•				•	

Retry-making	Pr.65 setting					
fault	0	1	2	3	4	5
E.OP1	•				•	
E. PE	•				•	
E.OS	•				•	
E.PTC	•					
E.CDO	•				•	
E.SER	•				•	
E.USB	•				•	
E.ILF	•				•	
E.PID	•				•	
E.PCH	•				•	
E.SOT	•	•		•	•	•
E.LCI	•				•	
E.LUP	•				•	
E.LDN	•				•	

### NOTE:

- · Use the retry function only when the operation can be resumed after resetting a protective function activation. Making a retry against the protective function, which is activated by an unknown condition, will lead the inverter and motor to be faulty. Identify what condition the protective function was activated, and eliminate such condition before resuming the operation.
- If the retry function operates during PU operations, the operating conditions (forward/reverse rotation) are stored; and operations resume after retry reset.
- Only the fault details for the first fault that occurred are stored in the faults history.
- The reset by the retry function does not clear the accumulated data of the electronic thermal O/L relay, regenerative brake duty, etc. (This is different from power supply reset or reset by RES signal.)
- When the parameter storage device fault (E.PE) is occurring and reading of the retry-function-related parameters is not possible, retry cannot operated.
- · Changing the terminal assignment using Pr.190 to Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.



### **Caution**

• When the retry function is set enabled, stay away from the motor and machine in the case of an inverter trip. The motor and machine will start suddenly (after the reset time has elapsed) after the inverter trip. When the retry function is set enabled, apply in easily visible places the CAUTION stickers supplied to this product.

### Parameters referred to

Pr.57 Restart coasting time page 414, page 420

### 5.7.8 **Emergency drive**

This function is used in case of emergency such as a fire to forcibly continue inverter operation to drive a motor without activating protective functions even if the inverter detects a fault. Using this function may cause damage of the motor or the inverter because driving the motor is given the highest priority. Use this function for emergency operation only. When the inverter is damaged by a fault, the motor operation can be continued by switching to the commercial power supply operation.

The emergency drive function is available only for the standard model.

Pr.	Name	Initial value		0-44	5
		FM	CA	Setting range	Description
523 H320*1	Emergency drive mode selection	9999		100, 111, 112, 121, 122, 123, 124, 200, 211, 212, 221, 222, 223, 224, 300, 311, 312, 321, 322, 323, 324, 400, 411, 412, 421, 422, 423, 424	Select the operation mode of the emergency drive.
				9999	Emergency drive disabled
524 H321 *1*2	Emergency drive running speed	9999		0 to 590 Hz*3	Set the running frequency in the fixed frequency mode of the emergency drive. (when the fixed frequency mode is selected in <b>Pr.523</b> )
				0 to 100%*3	Set the PID set point in the PID control mode of the emergency drive. (when the PID control mode is selected in <b>Pr.523</b> )
				9999*3	Emergency drive disabled
515	Emergency drive	1		1 to 200	Set the retry count during emergency drive operation.
H322*1	dedicated retry count			9999	Without retry count excess (no restriction on the number of retries)
1013 H323*1	Emergency drive running speed after retry reset	60 Hz	50 Hz	0 to 590 Hz	Set the frequency for operation after a retry when any of E.CPU, E.1 to E.3, E.5 to E.7 occurs during emergency drive operation.
514 H324*1	Emergency drive dedicated waiting time	9999		0.1 to 600 s	Set the retry waiting time during emergency drive operation.
П324*1	dedicated waiting time			9999	As set in <b>Pr.68</b> .
136 A001	MC switchover interlock time	1 s		0 to 100 s	Set the operation interlock time for MC2 and MC3.
139 A004	Automatic switchover frequency from inverter to bypass operation			0 to 60 Hz	Set the frequency at which the inverter-driven operation is switched over to the commercial power supply operation when the condition for electronic bypass is established during emergency drive operation.
				9999	Without automatic switchover
57 A702	Restart coasting time	9999		0	Coasting time differs according to the inverter capacity. (Refer to page 414.)
				0.1 to 30 s	Set the waiting time for the inverter to perform a restart after the power lost by an instantaneous power failure restores.
				9999	No restart


<sup>\*1</sup> The setting is available only for standard models.

<sup>\*2</sup> Set Pr.524 after setting Pr.523.

<sup>\*3</sup> When **Pr.523** = "100, 200, 300, 400", the emergency drive is activated regardless of the **Pr.524** setting.

## **◆**Connection diagram

• An example connection diagram of the emergency drive is shown below.



\*1 Be careful of the capacity of the sequence output terminals.

The applied terminals differ by the settings of Pr.190 to Pr.196 (output terminal function selection).

Output terminal capacity	Output terminal permissible load
Inverter open collector output (RUN, SU, IPF, OL, FU)	24 VDC 0.1 A
Inverter relay output (A1-C1, B1-C1, A2-B2, B2-C2) Relay output option (FR-A8AR)	230 VAC 0.3 A 30 VDC 0.3 A

- \*2 When connecting a DC power supply, insert a protective diode. When connecting an AC power supply, use the relay output option (FR-A8AR) and use contact outputs.
- \*3 The applied terminals differ by the settings of Pr.180 to Pr.189 (input terminal function selection).
- \*4 The applied terminals differ by the settings of Pr.190 to Pr.196 (output terminal function selection).


## NOTE

Always provide mechanical interlocks for MC2 and MC3.


#### **◆**Emergency drive execution sequence



- When X84 signal is ON for 3 s, the emergency drive is executed.
- Y65 signal turns ON during emergency drive operation.
- "ED" appears on the operation panel during emergency drive operation.
- ALM3 signal turns ON when a fault occurs during emergency drive operation.
- Operation of the emergency drive function (when the switchover to the commercial power supply during emergency drive is disabled, and the retry in case of critical faults is selected)



• When the electronic bypass during emergency drive is activated (CS signal is turned ON) (when the switchover to the commercial power supply during emergency drive is enabled)



#### ◆Emergency drive operation selection (Pr.523, Pr.524)

• Use Pr.523 Emergency drive mode selection to select the emergency drive operation. Set a value in the hundreds place to select the operation when a valid protective function is activated (critical fault) during emergency drive. Set values in the ones and tens places to select the operation method.

Pr.523 setting	Emergency drive	operation mode	Description
100	Output shutoff mode		Output shutoff at a critical fault occurrence.
200	Retry / output shutoff mode		Retry operation at a critical fault occurrence. (Output shutoff at the occurrence of a fault for which retry is not permitted.) The output is shut off when a critical fault for which retry is not permitted occurs, or the retry count is exceeded.
3[[[]*1	Retry / commercial mode		Retry operation at a critical fault occurrence. (Electronic bypass at the occurrence of a fault for which retry is not permitted.)  The operation is switched over to the commercial power supply operation when a critical fault for which retry is not permitted occurs, or the retry count is exceeded.  While Pr.515 = "9999", the operation is switched over to the commercial power supply operation when the retry count reaches 200.
4[][]*1	Commercial mode		The operation is switched over to the commercial power supply operation when a critical fault occurs.
[]00	Normal operation mode		The operation is performed with the same set frequency and by the same starting command as those in the normal operation.  Use this mode to avoid output shutoff due to a fault.
[]11		Forward rotation	The operation is forcibly performed with the frequency set in <b>Pr.524</b> .
[]12	Fixed frequency mode	Reverse rotation	Even when the motor is stopped, the operation is started by the emergency drive execution.
[]21		Forward rotation	The operation is performed under PID control using the
[]22		Reverse rotation	<b>Pr.524</b> setting as a set point. The measured values are input in the method set in <b>Pr.128</b> .
[]23	PID control mode	Forward rotation (Second PID measured value input)	The operation is performed under PID control using the
[]24	Reverse rotation (Second PID measured value input)		Pr.524 setting as a set point. The measured values are input in the method set in Pr.753.
9999	Emergency drive disable	ed	

<sup>\*1</sup> Under PM motor control, the operation is not switched over to the commercial power supply operation the output is shut off.

#### ◆Retry operation during emergency drive (Pr.515, Pr.514)

- Set the retry operation during emergency drive operation. Use Pr.515 Emergency drive dedicated retry count to set the retry count, and use Pr.514 Emergency drive dedicated waiting time to set the retry waiting time.
- The ALM signal output conditions depend on the Pr.67 Number of retries at fault occurrence setting. (Refer to page 236.)
- For the protective functions (critical faults) for which a retry is performed during emergency drive operation, refer to page



• During emergency drive operation, Pr.65 Retry selection is not available.

#### **◆Electronic bypass during emergency drive (Pr.136, Pr.139, Pr.57)**

- For selecting the commercial mode (**Pr.523** = "3[[[], 4[[[]"), setting is required as follows.
  - Set Pr.136 MC switchover interlock time and Pr.139 Automatic switchover frequency from inverter to bypass operation and assign MC2 and MC3 signals to output terminals.
  - When CS signal is assigned to an input terminal, set **Pr.57 Restart coasting time** ≠ "9999" and turns the CS signal ON. (In the initial setting, the CS signal is assigned to the terminal CS.)
  - V/F control or Advanced magnetic flux vector control (Under PM motor control, the operation is not switched over to the commercial power supply operation the output is shut off.)
- During emergency drive operation, the operation is switched over to the commercial power supply operation when any of the following conditions is satisfied.
  - CS signal turns OFF.
  - A critical fault for which retry is not permitted occurs while Pr.523="3[][]".
  - A critical fault occurs while Pr.523="4[[[]".
- While the motor is driven by the inverter during emergency drive operation, if a condition for electronic bypass is satisfied, the output frequency is accelerated/decelerated to the Pr.139 setting. When the frequency reaches the set frequency, the operation is switched over to the commercial power supply operation. (The operation is immediately switched over to the commercial power supply operation during output shutoff due to a critical fault occurrence.)
- If the parameter for electronic bypass is not set while the commercial mode is set (**Pr.523** = "3[[[], 4[[[]]"), the operation is not switched over to the commercial power supply operation even when a condition for switchover is satisfied, and the output is shut off.
- For the terminals used for the MC2 and MC3 signal output, set "18 (positive logic)" and "19 (positive logic)" in any two of **Pr.190 to Pr.196 (output terminal function selection)** to assign the function.
- Operation of magnetic contactor (MC2, MC3)

Magnetic		Operation		
Magnetic Installation location		During commercial power supply operation	During inverter operation	
MC2	Between power supply and motor	Shorted	Open	
MC3	Between inverter output and motor	Open	Shorted	

· The input signals are as shown below.

Signal	Function	Operation	MC operation *3	
Signal	Function	Operation	MC2	MC3
		ON Inverter operation	×	0
CS Inverter/bypass	OFF Emergency drive commercial power supply operation*I	0	×	
V04	Emergency drive evenution	ON Emergency drive execution	_	_
X84	mergency drive execution	OFF Normal operation*2	×	0
RES	Operation status reset	ON Reset	×	Invariance
INLO	Operation status reset	OFF Normal operation	_	_

- \*1 If the signal is turned ON after switchover to the emergency drive commercial power supply operation, the operation will not be returned to the inverter-driven operation.
- \*2 If the signal is turned OFF during the emergency drive operation, the operation will not be returned to normal.
- \*3 MC operation
  - O: MC-ON
  - X: MC-OFF
  - —: During inverter operation, MC2-OFF, MC3-ON During commercial power supply operation, MC2-ON, MC3-OFF

Invariance: The status before changing the signal ON or OFF is held.

#### • NOTE

During electronic bypass operation while the electronic bypass sequence is enabled (Pr.135 = "1"), the emergency drive function is not available

#### **♦PID** control during emergency drive operation

- During emergency drive operation in the PID control mode, the operation is performed under PID control using the **Pr.524** setting as a set point. Input the measured values in the method set in **Pr.128** or **Pr.753**.
- When the PID control mode is selected for emergency drive, the PID action during emergency drive operation is as follows depending on the PID control setting.

	PID control action			
ltem	Set point / measured value input setting	Deviation input setting	Without PID control setting	
Measured value input selection	Held	Terminal 4 input	Terminal 4 input	
Forward action / reverse action selection	Held	Held	Reverse action (initial setting)	
Proportional band	Held	Held	100% (initial setting)	
Integral time	Held	Held	1 s (initial setting)	
Differential time	Held	Held	Not used (initial setting)	
Applied to the frequency / calculation only	Applied to the frequency	Applied to the frequency	Applied to the frequency	
Other PID-related settings	Held	Held	Held	

• While the "retry" (**Pr.523** = "22[], 32[]") is selected in the PID control mode, if a retry occurs at an occurrence of E.CPU, E.1 to E.3, E.5 to E.7 during emergency drive operation, the operation is performed not under PID control but with the fixed frequency. Use **Pr.1013 Emergency drive running speed after retry reset** to set the fixed frequency.

#### NOTE

• For details of the PID control, refer to page 378.

#### **♦**Operation of protective functions during emergency drive

· Operation of protective functions during emergency drive is as follows.

Protective	Operation during
function	emergency drive
E.OC1	Retry
E.OC2	Retry
E.OC3	Retry
E.OV1	Retry
E.OV2	Retry
E.OV3	Retry
E.THT	Retry
E.THM	Retry
E.FIN	Retry
E.IPF	Disabled
E.UVT	Disabled
E.ILF	Disabled
E.OLT	Retry
E.SOT	Retry
E.LUP	Disabled
E.LDN	Disabled
E.BE	Retry*1
E.GF	Retry
E.LF	Disabled

1 TOTECTIVE	Operation during	
function	emergency drive	
E.OHT	Retry	
E.PTC	Retry	
E.OPT	Disabled	
E.OP1	Disabled	
E.OP2	Disabled	
E.OP3	Disabled	
E.16	Disabled	
E.17	Disabled	
E.18	Disabled	
E.19	Disabled	
E.20	Disabled	
E.PE	Output shutoff	
E.PUE	Disabled	
E.RET	Output shutoff	
E.PE2	Output shutoff	
E.CPU	Retry	
E.CTE	Disabled	
E.P24	Disabled	
E.CDO	Retry	

Protective Operation during

Protective	Operation during	
function	emergency drive	
E.IOH	Output shutoff	
E.SER	Disabled	
E.AIE	Disabled	
E.USB	Disabled	
E.SAF	Retry*1	
E.PBT	Retry*1	
E.OS	Disabled	
E.LCI	Disabled	
E.PCH	Disabled	
E.PID	Disabled	
E.1	Retry	
E.2	Retry	
E.3	Retry	
E.5	Retry	
E.6	Retry*1	
E.7	Retry*1	
E.13	Retry*1	

- \*1 While the switchover to the commercial power supply operation during emergency drive operation is enabled, when the same protective function is activated twice consecutively, the retry is attempted up to twice.
- The fault output during emergency drive operation is as follows.

	Pr.190 to Pr.196 setting			
Signal Positive Negative Description logic		Description		
ALM	99	199	Turns ON at the occurrence of a fault that causes the above-mentioned "retry" or "output shutoff" during emergency drive operation.	
ALM3	66	166	Output when a fault occurs during emergency drive operation.  During emergency drive operation, if a fault that does not activate any protective function occurs, the signal turns ON for 3 s and then turns OFF.	

GROUP **H** 

#### **♦Input signal operation**

- During emergency drive operation in the fixed frequency mode or in the PID control mode, input signals unrelated to the emergency drive become invalid with some exceptions.
- The table below shows functions of the signals that do not become invalid during emergency drive operation in the fixed frequency mode or in the PID control mode.

Input signal status	Fixed frequency mode	PID control mode
Valid	OH, TRG, TRC, X51, RES, X70, X71	OH, TRG, TRC, X51, RES, X70, X71
Held	RT, X18, SQ, X84	RT, X18, SQ, X64, X65, X66, X67, X79, X84
Always-ON	_	X14, X77, X78, X80

#### Emergency drive status monitor

- Set "68" in Pr.52, Pr.774 to Pr.776, Pr.992 to monitor the status of the emergency drive on the operation panel.
- · Description of the status monitor

Operation		Descri	ption	
panel indication	Emergency drive setting	Emergency drive operating status		
0	Emergency drive function setting is not available.	_		
1		During normal operation		
2			Operating properly	
3	Electronic bypass during		A certain alarm is occurring.	
4	emergency drive operation is disabled.	During emergency drive operation	A critical fault is occurring. The operation is being continued by the retry.	
5			A critical fault is occurring. The continuous operation is not allowed due to output shutoff.	
11		During normal operation		
12			Operating properly	
13			A certain alarm is occurring.	
14	Electronic bypass during	During emergency drive operation	A critical fault is occurring. The operation is being continued by the retry.	
15	emergency drive operation is enabled.		A critical fault is occurring. The continuous operation is not allowed due to output shutoff.	
2[]*1		Electronic bypass is started during emergency drive (during acceleration/deceleration to the switchover frequency).		
3[]*1		During electronic bypass du	uring emergency drive (waiting during the interlock time).	
4[]*1		During commercial power supply operation during emergency drive		

\*1 The first digit remains the same as the previous numerical value (fault condition).

#### • NOTE

- When the "retry" (**Pr.523** = "2[][], 3[][]") is selected, it is recommended to use the automatic restart after instantaneous power failure function at the same time.
- · Parameter setting is not available during emergency drive operation.
- To return to the normal operation during emergency drive operation, do the following.

(The operation will not be returned to normal only by turning OFF the X84 signal.)

- Reset the inverter, or turn the power supply OFF.
- Clear a fault by turning ON the X51 signal while the sequence function is enabled (when the protective function is activated).
- The operation is switched over to the commercial power supply operation in case of the following during emergency drive operation.
  - 24 V external power supply operation, power failure status or operation with the power supplied through R1/S1, undervoltage
- While the electronic bypass sequence is set or when the operation is performed with the power supplied through R1/S1, when **Pr.30** = "2", the emergency drive function is disabled.

#### **⚠** Caution

• When the emergency drive operation is performed, the operation is continued or the retry is repeated even when a fault occurs, which may damage or burn the inverter and motor. Before restarting the normal operation after using this function, make sure that the inverter and motor have no fault. Any damage of the inverter or the motor caused by using the emergency drive function is not covered by the warranty even within the free guarantee period.

#### 5.7.9 Limiting the output frequency (maximum/ minimum frequency)


Motor speed can be limited. Clamp the output frequency at the upper and lower limits.

Pr.	Name	Initial value	Setting range	Description	
1	Maximum frequency	120 Hz*1	0 to 120 Hz	Set the upper limit of the output frequency.	
H400	waxiiiuiii irequency	60 Hz*2	0 10 120 112	Set the upper limit of the output frequency.	
2 H401	Minimum frequency	0 Hz	0 to 120 Hz	Set the lower limit of the output frequency.	
18	High speed maximum frequency	120 Hz*1	0 to 590 Hz	Set when operating at 120 Hz or higher.	
H402	I mgm speed maximum frequency	60 Hz*2	0 10 390 112		

- For the FR-F820-02330(55K)or lower and FR-F840-01160(55K) or lower.
- \*2 For the FR-F820-03160(75K)or higher and FR-F840-01800(75K) or higher.

#### ◆Setting the maximum frequency (Pr.1, Pr.18)

- Set Pr.1 Maximum frequency to the upper limit of the output frequency. If the value of the frequency command entered is higher than the setting, the output frequency is clamped at the maximum frequency.
- To operate at a frequency higher than the 120 Hz, adjust the upper output frequency limit with Pr.18 High speed maximum frequency. (When setting a frequency in Pr.18, the Pr.1 setting automatically changes to the frequency set in Pr.18. Also, when setting a frequency in Pr.1, the Pr.18 setting automatically changes to the frequency set in Pr.1.)



#### ◆ Setting the minimum frequency (Pr.2)

- · Set Pr.2 Minimum frequency to the lower limit of the output frequency.
- If the set frequency is Pr.2 or less, the output frequency is clamped at Pr.2 (will not fall below Pr.2).

#### NOTE:

- To operate with a frequency higher than 60 Hz using frequency-setting analog signals, change the Pr.125 (Pr.126) (frequency setting gain) setting. Simply changing the Pr.1 and Pr.18 settings does not enable operation at a frequency higher than 60 Hz.
- During PM motor control, the upper and lower limits are for the commanded frequency.
- When Pr.15 Jog frequency setting is equal to or less than Pr.2 setting, the Pr.15 setting has precedence over the Pr.2
- If a jump frequency that exceeds Pr.1(Pr.18) Maximum frequency is set for the 3-point frequency jump, the maximum frequency setting is the set frequency. If the set frequency is less than the jump frequency Pr.2 Minimum frequency, the jump frequency is the set frequency. (The set frequency can be equal to or lower than the frequency lower limit.) When stall prevention is activated to decrease the output frequency, the output frequency may drop to Pr.2 or below.



#### Caution

Note that when Pr.2 is set to any value equal to or higher than Pr.13 Starting frequency, simply turning ON the start signal will run the motor at the frequency set in Pr.2 even if the command frequency is not input.

#### # Parameters referred to

Pr.13 Starting frequency page 197, page 198

Pr.15 Jog frequency page 221

Pr.125 Terminal 2 frequency setting gain frequency, Pr.126 Terminal 4 frequency setting gain frequency page 314

GROUP н


#### 5.7.10 **Avoiding the mechanical resonance points** (frequency jump)

When it is desired to avoid resonance attributable to the natural frequency of a mechanical system, these parameters allow resonant frequencies to be jumped.


Pr.	Name	Initial value	Setting range	Description			
31 H420	Frequency jump 1A						
32 H421	Frequency jump 1B		0 to 590 Hz, 9999				
33 H422	Frequency jump 2A	9999		1A to 1B, 2A to 2B, 3A to 3B are frequency jumps.			
34 H423	Frequency jump 2B			(3-point jump) 9999: Function disabled			
35 H424	Frequency jump 3A						
36 H425	Frequency jump 3B						
552	Frequency jump range	9999	0 to3 (0 Hz)	Set the jump range for the frequency jumps (6-point jump).			
H429	29		9999	3-point jump			

#### ◆3-point frequency jump (Pr.31 to Pr.36)


- Up to three areas may be set, with the jump frequencies set to either the top or bottom point of each area.
- The settings of frequency jumps 1A, 2A, 3A are jump points, and operation is performed at these frequencies in the jump areas.



• [Example 1] To fix the frequency to 30 Hz in the range of 30 Hz to 35 Hz, set 35 Hz in Pr.34 and 30 Hz in Pr.33.




• [Example 2] To jump the frequency to 35 Hz in the range of 30 Hz to 35 Hz, set 35 Hz in Pr.33 and 30 Hz in Pr.34.




#### ♦6-point frequency jump (Pr.552)

- A total of six jump areas can be set by setting the common jump range for the frequencies set in Pr.31 to Pr.36.
- · When frequency jump ranges overlap, the lower limit of the lower jump range and the upper limit of the upper jump range are used.
- When the set frequency decreases and falls within the jump range, the upper limit of the jump range is the set frequency. When the set frequency increases and falls within the jump range, the lower limit of the jump range is the set frequency.



#### NOTE:

- · During acceleration/deceleration, the running frequency within the set area is valid.
- If the setting ranges of individual groups (1A and 1B, 2A and 2B, 3A and 3B) overlap, write disable error (Er1) will occur.
- Setting **Pr.552** = "0" disables frequency jumps.
- If a jump frequency that exceeds Pr.1(Pr.18) Maximum frequency is set for the 3-point jump, the maximum frequency setting is the set frequency. If the set frequency is less than the jump frequency Pr.2 Minimum frequency, the jump frequency is the set frequency. (The set frequency can be equal to or lower than the frequency lower limit.) Example with 6-point frequency jump



#### Parameters referred to

Pr.1 Maximum frequency, Pr.18 High speed maximum frequency, Pr.2 Minimum frequency page 245

#### 5.7.11 **Stall prevention operation**


This function monitors the output current and automatically changes the output frequency to prevent the inverter from tripping due to overcurrent, overvoltage, etc. It can also limit the stall prevention and fast-response current limit operation during acceleration/deceleration and power/regenerative driving.

- · Stall prevention
  - If the output current exceeds the stall prevention operation level, the output frequency of the inverter is automatically changed to reduce the output current.
  - Also the second stall prevention function can limit the output frequency range in which the stall prevention function is enabled.
- · Fast-response current limit
  - If the current exceeds the limit value, the output of the inverter is shut off to prevent an overcurrent.

Pr.	Name	Initial	value	Setting	Description		
FI.	Name	FM	CA	range		•	
22	Stall prevention operation			0	Stall prevention operation		
H500	level	120%	110%	0.1 to 400% *1	Set the current limit at v will start.	which the stall prevention operation	
156 H501	Stall prevention operation selection	0		0 to 31, 100 to 101	Enable/disable the stall prevention operation and the fast-response current limit operation.		
48				0	Second stall prevention operation disabled.  The stall prevention operation level can be changed using the RT signal.		
H600  Magnetic flux	Second stall prevention operation level	120%	110%	0.1 to 400% *1			
49				0	Second stall prevention		
H601	Second stall prevention operation frequency	0 Hz		0.01 to 590 Hz	operation will start.	ich the Pr.48 stall prevention	
<b>Magnetic flux</b>				9999	Pr.48 is enabled when	RT signal is ON.	
23 H610	Stall prevention operation level compensation	0000		0 to 200%	The stall operation leve above the rated frequer	I when running at high speeds ncy can be reduced.	
Magnetic flux	factor at double speed	9999		9999	Stall prevention operation	on disabled at double speed.	
66 H611 Magneticiflux	Stall prevention operation reduction starting frequency	60 Hz	50 Hz	0 to 590 Hz	Set the frequency at which the stall operation level reduction will start.		
148 H620 Magnetic flux	Stall prevention level at 0 V input	120%	110%	0 to 400% *1	The stall prevention ope	eration level can be changed by the	
149 H621 Magnetic flux	Stall prevention level at 10 V input	150%	120%	0 to 400% *1	analog signal input to the terminal 1 (terminal 4).		
				0	Output voltage reduction enabled.	Enable/disable the output voltage reduction during stall prevention	
154 H631	Voltage reduction			1	Output voltage reduction disabled.	operation.	
Magneticiflux	selection during stall prevention	1		10	Output voltage reduction enabled.	Use this setting when the overvoltage protective function	
				11	Output voltage reduction disabled.	(E.OV[]) activates during stall prevention operation in an application with large load inertia.	
157 M430	OL signal output timer	0 s		0 to 25 s	Set the OL signal output start time when stall prevention activated.		
	Tomobial A.C. (C)			9999	No OL signal output.		
858 T040	Terminal 4 function assignment	0		0, 4, 9999	When set "4", the stall prevention level can be changed with the signal to the terminal 4.  When set "4", the stall prevention level can be changed with the signal to the terminal 1.  A trip can be set for when the stall prevention is activated and the motor stalls. Set the output at which to activate the trip.		
868 T010	Terminal 1 function assignment	0		0, 4, 9999			
874 H730	OLT level setting	120%	110%	0 to 400%			

<sup>\*1</sup> The upper limit of stall prevention operation is limited internally to the following. 120% (SLD rating), 150% (LD rating)

#### ◆ Setting the stall prevention operation level (Pr.22)



- For Pr.22 Stall prevention operation level, set the ratio of the output current to the inverter's rated current at which the stall prevention operation will be activated. Normally, use this parameter in the initial setting.
- · Stall prevention operation stops acceleration (makes deceleration) during acceleration, makes deceleration during constant speed, and stops deceleration during deceleration.
- · When the stall prevention operation is performed, the Overload warning (OL) signal is output.

#### • NOTE

- · A continuous overloaded condition may activate a protective function such as motor overload trip (electronic thermal O/L relay function) (E.THM).
- When Pr.156 has been set to activate the fast response current limit (initial value), the Pr.22 setting should not be higher than 140%. Such setting will prevent torque generation
- · Under PM motor control, the stall prevention operation level is reduced inversely proportional to the output frequency in the constant output range of the rated motor frequency or higher.

# ◆Disabling the stall prevention operation and fast-response current limit according to operating conditions (Pr.156)

• Referring to the table below, enable/disable the stall prevention operation and the fast-response current limit operation, and also set the operation at OL signal output.

Pr.1 setti		Fast response current limit O: enabled •: disabled	opera	Constant speed consta	ection ed	OL signal output O: operation continued •: operation stopped*1
0 (initial v	alue)	0	0	0	0	0
1		•	0	0	0	0
2		0	•	0	0	0
3		•	•	0	0	0
4		0	0	•	0	0
5		•	0	•	0	0
6		0	•	•	0	0
7		•	•	•	0	0
8		0	0	0	•	0
9		•	0	0	•	0
10		0	•	0	•	0
11		•	•	0	•	0
12		0	0	•	•	0
13		•	0	•	•	0
14		0	•	•	•	0
15		•	•	•	•	<del>*</del> 2
	Power driving	0	0	0	0	0
100 *3	Regenerative driving Power driving	•	•	•	•	<b>*</b> 2

Pr.156 setting		Fast response current limit O: enabled •: disabled	opera	Constant speed disable	ection ed	OL signal output O: operation continued O: operation stopped*1
16		0	0	0	0	•
17		•	0	0	0	•
18		0	•	0	0	•
19		•	•	0	0	•
20		0	0	•	0	•
21		•	0	•	0	•
22		0	•	•	0	•
23		•	•	•	0	•
24		0	0	0	•	•
25		•	0	0	•	•
26		0	•	0	•	•
27		•	•	0	•	•
28		0	0	•	•	•
29		•	0	•	•	•
30		0	•	•	•	•
31		•	•	•	•	<b></b> *2
	Power driving	•	0	0	0	0
101	Regenerative driving	•	•	•	•	<b></b> *2

- \*2 The OL signal and E.OLT are not outputted because fast-response current limit and stall prevention are not operating.
- \*3 Setting values "100, 101" can be individually set for power driving and regenerative driving. The setting value "101" disables the fast-response current limit during power driving.


#### • NOTE

- When the load is heavy or the acceleration/deceleration time is short, stall prevention operates and acceleration/deceleration
  may not be performed according to the time set. In such case, set the Pr.156 and the stall prevention operation level to the
  optimum values.
- For lift applications, make settings to disable the fast-response current limit. Otherwise, the torque may be insufficient, causing the load to drop.

#### Adjusting the stall prevention operation signal output and output timing (OL signal, Pr.157)

- If the output current exceeds the stall prevention operation level and stall prevention is activated, Overload warning (OL) signal will turn ON for 100 ms or more. The output signal turns OFF when the output current falls to the stall prevention operation level or less.
- Pr.157 OL signal output timer can set whether to output the OL signal immediately, or to output it after a certain time period.
- This function also operates during regeneration avoidance operation  $\Box L$  (overvoltage stall).


Pr.157 setting	Description
0 (initial value)	Output immediately.
0.1 to 25	Output after the set time (s).
9999	Not output.




#### NOTE:

- · OL signal is assigned to the terminal OL in the initial status. The OL signal can be assigned to other terminals by setting "3 (positive logic) or 103 (negative logic)" in any of Pr.190 to Pr.196 (output terminal function selection).
- If the stall prevention operation has lowered the output frequency to 0.5 Hz and kept the level for 3 s, the stall prevention stop (E.OLT) is activated to shut off the inverter output.
- · Changing the terminal assignment using Pr.190 to Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### Setting for stall prevention operation in the high-frequency range (Pr.22, Pr.23. Pr.66) Magnetic flux





- · When operating at the rated motor frequency or higher, acceleration may not be made because the motor current does not increase. Also, when operating in the high-frequency range, the current flowing to the locked motor becomes less than the rated output current of the inverter; and even if the motor is stopped, the protective function will not operate (OL). In a case like this, the stall prevention level can be reduced in the high-frequency range to improve the motor's operating characteristics. This is useful when operating up to the high speed range, such as when using a centrifuge. Normally, set Pr.66 Stall prevention operation reduction starting frequency to 60 Hz, and Pr.23 Stall prevention operation level compensation factor at double speed to 100%.
- Calculation formula for stall prevention operation level

= A + B  $\times \left[ \frac{\text{Pr.22 -A}}{\text{Pr.22 -B}} \right] \times \left[ \frac{\text{Pr.23 -100}}{100} \right]$ Stall prevention operation level (%) in the high-frequency range

Where, A = 
$$\frac{\text{Pr.66 (Hz)} \times \text{Pr.22(\%)}}{\text{Output frequency (Hz)}}$$
, B =  $\frac{\text{Pr.66 (Hz)} \times \text{Pr.22(\%)}}{400 \text{ Hz}}$ 

• When Pr.23 ="9999" (initial value), the stall prevention operation level is constant at the Pr.22 level up to 590 Hz.


#### ◆Setting multiple stall prevention operation levels (Pr.48, Pr.49)



- By setting Pr.49 Second stall prevention operation frequency = "9999" and turning ON the RT signal, Pr.48 Second stall prevention operation level will be enabled.
- For Pr.48, set the stall prevention operation level that is effective in the output frequency range between 0 Hz and Pr.49. However, the operation level is Pr.22 during acceleration.
- Stop-on-contact operation can be used by decreasing the Pr.48 setting and loosening the reduction torque (torque when stopped).

Pr.49 setting	Operation
0 (initial value)	The second stall prevention function disabled.
0.01 Hz to 590 Hz	The second stall prevention function operates according to the frequency.*1
9999*2	The second stall prevention function operates according to the RT signal. RT signal ON: stall level <b>Pr.48</b> RT signal OFF: stall level <b>Pr.22</b>


- For the stall prevention operation level, the smaller of Pr.22 and Pr.48 has precedence.
- When Pr.858 = "4 (analog input to terminal 4 for stall prevention operation level)" or Pr.868 = "4 (analog input to terminal 1 for stall prevention operation level)", turning ON the RT signal will not enable the second stall prevention function. (Input to the terminal 4 or terminal 1 is valid.)



#### NOTE:

- When Pr.49 ≠ "9999" (level change according to frequency) and Pr.48 = "0%", the stall prevention function will be disabled at or lower than the frequency set in Pr.49.
- The RT signal is assigned to the terminal RT in the initial status. Set "3" in any of Pr.178 to Pr.189 (input terminal function selection) to assign the RT signal to another terminal.
- · Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.
- The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 333.)

- To use the terminal 1 (analog voltage input) to set the stall prevention operation level, set Pr.868 Terminal 1 function assignment = "4". Then, input a 0 to 5 V (or 0 to 10 V) to the terminal 1. To choose whether 5 V or 10 V, use Pr.73 Analog input selection. In the initial status, Pr.73 = "1 (initial value)" is set to choose 0 to ±10 V input.
- When setting the stall prevention operation level from terminal 4 (analog current input), set Pr.858 Terminal 4 function assignment = "4".
- Input 0 to 20 mA into terminal 4. There is no need to turn ON the AU signal.
- Set Pr.148 Stall prevention level at 0 V input to the current limit level when input voltage is 0 V (0 mA).
- Set Pr.149 Stall prevention level at 10 V input to the current limit level when input voltage is 10 V/5 V (20 mA).



Pr.858 setting	Pr.868 setting	V/F, Advanced magnetic flux vector control				
P1.000 Setting	F1.000 Setting	Terminal 4 function	Terminal 1 function			
0	0 (initial value)	Farmer (All sizes ON)	Auxiliary frequency			
(initial value)	4 *1	Frequency command (AU signal-ON)	Stall prevention			
	9999		_			
4.0	0 (initial value)	Stall prevention	Auxiliary frequency			
4*2	4 *1	<b></b> *3	Stall prevention			
	9999	Stall prevention	_			
9999	_	_	_			

- \*1 When Pr.868 = "4" (analog stall prevention), the other functions for terminal 1 (auxiliary input, override function, PID control) will be disabled.
- \*2 When Pr.858 = "4" (analog stall prevention), PID control and speed commands using terminal 4 will not operate, even if the AU signal turns ON.
- \*3 When both of Pr.858 and Pr.868 are set to "4" (stall prevention), terminal 1 functions take priority and terminal 4 has no function.

#### • NOTE

- · The fast-response current limit cannot be set.
- To change the stall prevention operation level with the analog signal under PM motor control, set C16 to C19 or C38 to C41 to calibrate terminal 1 or terminal 4. (Refer to page 320.)


#### ◆To further prevent a trip (Pr.154) Magnetic flux

- When Pr.154 Voltage reduction selection during stall prevention operation = "0, 10", the output voltage is reduced. By making this setting, an overcurrent trip becomes less likely to occur. Use this setting when torque reduction does not pose a problem. (Under V/F control, the output voltage is reduced only during the stall prevention operation is activated.)
- Set Pr.154 = "10, 11" when the overvoltage protective function (E.OV[]) activates during stall prevention operation in an application with large load inertia. Note that turning OFF the start signal (STF/STR) or varying the frequency command during stall prevention operation may delay the acceleration/deceleration start.

Pr.154	E.OC[] countermeasure	E.OV[] countermeasure
0	Effective	_
1 (initial value)	_	_
10	Effective	Effective
11	_	Effective

#### ◆Trip during stall prevention operation (Pr.874)

- The inverter can be set to trip at activation of stall prevention and stalling of the motor.
- · When a high load is applied and the stall prevention is activated, the motor stalls. At this time, if the rotation speed is lower than 1.5 Hz and the output torque exceeds the level set in Pr.874 OLT level setting and such a state continues for 3 s, stall prevention stop (E.OLT) is activated and the inverter output is shut off.



#### NOTE

Under V/F control or Advanced magnetic flux vector control, if the output frequency drops to 0.5 Hz due to the stall prevention operation and this state continues for 3 s, a fault indication (E.OLT) appears, and the inverter output is shut off. This operation is activated regardless of the Pr.874 setting.

## Caution

- Do not set the stall prevention operation current too low. Doing so will reduce the generated torque.
- Be sure to perform a test run. Stall prevention operation during acceleration may extend the acceleration time. Stall prevention operation during constant-speed operation may cause sudden speed changes. Stall prevention operation during deceleration may extend the deceleration time.

#### # Parameters referred to

Pr.73 Analog input selection page 306

Pr.178 to Pr.189 (Input terminal function selection) page 329

Pr.190 to Pr.196 (output terminal function selection) page 288

Pr.858 Terminal 4 function assignment, Pr.868 Terminal 1 function assignment page 310


#### 5.7.12 Load characteristics fault detection

This function is used to monitor whether the load is operating in normal condition by storing the speed/torque relationship in the inverter to detect mechanical faults or for maintenance. When the load operating condition is deviated from the normal range, the protective function is activated or the warning is output to protect the inverter or the motor.

Pr.	Name	Initial	value	Setting	Description		
Pr.	Name	FM	CA	range	Description		
				0	Load characteristics measurement is normally completed.		
1480	Load characteristics	0		1	Load characteristics measurement mode is started.		
H520	measurement mode			2, 3, 4, 5, 81, 82, 83, 84, 85	The load characteristics measurement status is displayed. (Read-only)		
1481 H521	Load characteristics load reference 1	9999					
1482 H522	Load characteristics load reference 2	9999					
1483 H523	Load characteristics load reference 3	9999		0 to 400%	Set the reference value of normal load characteristics.  8888: The present load status is written as reference status.  9999: The load reference is invalid.		
1484 H524	Load characteristics load reference 4	9999	_				
1485 H525	Load characteristics load reference 5	9999					
1486 H526	Load characteristics maximum frequency	60 Hz	50 Hz	Hz 0 to 590 Hz Set the maximum frequency of the load characteri detection range.			
1487 H527	Load characteristics minimum frequency	6 Hz		0 to 590 Hz	Set the minimum frequency of the load characteristics fault detection range.		
1488 H530	Upper limit warning detection width	20%		0 to 400%	Set the detection width when the upper limit warning is output for load faults.		
пээи	detection width			9999	Function disabled		
1489 H531	Lower limit warning detection width			0 to 400%	Set the detection width when the lower limit warning is output for load faults.		
ПООТ	detection width			9999	Function disabled		
1490 H532	Upper limit fault	9999		0 to 400%	Set the detection width when output is shut off when the upper limit load fault occurs.		
пээг	detection width			9999	Function disabled		
1491 H533	Lower limit fault detection width	9999		0 to 400%	Set the detection width when output is shut off when the lower limit load fault occurs.		
11000	detection width			9999	Function disabled		
1492 H534	Load status detection signal delay time / load reference measurement waiting time	1 s		0 to 60 s	Set the waiting time after the load fault is detected until warning output or output shutoff.  In the load characteristics measurement mode, set the waiting time after the load measurement frequency is reached until the load reference is set.		

#### ◆Load characteristics setting (Pr.1481 to Pr.1487)

- Use Pr.1481 to Pr.1485 to set the reference value of load characteristics.
- Use **Pr.1486 Load characteristics maximum frequency** and **Pr.1487 Load characteristics minimum frequency** to set the output frequency range for load fault detection.



## ◆Automatic measurement of the load characteristics reference (Load characteristics measurement mode) (Pr.1480)




- · Perform measurement under actual environment with the motor connected.
- Set the Pr.1487 Load characteristics minimum frequency higher than the Pr.13 Starting frequency.
- Setting **Pr.1480 Load characteristics measurement mode** = "1" enables automatic measurement of the load characteristics reference. (Load characteristics measurement mode)
- Use **Pr.1486** and **Pr.1487** to set the frequency band for the measurement, and set **Pr.1480** = "1". When the inverter is started after the setting, the measurement is started.
- The automatically measured load characteristics reference is written in Pr.1481 to Pr.1485.
- After the measurement is started, read Pr.1480 to display the status of the measurement. If "8" appears in the tens place, the measurement has not properly completed.

Read value of Pr.1480		Status				
Tens place	Ones place	Status				
_	1	During measurement from the starting point to Point 1				
_	2	During measurement from Point 1 to Point 2				
_	3	During measurement from Point 2 to Point 3				
_	4	During measurement from Point 3 to Point 4				
_	5	During measurement from Point 4 to Point 5				
_	0	Normal completion				
8	1 to 5	Termination of measurement by an activation of a protective function, inverter reset, turning ON of MRS signal, turning OFF of the start command, or timeout. (The value in the ones place represents the above-mentioned measurement point.)				

- During automatic measurement, During load characteristics measurement signal (Y213) is output. For the Y213 signal, assign the function by setting "213 (forward action)" or "313 (reverse action)" in any of **Pr.190 to Pr.196 (output terminal function selection)**.
- Setting "8888" in **Pr.1481 to Pr.1485** enables fine adjustment of load characteristics. When setting **Pr.1481 to Pr.1485** = "8888" during operation, the load status at that point is set in the parameter. (Only when the set frequency is within  $\pm 2$  Hz of the frequency of the measurement point, and SU signal is in the ON state)






#### NOTE

- · Even if the load measurement is not properly completed, the load characteristics fault is detected based on the load characteristics found by the already-completed portion of the measurement.
- · During the load characteristics measurement, the load characteristics fault detection is not performed.
- · During the load characteristics measurement, linear acceleration/deceleration is performed even if the S-pattern acceleration/ deceleration is set.
- · Changing the terminal assignment using Pr.190 to Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### **◆Load fault detection setting (Pr.1488 to Pr.1491)**

- · When the load is deviated from the detection width set in Pr.1488 Upper limit warning detection width, Upper limit warning detection signal (LUP) is output. When the load is deviated from the detection width set in Pr.1489 Lower limit warning detection width, Lower limit warning detection signal (LDN) is output. At the same time, Load fault warning (LDF) appears on the operation panel.
- For the LUP signal, assign the function by setting "211 (forward action)" or "311 (reverse action)" in any of Pr.190 to Pr.196 (output terminal function selection). For the LDN signal, assign the function by setting "212 (forward action)" or "312 (reverse action)" in any of Pr.190 to Pr.196 (output terminal function selection).
- When the load is deviated from the detection width set in Pr.1490 Upper limit fault detection width, the protective function (E.LUP) is activated and the inverter output is shut off. When the load is deviated from the detection width set in Pr.1491 Lower limit fault detection width, the protective function (E.LDN) is activated and the inverter output is shut off.
- · To prevent the repetitive on/off operation of the signal due to load fluctuation near the detection range, Pr.1492 Load status detection signal delay time / load reference measurement waiting time can be used to set the delay time. Even when a fault is detected out of the detection range once, the warning is not output if the characteristics value returns to the normal range from a fault state within the output delay time.



GROUF **H** 




· Changing the terminal assignment using Pr.190 to Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### **♦** Setting example

- The load characteristics are calculated from the parameter setting and the output frequency.
- A setting example is shown below. The reference value is linearly interpolated from the parameter settings. For example, the reference when the output frequency is 30 Hz is 26%, which is linearly interpolated from values of the reference 2 and the reference 3.

Reference	Frequency	Load reference
Load characteristics reference 1	f1: load characteristics minimum frequency ( <b>Pr.1487</b> ) = 10 Hz	<b>Pr.1481</b> = 15%
Load characteristics reference 2	f2 = (f5 - f1)/4 + f1 = 22.5 Hz	<b>Pr.1482</b> = 20%
Load characteristics reference 3	f3 = (f5 - f1)/2 + f1 = 35 Hz	<b>Pr.1483</b> = 30%
Load characteristics reference 4	$f4 = (f5 - f1) \times 3/4 + f1 = 47.5 Hz$	<b>Pr.1484</b> = 60%
Load characteristics reference 5	f5: load characteristics maximum frequency ( <b>Pr.1486</b> ) = 60 Hz	<b>Pr.1485</b> = 100%



When the load reference is not set for five points, the load characteristics value is determined by linear interpolation of the set load reference values only. If there is only one load reference setting, the set load reference is used as the load reference all through the range.

#### Parameters referred to >>>

Pr.41 Up-to-frequency sensitivity page 294


Pr.190 to Pr.196 (output terminal function selection) page 288

#### 5.7.13 **Motor overspeeding detection**

The Overspeed occurrence (E.OS) is activated when the motor speed exceeds the overspeed detection level. This function prevents the motor from accidentally speeding over the specified value, due to an error in parameter setting,

Pr.	Name	Initial value	Setting range	Description
374	Overspeed detection	0 to 590 Hz		If the motor rotation speed exceeds the speed set in <b>Pr.374</b> during PM motor control, Overspeed occurrence (E.OS) occurs, and the inverter output is shut off.
H800	level		9999	During PM motor control, E.OS occurs when the speed exceeds the "maximum motor frequency + 10 Hz".*I

<sup>\*1</sup> The maximum motor frequency is set in Pr.702 Maximum motor frequency. When Pr.702 = "9999 (initial value)", the Pr.84 Rated motor frequency setting is applied as the maximum motor frequency.



# **5.8** (M) Monitor display and monitor output signal

Purpose	Pa	arameter to set		Refer to page
To display the motor speed. To set to rotations per minute.	Speed display and rotations per minute setting	P.M000 to P.M002	Pr.37, Pr.144, Pr.505	261
To change the monitored item on the operation panel and the parameter unit	Operation panel monitored item selection, clearing the cumulative monitor	P.M020 to P.M023, P.M030, P.M031, P.M044, P.M050 to P.M052, P.M100 to P.M104	Pr.52, Pr.170, Pr.171, Pr.268, Pr.290, Pr.563, Pr.564, Pr.774 to Pr.776, Pr.891, Pr.992 Pr.1106 to Pr.1108	263
To change the monitored item output from the terminal FM(CA) and AM	Terminal FM(CA) function selection	P.M040 to P.M042, P.M044, P.M300, P.M301, P.D100	Pr.54, Pr.55, Pr.56, Pr.158, Pr.290, Pr.291, Pr.866	273
To adjusting the terminal FM, terminal CA, and AM output	Terminal FM(CA), AM calibration	P.M310, P.M320, P.M321, P.M330 to P.M334	Pr.867, Pr.869, C0(Pr.900), C1(Pr.901), C8(Pr.930) to C11(Pr.931)	279
To check the effects of energy saving	Energy saving monitor	P.M023, P.M100, P.M200 to P.M207, P.M300, P.M301	Pr.52, Pr.54, Pr.158, Pr.891 to Pr.899	283
To assign functions to the output terminals	Output terminal function assignment	P.M400 to P.M406, P.M431	Pr.190 to Pr.196, Pr.289	288
To detect the output frequency	Up-to-frequency sensitivity Output frequency detection Low speed detection	P.M440 to P.M444	Pr.41 to Pr.43, Pr.50, Pr.870	294
To detect the output current	Output current detection Zero current detection	P.M460 to P.M464	Pr.150 to Pr.153, Pr.166, Pr.167	296
To detecting the output torque	Output torque detection	P.M470	Pr.864	298
To use the remote output function	Remote output	P.M500 to P.M502	Pr.495 to Pr.497	298
To use the analog remote output function	Analog remote output	P.M530 to P.M534	Pr.655 to Pr.659	300
To output the fault code from a terminal	Fault code output function	P.M510	Pr.76	302
To detect the specified output power	Pulse train output of output power	P.M520	Pr.799	303
To detect the control circuit temperature	Control circuit temperature monitor	P.M060	Pr.663	304

### 5.8.1 Speed display and rotations per minute setting

The monitor display unit and the frequency setting on the operation panel can be switched to motor speed and machine speed.

Pr.	Name	Initial value		Setting range	Description				
FI.	Name	FM	CA	Setting range	Description				
37	Speed display	0		0	Frequency display and setting				
M000	Speed display	0		1 to 9998*1	Set the machine speed for <b>Pr.505</b> .				
505 M001	Speed setting reference	60 Hz	50 Hz	1 to 590 Hz	Set the reference speed for <b>Pr.37</b> .				
144 M002	Speed setting switchover	4		0, 2, 4, 6, 8, 10, 12, 102, 104, 106, 108, 110, 112	Set the number of motor poles when displaying the motor speed.				

<sup>\*1</sup> The maximum value of the setting range differs according to the **Pr.1 Maximum frequency**, **Pr.505 Speed setting reference**, and it can be calculated from the following formula.

#### **♦** Display in speed (Pr.37, Pr.144)

- Set the number of motor poles (2, 4, 6, 8, 10, 12) for **Pr.144**, or the number of motor poles + 100 (102, 104, 106, 108, 110, 112) to display the motor speed.
- The **Pr.144** setting will change automatically when setting the motor poles with **Pr.81 Number of motor poles**. **Pr.81** will not automatically change when **Pr.144** is changed.
  - Example 1) Changing the initial value of Pr.81 to "2" will change Pr.144 from "4" to "2".
  - Example 2) When setting Pr.81 = "2" while Pr.144 = "104", Pr.144 will change from "104" to "102".

#### ◆Display in motor speed (Pr.37, Pr.505)

- To display in the machine speed, set Pr.37 to the machine speed at the frequency set in Pr.505.
- For example, when **Pr.505** = "60 Hz" and **Pr.37** = "1000", the running speed monitor will display "1000" at the running speed of 60 Hz.When running frequency is 30 Hz, "500" is displayed.

The maximum value of  $Pr.37 < 65535 \times Pr.505$  / Pr.1 setting value (Hz).

The maximum setting value of Pr.37 is 9998 if the result of the above formula exceeds 9998.

#### Monitor display (setting) increments

• When both Pr.37 and Pr.144 have been set, their priorities are as given below.

Pr.144 = 102 to 112 > Pr.37 = 1 to 9998 > Pr.144 = 2 to 12

• The combination of the Pr.37 and Pr.144 settings as shown below determines the setting increment for each monitor. (The initial values are shown within the thick lines.)

Pr.37 Setting	Pr.144 Setting	Output frequency monitor	Set frequency monitor	Running speed monitor	Frequency setting parameter setting
0	0	0.01 Hz	0.01 Hz	1 r/min*1	0.01 Hz
(initial	2 to 12	0.01 Hz	0.01 Hz	1 r/min*1	0.01 Hz
value)	102 to 112	1 r/min*1	1 r/min *1	1 r/min∗ı	1 r/min*1
	0	0.01 Hz	0.01 Hz	1 (machine speed*1)	0.01 Hz
1 to 9998	2 to 12	1 (machine speed*1)	1 (machine speed*1)	1 (machine speed*1)	1 (machine speed*1)
	102 to 112	0.01 Hz	0.01 Hz	1 r/min *1	0.01 Hz

Motor speed r/min conversion formula: .... frequency  $\times$  120 / number of motor poles (Pr.144)

Machine speed conversion formula: ....... Pr.37 × frequency / Pr.505

For Pr.144 in the above formula, the value is "Pr.144 - 100" when "102 to 112" is set in Pr.144; and the value is "4" when Pr.37 = 0 and Pr.144

Pr.505 is always set as frequency (Hz).

#### NOTE

- The inverter's output frequency is displayed as synchronous speed under V/F control. The displayed value is "actual motor speed" + "motor slip." When Advanced magnetic flux vector control or PM motor control is selected, the actual motor speed (estimated value by motor slip calculation) is used.
- When Pr.37 = "0" and Pr.144 = "0", the running speed monitor is displayed with the number of motor poles 4. (Displays 1800 r/min at 60 Hz)
- To change the PU main monitor (PU main display), refer to Pr.52.
- When using the machine speed display for the parameter unit (FR-PU07), do not change the speed with the up/down key if a set speed above 65535 is being displayed. The set speed may become an undetermined value.
- · When the FR-A8ND is connected, the frequency display (setting) will be used regardless of the Pr.37, Pr.144 settings.



#### Caution

Make sure to set the running speed and the number of motor poles. Otherwise, the motor might run at extremely high speed, damaging the machine.

#### Parameters referred to

Pr.1 Maximum frequency page 245

Pr.52 Operation panel main monitor selection page 263

Pr.81 Number of motor poles page 143

Pr.800 Control method selection page 143

#### 5.8.2 Monitor indicator selection using operation panel or via communication

The monitored item to be displayed on the operation panel or the parameter unit can be selected.

Pr.	Name	Initial value	Setting range	Description
52 M100	Operation panel main monitor selection	0 (output frequency)	0, 5 to 14, 17, 18, 20, 23 to 25, 34, 38, 40 to 45, 50 to 57, 61, 62, 64, 67, 68, 81 to 96, 98, 100	Select the monitor to be displayed on the operation panel and the parameter unit. Refer to page 264 for the monitor description.
774 M101 775 M102 776 M103	Operation panel monitor selection 1 Operation panel monitor selection 2 Operation panel monitor selection 3	9999	1 to 3, 5 to 14, 17, 18, 20, 23 to 25, 34, 38, 40 to 45, 50 to 57, 61, 62, 64, 67, 68, 81 to 96, 98, 100, 9999	The output frequency, output current and output voltage monitor that are displayed in monitor mode on the operation panel and the parameter unit can be switched to a specified monitor.  9999: Follows the <b>Pr.52</b> setting.
992 M104	Operation panel setting dial push monitor selection	0 (Set frequency)	0 to 3, 5 to 14, 17, 18, 20, 23 to 25, 34, 38, 40 to 45, 50 to 57, 61, 62, 64, 67, 68, 81 to 96, 98, 100	Select the monitor to be displayed when the setting dial on the operation panel is pushed.
170 M020	Watt-hour meter clear	9999	10	Set "0" to clear the watt-hour meter monitor.  Set the maximum value for monitoring via communication. Set it in the range of 0 and 9999 kWh.
			9999	Set the maximum value for monitoring via communication. Set it in the range of 0 and 65535 kWh.
563 M021	Energization time carrying- over times	0	(0 to 65535) (Read-only)	Displays the numbers of times that the cumulative energization time monitor exceeded 65535 h. Read-only.
268 M022	Monitor decimal digits selection	9999	0 1 9999	Displays as integral value.  Displays in 0.1 increments.  No function
891 M023	Cumulative power monitor digit shifted times	9999	0 to 4	Set the number of times to shift the cumulative power monitor digit.  The monitor value is clamped at the maximum value.
	. •		9999	No shift Monitor value is cleared when it exceeds the maximum value.
171 M030	Operation hour meter clear	9999	9999	Set "0" to clear the operation hour monitor.  The read value is always 9999. Nothing
564 M031	Operating time carrying- over times	0	(0 to 65535) (Read-only)	happens when "9999" is set.  Displays the numbers of times that the operating time monitor exceeded 65535 h. Read-only.
290 M044	Monitor negative output selection	0	0 to 7	Set the availability of output with a minus sign for the terminal AM, the operation panel display, or monitoring via communication. (Refer to page 272)
1106 M050	Torque monitor filter	9999	0 to 5 s	The filter time constant is selectable for monitoring of the torque. A larger setting results in slower response.  0.3 s filter
1107 M051	Running speed monitor filter	9999	0 to 5 s	The filter time constant is selectable for monitoring of the running speed. A larger setting results in slower response.
1108 M052	Excitation current monitor filter	9999	0 to 5 s	O.08 s filter     The filter time constant is selectable for monitoring of the motor excitation current.     A larger setting results in slower response.
			9999	0.3 s filter

#### ♦ Monitor description list (Pr.52, Pr.774 to Pr.776, Pr.992)

- Set the monitor to be displayed on the operation panel and the parameter unit in Pr.52, Pr.774 to Pr.776, Pr.992.
- Refer to the following table and set the monitor to be displayed. (The monitor marked —— cannot be selected. **o** in the [Minus (-) display] indicates a display with a minus sign.)

Types of monitor	Unit	Pr.52, Pr.774 to Pr.776, Pr.992	RS-485 communication dedicated monitor (hexadecimal)	Modbus- RTU real time monitor	Minus (-) display	Description
Output frequency/ speed*16	0.01 Hz/1 *15	1/0/100	H01	40201		Displays the inverter output frequency.
Output current *6*8*16	0.01 A/ 0.1 A*5	2/0/100	H02	40202		Displays the inverter output current effective value.
Output voltage*6*16	0.1 V	3/0/100	H03	40203		Displays the inverter output voltage.
Fault display	_	0/100	_	_		Displays 8 past faults individually.
Frequency setting value/speed setting	0.01 Hz/1 *15	5*1	H05	40205		Displays the set frequency
Running speed	1 (r/min)	6*1	H06	40206		Displays the motor speed (by the Pr.37, Pr.144 settings). (Refer to page 261)
Motor torque	0.1%	7*1	H07	40207	o	Displays motor torque as a percentage (0% under V/F control), considering the rated torque as 100%.
Converter output voltage*6	0.1 V	8*1	H08	40208		Displays the DC bus voltage value.
_	_	9	H09	40209		For manufacturer setteing. Do not set.
Electronic thermal O/L relay load factor	0.1%	10*1	НОА	40210		Displays the motor thermal cumulative value, considering the thermal operation level as 100%.
Output current peak value*6	0.01 A/ 0.1 A*5	11*1	НОВ	40211		Saves and displays the output current monitor peak value. (Cleared with each start.)
Converter output voltage peak value*6	0.1 V	12*1	H0C	40212		Saves and displays the DC bus voltage peak value. (Cleared with each start.)
Input power	0.01 kW/ 0.1 kW*5	13*1	HOD	40213		Displays the power at the inverter input side.
Output power*8	0.01 kW/ 0.1 kW*5	14*1	H0E	40214		Displays the power at the inverter output side.
Load meter	0.1%	17	H11	40217		Displays torque current as a percentage, considering <b>Pr.56</b> setting value as 100%.
Motor excitation current*6	0.01 A/ 0.1 A*5	18	H12	40218		Displays the motor excitation current
Cumulative energization time*2	1 h	20	H14	40220		Displays the cumulative energization time since the inverter shipment. Check how many times the monitor value exceeded 65535 h with <b>Pr.563</b> .
Actual operation time*2*3	1 h	23	H17	40223		Displays the cumulative time since the inverter began running. The number of times the monitor value exceeded 65535 h can be checked with Pr.564 This can be cleared with Pr.171. (Refer to page 271)
Motor load factor	0.1%	24	H18	40224		Displays the output current value as a percentage, considering the inverter rated current value as 100%.  Monitor value = output current monitor value / inverter rated current × 100 [%]

			-	RS-485	Modbus-			
Types of monitor	Unit	Pr.5 Pr.774 to Pr.9	Pr.776,	dedicated monitor	RTU real time monitor	Minus (-) display	Description	
				(hexadecimal)			Displays the cumulative energy	
Cumulative power*6	0.01 kWh/ 0.1 kWh *4*5	25		H19	40225		based on the output power monitor. This can be cleared with <b>Pr.170</b> . (Refer to <b>page 271</b> .)	
Motor output	0.01 kW/ 0.1 kW*5	34		H22	40234		Multiplies the output torque at that time with the motor speed, and displays the machine output for the motor shaft end.	
Trace status	1	38		H26	40238		Displays the trace status. (Refer to page 433)	
PLC function user monitor 1		40		H28	40240		Displays the arbitrary monitoring item using the PLC function.	
PLC function user monitor 2	According to the	41		H29	40241		Displays the following special register values.	
PLC function user monitor 3	SD1215 setting	42		H2A	40242		SD1216: Displays in No.40 SD1217: Displays in No.41 SD1218: Displays in No.42 (Refer to the PLC Function Programming Manual.)	
Station number (RS-485 terminals)	1	43		H2B	40243		Displays which station number (0 to 31) can currently be used for communication from the RS-485 terminal block.	
Station number (PU)	1	44		H2C	40244		Displays which station number (0 to 31) can currently be used for communication from the PU connector.	
Station number (CC-Link)	1	45		H2D	40245		Displays which station number (0 to 31) can currently be used for CC-Link communication. Displays "0" when the FR-A8NC is not connected.	
Energy saving effect	Changeab	50		H32	40250		Displays the energy saving effect monitor.	
Cumulative energy saving	le by parameter setting.			Н33	40251		Conversion to power saving, average power saving, price display, and percentage display can be done using parameters. (Refer to page 283.)	
PID set point	0.1%	52		H34	40252		Displays the set point, measured	
PID measured value	0.1%	53		H35	40253		value, and deviation under PID control.	
PID deviation	0.1%	54		H36	40254	0	(Refer to page 389)	
Input terminal status	_	-55*17		H0F*10	40215*10		Displays input terminal ON/OFF state of the inverter. (Refer to page 270 for DU display.)	
Output terminal status	_	30.17		H10*11	40216*11		Displays output terminal ON/OFF state of the inverter. (Refer to page 270 for DU display.)	
Option input terminal status*9	_	56	_	_	_		Displays input terminal ON/OFF state of the digital input option (FR-A8AX) on the DU. (Refer to page 270 for details.)	
Option output terminal status*9	_	57	_	_	_		Displays output terminal ON/OFF state of the digital output option (FR-A8AY) and the relay output option (FR-A8AR) on the DU. (Refer to page 270 for details.)	
Option input terminal status 1 (for communication)*9	_	_		H3A*12	40258*12		Input terminal X0 to X15 ON/OFF state of the digital input option (FR-A8AX) can be monitored via RS-485 communication and the communication option.	

Types of monitor	Unit	Pr.52, Pr.774 to Pr.776, Pr.992	RS-485 communication dedicated monitor (hexadecimal)	Modbus- RTU real time monitor	Minus (-) display	Description
Option input terminal status 2 (for communication)*9	_	_	H3B*13	40259*13		Input terminal DY ON/OFF state of the digital input option (FR-A8AX) can be monitored via RS-485 communication and the communication option.
Option output terminal status 1 (for communication)*9	_	_	H3C*14	40260*14		Output terminal ON/OFF state of the digital output option (FR-A8AY) and relay output option (FR-A8AR) can be monitored via RS-485 communication and the communication option.
Motor thermal load factor	0.1%	61	H3D	40261		Displays the accumulated heat value of the motor thermal O/L relay. The motor overload trip (E.THM) occurs at 100%.
Inverter thermal load factor	0.1%	62	Н3Е	40262		Displays the accumulated heat value of the inverter thermal O/L relay. The inverter overload trip (E.THT) occurs at 100%.
PTC thermistor resistance	0.01 kΩ	64	H40	40264		Displays the PTC thermistor resistance when <b>Pr.561 PTC thermistor protection level</b> ≠ 9999 (voltage monitor when <b>Pr.561</b> = 9999).
PID measured value 2	0.1%	67	H43	40267		Displays the PID control measured value even when PID control is disabled. (Refer to page 389)
Emergency drive status *7	1	68	H44	40268		Displays the emergency drive status (Refer to page 238)
32-bit cumulative power (lower 16 bits)	1 kWh	_	H4D	40277		Displays the 32-bit cumulative power
32-bit cumulative power (upper 16 bits)	1 kWh	_	H4E	40278		value in multiplies of 16 bits. Monitoring can be performed via RS- 485 communication and communication options. (To find the
32-bit cumulative power (lower 16 bits)	0.01 kWh/ 0.1 kWh*5	_	H4F	40279		monitor codes for each communication option, refer to the Instruction Manual of each
32-bit cumulative power (upper 16 bits)	0.01 kWh/ 0.1 kWh*5	_	H50	40280		communication option.)
BACnet reception status	1	81	H51	40281		Displays the BACnet reception status.
BACnet token pass counter	1	82	H52	40282		Displays the count of received token.
BACnet valid APDU counter	1	83	H53	40283		Displays the count of valid APDU detection.
BACnet communication error counter	1	84	H54	40284		Displays the count of communication error detection.
BACnet terminal FM/CA output level	0.1%	85	H55	40285		Displays the value set in the Analog Output object (ID=0: Terminal FM/CA) for BACnet communication.
BACnet terminal AM output level	0.1%	86	H56	40286	0	Displays the value set in the Analog Output object (ID=1: Terminal AM) for BACnet communication. (A display without signs displays negative values as absolute values.)

Types of monitor	Unit	Pr.52, Pr.774 to Pr.776, Pr.992	RS-485 communication dedicated monitor (hexadecimal)	Modbus- RTU real time monitor	Minus (-) display	Description
Remote output value 1	0.1%	87	H57	40287		
Remote output value 2	0.1%	88	H58	40288	0	Displays the setting values of <b>Pr.656 to Pr.659</b> (analog remote output).
Remote output value 3	0.1%	89	H59	40289		(Refer to page 300.)
Remote output value 4	0.1%	90	H5A	40290		
PID manipulated variable	0.1%	91	H5B	40291	o	Displays the PID control manipulated amount. (Refer to page 389)
Second PID set point	0.1%	92	H5C	40292		
Second PID measured value	0.1%	93	H5D	40293		Displays the set point, measured value, and deviation under second PID control. (Refer to page 389)
Second PID deviation	0.1%	94	H5E	40294	0	(Reier to page 303)
Second PID measured value 2	0.1%	95	H5F	40295		Displays the second PID control measured value even when the second PID control is disabled.(Refer to page 389)
Second PID manipulated variable	0.1%	96	H60	40296	o	Displays the second PID control manipulated amount. (Refer to page 389)
Control circuit temperature	1°C	98	H62	40298	o	Displays the temperature of the control circuit board. Without minus sign: 0 to 100°C With minus sign: -20 to 100°C

#### (M) Monitor display and monitor output signal

- When using the item as the main monitor data on the LCD operation panel (FR-LU08) or the parameter unit (FR-PU07), use Pr.774 to Pr.776 or the monitor function of the FR-LU08 or the FR-PU07 for setting.
- The cumulative energization time and actual operation time are accumulated from 0 to 65535 hours, then cleared, and accumulated again from
- \*3 The actual operation time does not increase if the cumulative running time before power OFF is less than an hour.
- When using the parameter unit (FR-PU07), "kW" is displayed.
- Differs according to capacities. (FR-F820-02330(55K) or lower, FR-F840-01160(55K) or lower /FR-F820-03160(75K) or higher, FR-F840-01160(55K) or higher, FR-F840-0160(55K) or higher, FR-F840-0160(55
- Since the voltage and current display on the operation panel (FR-DU08) is shown in four digits, a monitor value of more than "9999" is displayed
- The setting is available only for standard models.
- When the output current is less than the specified current level (5% of the rated inverter current), the output current is monitored as 0 A. Therefore, the monitored value of an output current and output power may be displayed as "0" when using a much smaller-capacity motor compared to the inverter or in other instances that cause the output current to fall below the specified value.
- \*9 Available when the plug-in option is connected.
- \*10 Input terminal monitor details ("1" denotes terminal ON, "0" denotes terminal OFF, and "--" denotes undetermined value.)

b15															bU
_	_	ı	ı	CS	RES	STP (STOP)	MRS	JOG	RH	RM	RL	RT	AU	STR	STF

\*11 Output terminal monitor details ("1" denotes terminal ON, "0" denotes terminal OFF, and "—" denotes undetermined value.)

b15															b0
_	_	_	_	_	_	_	_	SO	ABC2	ABC1	FU	OL	IPF	SU	RUN

\*12 Option input terminal monitor 1 details (FR-A8AX input terminal status, "1" denotes terminal ON and "0" denotes terminal OFF.) — - All are OFF when the option is not connected.

บาอ															bu
X15	X14	X13	X12	X11	X10	X9	X8	X7	X6	X5	X4	Х3	X2	X1	X0

\*13 Option input terminal monitor 2 details (FR-A8AX input terminal status. "1" denotes terminal ON, "0" denotes terminal OFF, "—" denotes undetermined value.) —— All are OFF when the option is not connected.

b15															b0
_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	DY

\*14 Option output terminal monitor details (FR-A8AY/A8AR output terminal status. "1" denotes terminal ON, "0" denotes terminal OFF, and "—" denotes undetermined value.)—— All are OFF when the option is not connected.

b15															b0
_	_	_	_	_	_	RA3	RA2	RA1	Y6	Y5	Y4	Y3	Y2	Y1	Y0

- \*15 The increment is 1 when Pr.37 = "1 to 9998" or when Pr.144 = "2 to 12" or "102 to 112". (Refer to page 261.)
- \*16 The monitored values are retained even if an inverter fault occurs. Resetting will clear the retained values.
- \*17 Parameter setting is not available for setting the item as the main monitor data on the LCD operation panel (FR-LU08) or the parameter unit (FR-PU07). Use the monitor function of the FR-LU08 or the FR-PU07 for setting.

SET


#### ◆Monitor display for operation panel (Pr.52, Pr.774 to Pr.776)

- When Pr.52 = "0" (initial value), the monitoring of output frequency, output current, output voltage and fault display can be selected in sequence by pressing
- The Load meter, Motor excitation current and Motor load factor are displayed on the second monitor (output current) position, among the monitors set in Pr.52. Other monitors are displayed in the third monitor (output voltage) position.
- The monitor displayed at power ON is the first monitor (the output frequency monitor, according to the initial value). Display the monitor that will be the first monitor, and continue pressing set for 1 s. (To return to the output frequency monitor,

display the output frequency monitor and press | SET for 1 s.) • Power-on monitor (first monitor) Second monitor · Third monitor Fault monitor With fault SET SET Output frequency monitor Output voltage monitor Output current monitor

SET

• For example, when Pr.52 = "20" (cumulative energization time), the monitor is displayed on the operation panel as shown below



• Pr.774 sets the output frequency monitor, Pr.775 sets the output current monitor, and Pr.776 sets the monitor description to be displayed at the output voltage monitor position. When Pr.774 to Pr.776 = "9999" (initial value), the Pr.52 setting value is used.

#### NOTE

· On the operation panel (FR-DU08), the "Hz" unit indicator is lit while displaying the output frequency, the "Hz" flickers when displaying the set frequency.

#### ◆Displaying the set frequency during stop (Pr.52)

• When Pr.52 = "100", the set frequency is displayed during stop, and output frequency is displayed during running. (LED of Hz flickers during stop and is lit during operation.)

Pr.52 setting	Status	Output frequency	Output current	Output voltage	Fault or alarm indication	
0	During running/stop	Output frequency			Fault on alama	
100	During stop	Set frequency*1	Output current	Output voltage	Fault or alarm indication	
100	Running	Output frequency			maioation	

\*1 Displays the frequency that is output when the start command is ON. The value considers the maximum/minimum frequency and frequency jumps. It is different from the frequency setting displayed when Pr.52 = "5".

#### NOTE:

- During an error, the output frequency at error occurrence appears.
- During output shutoff by the MRS signal, the values displayed are the same as during a stop.
- · During offline auto tuning, the tuning state monitor takes priority.

#### ◆Operation panel setting dial push display (Pr.992)

- Use Pr.992 to select the monitor that appears when the setting dial on the operation panel (FR-DU08) is pushed.
- When **Pr.992** = "0 (initial value)", keep pressing the setting dial when in PU operation mode or External/PU combined operation mode 1 (**Pr.79 Operation mode selection** = "3") to show the presently set frequency.
- When Pr.992 = "100", the set frequency is displayed during stop, and output frequency is displayed during running.

Pr.992 setting	Status	Monitor displayed by the setting dial push		
0	During running/stop	Set frequency (PU direct-in frequency)		
100	During stop	Set frequency*1		
100	Running	Output frequency		


<sup>\*1</sup> Displays the frequency that is output when the start command is ON. The value considers the maximum/minimum frequency and frequency jumps. It is different from the frequency setting displayed when **Pr.992** = "5".

#### ◆Operation panel (FR-DU08) I/O terminal monitor (Pr.52)


- When Pr.52 = "55 to 57", the I/O terminal state can be monitored on the operation panel (FR-DU08).
- The output terminal monitor is displayed on the third monitor.
- The LED is ON when the terminal is ON, and the LED is OFF when the terminal is OFF. The center line of LED is always ON.

Pr.52 setting	Monitor description			
55	Displays the I/O terminal ON/OFF state of the inverter.			
56*1	Displays input terminal ON/OFF state of the digital input option (FR-A8AX)			
57*1	Displays output terminal ON/OFF state of the digital output option (FR-A8AY) or the relay output option (FR-A8AR).			


- \*1 The setting values "56, 57" can be set even if the option is not installed. All are OFF when the option is not connected.
- On the I/O terminal monitor (**Pr.52** = "55"), the upper LEDs denote the input terminal state, and the lower LEDs denote the output terminal state.



• The decimal point of the first digit on the LED will light for the input option terminal monitor (Pr.52 = "56").



• The decimal point of the second digit on the LED will light for the output option terminal monitor (Pr.52 = "57").



#### ◆Cumulative power monitor and clear (Pr.170, Pr.891)

- On the cumulative power monitor (Pr.52 = "25"), the output power monitor value is added up and updated in 100 ms increments. (The values are saved in EEPROM every hour.)
- Display increments and display ranges of the operation panel, parameter unit and communication (RS-485 communication, communication option) are as indicated below.

Operation panel, pa	rameter unit+1	Communication			
Range Unit		Ra	Range		
ixaliye	Oilit	Pr.170 = 10	Pr.170 = 9999	Unit	
0 to 999.99 kWh	0.01 kWh		0 to 65535 kWh		
1000.0 to 9999.9 kWh	0.1 kWh	0 to 9999 kWh	(initial value)	1 kWh	
10000 to 99999 kWh	1 kWh		(Illitial value)		

- Power is measured in the range of 0 to 99999.99 kWh, and displayed in five digits. When the monitor value exceeds "999.99", a carry occurs, for example "1000.0", so the value is displayed in 0.1 kWh increments.
- The monitor data digit can be shifted to the right by the number of **Pr.891**. For example, if the cumulative power value is 1278.56 kWh when Pr.891 = "2", the operation panel display is 12.78 (display in 100 kWh increments) and the communication data is 12.
- If the maximum value is exceeded at Pr.891 = "0 to 4", the monitor value is clamped at the maximum value, indicating that a digit shift is necessary. If the maximum value is exceeded at Pr.891 = "9999", the monitor value returns to 0, and the counting starts again.
- Writing "0" in Pr.170 clears the cumulative power monitor.

#### NOTE:

If "0" is written to Pr.170, and Pr.170 is read again, "9999" or "10" is displayed.

#### **◆**Cumulative energization time and actual operation time monitor (Pr.171, Pr.563, Pr.564)

- Cumulative energization time monitor (Pr.52= "20") accumulates energization time from shipment of the inverter every one hour.
- On the actual operation time monitor (Pr.52 = "23"), the inverter running time is added up every hour. (Time is not added up during a stop.)
- If the number of monitor value exceeds 65535, it is added up from 0. Pr.563 allows the user to check how many times the cumulative energization time monitor has exceeded 65535h. Pr.564 allows the use to check how many times the actual operation time monitor has exceeded 65535h.
- · Writing "0" in Pr.171 clears the actual operation time monitor. (The cumulative energization time monitor cannot be cleared.)

#### • NOTE

- The cumulative energization time does not increase if the power is turned OFF after less than an hour.
- The actual operation time does not increase if the cumulative running time before power OFF is less than an hour.
- If "0" is written to Pr.171 and Pr.171 is read again, "9999" is always displayed. Setting "9999" does not clear the actual operation time meter.

#### ◆Hiding the decimal places for the monitors (Pr.268)

• As the operation panel (FR-DU08) display is 5 digits long, the decimal places may vary during analog input, etc. The decimal places can be hidden by selecting the decimal digits with Pr.268.

Pr.268 setting	Description
9999 (initial value)	No function
0	For the first or second decimal places (0.1 increments or 0.01 increments) of the monitor, numbers in the first decimal place and smaller are rounded to display an integral value (1 increments). The monitor value equal to or smaller than 0.99 is displayed as 0.
1	When monitoring with the second decimal place (0.01 increments), the 0.01 decimal place is dropped and the monitor displays the first decimal place (0.1 increments). When monitoring with the first decimal place, the display will not change.



• The number of display digits on the cumulative energization time (Pr.52 = "20"), actual operation time (Pr.52 = "23"), cumulative power (Pr.52 = "25") and cumulative energy saving (Pr.52 = "51") does not change.

#### Minus sign display for the monitors (Pr.290)

• Values with minus signs can be output from the terminal AM (analog voltage output) and can be displayed on the operation panel. For a list of the monitors that can output values with minus signs, refer to the monitor description list (on page 264).

Pr.290 setting	Terminal AM output	Operation panel display	Monitoring via communication
0 (initial value)	_	_	_
1	Output with a minus sign	_	_
2	_	Displayed with minus sign.	_
3	Output with a minus sign	Displayed with minus sign.	_
4	_	_	Displayed with minus sign.
5	Output with a minus sign	_	Displayed with minus sign.
6	_	Displayed with minus sign.	Displayed with minus sign.
7	Output with a minus sign	Displayed with minus sign.	Displayed with minus sign.

—: Output without minus sign (positive values only)



- When terminal AM (analog voltage output) is "output with a minus sign", the output will be within the -10V DC to +10V DC range. Connect the meter with which output level is matched.
- Parameter unit (FR-PU07) displays only positive values.

#### ♦ Monitor filter (Pr.1106 to Pr.1108)

• The response level (filter time constant) of the following monitor indicators can be adjusted.

Pr.	Monitor number	Monitor indicator name		
	7	Motor torque		
1106	17	Load meter		
1100	32	Torque command		
	33	Torque current command		
1107	6	Running speed		
1108	18	Motor excitation current		

#### Parameters referred to >>>

Pr.30 Regenerative function selection page 508

Pr.37 motor speed display, Pr.144 Speed setting switchover page 261

Pr.55 Frequency monitoring reference, Pr.56 Current monitoring reference, Pr.866 Torque monitoring reference 🕮 page 273

#### 5.8.3 Monitor display selection for terminals FM/CA and AM

The monitored statuses can be output as the following items: analog voltage (terminal AM), pulse train (terminal FM) for the FM-type inverter, analog current (terminal CA) for the CA-type inverter.

The signal (monitored item) to be output to terminal FM/CA and terminal AM can be selected.

Pr.	Nama	Initial value		Catting yours	Decembries		
Pr.	Name	FM CA		Setting range	Description		
54 M300	FM/CA terminal function selection	1 (output frequency)		1 to 3, 5 to 14, 17, 18, 21, 24, 34, 50, 52, 53, 61, 62, 67, 70, 85, 87 to 90, 92, 93, 95, 98	Select the monitored item to be output the terminal FM and terminal CA.		
158 M301	AM terminal function selection			1 to 3, 5 to 14, 17, 18, 21, 24, 34, 50, 52 to 54, 61, 62, 67, 70, 86 to 96, 98	Select the monitored item to be output to the terminal AM.		
55 M040	Frequency monitoring reference	60 Hz 50 Hz  Inverter Rated current  150%		0 to 590 Hz	Set the full-scale va the frequency monit FM, CA and AM.	lue when outputting or value to terminals	
56 M041	Current monitoring reference			0 to 500 A*1 0 to 3600 A*2	Set the full-scale value when outputting the output current monitor value to terminals FM, CA and AM.		
866 M042	Torque monitoring reference			0 to 400%	Set the full-scale value when outputting the torque monitor value to terminals FM CA and AM.		
290 M044	Monitor negative output selection			0 to 7	Set the availability of output with a minus sign for the terminal AM, the operation panel display, or monitoring via communication. (Refer to page 272)		
					Pulse train input (terminal JOG)	Pulse train output (terminal FM)	
				0	JOG signal*3	FM output*4	
				1	Pulse train input	FM output*4	
		0		10*4	JOG signal∗₃	High-speed pulse train output (50% duty)	
291	Pulse train I/O selection			11*4	Pulse train input	High-speed pulse train output (50% duty)	
D100	Pulse train i/O selection			20*4	JOG signal <sub>*3</sub>	High-speed pulse train output (ON width fixed)	
				21*4	Pulse train input	High-speed pulse train output (ON width fixed)	
				100*4	Pulse train input	High-speed pulse train output (ON width fixed) Output the pulse train input without changes.	

- \*1 FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower.
- \*2 FR-F820-03160(75K) or more, FR-F840-01800(75K) or more.
- \*3 Function assigned to Pr.185 JOG terminal function selection.
- \*4 Valid only for the FM type inverters.

#### **♦** Monitor description list (Pr.54, Pr.158)

- Set **Pr.54 FM/CA terminal function selection** for the monitor to be output to the terminal FM (pulse train output) and terminal CA (analog current output).
- Set **Pr.158 AM terminal function selection** for the monitor to be output to the terminal AM (analog voltage output). Output with a negative sign can be made (-10 VDC to +10 VDC) from the terminal AM. **o** in the [Negative (-) output] indicates the output value is negative at the terminal AM. (For setting of the output with/without minus sign, refer to page 263.)
- Refer to the following table and set the monitor to be displayed. (Refer to page 264 for the monitor description.)


Types of monitor	Unit	Pr.54 (FM/CA) Pr.158 (AM) setting	Terminal FM, CA, AM Full-scale value	Negative (-) output	REMARKS
Output frequency	0.01 Hz	1	Pr.55		
Output current*2	0.01 A/0.1 A*1	2	Pr.56		
Output voltage	0.1 V	3	200 V class: 400 V 400 V class: 800 V		
Frequency setting value	0.01 Hz	5	Pr.55		
Running speed	1 (r/min)	6	Value is <b>Pr.55</b> converted by <b>Pr.37</b> , <b>Pr.144</b> . (Refer to page 261.)		Refer to page 261 for the running speed monitor.
Motor torque	0.1%	7	Pr.866	0	
Converter output voltage*2	0.1 V	8	200 V class: 400 V 400 V class: 800 V		
_	_	9	_		For manufacturer setting. Do not set.
Electronic thermal O/L relay load factor	0.1%	10	Electronic thermal O/L relay operation level (100%)		
Output current peak value	0.01 A/0.1 A*1	11	Pr.56		
Converter output voltage peak value	0.1 V	12	200 V class: 400 V 400 V class: 800 V		
Input power	0.01 kW/ 0.1 kW*1	13	Rated inverter power × 2		
Output power*2	0.01 kW/ 0.1 kW*1	14	Rated inverter power × 2		
Load meter	0.1%	17	Pr.866		
Motor excitation current	0.0 1 A/0.1 A*1	18	Pr.56		
Reference voltage output	_	21	_		Terminal FM: 1440 pulses/s is output when Pr.291 = 0,1. 50k pulses/s is output when Pr.291 ≠ 0,1. Terminal CA: output is 20 mA Terminal AM: output is 10 V.
Motor load factor	0.1%	24	200%		
Motor output	0.01 kW/ 0.1 kW*1	34	Rated motor capacity		
Energy saving effect	Changeable by parameter setting	50	Inverter capacity		Regarding the energy saving monitor, refer to page 283
PID set point	0.1%	52	100%		Refer to page 389 for the PID
PID measured value	0.1%	53	100%		control.
PID deviation	0.1%	54*3	100%	0	Output with a negative sign (terminal AM)
Motor thermal load factor	0.1%	61	Motor thermal operation level (100%)		
Inverter thermal load factor	0.1%	62	Inverter thermal operation level (100%)		
PID measured value 2	0.1%	67	100%		
PLC function analog output	0.1%	70	100%	0	Refer to page 431 for the PLC function.


Types of monitor	Unit	Pr.54 (FM/CA) Pr.158 (AM) setting	Terminal FM, CA, AM Full-scale value	Negative (-) output	REMARKS
BACnet terminal FM/CA output level	0.1%	85*4	100%		The value set in the Analog Output object (ID=0: Terminal FM/CA) for BACnet communication is output.
BACnet terminal AM output level	0.1%	86*3	100%	o	The value set in the Analog Output object (ID=1: Terminal AM) for BACnet communication is output. (The output is always negative regardless of the Pr.290 setting when the monitored value is negative.)
Remote output value 1	0.1%	87	1000%	0	
Remote output value 2	0.1%	88	1000%		Refer to page 300 for the
Remote output value 3	0.1%	89	1000%		analog remote output.
Remote output value 4	0.1%	90	1000%		
PID manipulated variable	0.1%	91*3	100%	0	Output with a minus sign (terminal AM)
Second PID set point	0.1%	92	100%		
Second PID measured value	0.1%	93	100%		
Second PID deviation	0.1%	94*3	200%	0	Refer to page 389 for the PID
Second PID measured value 2	0.1%	95	100%		control.
Second PID manipulated variable	0.1%	96*3	100%	0	
Control circuit temperature	1°C	98	100°C	0	Terminal FM/CA: 0 to 100°C terminal AM: -20 to 100°C


- Differs according to capacities. (FR-F820-02330(55K) or lower, FR-F840-01160(55K) or lower /FR-F820-03160(75K) or higher, FR-F840-01160(75K) or higher, FR-F840-0160(75K) or hig 01800(75K) or higher)
- \*2 When the output current is less than the specified current level (5% of the rated inverter current), the output current is monitored as 0 A. Therefore, the monitored value of an output current and output power may be displayed as "0" when using a much smaller-capacity motor compared to the inverter or in other instances that cause the output current to fall below the specified value.
- \*3 The setting is available only with terminal AM (**Pr.158**).
- \*4 The setting is available only with terminal FM/CA (Pr.54).

#### **♦**Frequency monitor reference (Pr.55)

• Set the full-scale value for outputting the monitored items of output frequency, frequency setting value to the terminals FM, CA and AM.







- For the FM-type inverters, set the full-scale value of the connected meter when the pulse speed of terminal FM is 1440 pulses/s (50k pulses/s). Set the frequency to be indicated as the full scale value on the frequency meter (1 mA analog meter) connected between terminal FM and SD. (For example, 60 Hz or 120 Hz.) Pulse speed is proportional to the output frequency of the inverter. (Maximum pulse train output is 2400 pulses/s (55k pulses/s).)
- For the CA-type inverters, set the full-scale value of the connected meter when output current of terminal CA is 20 mA. Set the frequency to be indicated as the full scale value on the meter (20 mA DC ammeter connected between terminal CA and 5; for example, 60 Hz or 120 Hz. Output current is proportional to the frequency. (The maximum output current is 20 mA DC.)
- For the calibration of terminal AM, set the full-scale value of the connected meter when output voltage of terminal FM is 10 VDC. Set the frequency to be indicated as the full scale value on the meter (10 VDC voltmeter) connected between terminal AM and 5. (For example, 60 Hz or 120 Hz) Output voltage is proportional to the frequency. (The maximum output voltage is 10 VDC.)
  - \*1 FM type: 60 Hz; CA type: 50 Hz
  - \*2 Output with a negative sign available when Pr.290 Monitor negative output selection = "1, 3"

## **♦** Current monitor reference (Pr.56)


- · Output current, Output current peak value, Motor excitation current and monitor from the terminals FM, CA and AM.
- For the FM-type inverters, set the full-scale value of the connected meter when the pulse speed of terminal FM is 1440 pulses/s (50k pulses/s).
  - Set the current to be indicated as the full scale value to the meter (1 mA analog meter) connected between terminal FM and SD.
  - Pulse speed is proportional to the monitored value of output current. (Maximum pulse train output is 2400 pulses/s (55k pulses/s).)
- For the CA-type inverters, set the full-scale value of the connected current meter when output current of terminals CA is 20 mA. Set the current to be indicated as the full scale value on the meter (20 mADC ammeter) connected between terminals CA and 5.Output current is proportional to the monitored value of output current. (The maximum output current is 20 mADC.)
- For the calibration of terminal AM, set the full-scale value of the connected current meter when the output voltage of terminal AM is 10 VDC.
  - Set the current to be indicated as the full scale value on the meter (10 VDC voltmeter) connected between terminal AM and 5.
  - Output voltage is proportional to the monitored value of output current. (The maximum output voltage is 10 VDC.)

#### ◆Torque monitor reference (Pr.866)


- Set the full scale value when outputting the current monitor from terminal the FM, CA or AM.
- · For the FM-type inverters, set the full-scale value of the connected torque meter when the pulse speed of terminal FM is 1440 pulses/s (50k pulses/s). Set the torque to be indicated as the full scale value on the meter (1 mA analog meter) connected between terminals FM and SD.
  - Pulse speed is proportional to the monitored value of torque. (Maximum pulse train output is 2400 pulses/s (55k pulses/s).)
- · For the CA-type inverters, set the full-scale value of the connected torque meter when output current of the terminal CA is 20 mADC.
  - Set the torque to be indicated as the full scale value on the meter (20 mADC ammeter) connected between terminals CA and 5.
  - Output current is proportional to the monitored value of torque. (The maximum output voltage is 20 mADC.)
- · For the calibration of terminal AM, set the full-scale value of the connected torque meter when the output voltage of terminal AM is at 10 VDC.
  - Set the torque to be indicated as the full scale value on the meter (10 VDC voltmeter) connected between terminal AM and
  - Output voltage is proportional to the monitored value of torque. (The maximum output voltage is 10 VDC.)

#### Terminal FM pulse train output (Pr.291)

· Two kinds of pulse trains can be output to the terminal FM.




- When Pr.291 Pulse train I/O selection = "0 (initial value) or 1", this is FM output with a maximum output of 8 VDC and 2400 pulses/s.
  - The pulse width can be adjusted by using the operation panel or the parameter unit and calibration parameter C0(Pr.900) FM/CA terminal
- · Commands can be sent (such as inverter output frequency) by connecting a 1 mA full-scale DC ammeter or a digital meter.




- Not needed when the operation panel or the parameter unit is used for calibration.
  - Use a calibration resistor when the indicator (frequency meter) needs to be calibrated by a neighboring device because the indicator is located far from the inverter.
  - However, the frequency meter needle may not deflect to full-scale if the calibration resistor is connected. In this case, calibrate additionally with the operation panel or the parameter unit.
- \*2 In the initial setting, 1 mA full-scale and 1440 pulses/s terminal FM are used at 60 Hz.

#### (M) Monitor display and monitor output signal

#### High-speed pulse train output circuit (example of connection to pulse counter)






- When Pr.291 Pulse train I/O selection = "10, 11, 20, 21, 100", this is high-speed pulse train output for open collector output. A maximum pulse train of 55k pulses/s is outputted. There are two types of pulse width: "50% duty" and "fixed ON width"; this cannot be adjusted with the calibration parameter C0 (Pr.900) FM/CA terminal calibration.
  - \*3 The pulses may weaken due to stray capacitance in the wiring if the wiring is long, and the pulse counter will be unable to recognize the pulses. Connect the open collector output to the power source with a pull-up resistor if the wiring is too long. Check the pulse counter specs for the pull-up resistance. The resistance should be at 80 mA of the load current or less.
- When **Pr.291** = "10, 11", the pulse cycle is 50% duty (ON width and OFF width are the same).
- When Pr.291 = "20, 21, 100", the pulse ON width is output at a fixed width (approx. 10 µs).
- At the "100" setting, the same pulse train from the pulse train input (terminal JOG) will be outputted. This is used when running at a synchronized speed with more than one inverter. (Refer to page **218**.)
  - \*4 "HIGH" indicates when the open collector output transistor is OFF.

Item	High-speed pulse train output specifications
Output method	NPN open collector output
Voltage between collector-emitter	30 V (max.)
Maximum permissible load current	80 mA
Output pulse rate	0 to 55 kpps*1
Output resolution	3 pps (excluding jitter)

\*1 50 kpps when the monitor output value is 100%.

#### NOTE

- Terminal JOG input specifications (pulse train input or contact input) can be selected with Pr.291. When changing the setting value, be careful not to change the terminal JOG input specifications. (Refer to page 218 for pulse train input.)
- · Connect a meter between the terminals FM and SD after changing the Pr.291 setting value. When using the pulse train of FM output (voltage output), be careful that voltage is not added to terminal FM.
- · A connection cannot be made to the pulse input of a source logic type.
- If all parameter clear is performed when selecting the high-speed pulse train output (Pr.291 = "10, 11, 20, 21, 100"), the terminal FM output can be changed from high-speed pulse train output to FM output (voltage output), since the Pr.291 setting value returns to the initial value of "0". Perform all parameter clear after removing the device connected to the terminal FM.



#### 5.8.4 Monitor display selection for terminals FM/CA and AM


By using the operation panel or the parameter unit, terminals FM, CA and AM can be adjusted (calibrated) to the full

Pr.	Name	Initial value	Setting range	Description
C0 (900)*1 M310	FM/CA terminal calibration	_	_	Calibrates the scale of the meter connected to terminals FM and CA.
C1 (901)*1 M320	AM terminal calibration	_	_	Calibrates the scale of the analog meter connected to terminal AM.
C8 (930)*1 M330	Current output bypass signal	0%	0 to 100%	Set the signal value at the minimum analog current output.
C9 (930)*1 M331	Current output bypass current	0%	0 to 100%	Set the current value at the minimum analog current output.
C10 (931)*1 M332	Current output gain signal	100%	0 to 100%	Sets the signal value when the analog current output is at maximum.
C11 (931)*1 M333	Current output gain current	100%	0 to 100%	Set the current value at the maximum analog current output.
867 M321	AM output filter	0.01 s	0 to 5 s	Set the terminal AM output filter.
869 M334	Current output filter	0.01 s	0 to 5 s	Set the terminal AM output filter.

<sup>\*1</sup> The parameter number in parentheses ( ) is the one for use with the LCD operation panel and the parameter unit (FR-PU07).

#### ◆Terminal FM calibration (C0 (Pr.900))

- The terminal FM is preset to output pulses. By setting C0 (Pr.900), the meter connected to the inverter can be calibrated by parameter setting without use of a calibration resistor.
- · Using the pulse train output of the terminal FM, a digital display can be provided to connect a digital counter. The monitor value is 1440 pulses/s output at the full-scale value of the monitor description list (on page 264) (Pr.54 FM/CA terminal function selection).



- Not needed when the operation panel or the parameter unit is used for calibration.
  - Use a calibration resistor when the indicator (frequency meter) needs to be calibrated by a neighboring device because the indicator is located far from the inverter.
  - However, the frequency meter needle may not deflect to full-scale if the calibration resistor is connected. In this case, perform calibration using the operation panel or the parameter unit.
- \*2 In the initial setting, 1 mA full-scale and 1440 pulses/s terminal FM are used at 60 Hz.
- Calibrate the terminal FM in the following procedure.
  - 1) Connect an indicator (frequency meter) across terminals FM and SD of the inverter. (Note the polarity. The terminal FM is positive.)
  - 2) When a calibration resistor has already been connected, adjust the resistance to "0" or remove the resistor.
  - 3) Refer to the monitored item list (page 264) and set Pr.54. When the running frequency or inverter output current is selected on the monitor, set the running frequency or current value at which the output signal will be 1440 pulses/s, using Pr.55 Frequency monitoring reference or Pr.56 Current monitoring reference beforehand. Normally, at 1440 pulses/s the meter deflects to full-scale.
  - 4) If the meter needle does not point to maximum even at maximum output., calibrate it with C0(Pr.900).

GROUP

#### • NOTE

- When outputting such an item as the output current, which cannot reach a 100% value easily by operation, set **Pr.54** to "21" (reference voltage output) and calibrate. 1440 pulses/s are output from the terminal FM.
- When **Pr.310 Analog meter voltage output selection** = "21", the terminal FM calibration cannot be performed. For the details of **Pr.310**, refer to the Instruction Manual of FR-A8AY.
- The wiring length of the terminal FM should be 200 m at maximum.
- The initial value of the calibration parameter **C0(Pr.900)** is set to 1 mA full-scale and 1440 pulses/s terminal FM pulse train output at 60 Hz. The maximum pulse train output of terminal FM is 2400 pulses/s.
- When connecting a frequency meter between terminals FM-SD and monitoring the running frequency, it is necessary to change **Pr.55** to the maximum frequency, since the FM terminal output will be saturated at the initial value when the maximum frequency reaches 100 Hz or greater.
- Calibration with the calibration parameter **C0(Pr.900)** cannot be done when **Pr.291** Pulse train I/O selection = "10, 11, 20, 21, 100" (high-speed pulse train output).

# ◆Calibration procedure for terminal FM when using the operation panel (FR-DU08)


	Operation ———
1.	Screen at power-ON
••	The monitor display appears.
	Changing the operation mode
2.	Press PU to choose the PU operation mode. [PU] indicator is lit.
	Calibration is also possible in the External operation mode.
_	Parameter setting mode
3.	Press MODE to choose the parameter setting mode. (The parameter number read previously appears.)
	Calibration parameter selection
4.	Turn until _ appears. Press SET to display
	Selecting the parameter number
5.	Turn until [ (C0(Pr.900) FM/CA terminal calibration) appears. Press SET to enable the parameter
•	setting. The monitored value of the item (initially the output frequency) selected by Pr.54 FM/CA terminal function
	selection will appear.
	Pulse output via terminal FM
6.	If stopped, press FWD or REV to start the inverter operation. (To monitor the output frequency, motor connection is not
	required.
	Calibration is also possible in a stop status.
7.	Scale adjustment
٠.	Turn to move the meter needle to a desired position.
	Setting completed
	Press SET to enter the setting. The monitored value and [
8.	Turn  to read another parameter.
	• Press SET to return to the [ display.
	Press SET twice to show the next parameter.


## NOTE

- Calibration can also be made for the External operation. Set the frequency in the External operation mode, and make calibration in the above procedure.
- Calibration can be performed during operation.
- For the operation from the parameter unit, refer to the Instruction Manual of the parameter unit.

#### **◆Terminal CA calibration (C0 (Pr.900), C8 (Pr.930) to C11 (Pr.931))**

- Terminal CA is initially set to provide a 20 mADC output in the full-scale state of the corresponding monitor item. Calibration parameter C0 (Pr.900) allows the output current ratio (gains) to be adjusted according to the meter scale. Note that the maximum output current is 20 mADC.
- Set a value at the minimum current output in the calibration parameters C8 (Pr.930) and C9 (Pr.930). Calibration parameter C10 (Pr.931) and C11 (Pr.931) are used to set a value at the maximum current output.
- Set the output signal values (output monitor set with Pr.54) at zero and at the maximum current output from the terminal CA (using calibration parameters C8 (Pr.930) and C10 (Pr.931). The full scale for each monitor is 100% at this time.
- Set the output current values (output monitor set with Pr.54) at zero and at the maximum current output from the terminal CA (using calibration parameters C9 (Pr.930) and C11 (Pr.931). The output current calibrated by calibration parameter C0 (Pr.900) is 100% at this time.





- · Calibrate the terminal CA in the following procedure.
  - 1) Connect a 0-20 mADC indicator (frequency meter) across terminals CA and 5 of the inverter. (Note the polarity. The terminal CA is positive.)
  - 2) Set the initial value of calibration parameter C8 (Pr.930) to C11 (Pr.931). If the meter needle does not indicate zero when the current input is at zero, calibrate the meter using C8 (Pr.930) and C9 (Pr.930).
  - 3) Refer to the monitor description list (page 274) and set Pr.54. When the running frequency or inverter output current is selected on the monitor, set the running frequency or current value at which the output signal will be 20 mA, using Pr.55 or Pr.56 beforehand.
  - If the meter needle does not point to maximum even at maximum output, calibrate it with C0 (Pr.900).


## NOTE :

- When outputting such an item as the output current, which cannot reach a 100% value easily by operation, set Pr.54 to "21" (reference voltage output) and calibrate 20 mADC is output from the terminal CA.
- When Pr.310 Analog meter voltage output selection = "21", the terminal CA calibration cannot be performed. For the details of Pr.310, refer to the Instruction Manual of FR-A8AY.
- Output is possible from terminal CA even if C8 (Pr.930) ≥ C10 (Pr.931), C9 (Pr.930) ≥ C11 (Pr.931).

## **◆**Adjusting the response of terminal CA (Pr.869)

- Using Pr.869, the output voltage response of the terminal CA can be adjusted in the range of 0 to 5 s.
- Increasing the setting stabilizes the terminal CA output more but reduces the response level. (Setting "0" sets the response level to 7 ms.)

## ◆Calibration of terminal AM (C1 (Pr.901))



· Terminal AM is initially set to provide a 10 VDC output in the full-scale state of the corresponding monitor item. Calibration parameter C1 (Pr.901) allows the output voltage ratio (gains) to be adjusted according to the meter scale. Note that the maximum output voltage is 10 VDC.

- Calibrate the AM terminal in the following procedure.
  - 1) Connect a 0-10 VDC indicator (frequency meter) across terminals AM and 5 of the inverter.(Note the polarity. The terminal AM is positive.)
  - 2) Refer to the monitor description list (page 264) and set Pr.158 AM terminal function selection. When the running frequency or inverter output current is selected on the monitor, set the running frequency or current value at which the output signal will be 10 V, using Pr.55 or Pr.56 beforehand.
  - 3) If the meter needle does not point to maximum even at maximum output., calibrate it with C1 (Pr.901).

#### NOTE:

- · When outputting such an item as the output current, which cannot reach a 100% value easily by operation, set Pr.158 to "21" (reference voltage output) and calibrate.10 VDC is output from the terminal AM.
- When Pr.306 Analog output signal selection = "21", the terminal AM calibration cannot be performed. For the details of Pr.306, refer to the Instruction Manual of FR-A8AY.
- Use Pr.290 Monitor negative output selection to enable negative output from the terminal AM. When this is set, the output voltage range will be -10 VDC to +10 VDC. Calibrate the terminal AM with the maximum positive output value.

#### **◆**Adjusting the response of terminal AM (Pr.867)

- Using Pr.867, the output voltage response of the terminal AM can be adjusted in the range of 0 to 5 s.
- Increasing the setting stabilizes the terminal AM output more but reduces the response level. (Setting "0" sets the response level to 7 ms.)

#### # Parameters referred to

Pr.54 FM/CA terminal function selection page 273 Pr.55 Frequency monitoring reference page 273 Pr.56 Current monitoring reference page 273 Pr.158 AM terminal function selection page 273 Pr.290 Monitor negative output selection page 273 Pr.291 Pulse train I/O selection page 218

#### 5.8.5 **Energy saving monitor**

From the estimated consumed power during commercial power supply operation, the energy saving effect by use of the inverter can be monitored and output.

Pr.	Name	Initial value	Setting range	Description
52	Operation panel main	0		
M100	monitor selection	(output		
		frequency)	<u> </u>	
774	Operation panel monitor			
M101	selection 1			
775 M102	Operation panel monitor selection 2	9999	Refer to page 263	50: Power saving monitor
776	Operation panel monitor	-	. •	51: Cumulative power saving monitor
M103	selection 3			
	Operation panel setting	0	-	
992	dial push monitor			
M104	selection	frequency)		
54	FM/CA terminal function	,		
M300	selection	1		
158	AM terminal function	(output	Refer to page 273	50: Power saving monitor
M301	selection	frequency)		
				Set the number of times to shift the
			0 to 4	cumulative power monitor digit.
891	Cumulative power		0 10 4	The monitored value is clamped at the
M023	monitor digit shifted	9999		maximum value.
	times		9999	No shift. The monitored value is cleared when it
			9999	exceeds the maximum value.
				Set the load factor for the commercial power
902				supply operation.
892 M200	Load factor	100%	30 to 150%	This is multiplied by the power consumption
				rate (page 286) during commercial power
				supply operation.
893	Energy saving monitor	Rated inverter current	0.1 to 55 kW*1	Set the motor capacity (pump capacity). Set
M201	reference (motor		0 to 3600 kW*2	when calculating the power saving power rate, average power saving rate, and power
141201	capacity)		0 to 3000 kvv*2	during commercial power supply operation.
			0	Discharge damper control (fan)
894	Control selection during commercial power-supply	0	1	Inlet damper control (fan)
M202	operation	U	2	Valve control (pump)
	operation		3	Commercial power supply drive (fixed value)
			0	Consider the value during commercial power
895	Power saving rate	9999		supply operation as 100%.
M203	reference value		9999	Consider <b>Pr.893</b> setting as 100%.  No function
			9999	Set the power unit cost. The power cost
896			0 to 500	savings are displayed on the energy saving
M204	Power unit cost	9999		monitor.
			9999	No function
897	Power saving monitor		0	Average of 30 minutes
M205	average time	9999	1 to 1000 h	Average of the set time
			9999	No function
			0	Cumulative monitor value clear
898	Power saving cumulative		1	Cumulative monitor value hold
	monitor clear	9999	10	Continue accumulation (communication data upper limit 9999)
M206	o.iitoi olodi			Continue accumulation
			9999	(communication data upper limit 65535)
				This value is used for calculating the annual
899	Operation time rate		0 to 100%	power saving amount. Set the annual
M207	(estimated value)	9999	3.3.10070	operation ratio (consider 365 days × 24h as
	(		0000	100%).
*1	For the FR-F820-02330(55K) or lowe	<u> </u>	9999	No function

<sup>\*1</sup> For the FR-F820-02330(55K) or lower, and FR-F840-01160(55K) or lower.

GROUP

<sup>\*2</sup> For the FR-F820-03160(75K) or higher, and FR-F840-01800(75K) or higher.

## **♦**Energy saving monitor list

• The items that can be monitored on the power saving monitor (Pr.52, Pr.54, Pr.158, Pr.774 to Pr.776, Pr.992 = "50") are indicated below.

(Only [1 Power saving] and [3 Average power saving] can be set to Pr.54 (terminal FM, terminal CA) and Pr.158 (terminal AM).)

	Energy saving monitored item	Description and formula	Increment		Parameter setting		
	monitored item	Description and formula	Increment	Pr.895	Pr.896	Pr.897	Pr.899
1	Power saving	The difference between the estimated value of the required power during commercial power supply operation and the input power calculated with the inverter. Power supply during commercial power supply operation - input power monitor	0.01 kW/ 0.1 kW*3	9999			
2	Power saving rate	e power saving ratio with the commercial power ply operation as 100%.  [1 Power saving]  ver during commercial power supply operation × 100  0.1%	9999				
	Tonor saving rate	The power saving ratio with Pr.893 as 100%.  [2 Power saving] Pr.893 × 100	1				
3	Average power saving	The average power saving per hour during a predetermined time (Pr.897).  ∑ ([1 Power saving] × ∆t)  Pr.897	0.01 kWh/ 0.1 kWh*3	9999			_
4	Average power saving rate	The average power saving ratio with the commercial power supply operation as 100%. $\frac{\sum ([2 \text{ Power saving rate}] \times \Delta t)}{\text{Pr.897}} \times 100$	0.1%	0	-	0 to 1000 h	
		The average power saving ratio with <b>Pr.893</b> as 100%.  [3 Average power saving] Pr.893  × 100		1			
5	Average power cost savings	The average power saving in terms of cost.  [3 Average power saving] × Pr.896	0.01/0.1*3	-	0 to 500		

<sup>•</sup> The items that can be monitored on the cumulative energy saving monitor (Pr.52, Pr.774 to Pr.776, Pr.992 = "51") are indicated below.

(The monitor value of the cumulative monitor can be shifted to the right with Pr.891 Cumulative power monitor digit shifted times.)

	Energy saving	Description and formula	Increment		Paramete	er setting	3
	monitored item	Description and formula	increment	Pr.895	Pr.896	Pr.897	Pr.899
6	Power saving amount	The cumulative power saving is added up per hour. $\sum ([1 \ \text{Power saving}] \times \Delta t)$	0.01 kWh/ 0.1 kWh *1*2*3	_	9999		9999
7	Power cost saving	The power saving amount in terms of cost.  [6 Power saving amount] × Pr.896	0.01/0.1 *1*3	_	0 to 500		
8	Annual power saving amount	Estimated value of annual power saving amount.  [6 Power saving amount]  Operation time during power saving accumulation ×  Pr.899  24 × 365 × Pr.899	0.01 kWh/ 0.1 kWh *1*2*3	_	9999	_	0 to 100%
9	Annual power cost savings	Annual power saving amount in terms of cost.  [8 Annual power saving amount] × Pr.896	0.01/0.1 *1*3	_	0 to 500		

<sup>\*1</sup> For communication, (RS-485 communication, communication option), the display increments are 1. For example, "10.00 kWh" is displayed as "10" for communication data.

<sup>\*2</sup> When using the LCD operation panel or the parameter unit, "kW" is displayed

<sup>\*3</sup> The increment differs according to capacities. (FR-F820-02330(55K) or lower, FR-F840-01160(55K) or lower / FR-F820-03160(75K) or higher, FR-F840-01800(75K) or higher.)



- The operation panel and the parameter unit has a 5-digit display. This means, for example, that when a monitor value in 0.01 units exceeds "999.99", the decimal place is moved up as in "1000.0" and the display changes to 0.1 units. The maximum display number is "99999".
- The maximum value for communication (RS-485 communication, communication option) when **Pr.898 Power saving cumulative monitor clear** = "9999" is "65535". The maximum value for the 0.01-unit monitor is "655.35", and the maximum value for the 0.1-unit monitor is "6553.5".


# ◆Power saving real-time monitor ([1 Power saving] and [2 Power saving rate])

- On the [1 Power saving monitor], an energy saving effect as compared to the consumed power during commercial power supply operation (estimated value) is calculated and displays on the main monitor.
- In the following cases, the [1 Power saving monitor] indicates "0".
  - Calculated values of the power saving monitor are negative values.
  - During DC injection brake operation.
  - The motor is not connected (output current monitor is 0A).
- On the [2 Power saving rate monitor], the power saving rate considering the consumed power during the power supply operation (estimated value) as 100% is displayed. **Pr.895 Power saving rate reference value** needs to be set to "0". Energy saving monitor reference (motor capacity)

# ◆Average power saving monitor ([3 Average power saving], [4 Average power saving rate], [5 Average power cost savings])

- The average power saving monitors are displayed by setting a value other than 9999 in **Pr.897 Power saving monitor** average time.
- On the [3 Average power saving monitor], average power saving amount for each average time period s displayed.
- When Pr.897 is set, the average value is updated each time the average time period elapses, with the power-ON or inverter reset as the starting point.

The power savings average value update timing signal (Y92) is inverted every time the average value is updated.




- When Pr.895 Power saving rate reference value the [2 Average power saving rate] for the averaging time period is displayed on the [4 Average power saving rate] monitor.
- When the power cost per 1 kWh power amount is set in Pr.896 Power unit cost, the cost of the saved power ([3
   Average power saving] × Pr.896) is displayed on the [5 Average power cost savings].

GROUP M

## ◆Cumulative energy saving monitors ([6 Power saving amount], [7 Power cost saving], [8 Annual power saving amount], [9 Annual power saving savings]).

- · On the cumulative energy saving cumulative monitors, the monitor data digit can be shifted to the right by the number of Pr.891 Cumulative power monitor digit shifted times. setting. For example, if the cumulative power value is 1278.56 kWh when Pr.891 = "2", the PU/DU display is 12.78 (display in 100 kWh increments) and the communication data is 12. If the maximum value is exceeded when Pr.891 = "0 to 4", the value is clamped at the maximum value, indicating that a digit shift is necessary. If the maximum value is exceeded when Pr.891 = "9999", the value returns to 0, and the counting starts again. In other monitors, the value is clamped at the displayed maximum value.
- The [6 Cumulative power saving amount] monitor (6)] can measure the power during a predetermined period. Measure with the following procedure.
  - 1) Write "9999" or "10" in Pr.898 Power saving cumulative monitor clear.
  - 2) Write "0" in Pr.898 at the measurement start time to clear the power saving cumulative monitor value and start power saving accumulation.
  - 3) Write "1" in Pr.898 at the measurement end time to hold the power saving cumulative monitor value.




## • NOTE

The power saving cumulative monitor value is saved every hour. This means that if the power is turned OFF after less than an hour, when then the power is turned ON again, the previously saved monitor value is displayed, and accumulation starts. (In some cases, the cumulative monitor value may go down.)

## **◆**Estimated power value in commercial power supply operation (Pr.892, Pr.893, Pr.894)

- · Select the pattern for commercial power supply operation from the four patterns of discharge damper control (fan), suction damper control (fan), valve control (pump) and commercial power driving, and set it in Pr.894 Control selection during commercial power-supply operation.
- Set the motor capacity (pump capacity) in Pr.893 Energy saving monitor reference (motor capacity).
- · As shown below, the consumed power ratio (%) during commercial power supply operation is estimated from the rotations per minute ratio for each operation pattern and rating (current output frequency/Pr.3 Base frequency).



#### NOTE:

 In commercial power supply operation, because the rotations per minute cannot rise higher than the power supply frequency, if the output frequency rises to Pr.3 Base frequency or higher, it stays at a constant value.

#### Annual power saving amount and power cost savings (Pr.899)

- When the operation time rate [%] (ratio of time in year that the inverter actually drives the motor) is set in Pr.899, the annual energy saving effect can be estimated.
- When the operation pattern is determined to a certain extent, the estimated value of the annual power saving amount can be calculated by measuring the power saving in a certain measurement period.
- · Refer to the following to set the operation time rate.
  - 1) Estimate the average time of operation per day [h/day].
  - 2)Calculate the number of operation days per year [days/year]. (Average number of operation days per month × 12 months)
  - 3) Calculate the annual operation time [h/year] from 1) and 2).

Annual operation time (h/year) = average time (h/day) 
$$\times$$
 number of operation days (days/year)

4) Calculate the operation time rate and set it in Pr.899.

Operation time rate (%) = 
$$\frac{\text{Annual operation time (h/year)}}{24 \text{ (h/day)} \times 365 \text{ (days/year)}} \times 100 \text{ (%)}$$

#### • NOTE

 Setting example for operation time rate: When operation is performed about 21h per day for an average 16 operation days per month,

Annual operation time = 21 (h/day)  $\times$  16 (days/month)  $\times$  12 months = 4032 (h/year) 4032 (h/year) Operation time rate (%) =  $\frac{100 - (4.7 \text{ Jos/y})}{24 \text{ (h/day)} \times 365 \text{ (days/year)}} \times 100(\%) = \frac{46.03\%}{46.03\%}$ 

Set 46.03% in Pr.899.

· Calculate the annual power saving amount from Pr.899 Operation time rate (estimated value) and the average power saving monitor.

· When the power cost per hour is set in Pr.896 Power unit cost, the annual power cost savings can be monitored.

Annual power cost saving = annual power saving amount (kWh/year) × Pr.896

## NOTE

· During regenerative driving, make calculation on the assumption that "power saving = power during commercial power supply operation (input power = 0)".

#### Parameters referred to

Pr.3 Base frequency page 497

Pr.52 Operation panel main monitor selection page 263

Pr.54 FM/CA terminal function selection page 273

Pr.158 AM terminal function selection page 273

5

#### 5.8.6 **Output terminal function selection**

Use the following parameters to change the functions of the open collector output terminals and relay output terminals.

Pr.	Name		Initial value	Initial set signal	Setting range
190 M400	RUN terminal function selection		0	RUN (Inverter running)	
191 M401	SU terminal function selection	Open	1	SU (Up to frequency)	0 to 5, 7, 8, 10 to 19, 25, 26, 35, 39, 40, 45 to 54, 57, 64 to 68, 70 to 79, 82, 85,
192 M402	IPF terminal function selection	collector	2*1	IPF (Instantaneous power failure/undervoltage)	90 to 96, 98 to 105, 107, 108, 110 to 116, 125, 126, 135, 139, 140, 145 to 154, 157,
WITUZ	Selection	terminal	9999*2	No function	164 to 168, 170 to 179, 182, 185,
193 M403	OL terminal function selection	terrimai	3	OL (Overload warning)	1 190 to 196, 198 to 208, 211 to 213, 215, 300 to 308, 311 to 313, 315
194 M404	FU terminal function selection		4	FU (Output frequency detection)	
195 M405	ABC1 terminal function selection	Relay	99	ALM (Fault)	0 to 5, 7, 8, 10 to 19, 25, 26, 35, 39, 40, 45 to 54, 57, 64 to 68, 70 to 79, 82, 85, 90, 91, 94 to 96, 98 to 105, 107, 108,
196 M406	ABC2 terminal function selection	output terminal	9999	No function	1 110 to 116, 125, 126, 135, 139, 140, 145 to 154, 157, 164 to 168, 170 to 179, 182, 185, 190, 191, 194 to 196, 198 to 208, 211 to 213, 215, 300 to 308, 311 to 313, 315

Pr.	Name	Initial value	Setting range	Description
289	Inverter output terminal	9999	5 to 50 ms	Set the time delay for the output terminal response.
M431	filter	9999	9999	No output terminal filter.

The initial value is for standard models.

## **♦**Output signal list

- The functions of the output terminals can be set.
- Refer to the following table and set each parameter. (0 to 99: Positive logic, 100 to 199: Negative logic)

Set	ting	Signal			Related	Refer
Positive logic	Negative logic	name	Function   Operation		parameter	to page
0	100	RUN	Inverter running	Output during operation when the inverter output frequency reaches <b>Pr.13 Starting frequency</b> or higher.	_	292
1	101	su	Up to frequency *1	Output when the output frequency reaches the set frequency.	Pr.41	294
2	102	IPF	Instantaneous power failure/ undervoltage *2	Output when an instantaneous power failure or undervoltage protection operation occurs.	Pr.57	414, 420
3	103	OL	Overload warning	Output during operation of the stall prevention function.	Pr.22, Pr.23, Pr.66, Pr.148, Pr.149, Pr.154	248
4	104	FU	Output frequency detection	Output when the output frequency reaches the frequency set in <b>Pr.42</b> ( <b>Pr.43</b> during reverse rotation) or higher.	Pr.42, Pr.43	294
5	105	FU2	Second output frequency detection	Output when the output frequency reaches the frequency set in <b>Pr.50</b> or higher.	Pr.50	294
7	107	For man	ufacturer setting. Do not set.			
8	108	THP	Electronic thermal O/L relay pre-alarm	Output when the cumulative electronic thermal O/L relay value reaches 85% of the trip level. (Electronic thermal O/L relay protection (E.THT/E.THM) is activated when the value reaches 100%.)	Pr.9	225
10	110	PU	PU operation mode	Output when PU operation mode is selected.	Pr.79	200

<sup>\*2</sup> The initial value is for separated converter types.

	ting	Signal			Related	Refer
Positive logic	Negative logic	name	Function	Operation	parameter	to page
11	111	RY	Inverter operation ready	Output when the reset process is completed after powering ON the inverter (when starting is possible by switching the start signal ON or during operation).	_	292
12	112	Y12	Output current detection	Output when the output current is higher than the <b>Pr.150</b> setting for the time set in <b>Pr.151</b> or longer.	Pr.150, Pr.151	296
13	113	Y13	Zero current detection	Output when the output current is lower than the <b>Pr.152</b> setting for the time set in <b>Pr.153</b> or longer.	Pr.152, Pr.153	296
14	114	FDN	PID lower limit	Output when the value is lower than the lower limit of PID control.		
15	115	FUP	PID upper limit	Output when the value is higher than the upper limit of PID control.	Pr.127 to Pr.134, Pr.575 to Pr.577	378
16	116	RL	PID forward/reverse rotation output	Output during forward rotation under PID control.		
17	_	MC1	Electronic bypass MC1		D= 425 to D= 420	
18		MC2	Electronic bypass MC2	Used when using the electronic bypass function.	Pr.135 to Pr.139, Pr.159	363
19	_	МС3	Electronic bypass MC3		1.100	
25	125	FAN	Fan fault output	Output when a fan fault occurs.	Pr.244	233
26	126	FIN	Heatsink overheat pre-alarm	Output when the heatsink temperature reaches about 85% of the heatsink overheat protection operation temperature.	_	543
35	135	TU	Torque detection	Output when the motor torque is higher than the <b>Pr.864</b> setting.	Pr.864	298
39	139	Y39	Start time tuning completion	Output when tuning is completed during start-up.	Pr.95, Pr.574	359
40	140	Y40	Trace status	Output during trace operation.	Pr.1020 to Pr.1047	433
45	145	RUN3	Inverter running and start command is ON	Output while the inverter is running and the start command is ON.	_	292
46	146	Y46	During deceleration at occurrence of power failure (retained until release)	Output after the power-failure deceleration function operates. (Retained until canceled.)	Pr.261 to Pr.266	426
47	147	PID	During PID control activated	Output during PID control.	Pr.127 to Pr.134, Pr.575 to Pr.577	378
48	148	Y48	PID deviation limit	Output when the absolute deviation value exceeds the limit value.	Pr.127 to Pr.134, Pr.553, Pr.554	378
49	149	Y49	During pre-charge operation			
50	150	Y50	During second pre-charge operation	Output during pre-charge operation.	Pr.127 to Pr.134,	
51	151	Y51	Pre-charge time over	Output when the pre-charge operation reaches	Pr.241, Pr.553,	
52	152	Y52	Second pre-charge time over	the time limit set in <b>Pr.764</b> or <b>Pr.769</b> .	Pr.554, Pr.575 to Pr.577,	402
53	153	Y53	Pre-charge level over	Output when the measured value before reaching	Pr.753 to Pr.769, C42 to C45	
54	154	Y54	Second pre-charge level over	the ending time during pre-charge operation is higher than the detection level set in <b>Pr.763</b> or <b>Pr.768</b> .	042 (0 045	
57	157	IPM	During PM motor control	Output while the control method is PM motor control.	Pr.71, Pr.80, Pr.998	149
64	164	Y64	Control circuit capacitor life	Output during retry processing.	Pr.65 to Pr.69	236
65	165	Y65	Emergency drive in operation *2	Output during emergency drive operation.	Pr.514, Pr.515,	220
66	166	ALM3	Fault output during emergency drive *2	Output when a fault occurs during emergency drive operation.	Pr.523, Pr.524, Pr.1013	238
67	167	Y67	Power failed signal *3	Output when the power failure time deceleration- to-stop function is activated during output shutoff due to power failure or undervoltage.	Pr.261 to Pr.266	426
68	168	EV	24 V external power supply operation	Output while operating with a 24 V power supply input from an external source.	_	57
70	170	SLEEP	PID output interruption	Output during PID output suspension function operation.	Pr.127 to Pr.134, Pr.575 to Pr.577	378

Set	ting					Refer
	Negative	Signal	Function	Operation	Related	to
logic	logic	name			parameter	page
71	171	RO1	Commercial power supply side motor 1 connection RO1			
72	172	RO2	Commercial power supply side motor 2 connection RO2			
73	173	RO3	Commercial power supply side motor 3 connection RO3			
74	174	RO4	Commercial power supply side motor 4 connection RO4	Output depending on the motor drive conditions when the multi-pump function is used.	Pr.575 to Pr.591	406
75	175	RIO1	Inverter side motor 1 connection RIO1			
76	176	RIO2	Inverter side motor 2 connection RIO2			
77	177	RIO3	Inverter side motor 3 connection RIO3			
78	178	RIO4	Inverter side motor 4 connection RIO4			
79	179	Y79	Pulse train output of output power	Output in pulses every time the accumulated output power of the inverter reaches the <b>Pr.799</b> setting.	Pr.799	303
82	182	Y82	BACnet binary output	Enables output from the Binary Output object for BACnet communication.	Pr.549	480
85	185	Y85	DC current feeding *2	Output when there is a power failure or undervoltage for the AC current.	Pr.30	508
86	186	Y86	Control circuit capacitor life (for FR-A8AY, FR-A8AR) *4	Output when the control circuit capacitor approaches the end of its life.		
87	187	Y87	Main circuit capacitor life (for FR-A8AY, FR-A8AR) *2*4	Output when the main circuit capacitor approaches the end of its life.		
88	188	Y88	Cooling fan life (for FR-A8AY, FR-A8AR) *4	Output when the cooling fan approaches the end of its life.	Pr.255 to Pr.259	180
89	189	Y89	Inrush current limit circuit life (for FR-A8AY, FR-A8AR) *2*4	Output when the inrush current limit circuit approaches the end of its life.	11.200 to 11.200	100
90	190	Y90	Life alarm	Output when any of the control circuit capacitor, main circuit capacitor and inrush current limit circuit or the cooling fan approaches the end of its life.		
91	191	Y91	Fault output 3(power-OFF signal)	Output when an error occurs due to an inverter circuit fault or connection fault.	_	293
92	192	Y92	Energy saving average value updated timing	Switches between ON and OFF each time the average power saving is updated when using the power saving monitor. This cannot be set in <b>Pr.195 or Pr.196</b> , <b>Pr.320 to Pr.322</b> (relay output terminal).	Pr.52, Pr.54, Pr.158, Pr.891 to Pr.899	283
93	193	Y93	Current average monitor signal	Outputs the average current and maintenance timer value as a pulse. This cannot be set in <b>Pr.195</b> or <b>Pr.196</b> , <b>Pr.320</b> to <b>Pr.322</b> (relay output terminal).	Pr.555 to Pr.557	185
94	194	ALM2	Fault output 2	Output when the inverter's protective function is activated to stop the output (at fault occurrence). The signal output continues even during an inverter reset, and the signal output stops after the reset release. *5	_	293
95	195	Y95	Maintenance timer signal	Output when <b>Pr.503</b> reaches the <b>Pr.504</b> setting or higher.	Pr.503, Pr.504	184
96	196	REM	Remote output	Output via terminals when certain parameters are set.	Pr.495 to Pr.497	298
98	198	LF	Alarm	Output when an alarm (fan fault or communication error warning) occurs.	Pr.121, Pr.244	233, 446
99	199	ALM	Fault	Output when the inverter's protective function is activated to stop the output (at fault occurrence). The signal output is stopped after a reset.	_	293

Setting		Cianal			Related	Refer
Positive logic	Negative logic	Signal name	Function	Operation	parameter	to page
200	300	FDN2	Second PID lower limit	Output when the value is lower than the lower limit of second PID control.		
201	301	FUP2	Second PID upper limit	Output when the value is higher than the upper limit of second PID control.	Pr.753 to Pr.758	
202	302	RL2	Second PID forward/reverse rotation output	Output during forward rotation under second PID control.	Pr.753 to Pr.758	378
203	303	PID2	Second During PID control activated	Output during second PID control.		3/0
204	304	SLEEP 2	During second PID output shutoff	Output during second PID output suspension function operation.	Pr.753 to Pr.758, Pr.1147 to Pr.1149	
205	305	Y205	Second PID deviation limit	Output when the absolute deviation value during second PID control exceeds the limit value.	Pr.753 to Pr.758, Pr.1145, Pr.1146	
206	306	Y206	Cooling fan operation command signal	Output when the cooling fan operation is commanded.	Pr.244	233
207	307	Y207	Control circuit temperature signal	Output when the temperature of the control circuit board reaches the detection level or higher.	Pr.663	304
208	308	PS	PU stopped signal	Output while the PU is stopped.	Pr.75	162
211	311	LUP	Upper limit warning detection	Output when the load fault upper limit warning is detected.		
212	312	LDN	Lower limit warning detection	Output when the load fault lower limit warning is detected.	Pr.1480 to Pr.1492	255
213	313	Y213	During load characteristics measurement	Output during measurement of the load characteristics.		
215	315	Y215	During cleaning	Output during operation of the cleaning function.	Pr.1469 to Pr.1479	375
9999	•	_	No function	_	_	_


- Take caution when changing the frequency setting with an analog signal or the setting dial of the operation panel (FR-DU08), because this change speed and the timing of the change speed determined by the acceleration/deceleration time setting may cause the output of the SU (up to frequency) signal to switch repeatedly between ON and OFF. (This repeating does not occur when the acceleration/deceleration time setting is "0 s".)
- \*2 The setting is available only for standard models.
- \*3 This signal cannot be assigned to the output terminals for plug-in options (FR-A8AY, FR-A8AR).
- Available when the plug-in option is connected.
- \*5 When the power is reset, the fault output 2 signal (ALM2) turns OFF at the same time as the power turns OFF.

## • NOTE

- The same function may be set to more than one terminal
- The terminal conducts during function operation when the setting is "0 to 99, 200 to 299", and does not conduct when the setting is "100 to 199, 300 to 399".
- When Pr.76 Fault code output selection = "1", the output signals of terminals SU, IPF, OL and FU operate according to Pr.76 setting. (When the inverter's protective function is activated, the signal output switches to fault code output.)
- The outputs of terminal RUN and the fault output relay are assigned according to the settings above, regardless of Pr.76.
- Changing the terminal assignment using Pr.190 to Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.
- Do not assign signals which repeat frequently between ON and OFF to terminals A1B1C1 or A2B2C2. The life of the relay contacts will be shortened.

#### ◆Adjusting the output terminal response level (Pr.289)


• The response level of the output terminals can be delayed in a range of 5 to 50 ms. (Operation example for the RUN signal.)



#### NOTE:

- When Pr.157 OL signal output timer is set for the Overload warning (OL) signal output, the OL signal is output when the set time of (Pr.157 + Pr.289) elapses.
- For the output signal and the fault code output (on page 300) used in the PLC function (on page 431), the Pr.289 setting is invalid (no filter).

## Inverter operation ready signals (RY signal) and inverter running signals (RUN, RUN3 signals)



- · When the inverter is ready for operation, the Inverter operation ready (RY) signal turns ON (stays ON during operation.)
- · When the inverter output frequency reaches Pr.13 Starting frequency or higher, the Inverter running (RUN) signals turn ON. The signal is OFF while the inverter is stopped and during DC injection brake operation. Inverter
- The Inverter running and start command is ON (RUN3) signal is ON while the inverter is running or the start signal is ON. (When the start command is ON, the RUN3 signal output turns ON even while the inverter's protective function is activated or the MRS is ON.) **During DC** 
  - injection brake operation as well, the output is ON, and when the inverter stops, it turns OFF.
- · According to the inverter condition, the ON/OFF operation of each signal is as shown below.

Output signal	Start signal OFF	Start signal ON	Start injection		Output	shutoff*2		tart after wer failure	
	(during stop)	(during stop)	(running)	brake operation	Start signal ON	Start signal OFF	Start signal ON	Start signal OFF	Restarting
RY*3	ON	ON	ON	ON	OFF		ON*1		ON
RUN	OFF	OFF	ON	OFF	OFF		OFF		ON
RUN3	OFF	ON	ON	ON	ON	OFF	ON	OFF	ON

- OFF during power failure or undervoltage.
- \*2 Output is shutoff in conditions like a fault and when the MRS signal is ON.
- OFF while power is not supplied to the main circuit power supply.


• When using the RY, RUN and RUN3 signals, refer to the following and assign the functions by Pr.190 to Pr.196 (output terminal function selection).

Output signal	Pr.190 to Pr.196 settings						
Output signal	Positive logic	Negative logic					
RY	11	111					
RUN	0	100					
RUN3	45	145					

#### NOTE:

• The RUN signal (positive logic) is assigned to the terminal RUN in the initial status.

#### ◆Fault output signals (ALM, ALM2)



- The Fault (ALM, ALM2) signals are output when the inverter protective function is activated.
- The ALM2 signal stays ON during the reset period after the fault occurs.
- To use the ALM2 signal, set "94 (positive logic) or 194 (negative logic)" in any of Pr.190 to Pr.196 (output terminal function selection) to assign the function to the output terminal.
- · The ALM signal is assigned to the A1B1C1 contacts in the initial

#### NOTE :

• For the inverter fault details, refer to page 535.

#### ◆Input MC shutoff signal (Y91)

- The Fault output 3 (Y91) signal is output when a fault originating in the inverter circuit or a connection fault occurs.
- To use the Y91 signal, set "91 (positive logic) or 191 (negative logic)" in any of Pr.190 to Pr.196 (output terminal function selection) to assign the function to the output terminal.
- The following table shows the faults that output the Y91 signal. (For the fault details, refer to page 535.)

Fault record
Inrush current limit circuit fault (E.IOH)
CPU fault (E.CPU)
CPU fault (E.6)
CPU fault (E.7)
Parameter storage device fault (E.PE)
Parameter storage device fault (E.PE2)
24 VDC power fault (E.P24)
Operation panel power supply short circuit/RS-485 terminals power supply short circuit (E.CTE)
Output side earth (ground) fault overcurrent (E.GF)
Output phase loss (E.LF)
Brake transistor alarm detection (E.BE)
Internal circuit fault (E.13/E.PBT)

#### Parameters referred to


Pr.13 Starting frequency page 197, page 198 Pr.76 Fault code output selection page 302

#### 5.8.7 **Output frequency detection**

The inverter output frequency is detected and output as output signals.

Pr.	Name	Initial	value	Setting range	Description			
FI.	Name	FM CA		Setting range	Description			
41 M441	Up-to-frequency sensitivity	10%		0 to 100%	Set the level where the SU signal turns ON.			
42 M442	Output frequency detection	6 Hz	6 Hz 0 to 590 Hz		Set the frequency where the FU signal turns ON.			
43	Output frequency detection for reverse			0 to 590 Hz	Set the frequency where the FU signal turns ON in reverse rotation.			
M443	rotation			9999	Same as the <b>Pr.42</b> setting.			
50 M444	Second output frequency detection	30 Hz		0 to 590 Hz	Set the frequency where the FU2 signal turns ON.			
870 M400	Speed detection hysteresis	0 Hz		0 to 5 Hz	Set the hysteresis width for the detected frequency.			


#### Output up-to-frequency sensitivity (SU signal, Pr.41)



- Up to frequency (SU) is output when the output frequency reaches the set frequency.
- The **Pr.41** value can be adjusted within the range ±1% to ±100% consindering the set frequency as 100%.
- This parameter can be used to check that the set frequency has been reached, and provide signals such as the operation start signal for related equipment.

#### ◆Output frequency detection (FU signal, FU2 signal, Pr.42, Pr.43, Pr.50)

- · Output frequency detection (FU) is output when the output frequency reaches the Pr.42 setting or higher.
- The FU (FU2) signals can be used for electromagnetic brake operation, opening, etc.
- Frequency detection that is dedicated to reverse rotation can be set by setting the detection frequency in Pr.43. This is useful for changing the timing of the electromagnetic brake operation during forward rotation (lifting) and reverse rotation (lowering) in operations such as lift operation.
- When Pr.43 ≠ "9999", forward rotation uses the Pr.42 setting and reverse rotation uses the Pr.43 setting.
- When outputting a frequency detection signal separately from the FU signal, set the detection frequency in Pr.50. When the output frequency reaches the Pr.50 setting or higher, the FU2 signal is output.




• For each signal, refer to the following table and assign the function by Pr.190 to Pr.196 (output terminal function selection)

Pr.	Output	Pr.190 to Pr.196 settings					
	signal	Positive logic	Negative logic				
42, 43	FU	4	104				
50	FU2	5	105				

## ◆Speed detection hysteresis (Pr.870)

• This function prevents chattering of the speed detection signals. When an output frequency fluctuates, the up to frequency signal (SU) may repeat ON/OFF (chatter).

Setting hysteresis to the detected frequency prevents chattering of these signals.



#### NOTE

- In the initial setting, the FU signal is assigned to the terminal FU, and the SU signal is assigned to the terminal SU.
- · All signals turn OFF during DC injection brake, tuning at start-up.
- · Each signal's reference frequency differs by the control method.

Control method	Compared frequency						
Control method	FU, FU2	SU					
V/F control	Output frequency	Output frequency					
Advanced magnetic flux vector control	Output frequency before the slip compensation	Output frequency before the slip compensation					
PM motor control	Frequency command value	Estimated frequency (actual motor speed)					

- Setting a higher value in Pr.870 slows the response of frequency detection signals (SU).
- Changing the terminal assignment using Pr.190 to Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### Parameters referred to


Pr.190 to Pr.196 (output terminal function selection) page 288

#### 5.8.8 **Output current detection function**

The output current during inverter running can be detected and output to the output terminal.

Pr.	Name	Initial	value	Setting range	Description						
FI.	Name	FM CA		Setting range	Description						
150 M460	Output current detection level	120% 110%		0 to 220%	Set the output current detection level. 100% is the rated inverter current.						
151 M461	Output current detection signal delay time	0 s		0 s		0 s 0 to 10 s		0 to 10 s	Set the output current detection time. Set the time from when the output current reaches the setting or higher until the output current detection (Y12) signal is output.		
152 M462	Zero current detection level	5%		5%		0 to 220%	Set the zero current detection level. The rated inverter current is regarded as 100%.				
153 M463	Zero current detection time	0.5 s		0 to 10 s	Set the time from when the output current drops to the <b>Pr.152</b> setting or lower until the zero current detection (Y13) signal is output.						
166	Output current detection	0.1 s		0 to 10 s	Set the retention time when the Y12 signal is ON.						
M433	signal retention time			9999	Retain the Y12 signal ON status. The signal is turned OFF at the next start.						
167 M464	Output current detection operation selection	0		0, 1, 10, 11	Select the operation when Y12 and Y13 signals turn ON.						


#### ◆Output current detection (Y12 signal, Pr.150, Pr.151, Pr.166, Pr.167)



- The output current detection function can be used for purposes such as overtorque detection.
- If the output during inverter running remains higher than the Pr.150 setting for the time set in Pr.151 or longer, the Output current detection (Y12) signal is output from the inverter's open collector or relay output terminal.
- When the Y12 signal turns ON, the ON state is retained for the time set in Pr.166.
- When Pr.166 = "9999", the ON state is retained until the next start.
- Setting **Pr.167** = "1" while the Y12 signal is ON does not cause E.CDO. The Pr.167 setting becomes valid after the Y12 signal is turned OFF.
- For the Y12 signal, set "12 (positive logic) or 112 (negative logic)" in any of Pr.190 to Pr.196 (output terminal function selection) to assign the function to the output terminal.
- Select whether the inverter output stops or the inverter operation continues when Y12 signal turns ON, by setting Pr.167.

Pr.167 setting	When Y12 signal turns ON	When Y13 signal truns ON
0 (Initial value)	Continuous operation	Continuous operation
1	Inverter trip (E.CDO)	Continuous operation
10	Continuous operation	Inverter trip (E.CDO)
11	Inverter trip (E.CDO)	Inverter trip (E.CDO)

## ◆Zero current detection (Y13 signal, Pr.152, Pr.153)



\* When the output is restored to the Pr.152 level, the Y13 signal is turned OFF after 0.1 s.

- If the output during inverter running remains higher than the Pr.152 setting for the time set in **Pr.153** or longer, the Zero current detection (Y13) signal is output from the inverter's open collector or relay output terminal.
- Once turned ON, the zero current detection time signal (Y13) is held ON for at least 0.1s.
- If the inverter output current drops to "0", because torque is not generated, slippage due to gravity may occur, especially in a lift

To prevent this, the Y13 signal, which closes the mechanical brake at "0" output current, can be output from the inverter.

- For the Y13 signal, set "13 (positive logic) or 113 (negative logic)" in any of Pr.190 to Pr.196 (output terminal function selection) to assign the function to the output terminal.
- Select whether the inverter output stops or the inverter operation continues when Y13 signal turns ON, by setting Pr.167.

## NOTE:

- The signals are enabled even when online or offline auto tuning is being executed.
- The response time of the Y12 and Y13 signals is approximately 0.1 s. Note that the response time varies with the load.
- When Pr.152 = "0", detection is disabled.
- · Changing the terminal assignment using Pr.190 to Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.



#### Caution

- The zero current detection level setting should not be too low, and the zero current detection time setting not too long. When the output current is low and torque is not generated, the detection signal may not be output.
- Even when using the zero current detection signal, a safety backup such as an emergency brake must be provided to prevent hazardous machine or equipment conditions.

#### Parameters referred to

Online auto tuning page 359

Offline auto tuning page 341, page 351


Pr.190 to Pr.196 (output terminal function selection) page 288

## 5.8.9 Output torque detection Magneticifix PM

A signal is output when the motor torque is higher than the setting.

This function can be used for electromagnetic brake operation, open signal, etc.

Pr.	Name	Initial value	Setting range	Description
864 M470	Torque detection	150%	0 to 400%	Set the torque value where the TU signal turns ON.



- The Torque detection (TU) signal turns ON when the output torque reaches the detection torque value set in Pr.864 or higher.
- Pr.864 is not available under V/F control.
- For the TU signal, set "35 (positive logic) or 135 (negative logic)" in one of Pr.190 to Pr.196 (output terminal function selection) to assign the function to the output terminal.



 Changing the terminal assignment using Pr.190 to Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### **«** Parameters referred to »

Pr.190 to Pr.196 (output terminal function selection) page 288

## 5.8.10 Remote output function

The inverter output signals can be turned ON/OFF like the remote output terminals of a programmable controller.

Pr.	Name	Initial value	Setting range	Description			
		Remote output data is cleared with the power supply is turned OFF		Remote output data is cleared when the power supply is turned OFF	Remote output data is cleared during an inverter		
495	Remote output	0	1	Remote output data is retained when the power supply is turned OFF	reset		
M500	selection	O	10	Remote output data is cleared when the power supply is turned OFF	Remote output data is retained during an inverter		
			11	Remote output data is retained when the power supply is turned OFF	reset		
496 M501	Remote output data 1	0	0 to 4095	Set values for the bits corresponding to each output terminal of the inverter output terminal. (Refer to the diagram below.)			
497 M502	Remote output data 2	0	0 to 4095	Set values for the bits corresponding to each output terminal of options FR-A8AY and FR-A8AR. (Refer to the diagram below.)			

#### ◆Remote output setting (REM signal, Pr.496, Pr.497)

#### Pr.496

b11											b0
*1	*	*1	*1	*1	ABC2	ABC1	FU	OL	IPF	SU	RUN


#### Pr.497

b11									b0	
*1	*1	RA3 *3	RA2 *3	RA1 *3	Y6 *2	Y5 *2		Y1 *2	Y0 *2	

- \*1 Any value.
- \*2 Y0 to Y6 are available when the extension output option (FR-A8AY) is installed.
- \*3 RA1 to RA3 are available hen the relay output option (FR-A8AR) is installed.

- The output terminal can be turned ON/OFF with the Pr.496 and Pr.497 settings. ON/OFF control can be performed for the remote output terminal via the PU connector, RS-485 terminals and communication option.
- To assign the Remote output (REM) signal to the terminal to be used for remote output, set "96 (positive logic) or 196 (negative logic)" in any of Pr.190 to Pr.196 (output terminal function selection).
- Refer to the left figure, and set "1" in the terminal bit (terminal with the REM signal assigned) of Pr.496 or Pr.497 to turn ON the output terminal (OFF when using negative logic). Set "0" to turn OFF the output terminal (ON when using negative logic).
- For example, when Pr.190 RUN terminal function selection = "96" (positive logic) and "1" (H01) is set in Pr.496, the terminal RUN turns ON.

#### **◆**Remote output data retention (REM signal, Pr.495)



Signal condition during a reset



\* When **Pr.495** = "1", the signal condition saved in EEPROM (condition of the last power OFF) is applied.

- If the power supply is reset (including a power failure) while
   Pr.495 = "0 (initial value) or 10", t the REM signal output is
   cleared. (The terminal ON/OFF status is determined by the
   settings in Pr.190 to Pr.196.) "0" is also set in Pr.496 and
   Pr.497.
- When Pr.495 = "1 or 11", the remote output data is saved in EEPROM before the power supply is turned OFF. This means that the signal output after power restoration is the same as before the power supply was turned OFF.
   However, when Pr.495 = "1", the data is not saved during an inverter reset (terminal reset, reset request via communication).
- When **Pr.495** = "10 or 11", the signal before the reset is saved even during an inverter reset.

## • NOTE

- The output terminals that have not been assigned with a REM signal by **Pr.190 to Pr.196** do not turn ON/OFF even if "0 or 1" is set in the terminal bits of **Pr.496 and Pr.497**. (ON/OFF is performed with the assigned functions.)
- When **Pr.495** = "1 or 11" (remote output data retention at power OFF), take measures such as connecting R1/L11 with P/+, and S1/L21 with N/- so that the control power is retained. If the control power is not retained, the output signal after turning ON the power is not guaranteed to work. When connecting the high power factor converter (FR-HC2) or the converter unit (FR-CC2), assign the instantaneous power failure detection (X11) signal to an input terminal to input the IPF signal from the FR-HC2/FR-CC2 to the terminal for X11 signal.

#### Parameters referred to

Pr.190 to Pr.196 (output terminal function selection) page 288

GROUP


## 5.8.11 Analog remote output function

An analog value can be output from the analog output terminal.

Pr.	Name	Initial value	Setting range	Description		
			0	Remote output data is cleared when the power supply is turned OFF	Remote output data is cleared during an inverter	
655	Analog remote	0	1	Remote output data is retained when the power supply is turned OFF	reset	
M530	•		10	Remote output data is cleared when the power supply is turned OFF	Remote output data is	
			11	Remote output data is retained when the power supply is turned OFF	retained during an inverter reset	
656 M531	Analog remote output 1	1000%	800 to 1200%	Value output from the terminal set as "87" in terminal function selection (Pr.54, Pr.158)		
657 M532	Analog remote output 2	1000%	800 to 1200%	Value output from the terminal set as "88" in terminal function selection (Pr.54, Pr.158)	Set the analog value for outputting from the analog	
658 M533	100		800 to 1200%	Value output from the terminal set as "89" in terminal function selection (Pr.54, Pr.158)	output terminals FM/CA and AM and option FR-A8AY.	
659 M534	Analog remote output 4	1000%	800 to 1200%	Value output from the terminal set as "90" in terminal function selection (Pr.54, Pr.158)		


#### ◆Analog remote output (Pr.656 to Pr.659)

- The terminals FM/CA, AM and the analog output terminal of the option FR-A8AY can output the values set in **Pr.656** to **Pr.659** (Analog remote output).
- When **Pr.54 FM/CA terminal function selection** = "87, 88, 89, or 90" (remote output), the FM type inverter can output a pulse train from the terminal FM.
- For FM output (**Pr.291 Pulse train I/O selection** = "0 (initial value) or 1"): Terminal FM output [pulses/s] = 1440[Hz] × (analog remote output value 1000)/100 Where the output range is 0 to 2400 pulses/s.
- For high-speed pulse output (**Pr.291 Pulse train I/O selection** = "10, 11, 20, or 21"): Terminal FM output [pulses/s] =  $50K[Hz] \times (analog remote output value 1000)/100$  Where the output range is 0 to 55K pulses/s.




• When **Pr.54 FM/CA terminal function selection** = "87, 88, 89, or 90" (remote output), the CA type inverter can output any analog current from the terminal CA.


• Terminal CA output [mA] = 20 [mA] × (analog remote output value - 1000)/100 Where the output range is 0 to 20 mA.



- When Pr.158 AM terminal function selection = "87, 88, 89, or 90", an analog voltage can be output from the terminal AM.
- Terminal AM output [V] = 10 [V] × (analog remote output value 1000)/100 The output range is -10 V to +10 V regardless of the Pr.290 Monitor negative output selection setting.



#### ◆Analog remote output data retention (Pr.655)



\* When Pr.655 = "1", the signal condition saved in EEPROM (condition of the last power OFF) is applied.

- When the power supply is reset (including a power failure) while Pr.655 Analog remote output selection = "0" (initial value) or 10" and , the remote analog output (Pr.656 to Pr.659) returns to its initial value (1000%).
- When Pr.655 = "1 or 11", the analog remote output data is saved in EEPROM before the power supply is turned OFF. This means that the analog value output after power restoration is the same as before the power supply was turned OFF. However, when Pr.655 = "1", the data is not saved during an inverter reset (terminal reset, reset request via communication).
- When Pr.655 = "10 or 11", the analog output before the reset is saved even during an inverter reset.
- When the setting in Pr.655 is changed, the remote analog output (Pr.656 to Pr.659) returns to its initial value (1000%).

When Pr.655 = "1 or 11" (remote analog output data retention at power OFF), take measures such as connecting R1/L11 with P/+, and S1/L21 with N/- so that the control power is retained (While power is supplied to R/L1, S/L2 and T/L3). If the control power is not retained, the analog output after turning ON the power is not guaranteed to work. When connecting the high power factor converter FR-HC2, assign the instantaneous power failure detection (X11) signal to an input terminal to input the IPF signal from the FR-HC2 to the terminal for X11 signal.

#### Parameters referred to

Pr.54 FM/CA terminal function selection page 273 Pr.158 AM terminal function selection page 273 Pr.290 Monitor negative output selection page 273 Pr.291 Pulse train I/O selection page 273

M

#### 5.8.12 **Fault code output selection**

When a fault occurs, the corresponding data can be output as a 4-bit digital signal using via an open collector output terminal.

The fault code can be read using an input module of programmable controller, etc.

Pr.	Name	Initial value	Setting range	Description
			0	Without fault code output
76 M510	Fault code output selection	0	1	With fault code output (Refer to the table below.)
M510			2	Fault code is output only when a fault occurs. (Refer to the table below.)

- Fault codes can be output to the output terminals by setting Pr.76 Fault code output selection = "1 or 2".
- · When the setting is "2", a fault code is only output when a fault occurs. In normal operation the terminal outputs the signal assigned in Pr.191 to Pr.194 (output terminal function selection).
- The fault codes that can be output are shown in the table below. (0: Output transistor OFF, 1: Output transistor ON)

Operation panel	C	Output termi	nal operatio	n	Fault code
indication (FR-DU08)	SU	IPF	OL	FU	rault code
Normal *1	0	0	0	0	0
E.OC1	0	0	0	1	1
E.OC2	0	0	1	0	2
E.OC3	0	0	1	1	3
E.OV1 to E.OV3	0	1	0	0	4
E.THM	0	1	0	1	5
E.THT	0	1	1	0	6
E.IPF	0	1	1	1	7
E.UVT	1	0	0	0	8
E.FIN	1	0	0	1	9
E.BE	1	0	1	0	Α
E. GF	1	0	1	1	В
E.OHT	1	1	0	0	С
E.OLT	1	1	0	1	D
E.OPT E.OP1	1	1	1	0	Е
Other than the above	1	1	1	1	F

<sup>\*1</sup> When Pr.76 = "2", the terminal outputs the signal assigned by Pr.191 to Pr.194.



• If an error occurs while Pr.76 ≠ "0", the output terminals SU, IPF, OL, and FU output the signals in the table above regardless of the settings in Pr.191 to Pr.194 (output terminal function selection). Take caution when controlling the inverter with the output signals set by Pr.191 to Pr.194.

#### Parameters referred to >>>

Pr.190 to Pr.196 (output terminal function selection) page 288


#### 5.8.13 Pulse train output of output power

After power ON or inverter reset, output signal (Y79 signal) is output in pulses every time accumulated output power, which is counted after the Pr.799 Pulse increment setting for output power is set, reaches the specified value (or its integral multiples).

	Pr.	Name	Initial value	Setting range	Description
79 M	9 520	Pulse increment setting for output power	1 kWh	0.1 kWh, 1 kWh, 10 kWh, 100 kWh, 1000 kWh	Pulse train output of output power (Y79) is output in pulses at every output power (kWh) that is specified.

#### **◆Pulse increment setting for output power (Y79 signal, Pr.799)**

- · After power ON or inverter reset, output signal (Y79 signal) is output in pulses every time accumulated output power of the inverter exceeds Pr.799 Pulse increment setting for output power.
- · The inverter continues to count the output power at retry function or when automatic restart after instantaneous power failure function works without power OFF of output power (power failure that is too short to cause an inverter reset), and it does not reset the count.
- · If power failure occurs, output power is counted from 0kWh again.
- Assign pulse output of output power (Y79: setting value 79 (positive logic), 179 (negative logic)) to any of Pr.190 to Pr.196 (Output terminal function selection).



## NOTE

- Because the accumulated data in the inverter is cleared when control power is lost by power failure or at an inverter reset, the value on the monitor cannot be used to charge electricity bill.
- · Changing the terminal assignment using Pr. 190 to Pr. 196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal. (Refer to page 288)
- In an application where the pulse outputs are frequently turned ON/OFF, do not assign the signal to the terminal ABC1 or

Otherwise, the life of the relay contact decreases.

#### # Parameters referred to

Pr.190 to Pr.196 (output terminal function selection) \* page 288

#### 5.8.14 **Detection of control circuit temperature**

The temperature of the control circuit board can be monitored, and a signal can be output according to a predetermined temperature setting.

Pr.	Name	Initial value	Setting range	Description
663 M060	Control circuit temperature signal output level	0°C	0 to 100°C	Set the temperature where the Y207 signal turns ON.

#### Control circuit temperature monitor

- The operation panel, terminal FM/CA, or terminal AM can be used to monitor the temperature of the control circuit board within the range of 0 to 100°C.
- When monitoring with the operation panel or terminal AM, the range becomes -20 to 100°C by setting the display/output with a minus sign in Pr.290 Monitor negative output selection.

#### **◆**Control circuit temperature detection (Pr.663, Y207 signal)

- The Y207 signal can be output when the control circuit temperature reaches the Pr.663 setting or higher.
- For the Y207 signal, set "207 (positive logic) or 307 (negative logic)" in one of Pr.190 to Pr.196 (output terminal function selection) to assign the function to the output terminal.



- The Y207 signal is turned OFF when the control circuit temperature becomes 5°C or more lower than the Pr.663 setting.
- · Changing the terminal assignment using Pr.190 to Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### Parameters referred to >>>

Pr.54 FM/CA terminal function selection page 273 Pr.158 AM terminal function selection page 273

Pr.190 to Pr.196 (output terminal function selection) Pr.190 to Pr.196 (output terminal function selection)

Pr.290 Monitor negative output selection page 273

## 5

# **5.9** (T) Multi-Function Input Terminal Parameters

Purpose	Pa	rameter to set		Refer to page
To inverse the rotation direction with the voltage/current analog input selection (terminals 1, 2, and 4)	Analog input selection	P.T000, P.T001	Pr.73, Pr.267	306
To assign functions to analog input terminals	Terminal 1 and terminal 4 function assignment	P.T010, P.T040	Pr.858, Pr.868	310
To adjust the main speed by the analog auxiliary input	Analog auxiliary input and compensation (addition compensation and override functions)	P.T021, P.T031, P.T050, P.T051	Pr.73, Pr.242, Pr.243, Pr.252, Pr.253	311
To eliminate noise on analog inputs	Analog input filter	P.T002, P.T003, P.T005, P.T007	Pr.74, Pr.822, Pr.832, Pr.849	313
To adjust analog input frequency/ voltage (current) (calibration)	Frequency setting voltage (current) bias and gain	P.T100 to P.T103, P.T200 to P.T203, P.T400 to P.T403, P.M043	Pr.125, Pr.126, Pr.241, C2 to C7 (Pr.902 to Pr.905), C12 to C15 (Pr.917 to Pr.918)	314
To adjust voltage (current) of stall prevention operation level (calibration)	Stall prevention operation level setting voltage (current) bias and gain	P.T110 to P.T113, P.T410 to P.T413, P.M043	Pr.241, C16 to C19 (Pr.919 to Pr.920), C38 to C41 (Pr.932 to Pr.933)	320
To continue operating at analog current input loss	4-mA input check	P.T052 to P.T054	Pr.573, Pr.777, Pr.778	325
To assign functions to input terminals	Input terminal function selection	P.T700 to P.T711, P.T740	Pr.178 to Pr.189, Pr.699	329
	Output stop signal (MRS) input selection	P.T720	Pr.17	332
To change the input specification (NO/NC contact) of input signals	Inverter run enable signal (X10) input selection	P.T721	Pr.599	510
(110/110 contact) of hiput signals	Power failure stop external signal (X48) input selection	P.T722	Pr.606	429
To enable the second function only during the constant speed	RT signal application period selection	P.T730	Pr.155	333
To assign start and forward/ reverse commands to different signals	Start signal (STF/STR) operation selection	P.G106	Pr.250	335


## 5.9.1 Analog input selection

The functions to switch the analog input terminal specifications, override function, forward/reverse rotation by the input signal polarity are selectable.

Pr.	Name	Initial value	Setting range		Description	
73	Analog input coloction	1	0 to 5, 10 to 15	Switch 1 - OFF (initial status)	The terminal 2 input specification (0 to 5 V, 0 to 10 V, 0 to 20 mA) and terminal 1 input specification (0 to ±5 V, 0 to ±10	
Т000	Analog input selection	1	6, 7, 16, 17	Switch 1 - ON	V) are selectable. Also the override and reversible operation settings are selectable.	
267	Terminal 4 input	0	0	Switch 2 - ON (initial status)	Terminal 4 input, 4 to 20 mA	
T001	selection		1	Cuitab 2 OFF	Terminal 4 input, 0 to 5 V	
			2	Switch 2 - OFF	Terminal 4 input, 0 to 10 V	

#### Analog input specification selection

• Concerning the terminals 2 and 4 used for analog input, the voltage input (0 to 5 V, 0 to 10 V) and current input (0 to 20 mA) are selectable. To change the input specification, change the parameters (Pr.73, Pr.267) and voltage/current input switch settings (switches 1, 2).



Switch 1: Terminal 2 input

ON: Current input

OFF: Voltage input (initial status)

Switch 2: Terminal 4 input

ON: Current input (initial status)

OFF: Voltage input

- The terminal 2/4 rating specifications change depending on the voltage/current input switch settings. Voltage input: input resistance 10 k $\Omega$  ±1 k $\Omega$ , permissible maximum voltage 20 VDC Current input: input resistance 245  $\Omega$  ±5  $\Omega$ , permissible maximum current 30 mA
- Correctly set **Pr.73**, **Pr.267** and voltage/current input switch settings so that the analog signal appropriate for the settings is input. The incorrect settings shown in the table below cause a failure. Other incorrect settings result in an incorrect operation.

Setting causing a failure			
Switch setting	Terminal input	Operation	
ON (current input) Voltage input		Causes an analog signal output circuit failure in an external device (due to increased loads on the signal output circuit of the external device).	
OFF (voltage input) Current input		Causes an input circuit failure in the inverter (due to an increased output power in the analog signal output circuit of an external device).	



 Check the voltage/current input switch number indication before setting, because it is different from the FR-F700(P) series switch number indication.

•	Set the Pr.73 and voltage/current input switch settings according to the table below. (	indicates the main
	speed setting.)	


Pr.73 setting	Terminal 2 input	Switch 1	Terminal 1 input	Compensation input terminal compensation method	Polarity reversible
0	0 to 10 V	OFF	0 to ±10 V		
1 (initial value)	0 to 5 V	OFF	0 to ±10 V	Terminal 1	
2	0 to 10 V	OFF	0 to ±5 V	Addition compensation	Not applied
3	0 to 5 V	OFF	0 to ±5 V	]	(state in which a negative
4	0 to 10 V	OFF	0 to ±10 V	Terminal 2	polarity frequency command signal is not accepted)
5	0 to 5 V	OFF	0 to ±5 V	Override	
6	0 to 20 mA	ON	0 to ±10 V		
7	0 to 20 mA	ON	0 to ±5 V	1	
10	0 to 10 V	OFF	0 to ±10 V	Terminal 1	
11	0 to 5 V	OFF	0 to ±10 V	Addition compensation	
12	0 to 10 V	OFF	0 to ±5 V	1	- Applied
13	0 to 5 V	OFF	0 to ±5 V	1	
14	0 to 10 V	OFF	0 to ±10 V	Terminal 2	
15	0 to 5 V	OFF	0 to ±5 V	Override	
16	0 to 20 mA	ON	0 to ±10 V	Terminal 1	1
17	0 to 20 mA	ON	0 to ±5 V	Addition compensation	

- Turning the Terminal 4 input selection(AU) signal ON sets terminal 4 to the main speed. With this setting, the main speed setting terminal is invalidated.
- Set the Pr.267 and voltage/current input switch setting according to the table below.


Pr.267 setting	Terminal 4 input	Switch 2
0 (initial value)	4 to 20 mA	ON
1	0 to 5 V	OFF
2	0 to 10 V	OFF

## • NOTE


- To enable the terminal 4, turn the AU signal ON.
- Set the parameters and the switch settings so that they agree. Incorrect setting may cause a fault, failure or malfunction.
- Terminal 1 (frequency setting auxiliary input) is added to the terminal 2 or 4 main speed setting signal.
- When the override setting is selected, terminal 1 or 4 is set to the main speed setting, and terminal 2 is set to the override signal (0 to 5 V or 0 to 10 V, and 50% to 150%). (If the main speed of terminal 1 or 4 is not input, the compensation by terminal 2 is disabled.)
- Use Pr.125 (Pr.126) (frequency setting gain) to change the maximum output frequency at the input of the maximum output frequency command voltage (current). At this time, the command voltage (current) need not be input. The acceleration/deceleration time inclines up/down to the acceleration/deceleration reference frequency, so it is not affected by change of Pr.73.
- When Pr.858 Terminal 4 function assignment and Pr.868 Terminal 1 function assignment = "4", the terminal 1 and terminal 4 values are set to the stall prevention operation level.
- After the voltage/current input signal is switched with Pr.73, Pr.267, and voltage/current input switches, be sure to let
- When Pr.561 PTC thermistor protection level ≠ "9999", terminal 2 does not function as an analog frequency command.



Connection diagram using terminal 2 (0 to 5 VDC)



Connection diagram using terminal 2 (0 to 10 VDC)



Connection diagram using terminal 4 (0 to 5 VDC)

#### **◆**To run with an analog input voltage


- Concerning the frequency setting signal, input 0 to 5 VDC (or 0 to 10 VDC) to terminals 2 and 5. The 5 V (10 V) input is the maximum output frequency.
- The power supply 5 V (10 V) can be input by either using the internal power supply or preparing an external power supply. The internal power source is 5 VDC output between terminals 10 and 5, and 10 VDC output between terminals 10E and 5.

Terminal	Inverter internal power source voltage	Frequency setting resolution	Pr.73 (terminal 2 input voltage)
10	5 VDC	0.030 Hz/60 Hz	0 to 5 VDC input
10E	10 VDC	0.015 Hz/60 Hz	0 to 10 VDC input


- To supply the 10 VDC input to terminal 2, set "0, 2, 4, 10, 12, or 14" in **Pr.73**. (The initial value is 0 to 5 V.)
- Setting "1 (0 to 5 VDC)" or "2 (0 to 10 VDC)" in Pr.267 and turning the voltage/ current input switches OFF sets the terminal 4 to the voltage input specification. Turning ON the AU signal activates terminal 4 input.




• The wiring length of the terminal 10, 2, 5 should be 30 m at maximum.



#### Connection diagram using terminal 4 (4 to 20mADC)



Connection diagram using terminal 2 (4 to 20mADC)



**Compensation input characteristics** when STF is ON

#### Running with analog input current

- · For constant pressure or temperature control with fans, pumps, or other devices, automatic operation is available by setting the regulator output signal 4 to 20 mADC to between terminals 4 and 5.
- To use the terminal 4, the AU signal needs to be turned ON.

• Setting "6, 7, 16, or 17" in Pr.73 and turning the voltage/current input switches ON sets terminal 2 to the current input specification. Concerning the settings, the AU signal does not need to be turned ON.

## **◆**To perform forward/reverse rotation with the analog input (polarity reversible operation)

- Setting Pr.73 to a value of "10 to 17" enables the polarity reversible operation.
- Setting ±input (0 to ±5 V or 0 to ±10 V) to the terminal 1 allows the operation of forward/reverse rotation by the polarity.

#### Parameters referred to

Pr.22 Stall prevention operation level page 248

Pr.125 Terminal 2 frequency setting gain frequency, Pr.126 Terminal 4 frequency setting gain frequency Terminal 9 frequency setting gain frequency

Pr.252, Pr.253 override bias/gain page 311

Pr.561 PTC thermistor protection level page 225

Pr.858 Terminal 4 function assignment, Pr.868 Terminal 1 function assignment page 310

#### 5.9.2 Analog input terminal (terminal 1, 4) function assignment

The analog input terminal 1 and terminal 4 functions are set and changeable with parameters.

Pr.	Name	Initial value	Setting range	Description
868 T010	Terminal 1 function assignment	0	0, 4, 9999	Select the terminal 1 function (Refer to the table below.)
858 T040	Terminal 4 function assignment	0	0, 4, 9999	Select the terminal 4 function (Refer to the table below.)

· Concerning terminal 1 and terminal 4 used for analog input, the frequency (speed) command, stall prevention operation level input, and other similar commands are usable. The functions available are different depending on Pr.868 Terminal 1 function assignment, Pr.858 Terminal 4 function assignment as shown in the table below.

Setting value	Terminal 1 function (Pr.868)	Terminal 4 function (Pr.858)
0 (initial value)	Frequency setting auxiliary	Frequency command (AU signal-ON)
4	Stall prevention operation level input	Stall prevention operation level input *1
9999	_	_

<sup>—:</sup> No function

<sup>\*1</sup> Invalid when **Pr.868** = "4"



• When Pr.868 = "4" (stall prevention), the terminal 4 function is enabled whether the AU terminal is turned ON/OFF.


## **D**

## 5.9.3 Analog input compensation

Addition compensation or fixed ratio analog compensation (override) with terminal 2 set to auxiliary input is applicable to the multi-speed operation or terminal 2/terminal 4 speed setting signal (main speed).

Pr.	Name	Initial value	Setting range	Description
73 T000	Analog input selection	1	0 to 3, 6, 7, 10 to 13, 16, 17	Addition compensation
			4, 5, 14, 15	Override compensation
242 T021	Terminal 1 added compensation amount (terminal 2)	100%	0 to 100%	Set the percentage of addition compensation when terminal 2 is set to the main speed.
243 T041	Terminal 1 added compensation amount (terminal 4)	75%	0 to 100%	Set the percentage of addition compensation when terminal 4 is set to the main speed.
252 T050	Override bias	50%	0 to 200%	Set the percentage of override function bias side compensation.
253 T051	Override gain	150%	0 to 200%	Set the percentage of override function gain side compensation.


#### ◆Addition compensation (Pr.242, Pr.243)



Example of addition compensation connection

- A compensation signal is addable to the main speed setting for such as synchronous or continuous speed control operation.
- Setting a value of "0 to 3, 6, 7, 10 to 13, 16, and 17" to **Pr.73** adds the voltage between terminals 1 and 5 to the voltage signal of the terminals 2 and 5.
- When **Pr.73**= "0 to 3, 6, or 7", and if the result of addition is negative, it is regarded as 0 and the operation is stopped. When **Pr.73** = "10 to 13, 16, or 17", the operation is reversed (polarity reversible operation) with STF signal ON.
- The terminal 1 compensation input is addable to the multi-speed setting or terminal 4 (initial value: 4 to 20 mA).
- The degree of addition compensation to terminal 2 is adjustable with Pr.242.
   The degree of addition compensation to terminal 4 is adjustable with Pr.243.


Analog command value with use of terminal 2 = terminal 2 input + terminal 1 input  $\times$   $\frac{\text{Pr.242}}{100 \text{ (\%)}}$ Analog command value with use of terminal 4 input + terminal 1 input  $\times$   $\frac{\text{Pr.243}}{100 \text{ (\%)}}$ 



## NOTE

 After changing the Pr.73 setting, check the voltage/current input switch setting. Incorrect setting may cause a fault, failure or malfunction. (For the settings, refer to page 306.)

#### **♦**Override function (Pr.252, Pr.253)




Connection example for the override function


- Use the override function to make the main speed changed at a specified rate.
- Set Pr.73 = "4, 5, 14, or 15" to select the override function.
- When the override function is selected, terminal 1 or 4 is used for the main speed setting, and terminal 2 is used for the override signal. (if the main speed is not input to the terminal 1 or 4, the compensation by terminal 2 is disabled.)
- · Specify the scope of override by using Pr.252 and Pr.253.
- · How to calculate the set frequency for override:

Set frequency (Hz) = main speed setting frequency (Hz)  $\times \frac{\text{compensation (\%)}}{100 \ (\%)}$ 

Main speed setting frequency (Hz): Terminals 1 or 4 input, multi-speed setting Compensation (%): Terminal 2 input



Example) When Pr.73 = "5"
 By the terminal 1 (main speed) and terminal 2 (auxiliary) input, the setting frequency is set as shown in the figure below.



#### • NOTE

- To use terminal 4, the AU signal needs to be turned ON.
- To make compensation input for the multi-speed operation or remote setting, set **Pr.28 Multi-speed input compensation** selection = "1" (with compensation) (initial value "0").
- After changing the **Pr.73** setting, check the voltage/current input switch setting. Incorrect setting may cause a fault, failure or malfunction. (For the settings, refer to **page 306**.)

#### Parameters referred to

Pr.28 Multi-speed input compensation selection page 222

Pr.73 Analog input selection page 306

## 5

# 5.9.4 Analog input responsiveness and noise elimination

The frequency command responsiveness and stability are adjustable by using the analog input (terminals 1, 2, and 4) signal.

Pr.	Name	Initial value	Setting range	Description
74 T002	Input filter time constant	1	0 to 8	The primary delay filter time constant to the analog input is selectable. The higher the value, the lower the responsiveness.
822 T003	Speed setting filter 1	9999	0 to 5 s	Set the primary delay filter time constant to the external speed command (analog input command).
			9999	Use the <b>Pr.74</b> setting.
832 T005	Speed setting filter 2	9999	0 to 5 s, 9999	Second function of <b>Pr.822</b> (enabled when the RT signal is ON)
849 T007	Analog input offset adjustment	100%	0 to 200%	Make the analog speed input (terminal 2) have an offset. This prevents the motor from rotating by noise to the analog input or another cause on the speed 0 command.

#### ◆Analog input time constant (Pr.74)

- · It is effective to eliminate noise on the frequency setting circuit.
- Increase the filter time constant if steady operation cannot be performed due to noise, etc.
   A larger setting results in slower response. (The time constant can be between 0 and 8, which are about 5 ms to 1 s.)

#### ◆Analog speed command input time constant (Pr.822, Pr.832)

- Set the primary delay filter time constant to the external speed command (analog input command) by using **Pr.822 Speed** setting filter 1.
- To change the time constant, for example, in a case where only one inverter is used to switch between more than one motor, use **Pr.832 Speed setting filter 2**.
- Pr.832 Speed setting filter 2 is enabled when the RT signal is ON.

## ◆Analog speed command input offset adjustment (Pr.849)

- This is used to set a range in which the motor is stopped for prevention of incorrect motor operation in a very low speed rotation by the analog input speed command.
- Regarding the Pr.849 Analog input offset adjustment value 100% is 0, the offset voltage is set as described below:


100% < **Pr.849** ...... Positive side

100% > **Pr.849** ...... Negative side

The detailed calculation of the offset voltage is as described below:

Offset voltage [V] = Voltage at the time of 100% (5 V or 10 V\*1)  $\times$  (Pr.849 - 100)/100

\*1 It depends on the Pr.73 setting.



• Under PID control, the analog input filter is invalid (no filter).

#### Parameters referred to

Pr.73 Analog input selection page 306

Pr.125, C2 to C4 (bias and gain of the terminal 2 frequency setting) page 314

#### 5.9.5 Frequency setting voltage (current) bias and gain

The degree (incline) of the output frequency to the frequency setting signal (0 to 5 VDC, 0 to 10 V or 4 to 20 mA) is selectable to a desired amount.

Use Pr.73 Analog input selection, Pr.267 Terminal 4 input selection, or the voltage/current input switch to switch among input 0 to 5 VDC, 0 to 10 V, and 4 to 20 mA. (Refer to page 306)

Pr.	Name	Initial value Setting		Description		
Pr.	Name	FM	CA	range		Description
C2 (902)*1 T200	Terminal 2 frequency setting bias frequency	0 Hz		0 to 590 Hz	Set the termina	al 2 input bias side frequency.
C3 (902)*1 T201	Terminal 2 frequency setting bias	0%		0 to 300%		rted % on the bias side voltage e terminal 2 input.
125 (903)*1 T202 T022	Terminal 2 frequency setting gain frequency	60 Hz	50 Hz	0 to 590 Hz	Set the termina frequency.	al 2 input gain (maximum)
C4 (903)*1 T203	Terminal 2 frequency setting gain	100%		0 to 300%		rted % on the gain side voltage e terminal 2 input.
C5 (904)*1 T400	Terminal 4 frequency setting bias frequency	0 Hz		0 to 590 Hz	Set the termina	al 4 input bias side frequency.
C6 (904)*1 T401	Terminal 4 frequency setting bias	20%		0 to 300%	Set the conver (voltage) of ter	rted % on the bias side current rminal 4 input.
126 (905)*1 T402 T042	Terminal 4 frequency setting gain frequency	60 Hz	50 Hz	0 to 590 Hz	Set the termina frequency.	al 4 input gain (maximum)
C7 (905)*1 T403	Terminal 4 frequency setting gain	100%		0 to 300%	Set the conver (voltage) of ter	rted % on gain side current rminal 4 input.
C12 (917)*1 T100	Terminal 1 bias frequency (speed)	0 Hz		0 to 590 Hz	Set the termina (speed). (spee	al 1 input bias side frequency ed limit)
C13 (917)*1 T101	Terminal 1 bias (speed)	0%		0 to 300%		rted % on bias side voltage of ut. (speed limit)
C14 (918)*1 T102	Terminal 1 gain frequency (speed)	60 Hz	50 Hz	0 to 590 Hz		al 1 input gain (maximum) eed). (speed limit)
C15 (918)*1 T103	Terminal 1 gain (speed)	100% 0 to 300% Set the converted % on the terminal 1 input. (speed line)		rted % on the gain side voltage of ut. (speed limit)		
241 M043	Analog input display unit switchover	0		0	% display V/mA display	Select the unit for analog input display

<sup>\*1</sup> The parameter number in parentheses is the one for use with the LCD operation panel and the parameter unit.

## ◆Relationship between the analog input terminal function and the calibration parameter

• Calibration parameter according to the terminal 1 function

Pr.868	Terminal function	Calibration parameter				
Setting	Terminal function	Bias setting	Gain setting			
0 (initial value)	Frequency (speed) setting auxiliary	C2 (Pr.902) Terminal 2 frequency setting bias frequency C3 (Pr.902) Terminal 2 frequency setting bias C5 (Pr.904) Terminal 4 frequency setting bias frequency C6 (Pr.904) Terminal 4 frequency setting bias	Pr.125 Terminal 2 frequency setting gain frequency C4 (Pr.903) Terminal 2 frequency setting gain Pr.126 Terminal 4 frequency setting gain frequency C7 (Pr.905) Terminal 4 frequency setting gain			
4	Stall prevention operation level*1 /torque limit	C16 (Pr.919) Terminal 1 bias command (torque) C17 (Pr.919) Terminal 1 bias (torque)	C18 (Pr.920) Terminal 1 gain command (torque) C19 (Pr.920) Terminal 1 gain (torque)			
9999	No function	_	_			

· Calibration parameter according to the terminal 4 function

Pr.858	Terminal function	Calibration parameter			
setting	Terminal function	Bias setting	Gain setting		
0 (initial value)	Frequency command	C5 (Pr.904) Terminal 4 frequency setting bias frequency C6 (Pr.904) Terminal 4 frequency setting bias	Pr.126 Terminal 4 frequency setting gain frequency C7 (Pr.905) Terminal 4 frequency setting gain		
4	Stall prevention operation level *1 /torque limit	C38 (Pr.932) Terminal 4 bias command (torque) C39 (Pr.932) Terminal 4 bias (torque)	C40 (Pr.933) Terminal 4 gain command (torque) C41 (Pr.933) Terminal 4 gain (torque)		
9999	No function	_	_		


<sup>\*1</sup> Use Pr.148 Stall prevention level at 0 V input and Pr.149 Stall prevention level at 10 V input to adjust the bias and gain for stall prevention operation level under V/F control and Advanced magnetic flux vector control.

## **◆**To change the frequency for the maximum analog input (Pr.125, Pr.126)

• To change only the frequency setting (gain) for the maximum analog input voltage (current), set Pr.125 (Pr.126). (C2 (Pr.902) to C7 (Pr.905) settings do not need to be changed.)

# ◆Analog input bias/gain calibration (C2 (Pr.902) to C7 (Pr.905), C12 (Pr.917) to C15 (Pr.918))

- The "bias" and "gain" functions serve to adjust the relationship between a setting input signal and the output frequency. A setting input signal is such as 0 to 5 VDC/0 to 10 V or 4 to 20 mADC externally input to set the output frequency.
- Set the terminal 2 input bias frequency by using C2 (Pr.902). (It is initially set to the frequency at 0 V.)
- Set the output frequency to the frequency command voltage (current) set by the **Pr.73 Analog input selection** by using **Pr.125**.
- Set the bias frequency of the terminal 1 input using C12 (Pr.917). (It is initially set to the frequency at 0 V.)
- Set the gain frequency of the terminal 1 input using C14 (Pr.918). (It is initially set to the frequency at 10 V.)
- Set the bias frequency of the terminal 4 input using C5 (Pr.904). (It is initially set to the frequency at 4 mA.)
- Set the output frequency for 20 mA of the frequency command current (4 to 20 mA) by using Pr.126.



- There are three methods to adjust the frequency setting voltage (current) bias/gain.
  - Adjust any point with application of a voltage (current) between terminals 2 and 5 (4 and 5). Fage 317
  - Adjust any point without application of a voltage (current) between terminals 2 and 5 (4 and 5). Fage 318
  - Adjust frequency only without adjustment of voltage (current). Tpage 319

## • NOTE

- Performing terminal 2 calibration that includes a change of the setting frequency incline changes terminal 1 setting.
- Calibration with voltage input to terminal 1 sets (terminal 2 (4) analog value + terminal 1 analog value) as the analog calibration value.
- Always calibrate the input after changing the voltage/current input signal with Pr.73, Pr.267, and the voltage/current input selection switch.

## ◆Analog input display unit changing (Pr.241)

- The analog input display unit (%/V/mA) for analog input bias and gain calibration can be changed.
- Depending on the terminal input specification set to **Pr.73**, **Pr.267**, and voltage/current input switches, the display unit of **C3** (**Pr.902**), **C4** (**Pr.903**), **C6** (**Pr.904**), and **C7** (**Pr.905**) change as described below:

Analog command (terminals 2, 4) (depending on Pr.73, Pr.267, and voltage/current input switch)	Pr.241 = 0 (initial value)	Pr.241 = 1
0 to 5 V input	0 to 5 V $\rightarrow$ 0 to 100% (0.1%)	0 to 100% $\rightarrow$ 0 to 5 V (0.01 V)
0 to 10 V input	0 to 10 V → 0 to 100% (0.1%)	0 to 100% $\rightarrow$ 0 to 5 V (0.01 V) display
0 to 20 mA input	0 to 20 mA $\rightarrow$ 0 to 100% (0.1%)	0 to 100% $\rightarrow$ 0 to 20 mA (0.01 mA)

## • NOTE

• When the terminal 1 input specification (0 to ±5 V, 0 to ±10 V) does not agree with the main speed (terminal 2, terminal 4 input) specification (0 to 5 V, 0 to 10 V, 0 to 20 mA), and if the voltages are applied to terminal 1, the analog input is not correctly displayed. (For example, in the initial status, when 0 V is applied to terminal 2 and 10 V is applied to terminal 1, and the analog value is displayed as 5 V (100%).)

Use the inverter with the Pr.241 = "0 (initial value)" setting. (0% display).

### ◆Frequency setting voltage (current) bias/gain adjustment method

(a) Adjust any point with application of a voltage (current) between terminals 2 and 5 (4 and 5). (Frequency setting gain adjustment example)

	Operation ———		
1.	Screen at power-ON		
	The monitor display appears.		
	Changing the operation mode		
2.	Press PU to choose the PU operation mode. [PU] indicator is on.		
	Calibration is also possible in the External operation mode.		
	Parameter setting mode		
3.	Press MODE to choose the parameter setting mode. (The parameter number read previously appears.)		
	Calibration parameter selection		
4.	Turn until [ appears. Press SET to display [		
	Selecting the parameter number		
5.	Turn to choose C4 C4(Pr.903) Terminal 2 frequency setting gain for the terminal 1.		
	and C7(Pr.905) Terminal 4 frequency setting gain for the terminal 4.		
	Analog voltage (current) display		
6.	Press SET to display the analog voltage (current) % currently applied to the terminal 1 (4).		
	Do not touch until calibration is completed.		
	Voltage (current) application		
7.	Apply a 5 V (20 mA) . (Turn the external potentiometer connected across terminals 1 and 5 (terminals 4 and 5) to a desired		
	position.)		
	Setting completed		
	Press set to enter the setting. The analog voltage (current) % and [		
8.	Press to read another parameter.		
	• Press SET to return to the ☐ display.		
	Press  twice to show the next parameter.		

#### (T) Multi-Function Input Terminal Parameters

(b) Adjust any point without application of a voltage (current) between terminals 2 and 5 (4 and 5). (Frequency setting gain adjustment example)

	Operation ———			
1.	Screen at power-ON			
١.	The monitor display appears.			
	Changing the operation mode			
2.	Press PU to choose the PU operation mode. [PU] indicator is on.			
Calibration is also possible in the External operation mode.				
	Parameter setting mode			
3.	Press MODE to choose the parameter setting mode. (The parameter number read previously appears.)			
	Calibration parameter selection			
4.	Turn until appears. Press SET to display			
	Selecting the parameter number			
5.	Turn to choose C4(Pr.903) Terminal 2 frequency setting gain for the terminal 1.			
	and C7(Pr.905) Terminal 4 frequency setting gain for the terminal 4.			
_	Analog voltage (current) display			
6.	Press SET to display the analog voltage (current) % currently applied to the terminal 1 (4).			
	Analog voltage (current) adjustment			
7.	When is turned, the gain voltage (current) % currently set to the parameter is displayed.			
	When until the desired gain voltage (current) % is displayed.			
	Setting completed			
	Press SET to enter the setting. The analog voltage (current) % and [			
8.	Turn  to read another parameter.			
	• Press SET to return to the [ display.			
	Press  twice to show the next parameter.			

## • NOTE

• By pressing after step 6, the present frequency setting bias/gain setting can be confirmed. Confirmation is not possible after executing step 7.

(c) Adjust only frequency without adjustment of gain voltage (current) (When changing the gain frequency from 60 Hz to 50 Hz)

#### Operation

#### Parameter selection

Turn (1) to choose [-] (Pr.125) for the terminal 2, and [-] (Pr.126) for the terminal 4.

set to show the present set value. (150.00%)

#### Torque setting change

Turn (130.00%) to change the set value to " \( \square\) ". (130.00%) 2.

> set to enter the setting. "5000" and "P. 125 (P. 125)" flicker alternately. Press

#### Checking the mode/monitor

3. MODE three times to change to the monitor / frequency monitor. Press

#### Start

1.

Turn ON the start switch (STF or STR) to apply a voltage across terminals 1 and 5 (4 and 5), Operation is performed with 130% torque.

#### NOTE

- If the frequency meter (display meter) connected across the terminals FM and SD (CA and 5) does not indicate exactly 60 Hz, set the calibration parameter C0 FM/CA terminal calibration. (Refer to page 279.)
- If the gain and bias of voltage (current) setting voltage are too close, an error ( ) may be displayed at setting.
- Changing C4 (Pr.903) or C7 (Pr.905) (gain adjustment) will not change Pr.20. Input to the terminal 1 (frequency setting auxiliary input) is added to the frequency setting signal.
- For operation outline of the parameter unit (FR-PU07), refer to the Instruction Manual of the FR-PU07.
- To set the value to 120 Hz or higher, the Pr.18 High speed maximum frequency needs to be 120 Hz or higher. (Refer to page 245.)
- Make the bias frequency setting using the calibration parameter C2 (Pr.902) and C5 (Pr.904). (Refer to page 316.)



#### Caution

Be cautious when setting any value other than "0" as the bias frequency at 0 V (0 mA). Even if a speed command is not given, simply turning ON the start signal will start the motor at the preset frequency.

#### Parameters referred to

Pr.1 Maximum frequency, Pr.18 High speed maximum frequency page 245

Pr.20 Acceleration/deceleration reference frequency page 187

Pr.73 Analog input selection, Pr.267 Terminal 4 input selection page 306

Pr.79 Operation mode selection page 200

Pr.858 Terminal 4 function assignment, Pr.868 Terminal 1 function assignment page 310

#### 5.9.6 Bias and gain for voltage (current) setting of stall prevention operation level PM

The magnitude (slope) of the stall prevention operation level can be set as desired in relation to the analog signal (0 to 5 VDC, 0 to 10 VDC, or 4 to 20 mA).

Use Pr.73 Analog input selection or Pr.267 Terminal 4 input selection to switch among input 0 to 5 VDC, 0 to 10 V, and 4 to 20 mA. (Refer to page 306.)

Pr.	Name	Initial	Setting		Description
	Nume	value	range		Description
C16 (919)*1 T110	Terminal 1 bias command (torque)	0%	0 to 400%	Set the stall proof terminal 1 in	evention operation level of the bias side uput.
C17 (919)*1 T111	Terminal 1 bias (torque)	0%	0 to 300%	Set the conver input.	ted % on bias side voltage of terminal 1
C18 (920)*1 T112	Terminal 1 gain command (torque)	150%	0 to 400%	· ·	evention operation level of the gain terminal 1 input
C19 (920)*1 T113	Terminal 1 gain (torque)	100%	0 to 300%	Set the convert	ted % on the gain side voltage of terminal
C38 (932)*1 T410	Terminal 4 bias command (torque)	0%	0 to 400%	Set the stall prevention operation level of the bias side of terminal 4 input.	
C39 (932)*1 T411	Terminal 4 bias (torque)	20%	0 to 300%	Set the converted % on bias side current (voltage) of terminal 4 input.	
C40 (933)*1 T412	Terminal 4 gain command (torque)	150%	0 to 400%		evention operation level of the gain terminal 4 input.
C41 (933)*1 T413	Terminal 4 gain (torque)	100%	0 to 300%	Set the conver terminal 4 inpu	ted % on gain side current (voltage) of it.
241	Analog input display unit	0	0	% display	Select the unit for analog input display.
M043	switchover	-	1	V/mA display	ocicet the unit for analog input display.

<sup>\*1</sup> The parameter number in parentheses is the one for use with the LCD operation panel and the parameter unit.

## Changing the function of analog input terminal

• The initial value for terminal 1 used as analog input is set to speed setting auxiliary (speed limit auxiliary), and terminal 4 is set to speed command. To use the analog input terminal to input the stall prevention operation level, set Pr.868 Terminal 1 function assignment and Pr.858 Terminal 4 function assignment to change the function. (Refer to page 310.)

## ◆Relationship between the analog input terminal function and the calibration parameter

· Calibration parameter according to the terminal 1 function

Pr.868	Terminal function	Calibration parameter			
setting	Terminal function	Bias setting	Gain setting		
0 (initial value)	Frequency (speed) setting auxiliary	C2 (Pr.902) Terminal 2 frequency setting bias frequency C3 (Pr.902) Terminal 2 frequency setting bias C5 (Pr.904) Terminal 4 frequency setting bias frequency C6 (Pr.904) Terminal 4 frequency setting bias	Pr.125 Terminal 2 frequency setting gain frequency C4 (Pr.903) Terminal 2 frequency setting gain Pr.126 Terminal 4 frequency setting gain frequency C7 (Pr.905) Terminal 4 frequency setting gain		
4	Stall prevention operation level *1	C16 (Pr.919) Terminal 1 bias command (torque) C17 (Pr.919) Terminal 1 bias (torque)	C18 (Pr.920) Terminal 1 gain command (torque) C19 (Pr.920) Terminal 1 gain (torque)		
9999	No function	_	_		

<sup>\*1</sup> Use Pr.148 Stall prevention level at 0 V input and Pr.149 Stall prevention level at 10 V input to adjust the bias and gain for stall prevention operation level under V/F control and Advanced magnetic flux vector control.

Calibration parameter according to the terminal 4 function

Pr.858	Terminal function	Calibration parameter			
setting		Bias setting	Gain setting		
0 (initial value)	Frequency (speed) command	C5 (Pr.904) Terminal 4 frequency setting bias frequency C6 (Pr.904) Terminal 4 frequency setting bias	Pr.126 Terminal 4 frequency setting gain frequency C7 (Pr.905) Terminal 4 frequency setting gain		
4	Stall prevention operation level *2	C38 (Pr.932) Terminal 4 bias command (torque) C39 (Pr.932) Terminal 4 bias (torque)	C40 (Pr.933) Terminal 4 gain command (torque) C41 (Pr.933) Terminal 4 gain (torque)		
9999	No function	_	_		


<sup>\*2</sup> Use Pr.148 Stall prevention level at 0 V input and Pr.149 Stall prevention level at 10 V input to adjust the bias and gain for stall prevention operation level under V/F control and Advanced magnetic flux vector control.

## **◆**Change the stall prevention operation level at maximum analog input. (C18 (Pr.920), C40 (Pr.933))

• To only change the stall prevention operation level setting (gain) of the maximum analog input voltage (current), set to C18 (Pr.920), C40 (Pr.933).

# ◆Calibration of analog input bias and gain (C16 (Pr.919) to C19 (Pr.920), C38 (Pr.932) to C41 (Pr.933))

- "Bias"/"gain" function can adjust the relation between the stall prevention operation level and the setting input signal. Examples of setting input signals are 0 to 5 VDC, 0 to 10 VDC, or 4 to 2 mADC, and they are externally input.
- Set the bias value of the terminal 1 input using **C16 (Pr.919)**. (Shipped from factory with the stall prevention operation level for 0 V)
- Set the stall prevention operation level against the input voltage set by **Pr.73 Analog input selection** with **C18 (Pr.920)**. (Initial value is 10 V.)
- Set the bias value of the terminal 4 input using C38 (Pr.932). (The initial value is the stall prevention operation level for 4 mA.)
- Set the stall prevention operation level against the 20 mA for input current (4 to 20 mA) with C40 (Pr.933).



- \*1 If a negative command is given, the stall prevention operation level is regarded as "0".
- There are three methods to adjust the torque setting voltage (current) bias and gain.
  - Method to adjust arbitrary point with application of a voltage (current) between terminals 1 and 5 (4 and 5). @ page 323
  - Method to adjust arbitrary point without application of a voltage (current) between terminals 1 and 5 (4 and 5). \*\*page\*\* 324
  - Method to adjust only stall prevention operation level without adjusting voltage (current). @page 325

## • NOTE

 Always calibrate the input after changing the voltage/input signal with Pr.73, Pr.267, and the voltage/current input selection switch.

## ◆Analog input display unit changing (Pr.241)

- The analog input display unit (%/V/mA) for analog input bias and gain calibration can be changed.
- Depending on the terminal input specification set to Pr.73 and Pr.267, the display units of C17 (Pr.919), C19 (Pr.920), C39 (Pr.932), and C41 (Pr.933) will change as shown below.

Analog command (terminals 1 and 4) (Depends on Pr.73, Pr.267)	Pr.241 = 0 (initial value)	Pr.241 = 1
0 to 5 V input	0 to 5 V $\rightarrow$ 0 to 100% (0.1%) display	0 to 100% $\rightarrow$ 0 to 5 V (0.01 V) display
0 to 10 V input	0 to 10 V $\to$ 0 to 100% (0.1%) display	0 to 100% $\rightarrow$ 0 to 10 V (0.01 V) display
0 to 20 mA input	0 to 20 mA $\rightarrow$ 0 to 100% (0.1%) display	0 to 100% → 0 to 20 mA (0.01 mA)

## ◆Adjust method for the stall prevention operation level setting voltage (current) bias and gain

(a) Adjust any point with application of a voltage (current) between terminals 1 and 5 (4 and 5).

	Operation
	Screen at power-ON
1.	The monitor display appears.
	Changing the operation mode
2.	Press PU to choose the PU operation mode. [PU] indicator is on.
	Calibration is also possible in the External operation mode.
3.	Parameter setting mode
J.	Press MODE to choose the parameter setting mode. (The parameter number read previously appears.)
	Calibration parameter selection
4.	Turn until ☐ appears. Press SET to display ☐
	Selecting the parameter number
5.	Turn to choose [ (C19(Pr.920) Terminal 1 gain (torque)) for the terminal 1, and [
	(C41(Pr.933) Terminal 4 gain (torque)) for the terminal 4.
	Analog voltage (current) display
6.	Press SET to display the analog voltage (current) % currently applied to the terminal 1 (4).
0.	
	Do not touch until calibration is completed.
	Voltage (current) application
7.	Apply a 5 V (20 mA). (Turn the external potentiometer connected across terminals 1 and 5 (terminals 4 and 5) to a desired
	position.) Setting completed
	Press SET to enter the setting. The analog voltage (current) % and [
8.	Turn  to read another parameter.
	• Press SET to return to the [ display.
	Press SET twice to show the next parameter.

#### (T) Multi-Function Input Terminal Parameters

(b) Adjust any point without application of a voltage (current) between terminals 1 and 5 (4 and 5). Operation Screen at power-ON The monitor display appears. Changing the operation mode 2. Press  $\left\| \frac{PU}{EXT} \right\|$  to choose the PU operation mode. [PU] indicator is on. Calibration is also possible in the External operation mode. Parameter setting mode 3. Press MODE to choose the parameter setting mode. (The parameter number read previously appears.) Calibration parameter selection 4. Turn appears. Press SET to display -----Selecting the parameter number 5. Turn to choose ☐ C19(Pr.920) Terminal 1 gain (torque) for the terminal 1, and ☐ ☐ ☐ C41(Pr.933) Terminal 4 gain (torque) for the terminal 4. Analog voltage (current) display 6. Press SET to display the analog voltage (current) % currently applied to the terminal 1 (4). Analog voltage (current) adjustment When is turned, the gain voltage (current) % currently set to the parameter is displayed. 7. Turn ( until the desired gain voltage (current) % is displayed. Setting completed • Turn ( to read another parameter. 8. to return to the [ -- -- display. Press Press twice to show the next parameter.

## • NOTE

• By pressing (3) after step 6, the bias/gain setting at the present stall prevention operation level can be confirmed. Confirmation is not possible after executing step 7.

(c) Method to adjust only stall prevention operation level without adjusting gain voltage (current). (When changing the gain value from 150% to 130%.)

	Operation ————
	Parameter selection
1.	Turn to choose [ (Pr.920) for the terminal 2, and [ (Pr.933) for the terminal 4.
	Press SET to show the present set value. (150.00%)
	Changing the stall prevention operation level
2.	Turn to change the set value to "   ☐ ☐ ☐ [ ] ". (130.00%)
	Press SET to enter the setting. "   ☐ [
	Checking the mode/monitor
3.	Press MODE three times to change to the monitor / frequency monitor.
	Start
4.	Turn ON the start switch (STF or STR) to apply a voltage across terminals 1 and 5 (4 and 5),
	Operation is performed with 130% stall prevention operation level.

#### NOTE

- If the gain and bias of the stall prevention operation level are too close, an error ( ) may displayed at setting.
- For operation outline of the parameter unit (FR-PU07), refer to the Instruction Manual of the FR-PU07.
- Set the bias setting using the calibration parameter C16 (Pr.919) or C38 (Pr.932). (Refer to page 322.)

#### Parameters referred to

Pr.73 Analog input selection, Pr.267 Terminal 4 input selection page 306

Pr.79 Operation mode selection page 200


Pr.858 Terminal 4 function assignment, Pr.868 Terminal 1 function assignment page 310

#### 5.9.7 Checking of current input on analog input terminal

When current is input to the analog input terminal 2 and terminal 4, operation when the current input has gone below the specified level (loss of analog current input) can be selected. It is possible to continue the operation even when the analog current input is lost.

Pr.	Name	Initial value	Setting range	Description
			1	Continues the operation with output frequency before the current input loss.
E72			2	4 mA input fault is activated when the current input loss is detected.
573 T052	4 mA input check selection	9999	3 is detected. After it is stoppe	Decelerates to stop when the current input loss is detected. After it is stopped, 4 mA input fault (E.LCI) is activated.
			4	Continues operation with the <b>Pr.777</b> setting.
			9999	No current input check
777	4 mA input fault operation	9999	0 to 590 Hz	Set the running frequency for current input loss. (Valid when <b>Pr.573</b> = "4")
T053	frequency		9999	No current input check when Pr.573 = "4"
778 T054	4 mA input check filter	0 s	0 to 10 s	Set the current input loss detection time.

#### ◆Analog current input loss condition (Pr.778)



\*1 When the **Pr.573** ≠ "9999" and terminal 4 (terminal 2) is calibrated to 2 mA or less with **C2** (**Pr.902**) (**C5** (**Pr.904**)), analog input frequency that is 2 mA or less will become input current loss, thus it will not be as the bias setting frequency.

- When the condition of current input to the terminal 4
   (terminal 2) continues to be 2 mA or less for Pr.778 setting
   time, it is considered as loss of analog current input and
   alarm (LF) signal is turned ON. The LF signal will turn OFF
   when the current input becomes 3 mA or higher.
- For the LF signal, set "98 (positive logic) or 198 (negative logic)" in any of Pr.190 to Pr.196 (output terminal function selection) to assigns the function.


## • NOTE

• Changing the terminal assignment using **Pr.190 to Pr.196 (output terminal function selection)** may affect the other functions. Set parameters after confirming the function of each terminal.

#### ◆Continue operation at analog current input loss (Pr.573 = "1, 4", Pr.777)

- When Pr.573 = "1", operation is continued with the output frequency before the current input loss.
- When Pr.573 = "4" and Pr.777 ≠ "9999", operation is continued with frequency set in Pr.777.
- When the start command is turned OFF during the input current loss, deceleration stop is immediately performed, and the operation is not restored even if start command is input again.
- When the current input is restored, the LF signal is turned OFF, and operation is performed according to the current input.

External operation



· PID control (reverse action)

Output frequency

20mA

Set point (fixed)

Measured value

4mA

STF

LF signal

Pr.573=1 : Operation continued with the frequency before being lost Pr.573=4 : Operation continued with Pr.777 setting

Input current decrease

Return

Time

Time


On during input decrease

## NOTE

• When the setting is changed to continuously operate after the input current loss (**Pr.573** = "1, 4"), the motor will operate as the frequency before loss is 0 Hz.


#### **♦**Fault output (Pr.573 = "2")

- . When the analog current input becomes 2 mA or lower, 4 mA input fault (E.LCI) will be activated and the output is shut off.
- PID control (reverse action)




## ◆Fault output after deceleration to stop (Pr.573 = "3")

- When the analog current input becomes 2 mA or lower, 4 mA input fault (E.LCI) will be activated after the deceleration stop and the output is shut off.
- · When the analog current input is restored during the deceleration, it will accelerate again and operate according to the current input.
- · PID control (reverse action)



• The analog input current is restored during deceleration under PID control (reverse action)



## **♦**Function related to current input check

Function	Operation	Refer to page		
Minimum frequency	When the operation continues, setting of the minimum frequency against the running frequency is valid even during the current input loss.	245		
Multi-speed operation	The multi-speed setting signal is prioritized even during current input loss (operate according to multi-speed setting even during operation in continuous frequency or during deceleration stop).  When the multi-speed setting signal is turned OFF due to input current loss condition during the multi-speed operation, it will perform deceleration stop even if it is set to continue operation for current input loss.			
JOG operation	JOG operation is prioritized even during current input loss (switch to JOB operation even during operation with continuous frequency or during deceleration stop). When the JOG signal is turned OFF due to input current loss condition during the JOG operation, it will perform deceleration stop even if it is set to continue operation for current input loss.	221		
MRS signal	MRS signal is enabled even during current input loss (output is shut off with MRS signal ON even during operation with continuous frequency or during deceleration stop).	332		
Remote setting	During operation with remote setting and transferred to operation continuation due to input current loss, acceleration, deceleration, and clear by the remote setting is invalid. They will become valid after restoring the current input loss.	194		
Retry function	When the protective function has operated during the operation continuation due to current input loss, and retry was a success, operation will continue without clearing the operation continuation frequency.	236		
Added compensation, override compensation	During operation with added compensation or override compensation and transferred to operation continuation due to input current loss, added compensation and override compensation will become invalid. They will become valid after restoring the current input loss.	311		
Input filter time constant	Current input loss is detected with the value before the filter.  Operation continuation before the input loss will use the value after the filter.	325		
PID control	PID calculation is stopped during the current input loss. However, PID control will not be disabled (normal operation).  During the pre-charge, end determination or fault determination by the pre-charge function will not be performed when the current input loss occurs.  Sleep function is prioritized even during current input loss. When the clearing condition of the sleep function is met during the current input loss, operation is restored with continuation frequency.	378		
Power failure stop	The power failure stop function is prioritized even if power failure current input loss is detected.  Set frequency after the power failure stop and re-acceleration is the operation continuation frequency at the current input loss.  When the E.LCI generation at the time of current input loss is selected, E.LCI will be generated after the power failure stop.	426		
Traverse function	Traverse operation is performed based on frequency even during the operation continuation during current input loss.	373		

#### ≪ Parameters referred to ≫

Pr.73 Analog input selection, Pr.267 Terminal 4 input selection page 306

#### 5.9.8 Input terminal function selection

Use the following parameters to select or change the input terminal functions.

Pr.	Name	Initial value	Initial signal	Setting range
178 T700	STF terminal function selection	60	STF (Forward rotation command)	0 to 8, 10 to 14, 16, 18, 24, 25, 28, 37 to 40, 46 to 48, 50, 51, 60, 62, 64 to 67, 70 to 73, 77 to 81, 84, 94 to 98, 9999
179 T7001	STR terminal function selection	61	STR (Reverse rotation command)	0 to 8, 10 to 14, 16, 18, 24, 25, 28, 37 to 40, 46 to 48, 50, 51, 61, 62, 64 to 67, 70 to 73, 77 to 81, 84, 94 to 98, 9999
180 T702	RL terminal function selection	0	RL (Low-speed operation command)	
181 T703	RM terminal function selection	1	RM (Middle-speed operation command)	
182 T704	RH terminal function selection	2	RH (High-speed operation command)	
183 T705	RT terminal function selection	3	RT (Second function selection)	
184 T706	AU terminal function selection	4	AU (Terminal 4 input selection)	0 to 8, 10 to 14, 16, 18, 24, 25, 28, 37 to 40, 46 to 48, 50, 51,
185 T707	JOG terminal function selection	5	JOG (Jog operation selection)	62, 64 to 67, 70 to 73, 77 to 81, 84, 94 to 98, 9999
186 T708	CS terminal function selection	9999	No function	
187	MRS terminal function	24*1	MRS (Output stop)	
T709	selection	10*2	X10 (Inverter run enable signal)	
188 T710	STOP terminal function selection	25	STP (STOP) (Start self-holding selection)	
189 T711	RES terminal function selection	62	RES (Inverter reset)	

Pr.	Name	Initial value	Setting range	Description
699	Input terminal filter	9999	5 to 50 ms	Set the time to delay the input terminal response.
T740	input terminar inter	9999	9999 No input terminal filter	No input terminal filter

- \*1 The initial value is for standard models.
- \*2 The initial value is for separated converter types.

## ♦ Input terminal function assignment

- Using Pr.178 to Pr.189, set the functions of the input terminals
- Refer to the following table and set the parameters.

Setting	Signal name		Function	Related parameter	Refer to page
0	RL	Pr.59 = 0 (initial value)	Low-speed operation command	Pr.4 to Pr.6, Pr.24 to Pr.27, Pr.232 to Pr.239	222
		Pr.59 ≠ 0 *1	Remote setting (setting clear)	Pr.59	194
1 RI	RM	Pr.59 = 0 (initial value)	Middle-speed operation command	Pr.4 to Pr.6, Pr.24 to Pr.27, Pr.232 to Pr.239	222
		Pr.59 ≠ 0 *1	Remote setting (deceleration)	Pr.59	194
2	RH	Pr.59 = 0 (initial value)	High-speed operation command	Pr.4 to Pr.6, Pr.24 to Pr.27, Pr.232 to Pr.239	222
		<b>Pr.59</b> ≠ 0 *1	Remote setting (acceleration)	Pr.59	194
3	RT	Second function selection		Pr.44 to Pr.51, Pr.450 to Pr.463, Pr.569, Pr.832, etc.	333
4	AU	Terminal 4 input selection		Pr.267	306
5	JOG	Jog operation selection	1	Pr.15, Pr.16	221

#### (T) Multi-Function Input Terminal Parameters


Setting	Signal name	Function	Related parameter	Refer to page
6	cs	Selection of automatic restart after instantaneous power failure, flying start	Pr.57, Pr.58, Pr.162 to Pr.165, Pr.299, Pr.611	414, 420
		Electronic bypass function	Pr.57, Pr.58, Pr.135 to Pr.139, Pr.159	363
7	ОН	External thermal relay input *2	Pr.9	225
8	REX	15-speed selection	Pr.4 to Pr.6, Pr.24 to Pr.27,	222
0	KEX	(Combination with multi-speeds of RL, RM, and RH)	Pr.232 to Pr.239	222
10	X10	Inverter run enable signal (FR-HC2/FR-CV/FR-CC2 connection)	Pr.30, Pr.599	508
11	X11	FR-HC2/FR-CC2 connection, instantaneous power failure detection	Pr.30	508
12	X12	PU operation external interlock	Pr.79	
13	X13 External DC injection brake operation start Pr.10 to F		Pr.10 to Pr.12	502
14	X14 PID control valid terminal		Pr.127 to Pr.134, Pr.575 to Pr.577	378
16	X16	PU/External operation switchover (External operation with X16-ON)	Pr.79, Pr.340	200
18	X18	V/F switchover (V/F control with X18-ON)	Pr.80, Pr.81, Pr.800	143
		Output stop	Pr.17	332
24	MRS	Electronic bypass function	Pr.57, Pr.58, Pr.135 to Pr.139, Pr.159	363
25	STP (STOP)	Start self-holding selection	Pr.250	335
28	X28	Start-time tuning start external input	Pr.95	359
37	X37	Traverse function selection	Pr.592 to Pr.597	373
38	PDI1	PID multistage set point setting 1		
39	PDI2	PID multistage set point setting 2	Pr.1460 to Pr.1466	378
40	PDI3	PID multistage set point setting 3		
46	TRG	Trace trigger input	Pr.1020 to Pr.1047	433
47	TRC	Trace sampling start/end	Pr.1020 to Pr.1047	433
48	X48	Power failure stop external	Pr.261 to Pr.266, Pr.294, Pr.668	426
50	SQ	Sequence start	Pr.414	431
51	X51	Fault clear	Pr.414	431
60	STF	Forward rotation command (Assignable to the STF terminal (Pr.178) only)	Pr.250	335
61	STR	Reverse rotation command (Assignable to the STR terminal (Pr.179) only)	Pr.250	335
62	RES	Inverter reset	Pr.75	162
64	X64	PID forward/reverse action switchover	Pr.127 to Pr.134	378
65	X65	PU/NET operation switchover (PU operation with X65-ON)	Pr.79, Pr.340	200
66	X66	External/NET operation switchover (NET operation with X66-ON)	Pr.79, Pr.340	200
67	X67	Command source switchover (Command by <b>Pr.338</b> , <b>Pr.339</b> enabled with X67-ON)	Pr.338, Pr.339	210
70	X70	DC feeding operation permission *4	Pr.30	508
71	X71	DC feeding cancel *4	Pr.30	508
72	X72	PID integral value reset	Pr.127 to Pr.134, Pr.575 to Pr.577	378
73	X73	Second PID P control switchover	Pr.127 to Pr.134, Pr.575 to Pr.577	378
77	X77	Pre-charge end command	Pr.760 to Pr.764	402
78	X78	Second pre-charge end command	Pr.765 to Pr.769	402
79	X79	Second PID forward/reverse action switchover	Pr.753 to Pr.758	378
80	X80	Second PID control valid terminal	Pr.753 to Pr.758	378
81	PGT	PID gain tuning start/forced end	Pr.1211 to Pr.1219	394
84	X84	Emergency drive execution command *4	Pr.514, Pr.515, Pr.523, Pr.524, Pr.1013	238
94	X94	Control signal input for main circuit power supply MC	Pr.30, Pr.137, Pr.248, Pr.254	370
95	X95	Converter unit fault input	Du 57 Du 60 Du 405 to Du 400 Du 450	202
96	X96	Converter unit fault input (E.CPU, E.OUT)	Pr.57, Pr.58, Pr.135 to Pr.139, Pr.159	363
97	X97	Cleaning valid	Dr 4460 to Dr 4470	275
98	X98	Cleaning trigger	Pr.1469 to Pr.1479	375
9999		No function		

- \*1 When **Pr.59 Remote function selection**  $\neq$  "0", functions of the RL, RM, and RH signals will be changed as in the table.
- \*2 OH signal will operate with the relay contact "open".
- \*3 Available when the plug-in option is connected. For details, refer to the Instruction Manual of the option.
- \*4 The setting is available only for standard models.

- · Same function can be assigned to two or more terminals. In this case, the logic of terminal input is OR.
- Priority of the speed command is JOG > multi-speed setting (RH, RM, RL, REX) > PID (X14).
- When the (X10) signal is not set up, Pr.79 Operation mode selection = "7", and PU operation external interlock (X12) signal is Inverter run enable signal.
- Same signal is used to assign multi-speed (7 speed) and remote setting. Setting cannot be performed individually.
- · When the terminal assignment is changed using Pr.178 to Pr.189 (input terminal function selection), the terminal name will be different, which may result in an error of wiring, or affect other functions. Set parameters after confirming the function of each terminal.

#### **◆**Adjusting the response of input terminal (Pr.699)

• Response of the input terminal can be delayed in a range between 5 to 50 ms. (Example of STF signal operation)





- · Setting of Pr.699 is disabled (no filter) in the following cases.
- Input terminal is already turned ON when the power is turned ON
- Input signal used for the PLC function
- Inverter run enable signal (X10) signal

#### 5.9.9 Inverter output shutoff signal

The inverter output can be shut off with the MRS signal. The logic of the MRS signal can also be selected.

Pr.	Name	Initial value	Setting range	Description
	MRS input selection		0	Normally open input
17		0	2	Normally closed input (NC contact input specification)
T720			4	External terminal: Normally closed input (NC contact input specification) Communication: Normally open input





#### About output shutoff signal (MRS signal)

- When the Output stop (MRS) signal is turned ON while operating the inverter, the inverter output is instantaneously shut off.
- · The response time of the MRS signal is within 2 ms.
- · Terminal MRS may be used as described below.
  - (a) To use a mechanical brake (e.g. electromagnetic brake) to stop the motor
    - The inverter output is shut off when the mechanical brake operates.
  - (b) To provide interlock to disable operation by the inverter With the MRS signal ON, the inverter cannot be operated even if the start signal is entered into the inverter.
  - (c) To coast the motor to a stop When the start signal is turned OFF, the inverter decelerates the motor to a stop in the preset deceleration time, but when the MRS signal is turned ON, the motor coasts to a stop.

#### ◆MRS signal logic inversion (Pr.17 = "2")

• When Pr.17 = "2", the MRS signal can be changed to normally closed (NC contact) specification. The inverter will shut off the output with MRS signal turned ON (opened).

## Assigning a different action for each MRS signal input via communication and external terminal (Pr.17 = "4")

• When Pr.17 = "4", the MRS signal from an external terminal can be set as the normally closed (NC contact) input, and the MRS signal from communication as the normally open (NO contact) input. This function is useful to perform operation by communication with MRS signal from external terminal remained ON.

External MRS	Communication MRS	Pr.17 setting			
External wing	Communication wiks	0	2	4	
OFF	OFF	Operation enabled	Output shutoff	Output shutoff	
OFF	ON	Output shutoff	Output shutoff	Output shutoff	
ON	OFF	Output shutoff	Output shutoff	Operation enabled	
ON	ON	Output shutoff	Operation enabled	Output shutoff	

## NOTE

- The MRS signal is assigned to the terminal MRS in the initial status. By setting "24" in either Pr.178 to Pr.189 (input terminal function selection), the RT signal can be assigned to the other terminal.
- · When using an external terminal to input the MRS signal, the MRS signal shuts off the output in any of the operation modes.
- · MRS signal is valid from either of communication or external, but when the MRS signals is to be used as Inverter run enable signal (X10), it is required to input from external.
- · When the terminal assignment is changed using Pr.178 to Pr.189 (input terminal function selection), the terminal name will be different, which may result in an error of wiring, or affect other functions. Set parameters after confirming the function of each terminal.

#### # Parameters referred to

Pr.178 to Pr.189 (input terminal function selection) Pr.178 to Pr.189 (input terminal function selection)


#### 5.9.10 Selecting operation condition of the second function selection signal (RT)

Second (third) function can be selected by the RT (X9) signal. Operating condition (validity condition) for second (third) function can be also set.


Pr.	Name	Initial value	Setting range	Description
155	PT signal function validity		0	Second function is immediately enabled with ON of RT signal.
T730	RT signal function validity condition selection	0	10	Second function will be enabled while RT signal is ON and running in constant speed. (Disabled while accelerating or decelerating)

- Turning ON the Second function selection (RT) signal enables the second functions.
- The following table lists application examples of the second functions.
  - Switching between regular use and emergency use
  - Switching between heavy load and light load
  - Change the acceleration/deceleration time by break point acceleration/deceleration
  - Switching characteristics of main motor and sub motor

#### Connection diagram for second function selection



#### Example of second acceleration/deceleration time



#### (T) Multi-Function Input Terminal Parameters

• When the RT signal is ON, the following second functions are selected at the same time.

Function	First function Parameter number	Second function Parameter number	Refer to page
Torque boost	Pr.0	Pr.46	496
Base frequency	Pr.3	Pr.47	497
Acceleration time	Pr.7	Pr.44	187
Deceleration time	Pr.8	Pr.44, Pr.45	187
Electronic thermal O/L relay	Pr.9	Pr.51	225
Free thermal	Pr.600 to Pr.604	Pr.692 to Pr.696	225
Motor permissible load level *1	Pr.607	Pr.608	225
Stall prevention	Pr.22	Pr.48, Pr.49	248
Applicable motor *1	Pr.71	Pr.450	337
Motor constant *1	Pr.80 to Pr.84, Pr.89 to Pr.94, Pr.298, Pr.702, Pr.706, Pr.707, Pr.711, Pr.712, Pr.717, Pr.721, Pr.724, Pr.725, Pr.859	Pr.453 to Pr.457, Pr.560, Pr.569, Pr.458 to Pr.462, Pr.738 to Pr.747, Pr.860	341, 351
Offline auto tuning *1	Pr.96	Pr.463	341, 351
Online auto tuning *1	Pr.95	Pr.574	359
PID control	Pr.127 to Pr.134	Pr.753 to Pr.758	378
PID Pre-charge function	Pr.760 to Pr.764	Pr.765 to Pr.769	402
Speed control gain	Pr.820, Pr.821	Pr.830, Pr.831	154
Analog input filter	Pr.822	Pr.832	313
Torque control gain	Pr.824, Pr.825	Pr.834, Pr.835	154
Torque detection filter	Pr.827	Pr.837	158

<sup>\*1</sup> The function can be changed by switching the RT signal ON/OFF while the inverter is stopped. If a signal is switched during operation, the operation method changes after the inverter stops. (Pr.450  $\neq$  9999)

#### • NOTE

- RT signal is assigned to the terminal RT in the initial status. Set "3" in any of Pr.178 to Pr.189 (input terminal function selection) to assign the RT signal to another terminal.
- Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### Parameters referred to

Pr.178 to Pr.189 (input terminal function selection) page 329

#### 5.9.11 Start signal operation selection

Operation of start signal (STF/STR) can be selected.


Select the stopping method (deceleration to stop or casting) at turn-OFF of the start signal.

Use this function to stop a motor with a mechanical brake at turn-OFF of the start signal.

		Initial value Setting ran		Descr	ption	
Pr.	Name		Setting range	Start signal (STF/STR)	Stop operation (Refer to page 507.)	
	Stop selection 9999 9999 8888	0 to 100 s	STF signal: Forward rotation start STR signal: Reverse rotation start	Turn OFF the start signal and it will coast to stop after the specified time period.		
250		9999	1000 s to 1100 s	STF signal: Start signal STR signal: Forward/reverse rotation signal	When set to 1000 s to 1100 s, will coast to stop after ( <b>Pr.250</b> - 1000) s.	
G106			9999	STF signal: Forward rotation start STR signal: Reverse rotation start	It will perform deceleration stop	
		8888	STF signal: Start signal STR signal: Forward/reverse rotation signal	when the start signal is turned OFF.		

## ◆2-wire type (STF, STR signal)

- The following figure shows the connection in 2-wire type.
- · As an initial setting, forward/reverse rotation signals (STF/STR) acts as both start and stop signals. Either one turned ON will be enabled, and the operation will follow that signal. The motor will perform a deceleration stop when both are turned OFF (or both are turned ON) during the operation.
- There are methods such as inputting 0 to 10 VDC between the speed setting input terminals 2 and 5, or Pr.4 to Pr.6 multispeed setting (fast, medium, slow) for the frequency setting signal. (For multi-speed operation, refer to page 222.)
- By setting Pr.250 = "1000 to 1100, 8888", STF signal becomes start command and STF signal becomes forward/reverse command.



2-wire type connection example (Pr.250 = "9999")


2-wire type connection example (Pr.250 = "8888")

## • NOTE

- By setting Pr.250 = "0 to 100, 1000 to 1100", it will perform coast to stop when the start command is turned OFF. (Refer to
- · The STF and STR signals are assigned to the terminals STF and STR in the initial status. STF signal can be assigned to a terminal by Pr.178 STF terminal function selection, and STR signal can be assigned to a terminal by Pr.179 STR terminal function selection.

#### ◆3-wire type (STF, STR, STP (STOP) signal)

- The following figure shows the connection in 3-wire type.
- Start self-holding function is enabled when the STP (STOP) signal is turned ON. In such case, forward/reverse signal will only operate as start signal.
- Even if start signal (STF or STR) is turned ON and then OFF, the start signal will be maintained and it will start. To change the rotation direction, turn STR (STF) ON once and then OFF.
- The inverter will perform deceleration stop by turning the STP (STOP) signal OFF once.



3-wire type connection example (Pr.250 = "9999")

3-wire type connection example (Pr.250 = "8888")

## • NOTE

- The STP (STOP) signal is assigned to the terminal STP (STOP) by the initial setting. Set "25" in any of **Pr.178 to Pr.189** to assign the STP (STOP) signal to another terminal.
- When the JOG operation is enabled by turning ON the JOG signal, STOP signal will be disabled.
- Even when the output is stopped by turning ON the MRS signal, self-holding function is not canceled.

## ◆Start signal selection

STF	STR	Pr.250 setting and inverter condition			
SIF SIK		0 to 100 s, 9999	1000 s to 1100 s, 8888		
OFF	OFF	Stop	Stop		
OFF	ON	Reverse rotation	Stop		
ON	OFF	Forward rotation	Forward rotation		
ON	ON	Stop	Reverse rotation		

#### Parameters referred to

Pr.4 to Pr.6 (multi-speed setting) page 222

Pr.178 to Pr.189 (input terminal function selection) page 329

## **5.10** (C) Motor constant parameters

Purpose		Refer to page		
To select the motor to be used	Applicable motor	P.C100, P.C200	Pr.71, Pr.450	337
To run by maximizing the performance of the induction motor	Offline auto tuning	P.C000, P.C100 to P.C105, P.C107, P.C108, P.C110, P.C120 to P.C126, P.C200 to P.C205, P.C207, P.C208, P.C210 and P.C220 to P.C226	Pr.9, Pr.51, Pr.71, Pr.80 to Pr.84, Pr.90 to Pr.94, Pr.96, Pr.453 to Pr.463, Pr.684, Pr.707, Pr.724, Pr.744, Pr.745, Pr.859 and Pr.860	341
To run by maximizing the performance of the PM motor	PM motor offline auto tuning	P.C000, P.C100 to P.C108, P.C110, P.C120, P.C122, P.C123, P.C126, P.C130 to P.C133, P.C150, P.C182, P.C185, P.C200 to P.C208, P.C210, P.C220, P.C222, P.C223, P.C226, P.C230 to P.C233, P.C282 and P.C285	Pr.9, Pr.51, Pr.71, Pr.80, Pr.81, Pr.83, Pr.84, Pr.90, Pr.92, Pr.93, Pr.96, Pr.450, Pr.453, Pr.454, Pr.456 to Pr.458, Pr.460, Pr.461, Pr.463, Pr.684, Pr.702, Pr.706, Pr.707, Pr.711, Pr.712, Pr.717, Pr.721, Pr.724, Pr.725, Pr.738 to Pr.747, Pr.788, Pr.859, Pr.860 and Pr.1002	351
To perform high accuracy operation without being affected by temperature and high-torque/ultra-low speed	Online auto tuning	P.C111 and P.C211	Pr.95, Pr.574	341

# 5.10.1 Applied motor

By setting the applied motor type, the thermal characteristic appropriate for the motor can be selected. When using a constant-torque or PM motor, the electronic thermal O/L relay is set according to the used motor. If the Advanced magnetic flux vector control or PM motor control is selected, the motor constant necessary for control (SF-PR, SF-JR, SF-HR, SF-JRCA, SF-HRCA, MM-EFS, MM-THE4, etc.) is also selected at the same time.

Pr.	Name	Initial value	Setting range	Description
71 C100	Applied motor	0	0 to 6, 13 to 16, 20, 23, 24, 40, 43, 44, 50, 53, 54, 70, 73, 74, 210, 213, 214, 8090, 8093, 8094, 9090, 9093, 9094	By selecting a motor, the thermal characteristic and motor constant of each motor are set.
450 C200	Second applied motor	9999	0, 1, 3 to 6, 13 to 16, 20, 23, 24, 40, 43, 44, 50, 53, 54, 70, 73, 74, 210, 213, 214, 8090, 8093, 8094, 9090, 9093, 9094	Set it when using the second motor. (the same specifications as <b>Pr.71</b> )
			9999	The function is disabled.

## **♦**Setting the applied motor

• Refer to the following list and set the parameters according to the applied motor.

Pr.71	Pr.450	Motor		tant value range when ning offline auto tuning	Operational characteristic of the electronic thermal O/L relay		
		(increment)				Constant- torque	PM
0 ( <b>Pr.71</b> in value)	nitial	Standard motor (such as SF-JR)	• 0 to 500 /	55) and Pr.859(Pr.860) A, 9999 (0.01 A)*1 A, 9999 (0.1 A)*2	0		
1		Constant-torque motor (SF-JRCA, etc.)	•	58) and Pr.91(Pr.459)		0	
2	_	Standard motor (such as SF-JR) Adjustable 5 points V/F (Refer to page 501.)	• 0 to 400 r	, 9999 (0.001 Ω)*1 mΩ, 9999 (0.01 mΩ)*2 <b>60) and Pr.93(Pr.461)</b>	0		
20		Mitsubishi standard motor (SF-JR 4P 1.5 kW or lower)	(Induction	, , ,		0	
40		Mitsubishi high-efficiency motor SF-HR		mH, 9999 (0.01 mH)*2	0		
50		Mitsubishi constant-torque motor SF-HRCA		60) and Pr.93(Pr.461)		0	
70		Mitsubishi high-performance energy-saving motor SF-PR	• 0 to 500 r	<b>r)</b> mH, 9999 (0.01 mH)∗ı		0	
210		IPM motor MM-EFS/MM-THE4		H, 9999 (0.001 mH)*2			0
8090		IPM motor (other than MM-EFS/MM-THE4)	Pr.94(Pr.4			0	
9090		SPM motor	• 0 to 100% Pr.706(Pr.	mV/(rad/s), 9999		0	
3 (4)*3		Standard motor (such as SF-JR)	,		0		
13 (14)*	3	Constant-torque motor (SF-JRCA, etc.)				0	
23 (24)*	3	Mitsubishi standard motor (SF-JR 4P 1.5 kW or lower)		55), Pr.859(Pr.860), 58), Pr.91(Pr.459),		0	
43 (44)*	3	Mitsubishi high-efficiency motor SF-HR		60), Pr.93(Pr.461),	0		
53 (54)*	3	Mitsubishi constant-torque motor SF-HRCA		62) and Pr.706(Pr.738)		0	
73 (74)*:	3	Mitsubishi high-performance energy-saving motor SF-PR	The displa	ata value 0 to 65534, 9999 (1) y increment can be changed		0	
213 (214		IPM motor MM-EFS/MM-THE4	in <b>Pr.684</b> .				0
8093 (80		IPM motor (other than MM-EFS/MM-THE4)				0	
9093 (90	094)*3	SPM motor				0	
5		Standard motor	Star	Pr.82(Pr.455) and Pr.859(Pr.860) • 0 to 500 A, 9999 (0.01 A) *1	0		
15		Constant-torque motor		• 0 to 3600 A, 9999 (0.1 A) *2 Pr.90(Pr.458) and Pr.91(Pr.459)		0	
6		Standard motor		• 0 to 50 $\Omega$ , 9999 (0.001 $\Omega$ ) *1 • 0 to 400 m $\Omega$ , 9999 (0.01 m $\Omega$ ) *2	0		
16		Constant-torque motor	Delta connection $ \begin{array}{l} \text{Pr.92(Pr.460) and} \\ \text{Pr.93(Pr.461)} \\ \text{-0 to } 50 \ \Omega, \ 9999 \ (0.001 \ \Omega) \ *1} \\ \text{-0 to } 3600 \ \text{m}\Omega, \ 9999 \ (0.11 \ \text{m}\Omega) \ *2} \\ \text{Pr.94(Pr.462)} \\ \text{-0 to } 500 \ \Omega, \ 9999 \ (0.01 \ \Omega) \ *1} \\ \text{-0 to } 100 \ \Omega, \ 9999 \ (0.01 \ \Omega) \ *2} \\ \end{array} $			0	
_	9999 (initial value)	No second applied motor			•		•

- \*1 For the FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower.
- $\ast 2$   $\,$  For the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.
- \*3 The same operation is performed for the both settings.

## NOTE

• Regardless of the Pr.71(Pr.450) setting, offline auto tuning can be performed according to Pr.96(Pr.463) Auto tuning setting/status. (Refer to page 341 for offlne auto tuning.)

#### **◆**Using two types of motors (RT signal, Pr.450)

- When using two types of motors with one inverter, set Pr.450 Second applied motor.
- The setting value "9999" (initial value) disables second applied motor.
- If **Pr.450** ≠ 9999, the following parameters will be enabled by turning ON the Second function selection(RT) signal.

Function	RT signal ON (second motor)	RT signal OFF (first motor)
Electronic thermal O/L relay	Pr.51	Pr.9
Applied motor	Pr.450	Pr.71
Motor capacity	Pr.453	Pr.80
Number of motor poles	Pr.454	Pr.81
Motor excitation current	Pr.455	Pr.82
Rated motor voltage	Pr.456	Pr.83
Rated motor frequency	Pr.457	Pr.84
Motor constant (R1)	Pr.458	Pr.90
Motor constant (R2)	Pr.459	Pr.91
Motor constant (L1)/d-axis inductance (Ld)	Pr.460	Pr.92
Motor constant (L2)/q-axis inductance (Lq)	Pr.461	Pr.93
Motor constant (X)	Pr.462	Pr.94
Auto tuning setting/status	Pr.463	Pr.96
Frequency search gain	Pr.560	P.r298
Online auto tuning selection	Pr.574	Pr.95
Induced voltage constant (phi f)	Pr.738	Pr.706
Motor Ld decay ratio	Pr.739	Pr.711
Motor Lq decay ratio	Pr.740	Pr.712
Starting resistance tuning compensation	Pr.741	Pr.717
Starting magnetic pole position detection pulse width	Pr.742	Pr.721
Maximum motor frequency	Pr.743	Pr.702
Motor inertia (integer)	Pr.744	Pr.707
Motor inertia (exponent)	Pr.745	Pr.724
Motor protection current level	Pr.746	Pr.725
Torque current/Rated PM motor current	Pr.860	Pr.859

## • NOTE

- The RT signal is a second function selection signal. The RT signal also enables other second functions. (Refer to page 333.)
- The RT signal is assigned to the terminal RT in the initial status. Set "3" in any of Pr.178 to Pr.189 (input terminal function selection) to assign the RT signal to another terminal.
- Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### **♦SF-PR** heavy duty setting

- When the SF-PR motor is selected (**Pr.71**="70, 73, 74"), the SF-PR heavy duty setting can be selected by setting **Pr.81 Number of motor poles** according to the number of the SF-PR motor poles.
- When the SF-PR heavy duty setting is selected, the Pr.0 Torque boost setting is automatically changed to enable output of the 6 Hz 150% torque under V/F control.



- When using the SF-PR heavy duty setting, set Pr.14 Load pattern selection = "0".
- When the Pr.0 setting is changed from its initial value, the automatic change is not performed.

## Automatic change of Pr.0 Torque boost and Pr.12 DC injection brake operation voltage

• When initial values are set in **Pr.0** and **Pr.12**, the **Pr.0** and **Pr.12** settings are automatically changed to the values in the table below by changing the **Pr.71** setting.

Inve	erter	Pr.0 value (%) after automatic change			Pr.12 value (%) after automatic change					
			0		S	F-PR *3				
FR-F820-[]	FR-F840-[]	Standard motor	-torque motor	Heavy duty setting Light duty setting			Standard motor	-torque motor	SF-PR	
		*1	*2	Pr.81 =2	Pr.81 =4	Pr.81 =6	Pr.81≠2,4,6	*1	*2	*3
00046(0.75K)	00023(0.75K)	6	6	7.4	6	6.4	4	4	4	4
00077(1.5K)	00038(1.5K)	4	4	5.8	5	3.7	3	4	4	2.5
00105(2.2K)	00052(2.2K)	4	4	6	4.5	3.3	2.5	4	4	2.5
00167(3.7K)	00083(3.7K)	4	4	6.4	4.5	4.2	2.5	4	4	2.5
00250(5.5K)	00126(5.5K)	3	2	4.5	3.7	3.3	2	4	2	2
00340(7.5K)	00170(7.5K)	3	2	4.4	4.5	3.8	2	4	2	2
00490(11K)	00250(11K)	2	2	3.5	3.3	3.5	1.5	2	2	1.5
00630(15K)	00310(15K)	2	2	4.5	3	3.5	1.5	2	2	1.5
00770(18.5K)	00380(18.5K)	2	2	4	3.2	3	1.5	2	2	1.5
00930(22K)	00470(22K)	2	2	2.5	3.4	3	1.5	2	2	1
01250(30K)	00620(30K)	2	2	3	2	2.5	1	2	2	1
01540(37K)	00770(37K)	2	2	2	2.5	2.6	1	2	2	1
01870(45K)	00930(45K)	1.5	1.5	2	2	2.4	1	2	2	1
02330(55K)	01160(55K)	1.5	1.5	2	2	0.7	0.7	2	2	1
03160(75K) or higher	01800(75K) or higher	1	1	1	1	1	1	1	1	1

- \*1 When changed to **Pr.71** = "0, 2 to 6, 20, 23, 24, 40, 43, or 44" (standard motor)
- \*2 When changed to **Pr.71** = "1, 13 to 16, 50, 53, or 54" (constant-torque motor)
- \*3 When changed to **Pr.71** = "70, 73, or 74" (SF-PR)



• When the Pr.0 and Pr.12 settings are changed from their initial values, the automatic change is not performed.



#### Caution

 Make sure to set this parameter correctly according to the motor used. Incorrect setting may cause the motor and inverter to overheat and burn.

#### Parameters referred to

Pr.0 Torque boost \*\* page 496

Pr.12 DC injection brake operation voltage page 502

Pr.14 Load pattern selection page 499

Pr.96 Auto tuning setting/status page 341

Pr.100 to Pr.109 (Adjustable 5 points V/F) page 501

Pr.178 to Pr.189 (input terminal function selection) page 329

Pr.684 Tuning data unit switchover page 341

# 5.10.2 Offline auto tuning Magnetic flux

The offline auto tuning enables the optimal operation of an motor.

· What is offline auto tuning?


Under Advanced magnetic flux vector control operation, measuring motor constants automatically (offline auto tuning) enables optimal operation of motors even when motor constants vary, when a motor of another company is used or when the wiring distance is long.

For the offline auto tuning for a PM motor, refer to page 351.

Pr.	Name	Initial value	Setting range	Description	
684	Tuning data unit	0	0	Internal data converted value	
C000	switchover	O	1	The value is indicated with "A, $\Omega$ , mH or %".	
71 C100	Applied motor	0	0 to 6, 13 to 16, 20, 23, 24, 40, 43, 44, 50, 53, 54, 70, 73, 74, 210, 213, 214, 8090, 8093, 8094, 9090, 9093, 9094	By selecting a motor, the thermal characteristic and motor constant of each motor are set.	
80			0.4 to 55 kW*1	Set the applied motor capacity.	
C101	Motor capacity	9999	0 to 3600 kW*2		
			9999	V/F control	
81	Number of motor	9999	2, 4, 6, 8, 10, 12	Set the number of motor poles.	
C102	poles	3333	9999	V/F control	
9	Electronic thermal O/	Rated	0 to 500 A*1		
C103	L relay	inverter current	0 to 3600 A*2	Set the rated motor current.	
83 C104	Rated motor voltage	200/400 V*3	0 to 1000 V	Set the rated motor voltage (V).	
84	Rated motor	0000	10 to 400 Hz	Set the rated motor frequency (Hz).	
C105	frequency	9999	9999	Use the value set in Pr.3 Base frequency.	
707 C107	Motor inertia (integer)	9999	10 to 999, 9999	Set the motor inertia. 9999: Uses the constant value of Mitsubishi	
724 C108	Motor inertia (exponent)	9999	0 to 7, 9999	motor (SF-PR, SF-JR, SF-HR, SF-JRCA, SF-HRCA and so on).	
			0	No offline auto tuning	
			1	Performs offline auto tuning without rotating the motor	
96 C110	Auto tuning setting/ status	0	11	Performs offline auto tuning without rotating the motor (V/F control, IPM motor MM-EFS/MM-THE4) (Refer to page 351)	
			101	Performs offline auto tuning by rotating the motor	
90	Motor constant (R1)	9999	0 to 50 Ω, 9999*1 *4		
C120	width constant (KT)	3333	0 to 400 mΩ, 9999*2 *4		
91	Motor constant (R2)	9999	0 to 50 Ω, 9999*1 *4		
C121	motor constant (N2)		0 to 400 mΩ, 9999*2 *4		
92	Motor constant (L1)/		0 to 6000 mH, 9999*1 *4		
C122	d-axis inductance (Ld)	9999	0 to 400 mH, 9999*2 *4	Tuning data (The value measured by offline auto tuning is	
93	Motor constant (L2)/		0 to 6000 mH, 9999*1 *4	automatically set.)	
C123		9999	0 to 400 mH, 9999*2 *4	9999: Uses the constant value of Mitsubishi motor (SF-PR, SF-JR, SF-HR, SF-JRCA, SF-	
94 C124	Motor constant (X)	9999	0 to 100%, 9999 *4	HRCA and so on).	
82	Motor excitation	0000	0 to 500 A, 9999*1 *4	1	
C125	current	9999	0 to 3600 A, 9999*2 *4	1	
859	Torque current/Rated	0000	0 to 500 A, 9999*1*4		
C126	PM motor current	9999	0 to 3600 A, 9999*2*4	1	

Pr.	Name	Initial value	Setting range	Description
298	Eroguenov goerob		0 to 32767	The offline auto tuning automatically sets the gain required for the frequency search.
A711	Frequency search gain	9999	9999	Uses the constant value of Mitsubishi motor (SF-PR, SF-JR, SF-HR, SF-JRCA, SF-HRCA and so on).
450 C200	Second applied motor	9999	0, 1, 3 to 6, 13 to 16, 20, 23, 24, 40, 43, 44, 50, 53, 54, 70, 73, 74, 210, 213, 214, 8090, 8093, 8094, 9090, 9093, 9094	Set this parameter when using the second motor. (the same specifications as <b>Pr.71</b> ).
			9999	The function is disabled.
453	Second motor	0000	0.4 to 55 kW*1	Set the capacity of the second motor.
C201	capacity	9999	0 to 3600 kW*2 9999	V/F control
454	Number of second		2, 4, 6, 8, 10, 12	Set the number of poles of the second motor.
C202	motor poles	9999	9999	V/F control
	motor poloc		0 to 500 A*1	This function is enabled when the RT signal is
51	Second electronic			ON.
C203	thermal O/L relay	9999	0 to 3600 A*2	Set the rated motor current.
			9999	Second electronic thermal O/L relay disabled
456 C204	Rated second motor voltage	200/400 V*3	0 to 1000 V	Set the rated voltage (V) of the second motor.
457	Rated second motor	0000	10 to 400 Hz	Set the rated frequency (Hz) of the second motor.
C205	frequency	9999	9999	Use the Pr.84 Rated motor frequency setting.
744 C207	Second motor inertia (integer)	9999	10 to 999, 9999	Set the inertia of the second motor. 9999: Uses the constant value of Mitsubishi
745 C208	Second motor inertia (exponent)	9999	10 to 7, 9999	motor (SF-PR, SF-JR, SF-HR, SF-JRCA, SF-HRCA and so on).
			0	No auto tuning for the second motor.
			1	Performs offline auto tuning without rotating the
463 C210	Second motor auto tuning setting/status	0	11	Performs offline auto tuning without rotating the motor (V/F control, IPM motor MM-EFS/MM-THE4)
			101	(Refer to page 351)  Performs offline auto tuning by rotating the
450	Canand mater		0 to 50 0 0000 t	second motor
458 C220	Second motor constant (R1)	9999	0 to 50 Ω, 9999*1 *4 0 to 400 mΩ, 9999*2 *4	
459	Second motor		0 to 50 Ω, 9999*1 *4	
C221	constant (R2)	9999	0 to 400 mΩ, 9999*2 *4	
	Second motor		0 to 6000 mH, 9999*1 *4	
460 C222	constant (L1) / d-axis inductance (Ld)	9999	0 to 400 mH, 9999*2 *4	Tuning data of the second motor
461	Second motor		0 to 6000 mH, 9999*1 *4	(The value measured by offline auto tuning is
C223	constant (L2) / q-axis inductance (Lq)	9999	0 to 400 mH, 9999*2 *4	automatically set.) 9999: Uses the constant value of Mitsubishi motor (SF-PR, SF-JR, SF-HR, SF-JRCA, SF-
462 C224	Second motor constant (X)	9999	0 to 100%, 9999 *4	HRCA and so on).
455	Second motor	9999	0 to 500 A, 9999*1 *4	
C225	excitation current	2222	0 to 3600 A, 9999*2 *4	
860	Second motor torque		0 to 500 A, 9999*1 *4	
C226	current/Rated PM motor current	9999	0 to 3600 A, 9999*2 *4	
560	Second frequency	9999	0 to 32767	The offline auto tuning automatically sets the gain required for the frequency search of the second motor.
A712			9999	Uses the constant value of Mitsubishi motor (SF-PR, SF-JR, SF-HR, SF-JRCA, SF-HRCA and so on).

- \*1 For the FR-F820-02330(55K) or lower and FR-F840-01160(55K)or lower. \*2 For the FR-F820-03160(75K) or higher and FR-F840-01800(75K)or higher.
- \*3 Differs according to the voltage class. (200 V/400 V)
- \*4 The setting range and unit change according to the **Pr.71** (**Pr.450**) setting.



- · The function is enabled under Advanced magnetic flux vector control.
- · Even if a motor other than Mitsubishi standard motors (SF-JR 0.4 kW or higher), high-efficiency motors (SF-HR 0.4 kW or higher), Mitsubishi constant-torque motors (SF-JRCA 4P, SF-HRCA 0.4 kW to 55 kW), or Mitsubishi high-performance energy-serving motor (SF-PR), such as other manufacturers' induction motors, SF-JRC, SF-TH, etc., is used, or when the wiring length is long (approx. 30 m or longer), a motor can run with the optimum operation characteristics by using the offline auto tuning function.
- · Tuning is enabled even when a load is connected to the motor.
- During offline auto tuning, the motor rotation can be locked (Pr.96 = "1") or unlocked (Pr.96 = "101"). The tuning is more accurate when the motor can rotate (unlocked).
- · Reading/writing of the motor constants tuned by offline auto tuning are enabled. The offline auto tuning data (motor constants) can be copied to another inverter with the operation panel.
- The offline auto tuning status can be monitored with the operation panel and the parameter unit.

#### Before performing offline auto tuning

Check the following points before performing offline auto tuning:

- A value other than "9999" is set in Pr.80 and Pr.81, and Advanced magnetic flux vector control.
- · A motor is connected. (The motor should not be rotated by the force applied from outside during the tuning.)
- For the motor capacity, the rated motor current should be equal to or less than the rated inverter current. (It must be 0.4 kW or higher.) If a motor with substantially low rated current compared with the rated inverter current is used, speed and torque accuracies may deteriorate due to torque ripples, etc. Set the rated motor current to about 40% or higher of the rated inverter current.
- The target motor is other than a high-slip motor, a high-speed motor, or a special motor.
- · The highest frequency is 400 Hz.
- The motor may rotate slightly even if the offline auto tuning without motor rotation (Pr.96 Auto tuning setting/status = "1") is selected. (The slight motor rotation does not affect the tuning performance.) Fix the motor securely with a mechanical brake, or before tuning, make sure that it is safe even if the motor rotates. (Caution is required especially in vertical lift applications.)
- Check the following points for the offline auto tuning with motor rotation (Pr.96 Auto tuning setting/status = "101"). Torque is not sufficient during tuning.
  - The motor can be rotated up to the speed close to the rated speed.
  - The mechanical brake is released.
- · Offline auto tuning is not performed correctly when the surge voltage suppression filter (FR-ASF-H/FR-BMF-H) are inserted between the inverter and motor. Be sure to remove them before performing tuning.

#### **◆**Setting

• To perform tuning, set the following parameters about the motor.

First motor Pr.	Second motor Pr.	Name	Initial value	Description
80	453	Motor capacity	9999 (V/F control)	Set the motor capacity (kW).
81	454	Number of motor poles	9999 (V/F control)	Set the number of motor poles (2 to 12).
9	51	Electronic thermal O/L relay	Rated inverter current	Set the rated motor current (A).
83	456	Rated motor voltage	200 V/400 V*1	Set the rated motor voltage (V) printed on the motor's rating plate.
84	457	Rated motor frequency	9999	Set the rated motor frequency (Hz). When the setting is "9999", the <b>Pr.3 Base frequency</b> setting is used.
71	450	Applied motor	0 (standard motor)	Set this parameter according to the motor.*2 Three types of motor constant setting ranges, units and tuning data can be stored according to settings.
96	463	Auto tuning setting/ status	0	Set "1" or "101".  1: Performs tuning without rotating the motor. (Excitation noise occurs at this point.)  101: Performs tuning without rotating the motor. The motor can rotate up to the speed near the rated motor frequency.

- \*1 Differs according to the voltage class. (200 V/400 V)
- \*2 According to the Pr.71 setting, the range of the motor constant parameter setting values and units can be changed. Set the Pr.71 Applied motor setting according to the motor to be used and the motor constant setting range. (For other setting values of Pr.71, refer to page 337.)

			Pr.71 setting	
	Motor	Motor constant parameter mH, % and A unit setting	Motor constant parameter Internal data setting	Motor constant parameter $\Omega$ , m $\Omega$ and A unit setting
Mitsubishi standard	SF-JR and SF-TH	0 (initial value)	3 (4)	_
motor	SF-JR 4P 1.5 kW or lower	20	23 (24)	_
Mitsubishi high-	SF-HR	40	43 (44)	_
efficiency motor	Others	0 (initial value)	3 (4)	_
	SF-JRCA 4P and SF-TH (constant-torque)	1	13 (14)	_
Mitsubishi constant-	SF-HRCA	50	53 (54)	_
torque motor	Other (SF-JRC, etc.)	1	13 (14)	_
Mitsubishi high- performance energy-saving motor	SF-PR	70	73(74)	_
Other manufacturer's standard motor	_	0 (initial value)	3 (4)	5 (star connection motor) 6 (delta connection motor)
Other manufacturer's constant-torque motor	_	1	13 (14)	15 (star connection motor) 16 (delta connection motor)

## • NOTE

- If Pr.11 DC injection brake operation time = "0" or Pr.12 DC injection brake operation voltage = "0", offline auto tuning is performed considering Pr.11 or Pr.12 is set to the initial value.
- If "star connection" or "delta connection" is incorrectly selected in Pr.71, Advanced magnetic flux vector control is not performed normally.

· For tuning accuracy improvement, set the following parameters when the motor constants are known in advance.

First motor Pr.	Second motor Pr.	Name	Mitsubishi motor (SF- JR, SF-HR, SF-JRCA, SF-HRCA)	Other motors
707	744	Motor inertia (integer)	9999 (initial value)	Motor inertia*3
724	745	Motor inertia (exponent)	9999 (Illiliai value)	$Jm=Pr.707 \times 10^{(-Pr.724)} (kg/m^2)$

<sup>\*3</sup> The setting is valid only when a value other than "9999" is set in both Pr.707 (Pr.744) and Pr.724 (Pr.745).

#### Performing tuning



- · Before performing tuning, check the monitor display of the operation panel or the parameter unit if the inverter is in the state ready for tuning. (Refer to 2) below.) Turning ON the start command while tuning is unavailable starts the motor.
- In the PU operation mode, press FWD / REV on the operation panel. For External operation, turn ON the start command (STF signal or STR signal). Tuning will start.

- · Satisfy the required inverter start conditions to start offline auto tuning. For example, stop the input of MRS signal.
- To force tuning to end, use the MRS or RES signal or press on the operation panel. (Turning the start signal (STF signal or STR signal) OFF also ends tuning.)
- During offline auto tuning, only the following I/O signals are valid. (initial value) Input terminals <effective signals>: STP (STOP), OH, MRS, RT, RES, STF, STR, S1 and S2 Output terminals: RUN, OL, IPF, FM/CA, AM, A1B1C1 and SO
- · When the rotation speed and the output frequency are selected for terminals FM/CA and AM, the progress status of offline auto tuning is output in fifteen steps from FM/CA and AM.
- Do not perform ON/OFF switching of the Second function selection(RT) signal during offline auto tuning. Auto tuning will not be performed properly.
- When the offline auto tuning is selected (Pr.96 Auto tuning setting/status = "101"), the motor rotates. Take caution and ensure the safety.
- Since the Inverter running (RUN) signal turns ON when tuning is started, pay close attention especially when a sequence which releases a mechanical brake by the RUN signal has been designed.
- · When executing offline auto tuning, input the run command after switching ON the main circuit power (R/L1, S/L2, T/L3) of the inverter.
- While Pr.79 Operation mode selection = "7", turn the PU operation external interlock (X12) signal ON to tune in the PU operation mode.
- Monitor is displayed on the operation panel (FR-DU08) and the parameter unit (FR-PU07) during tuning as below.

Pr.96 setting value	1	101	1	101
	Parameter unit (l	FR-PU07) display	Operation panel (	FR-DU08) display
(1) Setting	READ:List 1 STOP PU	READ:List 101 STOP PU	PU -MON -MON -MM -PM -NET -PAUN -PM	PU -NON -M -PXT -PRIM -PM -NET -RRUN -PM MODE SET ESC PWD
(2) During tuning	IIIIII   TUNE 2	IIIIII   TUNE 102	RU =NON = M -RU =NON = M -RUT = PM -NET = PRUN -NET = PRUN -NET = RUN -NET = RUN -NET = RUN	PI - MOI - IN -
(3) Normal completion	IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	PU -MON -IM -Flickering MoDE SET ESC + 6000	PU MON PM FM FINE REIN PRIN FICKERING
(4) Forced end	TUNE ERROR	B TOP PU	PU -MON - EXT - MAIN - SET - S	ESC FAVO

#### (C) Motor constant parameters

· Note: Offline auto tuning time (with the initial setting)

Offline auto tuning setting	Time
No motor rotation ( <b>Pr96</b> = "1") Approx. 25 to 120 s (The time depends on the inverter capacity and motor type.)	
With motor rotation ( <b>Pr96</b> = "101)	Approx. 40 s (The following offline auto tuning time is set according to the acceleration/deceleration time setting. Offline auto tuning time = acceleration time + deceleration time + approx. 30 s)

• When offline auto tuning ends, press on the operation panel during PU operation. For External operation, turn OFF the start signal (STF signal or STR signal).

This operation resets the offline auto tuning, and the PU's monitor display returns to the normal indication. (Without this operation, next operation cannot be started.)

- · The motor constants measured once in the offline auto tuning are stored as parameters and their data are held until the offline auto tuning is performed again. However, the tuning data is cleared by performing all parameter clear.
- Changing Pr.71 (Pr.450) after tuning completion will change the motor constant. For example, if Pr.71 = "3" is set after tuning is performed with Pr.71 = "0", the tuning data becomes invalid. Set Pr.71 = "0" again for using the tuning data.
- If offline auto tuning has ended in error (see the table below), motor constants are not set. Perform an inverter reset and restart tuning.

Error display Error cause		Countermeasures	
8	Forced end	Set <b>Pr.96</b> = "1" or "101" and try again.	
9	Inverter protective function operation	Make the setting again.	
91	The current limit (stall prevention) function is activated.	Set the acceleration/deceleration time longer. Set <b>Pr.156</b> = "1".	
92	The converter output voltage has dropped to 75% of the rated voltage.	Check for the power supply voltage fluctuation. Check the <b>Pr.84 Rated motor frequency</b> setting.	
93	Calculation error The motor is not connected.	Check the <b>Pr.83</b> and <b>Pr.84</b> settings. Check the motor wiring and make the setting again.	
94	Rotation tuning frequency setting error (The frequency command for the tuning was given to exceed the maximum frequency setting, or to be in the frequency jump range.)	Check the <b>Pr.1 Maximum frequency</b> and <b>Pr.31</b> to <b>Pr.36</b> Frequency jump settings.	

- When tuning is ended forcibly by pressing or turning OFF the start signal (STF or STR) during tuning, offline auto tuning does not end properly. (The motor constants have not been set.) Perform an inverter reset and restart tuning.
- If using a motor falling under the following conditions, set the value of Pr.9 Electronic thermal O/L relay as shown below after tuning is complete.
  - a) If the rated power supply of the motor is 200/220 V(400/440 V) 60 Hz, set the rated motor current multiplied by 1.1 in
  - b) If using a motor with a temperature detector such as PTC thermistor and Klixon and performs motor overheat protection, set **Pr.9** = "0" (disables the motor overheat protection feature of the inverter).

## NOTE

- · An instantaneous power failure occurring during tuning will result in a tuning error. After power is restored, the inverter starts normal operation. Therefore, when STF (STR) signal is ON, the motor runs in the forward (reverse) rotation.
- · Any alarm occurring during tuning is handled as in the normal operation. Note that even if a retry operation has been set, retry is not performed.
- The set frequency monitor displayed during the offline auto tuning is 0 Hz



#### Caution

- Note that the motor may start running suddenly.
- For the offline auto tuning in vertical lift applications, etc., caution is required to avoid falling due to insufficient torque.

## Changing the motor constants

- If the motor constants are known, the motor constants can be set directly or set using data measured through offline auto tuning.
- According to the Pr.71 (Pr.450) setting, the range of the motor constant parameter setting values and units can be changed. The setting values are stored in the EEPROM as motor constant parameters, and three types of motor constants can be stored.


## ◆Changing the motor constants (If setting the Pr.92 and Pr.93 motor constants in units of mH)

· Set Pr.71 as shown below.

	Pr.71 setting	
Mitsubishi standard motor Mitsubishi high-efficiency motor	SF-JR	0 (initial value)
	SF-JR 4P 1.5 kW or lower	20
Williaddishi High-emolericy Hiotor	SF-HR	40
Mitsubishi constant-torque motor	SF-JRCA 4P	1
Willsubishi constant-torque motor	SF-HRCA	50
Mitsubishi high-performance energy-saving motor	SF-PR	70

• Use the following formula to find the **Pr.94** setting value and set a given value as the motor constant parameter.

The setting value of Pr.94 = 
$$(1 - \frac{M^2}{L1 \times L2}) \times 100(\%$$



- R1: Primary resistance
- R2: Secondary resistance
- I1: Primary leakage inductance
- I2: Secondary leakage inductance
- M: Excitation inductance

L2= I2+ M: Secondary inductance

#### Equivalent circuit diagram of the motor

First motor Pr.	Second motor Pr.	Name	Setting range	Setting increments	Initial value
82 455	Motor excitation current (No-load current)	0 to 500 A, 9999 <sub>*1</sub>	0.01 A <sub>*1</sub>		
		0 to 3600 A, 9999 <sub>*2</sub>	0.1 A <sub>*2</sub>		
90 458	Motor constant (R1)	0 to 50 Ω, 9999*1	0.001 Ω*1	9999	
		0 to 400 mΩ, 9999 <sub>*2</sub>	0.01 mΩ <sub>*2</sub>		
91 459	Motor constant (R2)	0 to 50 Ω, 9999 <sub>*1</sub>	0.001 Ω*1		
		0 to 400 mΩ, 9999*2	0.01 mΩ <sub>*2</sub>		
92 460	Motor constant (L1)/d-axis inductance (Ld)	0 to 6000 mH, 9999 <sub>*1</sub>	0.1 mH∗₁		
		0 to 400 mH, 9999*2	0.01 mH <sub>*2</sub>		
93 461	Motor constant (L2)/q-axis inductance (Lq)	0 to 6000 mH, 9999*1	0.1 mH∗₁		
		0 to 400 mH, 9999*2	0.01 mH <sub>*2</sub>		
94 462	Motor constant (X)	0 to 100%, 9999	0.1%*1		
			0.01%*2		
859 860	000	Torque current/Rated PM motor	0 to 500 A, 9999 <sub>*1</sub>	0.01 A <sub>*1</sub>	]
	current	0 to 3600 A, 9999*2	0.1 A <sub>*2</sub>		
298	560	Frequency search gain	0 to 32767, 9999	1	

- \*1 For the FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower.
- \*2 For the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.



• If "9999" is set, tuning data will be invalid and the constant values for Mitsubishi motors (SF-PR, SF-JR, SF-HR, SF-JRCA, SF-HRCA and so on) are used.

## Changing the motor constants (If setting motor constants in the internal data of the inverter)

· Set Pr.71 as follows.

M	Pr.71 setting	
	SF-JR and SF-TH	3 (4)
Mitsubishi standard motor	SF-JR 4P 1.5 kW or lower	23 (24)
Mitsubishi high-efficiency motor	SF-HR	43 (44)
	Others	3 (4)
	SF-JRCA 4P SF-TH (constant-torque)	13 (14)
Mitsubishi constant-torque motor	SF-HRCA	53 (54)
	Other (SF-JRC, etc.)	13 (14)
Mitsubishi high-performance energy-saving motor	SF-PR	73(74)
Other manufacturer's standard motor	_	3 (4)
Other manufacturer's constant-torque motor	_	13 (14)

• Set given values as the motor constant parameters. The displayed increments of the read motor constants can be changed with **Pr.684 Tuning data unit switchover**.

First	Second		Pr.684 = 0 (init	tial value)	Pr.684 =	1	Initial	
motor Pr.	motor Pr.	Name	Setting range	Setting increments	Range indication	Unit indication	value	
82	455	Motor excitation			0 to 500 A, 9999*1	0.01 A*1		
02	400	current			0 to 3600 A, 9999*2	0.1 A*2		
90	458	Motor constant (R1)			0 to 50 Ω, 9999*1	0.001 Ω*1		
90	430	Woldi Constant (KT)			0 to 400 mΩ, 9999*2	0.01 mΩ*2		
91	450	Matanagarant (DO)			0 to 50 Ω, 9999*1	0.001 Ω*1		
91	459	Motor constant (R2)				0 to 400 mΩ, 9999*2	0.01 mΩ*2	
00	400	Motor constant (L1)/d-	0.4- *** 0000		0 to 6000 mH, 9999*1	0.1 mH*1		
92	460	axis inductance (Ld)	0 to ***, 9999	1	0 to 400 mH, 9999*2	0.01 mH*2	9999	
00	404	Motor constant (L2)/q-			0 to 6000 mH, 9999*1	0.1 mH*1		
93	461	axis inductance (Lq)			0 to 400 mH, 9999*2	0.01 mH*2		
0.4	400	Matan assets (V)			0.4- 4000/ 0000	0.1%*1		
94	462	Motor constant (X)				0 to 100%, 9999	0.01%*2	
050	000	Torque current/Rated			0 to 500 A, 9999*1	0.01 A*1		
859	860	PM motor current			0 to 3600 A, 9999*2	0.1 A*2		
298	560	Frequency search gain	0 to 32767, 9999	1	0 to 32767, 9999	1		

- \*1 For the FR-F820-02330(55K) lower and FR-F840-01160(55K) or lower.
- \*2 For the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.

## NOTE

- As the motor constants measured in the offline auto tuning have been converted into internal data (\*\*\*\*), refer to the following setting example when making setting:
- Setting example: To slightly increase the Pr.90 value (5%)

If **Pr.90** = "2516" is displayed,

the value is calculated with 2516  $\times$  1.05 = 2641.8. Therefore set **Pr.90** = "2642".

(The value displayed has been converted into a value for internal use. Hence, simple addition of a given value to the displayed value has no significance.)

• If "9999" is set, tuning data will be invalid and the constant values for Mitsubishi motors (SF-PR, SF-JR, SF-HR, SF-JRCA, SF-HRCA and so on) are used.

# ◆Changing the motor constants (If setting the Pr.92 and Pr.93 motor

• Set Pr.71 as shown below.

Applicable motor	Pr.71 setting			
Applicable illotol	Star connection motor			
Standard motor	5	6		
Constant-torque motor	15	16		

• Set given values as the motor constant parameters.

constants in units of  $[\Omega]$ )

Iq = torque current, I100 = rated current, I0 = no load current

$$Iq = \sqrt{1100^2 - 10^2}$$

First motor Pr.	Second motor Pr.	Name	Setting range	Setting increments	Initial value
82	455	Motor excitation current	0 to 500 A, 9999*1	0.01 A*1	
02	455	(No-load current)	0 to 3600 A, 9999*2	0.1 A*2	
90	458	Motor constant (r1)	0 to 50 Ω, 9999*1	0.001 Ω*1	1
90	456	Wiotor Constant (11)	0 to 400 mΩ, 9999*2	0.01 mΩ*2	1
91	450	Motor constant (r2)	0 to 50 Ω, 9999*1	0.001 Ω*1	1
91	459	Motor constant (r2)	0 to 400 mΩ, 9999*2	0.01 mΩ*2	
92	460	Motor constant (1)	0 to 50 Ω, 9999*1	0.001 Ω*1	
92	460	Motor constant (×1)	0 to 3600 mΩ, 9999*2	0.01 mΩ*2	9999
93	461	Motor constant (2)	0 to 50 Ω, 9999*1	0.001 Ω*1	
93	401	Motor constant (×2)	0 to 3600 mΩ, 9999*2	0.01 mΩ*2	
94	460	Motor constant (m)	0 to 500 Ω, 9999*1	10040	
94	462	Motor constant (×m)	0 to 100 Ω, 9999*2	- 0.01 Ω	
050	960	Torque current/Rated PM	0 to 500 A, 9999*1	0.01 A*1	
859	860	motor current	0 to 3600 A, 9999*2	0.1 A*2	
298	560	Frequency search gain	0 to 32767, 9999	1	1

- \*1 For the FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower.
- \*2 For the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.

## NOTE

- If "star connection" or "delta connection" is incorrectly selected in Pr.71, Advanced magnetic flux vector control is not performed normally.
- If "9999" is set, tuning data will be invalid and the constant values for Mitsubishi motors (SF-PR, SF-JR, SF-HR, SF-JRCA, SF-HRCA and so on) are used.

#### **◆**Tuning the second applied motor

- When one inverter switches the operation between two different motors, set the second motor in **Pr.450 Second applied motor**. (Refer to **page 337**.) In the initial setting, no second motor is applied.
- Turning ON the RT signal will enable the parameter settings for the second motor as shown below.

Function	RT signal ON (second motor)	RT signal OFF (first motor)
Motor capacity	Pr.453	Pr.80
Number of motor poles	Pr.454	Pr.81
Motor excitation current	Pr.455	Pr.82
Rated motor voltage	Pr.456	Pr.83
Rated motor frequency	Pr.457	Pr.84
Motor constant (R1)	Pr.458	Pr.90
Motor constant (R2)	Pr.459	Pr.91
Motor constant (L1)/d-axis inductance (Ld)	Pr.460	Pr.92
Motor constant (L2)/q-axis inductance (Lq)	Pr.461	Pr.93
Motor constant (X)	Pr.462	Pr.94
Auto tuning setting/status	Pr.463	Pr.96
Frequency search gain	Pr.560	Pr.298

## • NOTE

- The RT signal is assigned to the terminal RT in the initial status. Set "3" in any of **Pr.178 to Pr.189 (input terminal function selection)** to assign the RT signal to another terminal.
- Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### **«** Parameters referred to »

Pr.1 Maximum frequency (1877)

Pr.9 Electronic thermal O/L relay page 225

Pr.31 to Pr.36 Frequency jump 🕮

Pr.71 Applied motor page 337

Pr.156 Stall prevention operation selection page 248

Pr.178 to Pr.189 (input terminal function selection) Pr.178 to Pr.189 (input terminal function selection)

Pr.190 to Pr.196 (output terminal function selection) page 288

## 5.10.3 Offline auto tuning for a PM motor (motor constants tuning)

The offline auto tuning for an PM motor enables the optimal operation of a PM motor.

· What is offline auto tuning?

Under PM motor control, setting motor constants automatically (offline auto tuning) enables optimal operation of motors even when motor constants vary or when the wiring distance is long. IPM and SPM motors other than IPM motor MM-EFS/MM-THE4 can also be used.

For the offline auto tuning under Advanced magnetic flux vector control, refer to page 341.

Pr.	Name	Initial value	Setting range	Description
684			0	Internal data converted value
C000	Tuning data unit switchover	0	1	The value is indicated with "A, $\Omega$ , mH or mV".
1002 C150	Lq tuning target current adjustment coefficient	9999	50 to 150%	Perform adjustment if the overcurrent protective function is activated during tuning.
			9999	No adjustment
71 C100	Applied motor	0	0 to 6, 13 to 16, 20, 23, 24, 40, 43, 44, 50, 53, 54, 70, 73, 74, 210, 213, 214, 8090, 8093, 8094, 9090, 9093, 9094	By selecting a motor, the thermal characteristic and motor constant of each motor are set.
80			0.4 to 55 kW*1	Applied motor capacity setting.
C101	Motor capacity	9999	0 to 3600 kW*2	
			9999	V/F control
81	Number of motor poles	9999	2, 4, 6, 8, 10, 12	Set the number of motor poles.
C102	The state of the s	3000	9999	V/F control
9	Electronic thermal O/L relay	Rated inverter	0 to 500 A*1	Set the rated motor current.
C103	Liectronic thermal O/L relay	current	0 to 3600 A*2	oet the rated motor current.
83 C104	Rated motor voltage	200/400 V*3	0 to 1000 V	Set the rated motor voltage (V).
			10 to 400 Hz	Set the rated motor frequency (Hz).
84 C105	Rated motor frequency	9999	9999	The MM-EFS/MM-THE4 constant is used when the IPM motor MM-EFS/MM-THE4 is selected, and the inverter internal data is used when a PM motor other than MM-EFS/MM-THE4 is selected. Use the correct setting according to the motor specification.
			0 to 400 Hz	Set the maximum frequency of the motor.
702 C106	Maximum motor frequency	9999	9999	The MM-EFS/MM-THE4 motor maximum frequency is used when the IPM motor MM-EFS/MM-THE4 is selected, and Pr.84 setting is used when a PM motor other than MM-EFS/MM-THE4 is selected.
707 C107	Motor inertia (integer)	9999	10 to 999, 9999	Set the motor inertia.
724 C108	Motor inertia (exponent)	9999	0 to 7, 9999	– 9999: Uses MM-EFS/MM-THE4 inertia for IPM motor MM-EFS/MM-THE4.
			0, 101	No offline auto tuning.
96 C110	Auto tuning setting/status	0	1	Performs offline auto tuning without rotating the motor. (motor other than IPM motor MM-EFS/MM-THE4)
<b>5110</b>	Auto tuning setting/status		11	Performs offline auto tuning without rotating the motor (V/F control, IPM motor MM-EFS/MM-THE4).

Pr.	Name	Initial value	Setting range	Description	
90	Motor constant (D4)	9999	0 to 50 Ω, 9999*1*4		
C120	Motor constant (R1)	9999	0 to 400 mΩ, 9999*2*4	Tuning data	
92	Motor constant (L1)/d-axis	9999	0 to 500 mH, 9999*1*4	(The value measured by offline auto	
C122	inductance (Ld)	3333	0 to 50 mH, 9999*2*4	tuning is automatically set.) 9999: Uses the MM-EFS/MM-THE4	
93	Motor constant (L2)/q-axis	9999	0 to 500 mH, 9999*1*4	constant for the IPM motor MM-EFS/MM-	
C123	inductance (Lq)	0000	0 to 50 mH, 9999*2*4	THE4, and the inverter internal data for a	
859	Torque current/Rated PM	9999	0 to 500 A, 9999*1*4	PM motor other than MM-EFS/MM-THE4.	
C126	motor current		0 to 3600 A, 9999*2*4		
706	Induced voltage constant	9999	0 to 5000 mV/(rad/s)*4	Set this parameter according to the PM motor specifications.	
C130	(phi f)		9999	The value calculated by the motor constant parameter setting is used.	
711 C131	Motor Ld decay ratio	9999	0 to 100%, 9999	- Tuning data	
712 C132	Motor Lq decay ratio	9999	0 to 100%, 9999	(The value measured by offline auto tuning is automatically set.)	
717 C182	Starting resistance tuning compensation	9999	0 to 200%, 9999	9999: Uses the MM-EFS/MM-THE4 constant for the IPM motor MM-EFS/MM-	
721 C185	Starting magnetic pole position detection pulse width	9999	0 to 6000 μs, 10000 to 16000 μs, 9999	THE4, and the inverter internal data for a PM motor other than MM-EFS/MM-THE4.	
			100 to 500%	Set the maximum current (OCT) level of the motor.	
725 C133	Motor protection current level	9999	9999	Uses the MM-EFS/MM-THE4 constant for the IPM motor MM-EFS/MM-THE4, and 200% for a PM motor other than MM-EFS/MM-THE4.	
450 C200	Second applied motor	9999	0, 1, 3 to 6, 13 to 16, 20, 23, 24, 30, 33, 34, 40, 43, 44, 50, 53, 54, 70, 73, 74, 330, 333, 334, 8090, 8093, 8094, 9090, 9093, 9094	Set this parameter when using the second motor. (the same specifications as <b>Pr.71</b> ).	
			9999	The function is disabled.	
453			0.4 to 55 kW*1	Set the capacity of the second motor.	
C201	Second motor capacity	9999	0 to 3600 kW*2	. ,	
			9999	V/F control	
454 C202	Number of second motor poles	9999	2, 4, 6, 8, 10, 12	Set the number of poles of the second motor.	
0202	poles		9999	V/F control	
			0 to 500 A*1	Set the rated current of the second motor.	
51	Second electronic thermal	9999	0 to 3600 A*2		
C203	O/L relay		9999	Second electronic thermal O/L relay disabled.	
456 C204	Rated second motor voltage	200/400 V*3	0 to 1000 V	Set the rated voltage (V) of the second motor.	
			10 to 400 Hz	Set the rated frequency (Hz) of the second motor.	
457 C205	Rated second motor frequency	9999	9999	The MM-EFS/MM-THE4 constant is used when the IPM motor MM-EFS/MM-THE4 is selected for the second motor, and the inverter internal data is used when a PM motor other than MM-EFS/MM-THE4 is selected. Use the correct setting according to the motor specification.	
			0 to 400 Hz	Set the maximum frequency of the second motor.	
743 C206	Second motor maximum frequency	9999	9999	The maximum frequency of an MM-EFS/MM-THE4 motor when MM-EFS/MM-THE4 is selected. The setting value of <b>Pr.457</b> is used for non-MM-EFS/MM-THE4 motors.	

Pr.	Name	Initial value	Setting range	Description	
744 C207	Second motor inertia (integer)	9999	10 to 999, 9999	Set the inertia of the second motor.  9999: Uses MM-EFS/MM-THE4 inertia for	
745 C208	Second motor inertia (exponent)	9999	0 to 7, 9999	IPM motor MM-EFS/MM-THE4.	
			0, 101	No auto tuning for the second motor.	
463 C210	Second motor auto tuning setting/status	0	1	Performs offline auto tuning without rotating the second motor. (motor other than the IPM motor MM-EFS/MM-THE4)	
0210	Jetting/Julius		11	Performs offline auto tuning without rotating the motor (for IPM motor MM-EFS/MM-THE4).	
458	Second motor constant (R1)	9999	0 to 50 Ω, 9999*1*4		
C220	` ,	3333	0 to 400 mΩ, 9999*2*4	Tuning data of the second motor	
460	Second motor constant (L1)	9999	0 to 500 mH, 9999*1*4	(The value measured by offline auto	
C222	/ d-axis inductance (Ld)	0000	0 to 50 mH, 9999*2*4	tuning is automatically set.)	
461	Second motor constant (L2)	9999	0 to 500 mH, 9999*1*4	9999: Uses the MM-EFS/MM-THE4 constant for the IPM motor MM-EFS/MM-	
C223	/ q-axis inductance (Lq)		0 to 50 mH, 9999*2*4	THE4, and the inverter internal data for a	
860	Second motor torque	•	0 to 500 A, 9999*1*4	PM motor other than MM-EFS/MM-THE4.	
C226	current/Rated PM motor current	9999	0 to 3600 A, 9999*2*4		
738	Second motor induced	9999	0 to 5000 mV/(rad/s)*4	Set this parameter according to the PM motor specifications.	
C230	voltage constant (phi f)	3333	9999	Value calculated based on the tuning data.	
739 C231	Second motor Ld decay ratio	9999	0 to 100%, 9999	Tuning data of the second motor.	
740 C232	Second motor Lq decay ratio	9999	0 to 100%, 9999	(The value measured by offline auto 9999: Uses the MM-EFS/MM-THE4	
741 C282	Second starting resistance tuning compensation	9999	0 to 200%, 9999	constant for the IPM motor MM-EFS/MM-THE4, and the inverter internal data for a	
742 C285	Second motor magnetic pole detection pulse width	9999	0 to 6000 μs, 10000 to 16000 μs, 9999	PM motor other than MM-EFS/MM-THE	
			100 to 500%	Set the maximum current (OCT) level of the second motor.	
746 C233			9999	Uses the MM-EFS/MM-THE4 constant for the IPM motor MM-EFS/MM-THE4, and 200% for a PM motor other than MM-EFS/MM-THE4.	

- \*1 For the FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower.
- \*2 For the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.
- \*3 Differs according to the voltage class. (200 V/400 V)
- \*4 The setting range and unit change according to the **Pr.71** (**Pr.450**) setting.

## POINT

- The settings are valid under the PM motor control.
- The offline auto tuning enables the operation with SPM motors and IPM motors other than MM-EFS/MM-THE4. (When a PM motor other than the IPM motor MM-EFS/MM-THE4 is used, always perform the offline auto tuning.)
- Tuning is enabled even when a load is connected to the motor.
- Reading/writing of the motor constants tuned by offline auto tuning are enabled. The offline auto tuning data (motor constants) can be copied to another inverter with the operation panel.
- The offline auto tuning status can be monitored with the operation panel and the parameter unit.

#### **◆**Before performing offline auto tuning

Check the following points before performing offline auto tuning.

- The PM motor control is selected.
- A motor is connected. Note that the motor should be at a stop at a tuning start. (The motor should not be rotated by the force applied from outside during the tuning.)
- For the motor capacity, the rated motor current should be equal to or less than the rated inverter current. (It must be 0.4 kW or higher.) If a motor with substantially low rated current compared with the rated inverter current is used, speed and torque accuracies may deteriorate due to torque ripples, etc. Set the rated motor current to about 40% or higher of the rated inverter current.
- The maximum frequency under PM motor control is 400 Hz.
- The motor may rotate slightly even if the offline auto tuning without motor rotation (**Pr.96 Auto tuning setting/status** = "1 or 11") is selected. (It does not affect the tuning performance.) Fix the motor securely with a mechanical brake, or before tuning, make sure that it is safe even if the motor rotates. (Caution is required especially in vertical lift applications.)
- Offline auto tuning is not performed correctly when the surge voltage suppression filter (FR-ASF-H/FR-BMF-H) are inserted between the inverter and motor. Be sure to remove them before performing tuning.

#### Setting

• To perform tuning, set the following parameters about the motor.

First motor Pr.	Second motor Pr.	Name	Setting for a PM motor other than MM-EFS/MM-THE4	Setting for MM-EFS/MM-THE4
80	453	Motor capacity	Motor capacity (kW)	
81	454	Number of motor poles	The number of motor poles (2 to 12)	Set by the IPM parameter initialization (Refer to
9	51	Electronic thermal O/L relay	Rated motor current (A)	page 150.)
84	457	Rated motor frequency	Rated motor frequency (Hz)	pago 100.)
83	456	Rated motor voltage	Rated motor voltage (V)	Rated motor voltage (V) written on the motor's rating plate
71	450	Applied motor	8090, 8093 (IPM motor) 9090, 9093 (SPM motor)*1	210 and 213 <sub>*1</sub>
96	463	Auto tuning setting/status	1	11

<sup>\*1</sup> Set **Pr.71 Applied motor** according to the motor to be used. According to the **Pr.71** setting, the range of the motor constant parameter setting values and units can be changed. (For other setting values of **Pr.71**, refer to **page 337**.)

Motor		Pr.71 setting		
		Motor constant parameter Ω, mH and A unit setting	Motor constant parameter Internal data setting	
IDM master	MM-EFS/MM-THE4		213 (214)	
IPM motor Other than MM-EFS/MM-THE4		8090	8093 (8094)	
SPM motor		9090	9093 (9094)	

## • NOTE

- If PM motor control is performed, tuning cannot be performed even when **Pr.96** = "101" is set. If MM-EFS/MM-THE4 is set to the applied motor, tuning cannot be performed even when **Pr.96** = "1, 101" is set.
- · For the tuning accuracy improvement, set the following parameter when the motor constant is known in advance.

First motor Pr.	Second motor Pr.	Name	Setting for a PM motor other than MM-EFS/MM-THE4	Setting for MM-EFS/MM-THE4
702	743	Maximum motor frequency	The maximum motor frequency (Hz)	9999 (initial value)
707	744	Motor inertia (integer)	Motor inertia*1	9999 (initial value)
724	745	Motor inertia (exponent)	Jm= <b>Pr.707</b> × 10 <sup>^</sup> (- <b>Pr.724</b> ) (kg/m <sup>2</sup> )	9999 (Illitial value)
725	746	Motor protection current level	Maximum current level of the motor (%)	9999 (initial value)

<sup>\*1</sup> The setting is valid only when both of the Pr.707 (Pr.744) and Pr.724 (Pr.745) settings are other than "9999".

## Performing tuning



- · Before performing tuning, check the monitor display of the operation panel or the parameter unit if the inverter is in the state ready for tuning. Turning ON the start command while tuning is unavailable starts the motor.
- In the PU operation mode, press FWD / REV on the operation panel. For External operation, turn ON the start command (STF signal or STR signal). Tuning will start.

#### • NOTE

- · Satisfy the required inverter start conditions to start offline auto tuning. For example, stop the input of MRS signal.
- on the operation panel. (Turning the start signal (STF • To force tuning to end, use the MRS or RES signal or press signal or STR signal) OFF also ends tuning.)
- During offline auto tuning, only the following I/O signals are valid (initial value) Input terminals <effective signals>: STP (STOP), OH, MRS, RT, RES, STF, STR, S1 and S2 Output terminals: RUN, OL, IPF, FM/CA, AM, A1B1C1 and SO
- · When the rotation speed and the output frequency are selected for terminals FM/CA and AM, the progress status of offline auto tuning is output in fifteen steps from FM/CA and AM.
- Do not perform ON/OFF switching of the Second function selection(RT) signal during offline auto tuning. Auto tuning will not be performed properly.
- A motor with 14 or more poles cannot be tuned.
- · Since the Inverter running (RUN) signal turns ON when tuning is started, pay close attention especially when a sequence which releases a mechanical brake by the RUN signal has been designed.
- When executing offline auto tuning, input the run command after switching ON the main circuit power (R/L1, S/L2, T/L3) of the inverter.
- While Pr.79 Operation mode selection = "7", turn the PU operation external interlock (X12) signal ON to tune in the PU operation mode.
- Monitor is displayed on the operation panel (FR-DU08) and the parameter unit (FR-PU07) during tuning as below.

Pr.96 (Pr.463) Setting	1	11	1	11
	Parameter unit (I	FR-PU07) display	Operation panel	(FR-DU08) display
(1) Setting	READ:List 1 STOP PU	READ:List 11 STOP PU	PU -MON -IM -EXT -FRM -M -NET -FAUN MODE SET ESC FWD	PU - MON - IM - EXT - PRIM - PM - NET - PRIM - PM MODE SET ESC - FAVO
(2) During tuning	IIIIII   TUNE 2	TUNE 12	PU -MON -M -RU -MON -M -NET -RRUN -PM -NET -RRUN -PM	PU -MON -PM -SET -RRIN -PM -NET -RRIN -FW -FWD
(3) Normal completion	TUNE 3 COMPLETION STF STOP PU	TUNE 13 COMPETION STF STOP PU	PU JMON IM  EXT SEM SEM SET ESC DOWN	PN P
(4) Forced end	TUNE ERROR		PU -PU -P - NET -P MODE SET	HON THE

#### (C) Motor constant parameters

• When offline auto tuning ends, press on the operation panel during PU operation. For External operation, turn OFF the start signal (STF signal or STR signal).

This operation resets the offline auto tuning, and the PU's monitor display returns to the normal indication. (Without this operation, next operation cannot be started.)

#### **→** NOTE

- The motor constants measured once in the offline auto tuning are stored as parameters and their data are held until the offline auto tuning is performed again. However, the tuning data is cleared by performing all parameter clear.
- Changing **Pr.71** after tuning completion will change the motor constant. For example, if **Pr.71** = "8093" is set after tuning is performed with **Pr.71** = "8090", the tuning data becomes invalid. Set **Pr.71** = "8090" again for using the tuning data.
- If offline auto tuning has ended in error (see the table below), motor constants are not set. Perform an inverter reset and restart tuning.

Error display	Error cause	Countermeasures
8	Forced end	Set <b>Pr.96</b> ( <b>Pr.463</b> ) = "1" or "11" and try again.
9	Inverter protective function operation	Make the setting again.
92	The converter output voltage has dropped to 75% of the rated voltage.	Check for the power supply voltage fluctuation. Check the <b>Pr.84 Rated motor frequency</b> setting.
93	Calculation error. The motor is not connected.	Check the motor wiring and make the setting again.
94	Rotation tuning frequency setting error (The frequency command for the tuning was given to exceed the maximum frequency setting, or to be in the frequency jump range.)	Check the <b>Pr.1 Maximum frequency</b> and <b>Pr.31</b> to <b>Pr.36</b> Frequency jump settings.

• When tuning is ended forcibly by pressing or turning OFF the start signal (STF or STR) during tuning, offline auto tuning does not end properly. (The motor constants have not been set.)

Perform an inverter reset and restart tuning.

## • NOTE

- An instantaneous power failure occurring during tuning will result in a tuning error.
   After power is restored, the inverter starts normal operation. Therefore, when STF (STR) signal is ON, the motor runs in the forward (reverse) rotation.
- Any alarm occurring during tuning is handled as in the normal operation. However, if the retry function is set, no retry is performed even when a protective function that performs a retry is activated.
- The set frequency monitor displayed during the offline auto tuning is 0 Hz.



Note that the motor may start running suddenly.

## ◆Parameters in which the tuning results are set to after tuning

First motor Pr.	Second motor Pr.	Name	Other than MM-EFS/MM-THE4 Pr.96 (Pr.463) = 1	V/F control or MM-EFS/MM-THE4 Pr.96 (Pr.463) = 11	Description
90	458	Motor constant (R1)	0	0	Resistance per phase
92	460	Motor constant (L1)/d-axis inductance (Ld)	0	_	d-shaft inductance
93	461	Motor constant (L2)/q-axis inductance (Lq)	0	_	q-shaft inductance
711	739	Motor Ld decay ratio	0	_	d-shaft inductance decay ratio
712	740	Motor Lq decay ratio	0	_	q-shaft inductance decay ratio
717	741	Starting resistance tuning compensation	0	0	
721	742	Starting magnetic pole position detection pulse width	0	_	When the setting value is 10000 or more: With polarity inversion for compensation, voltage pulse (Pr. setting minus 10000) µs
859	860	Torque current/Rated PM motor current	0	_	
96	463	Auto tuning setting/status	0	0	

#### ▶Tuning adjustment (Pr.1002)

• The overcurrent protective function may be activated during Lq tuning for an easily magnetically saturated motor (motor with a large Lg decay ratio). In such case, adjust the target flowing current used for tuning with Pr.1002 Lq tuning target current adjustment coefficient.

#### Changing the motor constants

- · If the motor constants are known, the motor constants can be set directly or set using data measured through offline auto
- · According to the Pr.71 (Pr.450) setting, the range of the motor constant parameter setting values and units can be changed. The setting values are stored in the EEPROM as motor constant parameters, and two types of motor constants can be stored.

## lacktriangle Changing the motor constants (If setting motor constants in units of $[\Omega]$ , [mH] or [A])

· Set Pr.71 as shown below.

	Pr.71 setting	
IPM motor	MM-EFS/MM-THE4	210
IF WITHOUT	Other than MM-EFS/MM-THE4	8090
SPM motor		9090

· Set given values as the motor constant parameters.

First Pr.	Second Pr.	Name	Setting range	Setting increments	Initial value
90	458	Motor constant (R1)	0 to 50 Ω, 9999*1	0.001 Ω*1	
30	450	Motor constant (KT)	0 to 400 mΩ, 9999*2	0.01 mΩ*2	
92	460	Motor constant (L1)/d-axis inductance (Ld)	0 to 500 mH, 9999*1	0.01 mH*1	
32	92 400	I Wotor constant (E1)/d-axis inductance (Ed)	0 to 50 mH, 9999*2	0.001 mH*2	
93	461	Motor constant (L2)/q-axis inductance (Lq)	0 to 500 mH, 9999*1	0.01 mH*1	9999
93	401	Motor constant (L2)/q-axis inductance (Lq)	0 to 50 mH, 9999*2	0.001 mH*2	
706	738	Induced voltage constant (phi f)	0 to 5000 mV/(rad/s), 9999	0.1 mV/(rad/s)	
859	860	To revie a compant/Data d DM reactor accorde	0 to 500 A, 9999*1	0.01 A*1	
009	000	Torque current/Rated PM motor current	0 to 3600 A, 9999*2	0.1 A*2	

- \*1 For the FR-F820-02330(55K) or lower and FR-F840-01160(55K)or lower.
- \*2 For the FR-F820-03160(75K) or higher and FR-F840-01800(75K)or higher.



• Setting "9999" disables the tuning data. The MM-EFS/MM-THE4 constant is used for the IPM motor MM-EFS/MM-THE4, and the inverter internal constant is used for a PM motor other than MM-EFS/MM-THE4.

## ◆ Changing the motor constants (If setting a motor constants in the internal data of the inverter)

· Set Pr.71 as follows.

	Pr.71 setting	
IPM motor	MM-EFS/MM-THE4	213 (214)
IFW MOLO	Other than MM-EFS/MM-THE4	8093 (8094)
SPM motor		9093 (9094)

• Set given values as the motor constant parameters. The displayed increments of the read motor constants can be changed with **Pr.684 Tuning data unit switchover**.

First	Second		Pr.684 = 0 (	initial value)	Pr.684 =	1	Initial
motor Pr.	motor Pr.	Name	Setting range	Setting increments	Range indication	Unit indication	Initial value
90	458	Motor constant (R1)			0 to 50 Ω, 9999*1	0.001 Ω*1	
90	430	WOLOF CONSTANT (KT)			0 to 400 mΩ, 9999*2	0.01 mΩ*2	
92	460	Motor constant (L1)/d-	1		0 to 500 mH, 9999*1	0.01 mH*1	
92	400	axis inductance (Ld)			0 to 50 mH, 9999*2	0.001 mH*2	
93	461	Motor constant (L2)/q-	0 to ***, 9999	1	0 to 500 mH, 9999*1	0.01 mH*1	9999
93	401	axis inductance (Lq)	0 10 , 9999	'	0 to 50 mH, 9999*2	0.001 mH*2	3333
706	738	Induced voltage constant (phi f)			0 to 5000 mV/s/rad, 9999	0.1 mV/(rad/s)	
859	860	Torque current/Rated	1		0 to 500 A, 9999*1	0.01 A*1	
009	000	PM motor current			0 to 3600 A, 9999*2	0.1 A*2	

- \*1 For the FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower.
- \*2 For the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.

## • NOTE

- As the motor constants measured in the offline auto tuning have been converted into internal data (\*\*\*\*), refer to the following setting example when making setting:
- Setting example: To slightly increase **Pr.90** value (5%)

If Pr.90 = "2516" is displayed

The value can be calculated with "2516  $\times$  1.05 = 2641.8". Therefore set **Pr.90** = "2642".

(The value displayed has been converted into a value for internal use. Hence, simple addition of a given value to the displayed value has no significance)

• Setting "9999" disables the tuning data. The MM-EFS/MM-THE4 constant is used for the IPM motor MM-EFS/MM-THE4, and the inverter internal constant is used for a PM motor other than MM-EFS/MM-THE4.

#### # Parameters referred to

Pr.9 Electronic thermal O/L relay page 225

Pr.71 Applied motor page 337

Pr.178 to Pr.189 (input terminal function selection) page 329

#### 5.10.4 Online auto tuning Magneticifix

If online auto tuning is selected under Advanced magnetic flux vector control, favorable torque accuracy is retained by adjusting temperature even when the resistance value varies due to increase in the motor temperature.

Pr.	Name	Initial value	Setting range	Description
95	Online auto tuning	0	0	Do not perform online auto tuning
C111	selection	U	1	Perform online auto tuning at startup
574 C211	Second motor online auto tuning	0	0 and 1	Select online auto tuning for the second motor. (same as <b>Pr.95</b> )

#### ◆Performing online auto tuning at startup (setting value "1")

- By promptly tuning the motor status at startup, accurate operation without being affected by motor temperature is achieved. Also high torque can be provided at very low speed and stable operation is possible.
- When using Advanced magnetic flux vector control (Pr.80 Motor capacity, Pr.81 Number of motor poles), select the online auto tuning at start.
- Make sure to perform offline auto tuning before performing online auto tuning.
- · Operation method
  - 1) Perform offline auto tuning. (Refer to page 341.)
  - 2) Check that Pr.96 Auto tuning setting/status = "3 or 103 (offline auto tuning completion)".
  - 3) Set Pr.95 Online auto tuning selection = "1 (online auto tuning at start)".
  - 4) Check that the following parameters are set before starting operation.

Pr. Description	
9	Uses both rated motor current and electronic thermal O/L relay.
71	Applicable motor
80	Motor capacity (with the rated motor current equal to or lower than the rated inverter current)*1
81	Number of motor poles


- \*1 If a motor with substantially low rated current compared with the rated inverter current is used, speed and torque accuracies may deteriorate due to torque ripples, etc. Set the rated motor current to about 40% or higher of the rated inverter current.
- 5) In the PU operation mode, press FWD / REV on the operation panel.

For External operation, turn ON the start command (STF signal or STR signal).


## NOTE

- When performing the online auto tuning at start for a lift, consider utilization of tuning using the external terminal. The tuning is completed in approximately 500 ms at the maximum after the start. Not enough torque may be provided during that period. Caution is required to prevent the object from dropping. Use of the start-time tuning start (X28) signal is recommended to perform tuning. (Refer to page 360.)
- · Perform online auto tuning at startup when the motor is stopped.
- The online auto tuning is disabled when the MRS signal is being input, the setting speed is Pr.13 Starting frequency or lower (V/F control, Advanced magnetic flux vector control), an inverter fault is occurring, or the inverter's startup condition is not satisfied.
- · Online auto tuning does not operate during deceleration and restart from DC injection brake operation.
- · It is disabled during JOG operation.
- If automatic restart after instantaneous power failure is selected, automatic restart is prioritized. (Online auto tuning at startup does not run during frequency search.)
  - If automatic restart after instantaneous power failure is used together, perform online auto tuning while stopping operation with the X28 signal. (Refer to page 360.)
- · Zero current detection and output current detection are enabled during online auto tuning.
- No RUN signal is output during online auto tuning. The RUN signal is turned ON at operation startup.
- If the time between the inverter stop and restart is within 4 s, tuning is performed at startup but its result will not not applied.

## ◆Online auto tuning at startup using the external terminal (setting value "1", X28 signal and Y39 signal)



- Before turning ON the start signal (STF or STR), online auto tuning can be performed by turning ON the Start-time tuning start external input (X28) signal in a stopped status. Such operation will minimize the startup delay by turning at start.
- Perform offline auto tuning and set Pr.95 = "1" (tuning at start).
- When Start time tuning completion (Y39) is OFF, tuning at start can be performed with X28 signal.
- Time Up to 500 ms can be taken to complete tuning at startup.
  - To use the X28 signal, set "28" in any of Pr.178 to Pr.189 (Input terminal function selection) to assign the function to an input terminal.
  - To use the Y39 signal, set "39 (positive logic) or 139 (negative logic)" in any of Pr.190 to Pr.196 (output terminal function selection) to assign function to an output terminal.



## NOTE

- The Y39 signal remains ON as long as there is second flux even after the motor is stopped.
- The X28 signal is disabled while the Y39 signal is ON.
- The STF and STR signals are enabled after completing tuning at start.
- The Inverter running (RUN) signal is not turned ON during online auto tuning. The RUN signal is turned ON after starting up.
- It is disabled during V/F control or PM motor control.
- Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) and Pr.190 to Pr.196 (output terminal function selection) may affect other functions. Set parameters after confirming the function of each terminal.

#### **◆Tuning the second applied motor (Pr.574)**

• When switching two different motors by one inverter, set the second motor in Pr.450 Second applied motor. (In the initial setting, no second motor is applied. (Refer to page 337.))

Pr.574 is enabled when the Second function selection (RT) signal is turned ON.

Pr.	Description
450	Applicable motor
453	Motor capacity (with the rated motor current equal to or lower than the rated inverter current)*1
454	Number of motor poles

If a motor with substantially low rated current compared with the rated inverter current is used, speed and torque accuracies may deteriorate due to torque ripples, etc. Set the rated motor current to about 40% or higher of the rated inverter current.

#### • NOTE

- The RT signal is a second function selection signal. The RT signal also enables other second functions. (Refer to page 329.) The RT signal is assigned to the terminal RT in the initial status. Set "3" in any of Pr.178 to Pr.178 (input terminal function selection) to assign the RT signal to another terminal.
- · Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### # Parameters referred to

Pr.9 Electronic thermal O/L relay page 225 Pr.71 Applied motor page 337 Pr.80 Motor capacity page 143, page 341, page 351 Pr.81 Number of motor poles page 143, page 341, page 351 Pr.96 Auto tuning setting/status page 341, page 351 Pr.178 to Pr.189 (input terminal function selection) page 329 Pr.190 to Pr.196 (output terminal function selection) page 288

Purpose	Р	arameter to set		Refer to page
To operate by switching between the inverter and the commercial power supply operation	Electronic bypass function	P.A000 to P.A005	Pr.135 to Pr.139, Pr.159	363
To reduce the standby power	Self power management	P.A002, P.A006, P.A007, P.E300	Pr.30, Pr.137, Pr.248, Pr.254	370
To strengthen or weaken the frequency at a constant cycle	Traverse operation	P.A300 to P.A305	Pr.592 to Pr.597	373
To remove stains on the impellers or fans of pumps by repeating a forward/reverse rotation	Cleaning function	P.A420 to P.A430	Pr.1469 to Pr.1479	375
	Multi-pump function (Advanced PID function)	P.A400 to P.A413	Pr.578 to Pr.591	406
To perform process control, such as for the pump flow volume and air volume	PID control	P.A600 to P.A607, P.A610 to P.A615, P.A621 to P.A625, P.A640 to P.A644, P.A650 to P.A655, P.A661 to P.A665, P.A683 to P.A689	Pr.127 to Pr.134, Pr.553, Pr.554, Pr.575 to Pr.577, Pr.609, Pr.610, Pr.753 to Pr.758, Pr.1015, Pr.1134, Pr.1135, Pr.1140, Pr.1141, Pr.1143 to Pr.1149, Pr.1460 to Pr.1466	378
	PID pre-charge function	P.A616 to P.A620, P.A626, P.A656 to P.A660, P.A666	Pr.760 to Pr.769, Pr.1132, Pr.1133	402
	PID display adjustment	P.A630 to P.A633, P.A670 to P.A673	C42 to C45 (Pr.934, Pr.935), Pr.1136 to Pr.1139	399
To continue operating at analog current input loss	4 mA input check	P.A680 to P.A682	Pr.573, Pr.777, Pr.778	325
	Automatic restart after instantaneous power failure / flying start function for induction motors	P.A700 to P.A705, P.A710, P.F003	Pr.57, Pr.58, Pr.162 to Pr.165, Pr.299, Pr.611	414
To restart without stopping the motor at instantaneous power failure	Frequency search accuracy improvement (V/F control, offline auto tuning)	P.A700, P.A711, P.A712, P.C110, P.C210	Pr.96, Pr.162, Pr.298, Pr.463, Pr.560	422
	Automatic restart after instantaneous power failure / flying start function for IPM motors	P.A700, P.A702, P.F003, P.F004	Pr.57, Pr.162, Pr.611	420
To decelerate the motor to a stop at instantaneous power failure	Power failure time deceleration-to-stop function	P.A730 to P.A735, P.A785	Pr.261 to Pr.266, Pr.294	426
To operate with sequence program	PLC function	P.A800 to P.A804, P.A811 to P.A860	Pr.414 to Pr.417, Pr.498, Pr.1150 to Pr.1199	431
To store the inverter running status to a USB memory device	Trace function	P.A900 to P.A906, P.A910 to P.A920, P.A930 to P.A939	Pr.1020 to Pr.1047	433

#### 5.11.1 Electronic bypass function Magnetic flux

The inverter contains complicated sequence circuits for switching between the commercial power supply operation and inverter operation. Therefore, interlock operation of the magnetic contactor for switching can be easily performed by simply inputting start, stop, and automatic switching selection signals.

Pr.	Name	Initial	Setting	Description
	Hame	value	range	·
			0	Coasting time differs according to the inverter capacity.*1
57 A702	Restart coasting time	9999	0.1 to 30 s	Set the waiting time for the inverter to perform a restart at power restoration after an instantaneous power failure.
			9999	No restart
58 A703	Restart cushion time	1 s	0 to 60 s	Set the voltage cushion time for restart.
135	Electronic bypass	0	0	Without electronic bypass sequence
A000	sequence selection	U	1	With electronic bypass sequence
136 A001	MC switchover interlock time	1 s	0 to 100 s	Set the operation interlock time for MC2 and MC3.
137 A002	Start waiting time	0.5 s	0 to 100 s	Set a time period that is a little longer than the time period from the ON signal input to the actual pick-up operation of MC3 (0.3 to 0.5 s).
			0	Inverter output stop (motor coasting) at inverter failure
138 A003	Bypass selection at a fault	0	1	Automatic switchover to commercial power supply operation at inverter failure. (Switchover is not possible when an external thermal relay (E.OHT) or CPU fault (E.CPU) is occurring.)
139 A004	Automatic switchover frequency from inverter to bypass operation	9999	0 to 60 Hz	Set the frequency where the inverter operation is switched to commercial power supply operation.  The inverter operation is performed from a start to <b>Pr.139</b> setting, then it switches automatically to the commercial power supply operation when the output frequency is equal to or above <b>Pr.139</b> .
			9999	Without automatic switchover
159 A005	Automatic switchover frequency range from bypass to inverter	9999	0 to 10 Hz	Set the frequency where the commercial power supply operation, which has been switched from the inverter operation with <b>Pr.139</b> , switches back to inverter operation. When the frequency command becomes less than ( <b>Pr.139</b> - <b>Pr.159</b> ), the motor switches automatically to inverter operation and operates at the frequency of the frequency command. Turning OFF the inverter start command (STF/STR) also switches the operation to the inverter operation.
	operation		9999	To switch the commercial power supply operation, which has been switched from the inverter operation with <b>Pr.139</b> , to the inverter operation again, the inverter start command (STF/STR) is turned OFF. The operation switches to the inverter operation, and the motor decelerates to a stop.

<sup>\*1</sup> The coasting time when Pr.57 = "0" is as shown below. (When Pr.162 Automatic restart after instantaneous power failure selection is set to the initial value.)

FR-F820-00077(1.5K) or lower and FR-F840-00038(1.5K) or lower: 0.5 s

FR-F820-00105(2.2K) to FR-F820-00340(7.5K) and FR-F840-00052(2.2K) to FR-F840-00170(7.5K): 1 s

FR-F820-00490(11K) to FR-F820-02330(55K) and FR-F840-00250(11K) to FR-F840-01160(55K): 3.0 s


FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher: 5.0 s

## Electronic bypass sequence function

- When operating the motor at 60 Hz (or 50 Hz), the motor can be more efficiently operated with a commercial power supply. In addition, if the motor cannot be stopped for a long period of time even for an inverter maintenance and inspection, it is recommended that a commercial power supply circuit be installed.
- · When switching between inverter operation and commercial power supply operation, commercial power supply may be accidentally applied to the output side of the inverter. To avoid such situation, provide an interlock where the magnetic contactor at the commercial power supply side turns ON at turn OFF of the magnetic contactor at the inverter output side. The inverter's electronic bypass sequence that outputs timing signals for the magnetic contactors can act as a complicated interlock between the commercial power supply operation and the inverter operation.


#### ◆Connection diagram

- A tipical connection diagram of the electronic bypass sequence is shown below.
  - Sink logic, Pr.185 = "7", Pr.186 = "6", Pr.192 = "17", Pr.193 = "18", and Pr.194 = "19"



Standard models

- Sink logic, Pr.182 = "24", Pr.183 = "95", Pr.184 = "96", Pr.185 = "7", Pr.192 = "17", Pr.193 = "18", Pr.194 = "19"



Separated converter type

\*1 Be careful of the capacity of the sequence output terminals.

The applied terminals differ by the settings of Pr.190 to Pr.196 (output terminal function selection).

Output terminal capacity	Output terminal permissible load
Open collector output of inverter (RUN, SU, IPF, OL, FU)	24 VDC 0.1 A
Inverter relay output (A1-C1, B1-C1, A2-B2, B2-C2)	230 VAC 0.3 A
Relay output option (FR-A8AR)	30 VDC 0.3 A

- \*2 When connecting a DC power supply, insert a protective diode.
  - When connecting an AC power supply, use the relay output option (FR-A8AR) and use contact outputs.
- \*3 The applied terminals differ by the settings of Pr.180 to Pr.189 (input terminal function selection).
- \*4 To use the signal, assign the function to the output terminal Pr.190 to Pr.195 (output terminal function selection) of the converter unit. Always set the negative logic for the ALM signal.

## • NOTE

- Use the electronic bypass function in External operation mode. In addition, the wiring terminals R1/L11 and S1/L21 must be connected to a separate power source that does go through MC1. Be sure to connect using a separate power supply.
- Be sure to provide a mechanical interlock for MC2 and MC3.

· Operation of magnetic contactor (MC1, MC2, MC3)

Magnetic		Operation					
Magnetic contactor	Installation location	During commercial power supply operation	During inverter operation	During inverter fault			
MC1	Between power supply and inverter input side	Shorted	Shorted	Open (short by reset)			
MC2	Between power supply and motor	Shorted	Open	Open (Selected by <b>Pr.138</b> . Always open when the external thermal relay is operating.)			
MC3	Between inverter output side and motor	Open	Shorted	Open			

· The input signals are as shown below.

Cianal	Applied	Function	Onerstien	MC operation*8		
Signal	terminal	Function	Operation	MC1*6	MC2	MC3
MRS MRS*1	MDC .	Selects whether or not	ON Electronic bypass operation available	0	-	-
	IVIR'S*I	operation is available.*2	OFF Electronic bypass operation not available	0	×	Invariance
		Invertor/commercial newer	ON Inverter operation	0	×	0
CS	CS	Inverter/commercial power supply operation switchover*3	OFF Commercial power supply operation	0	0	x
STF (STR)	STF (STR)	Inverter operation command (Disabled during commercial	ON Forward rotation (reverse rotation)	0	×	0
(STK)	(31K)	power supply operation)*4	OFF Stop	0	×	0
ОН	Set one of Pr.180	External thermal relay input	ON Motor normal	0	-	-
5	to Pr.189 to "7".	External thermal relay input	OFF Motor fault	×	×	×
RES	RES	Operation status reset*5	ON Reset	Invariance	×	Invariance
KES	KES	Operation status reset*5	OFF Normal operation	0	-	-
			X95 signal OFF, X96 signal OFF Converter fault (E.OHT, E.CPU)	×	×	×
X95/X96	Set "95" and "96" in any of <b>Pr.180</b>	Converter unit fault / Converter unit fault (E.CPU,	X95 signal ON, X96 signal ON Converter normal	0	-	-
	to Pr.189.	E.OHT)	X95 signal OFF, X96 signal ON Converter fault (other than E.OHT or E.CPU)	×	- *7	×


- \*1 For separated converter types, the X10 signal is assigned to the terminal MRS in the initial setting. For the MRS signal, set "24" to any of Pr.180 to Pr.189 (input terminal function selection) to assign the function to another terminal.
- \*2 When the MRS signal is OFF, neither the commercial power supply operation nor the inverter operation can be performed.
- \*3 Terminal CS is initially set to "no function". To enable CS signal, set "6" in Pr.186 CS terminal function selection to assign the function to a terminal. The CS signal operates only when the MRS signal is ON.
- \*4 STF(STR) operates only when the MRS and CS signals are both ON.
- \*5 The RES signal can be used for reset input acceptance with Pr.75 Reset selection/disconnected PU detection/PU stop selection. When RES signal and another input signal are simultaneously input, the MC operation by the RES signal has a higher priority.
- \*6 MC1 turns OFF at an inverter fault.
- \*7 When Pr.138="0 (electronic bypass invalid at a fault)", MC2 is OFF. When Pr.138="1 (electronic bypass valid at a fault)", MC2 is ON.
- \*8 MC operation
  - O: MC-ON
  - ×: MC-OFF
  - -: During inverter operation, MC2-OFF, MC3-ON During commercial power supply operation, MC2-ON, MC3-OFF Invariance: The status before changing the signal ON or OFF is held.

• The output signals are as shown below.


Signal	Applied terminal (Pr.190 to Pr.196 setting)	Description
MC1	17	Operation output signal of the magnetic contactor MC1 on the inverter's input side.
MC2	18	Operation output signal of the magnetic contactor MC2 for the commercial power supply operation.
MC3	19	Operation output signal of the magnetic contactor MC3 on the inverter's output side.

## **♦**Electronic bypass operation sequence


• Example of operation sequence without automatic bypass sequence (Pr.139 = "9999")



• Example of operation sequence with automatic bypass sequence (Pr.139 ≠ "9999", Pr.159 = "9999")



• Example of operation sequence with automatic bypass sequence (Pr.139 ≠ "9999", Pr.159 ≠ "9999")




- C: Pr.57 Restart coasting time

- D: Pr.58 Restart cushion time

## Operation

· Procedure for operation



· Signal operation after setting parameters

- Pr.135 = "1" (open collector output terminal of inverter)
- Pr.136 = "2.0 s"
- Pr.137 = "1.0 s" (Set the time until MC3 is actually turned ON and the inverter and motor are electrically connected. If the time is short, the restart may not function properly.)
- **Pr.57** = "0.5 s"
- Pr.58 = "0.5 s" (Always set this to switchover from the commercial power supply operation to the inverter operation.)

Status	MRS	CS	STF	MC1	MC2	MC3	Remarks
Power ON	OFF (OFF)	OFF (OFF)	OFF (OFF)	OFF→ON (OFF→ON)	OFF (OFF)	OFF→ON (OFF→ON)	External operation mode (PU operation mode)
At start (Inverter)	OFF→ON	OFF→ON	OFF→ON	ON	OFF	ON	
During constant- speed operation (commercial power supply)	ON	ON→OFF	ON	ON	OFF→ON	ON→OFF	MC2 turns ON after MC3 turns OFF. Waiting time is 2 s (while coasting).
For deceleration, switched to the inverter operation (inverter)	ON	OFF→ON	ON	ON	ON→OFF	OFF→ON	MC3 turns ON after MC2 turns OFF. Waiting time is 4 s (while coasting).
Stop	ON	ON	ON→OFF	ON	OFF	ON	



- · Connect the control power (R1/L11, S1/L21) in front of the input-side MC1. If the control power is connected behind the inputside MC1, the electronic bypass sequence function will not operate.
- The electronic bypass sequence function is only enabled when Pr.135 = "1" and in the External operation mode or combined operation mode (PU speed command and External operation command with Pr.79 = "3"). MC1 and MC3 turn ON when Pr.135 = "1" and in an operation mode other than mentioned above.
- · MC3 turns ON when the MRS and CS signals are ON and the STF(STR) signal is OFF. If the motor was coasted to a stop from commercial power supply operation at the previous stop, the motor starts running only after waiting the time set in Pr.137.
- Inverter operation is only available when the MRS, STF(STR), and CS signals are ON. In all other cases (when the MRS signal is ON), commercial power supply operation is available.
- When the CS signal is OFF, the motor switches to the commercial power supply operation. However, when the STF(STR) signal is OFF, the motor decelerates to a stop during inverter operation.
- From the point where MC2 and MC3 are both turned OFF, there is a waiting time set in Pr.136, till MC2 or MC3 is turned ON.
- Even when the electronic bypass sequence is enabled (Pr.135 = "1"), the Pr.136 and Pr.137 settings are ignored in PU operation mode.
  - In addition, the input terminals (STF, CS, MRS, OH) return to perform their normal functions.
- When the electronic bypass sequence function (Pr.135 = "1") and PU operation interlock function (Pr.79 = "7") are used at the same time, the MRS signal is shared with the PU operation external interlock if the X12 signal is not assigned. (The inverter operation is available when the MRS and CS signals are ON.)
- Set the acceleration time to the level that does not activate the stall prevention operation.
- · When switching to the commercial power supply operation while a failure such as an output short circuit is occurring between the magnetic contactor MC3 and the motor, the damage may further spread. When a failure occurs between the MC3 and motor, make sure to provide a protection circuit, such as using the OH signal input.
- · Changing the terminal functions with Pr.178 to Pr.189 and Pr.190 to Pr.196 may affect other functions. Set parameters after confirming the function of each terminal.
- · Switching with the electronic bypass sequence is not available during retry. Switching occurs after the retry. When the electronic bypass is valid at a fault (Pr.138="1"), switching occurs also during retry.
- · When the electronic bypass sequence function and the retry function of the converter unit are used at the same time for the separated converter type, set 101 or more in the number of retries at fault occurrence (Pr.67) on the converter unit side. When a value less than 100 is set, ALM signal does not turn ON until the retry count is exceeded. In this case, the electronic bypass at a fault is not performed until the retry count is exceeded.

## ◆Operation in combination with the self power management function for the separated converter type

• When the self power management function is used at the same time for the separated converter type, the input signal operations are as follows.

	X96	X94	MC	operati	on*3	
X95 (Converter unit fault)	(Converter unit fault (E.CPU, E.OHT))	(Control signal for main circuit power supply MC)	MC1	MC2	мс3	Converter status
OFF	OFF	ON	O*2	×	×	Converter fault (E.OHT ( <b>Pr.248</b> ="2"))
OFF	OFF	OFF	×	×	×	Converter fault (E.OHT ( <b>Pr.248=</b> "1"), E.CPU)
ON	ON	ON	O*2	-	-	Converter normal
OFF	ON	ON	O*2	-*1	×	Converter fault (other than the faulty circuit fault or E.OHT) (Pr.248="2")
		OFF	×	-*1	×	Converter fault (other than E.OHT or E.CPU)

- \*1 When Pr.138="0 (electronic bypass invalid at a fault)", MC2 is OFF. When Pr.138="1 (electronic bypass valid at a fault)", MC2 is ON.
- \*2 The self power management operation is effective.
- \*3 MC operation
  - O: MC-ON
  - ×: MC-OFF
  - -: During inverter operation: MC2-OFF, MC3-ON
    During commercial power supply operation: MC2-ON, MC3-OFF

#### ≪ Parameters referred to ≫

Pr.11 DC injection brake operation time page 502

Pr.57 Restart coasting time page 414, page 420

Pr.58 Restart cushion time page 414

Pr.79 Operation mode selection page 200

Pr.178 to Pr.189 (input terminal function selection) page 329

Pr.190 to Pr.196 (output terminal function selection) \*page 288


#### 5.11.2 **Self power management**

By turning ON the magnetic contactor (MC) on the input side before the motor is started and turning OFF the MC after the motor is stopped, power is not supplied to the main circuit, reducing the standby power.

Pr.	Name	Initial value	Setting range	Description
			0	Self power management function disabled
248 A006	Self power management selection	0	1	Self power management function enabled (main circuit OFF at protective function activation)
A000	Selection		2	Self power management function enabled (main circuit OFF at protective function activation due to a circuit failure)
137 A002	Start waiting time	0.5 s	0 to 100 s	Set a time period that is a little longer than the time period from the ON signal input to the actual pick-up operation of MC1 (0.3 to 0.5 s).
254	Main circuit power OFF waiting time	600 s	0 to 3600 s	Set the waiting time until the main circuit power supply is turned OFF after the motor is stopped.
A007			9999	The main circuit power supply is turned OFF only when the protective function selected by <b>Pr.248</b> is activated.
30	Regenerative function selection	0	100, 101	Power supply to the inverter: AC (terminals R, S, and T) When power is supplied only to the control circuit, and then switched to be supplied to both the control and main circuits, inverter reset is not performed.
E300			0 to 2, 10, 11, 20, 21, 102, 110, 111, 120, 121	For other settings, refer to page 508.


#### **◆**Connection diagram

• For sink logic and Pr.192="17" (terminal R1, S1 inputs)




• For sink logic and Pr.192="17" (24 V external power supply input)

Standard models



#### Operation of the self power management function

- This function controls the magnetic contactor (MC) on the input side using the output relay to reduce the standby power during inverter stop. With the terminals R1/L11 and S1/L21 (refer to page 55) and 24 V external power supply input (refer to page 57), the main circuit power supply and control circuit power supply are separated, and the MC for main circuit power supply is controlled by the electronic bypass MC1 signal.
- Set Pr.248 Self power management selection = "1 or 2", Pr.30 Regenerative function selection ≠ "20, 21, 120, or 121" (other than DC feeding mode 2), and Pr.190 to Pr.196 (output terminal function selection) = "17 (positive logic)" to assign the Electronic bypass MC1 (MC1) signal to an output terminal.
- · After the inverter is stopped and the time set in Pr.11 DC injection brake operation time and Pr.254 Main circuit power OFF waiting time have passed, turning OFF the MC1 signal releases the MC on the input side (main circuit power supply OFF). Set Pr.254 to prevent frequent MC operation.
- Turning ON the start signal turns ON the MC1 signal and closes the MC on the input side (main circuit power supply ON). After the time set in Pr.137 Start waiting time has passed, the inverter starts. Set time slightly longer (about 0.3 to 0.5 s) than the time period from the MC1-ON to the actual pick-up operation of the MC is turned ON in Pr.137.



· When the protective function of the inverter is activated, the MC1 signal is immediately turned OFF according to the Pr.248 setting. (The MC1 signal is turned OFF before the time set in Pr.254 has passed.) When Pr.248="1", the MC1 signal is turned OFF when the protective function is activated due to any cause. When Pr.248="2", the MC1 signal is turned OFF only when the protective function is activated due to an error resulted from a failure in the inverter circuit or a wiring error (refer to the following table). (For the alarm details, refer to page 535.)

Fault record
Inrush current limit circuit fault (E.IOH)
CPU fault (E.CPU)
CPU fault (E.6)
CPU fault (E.7)
Parameter storage device fault (E.PE)
Parameter storage device fault (E.PE2)
24 VDC power fault (E.P24)
Operation panel power supply short circuit/RS-485 terminals power supply short circuit (E.CTE)
Output side earth (ground) fault overcurrent (E.GF)
Output phase loss (E.LF)
Brake transistor alarm detection (E.BE)
Internal circuit fault (E.13/E.PBT)


• To enable the self power management function for the separated converter type, enable the self power management function also on the converter unit side. To activate the self power management function when a converter unit fault occurs, connect the terminal to which Y17 signal of the converter unit is assigned and the terminal to which X94 signal of the inverter is assigned.

Y17 output signal (on the converter unit side)			Main circuit power supply	
OFF	OFF	OFF	Stop	
OFF	ON	OFF	Stop	
ON	OFF	OFF	Stop	
ON	ON	ON	Supplied	

#### NOTE:

When the start signal is turned OFF before the time set in Pr.137 has passed after the start signal is turned ON, the inverter does not start and the MC1 signal is turned OFF after the time set in Pr.254 has passed.

If the start signal is turned ON again before the time set in Pr.254 has passed, the inverter immediately starts outputting.



- At inverter reset, the status of the MC1 signal is held and operation of the magnetic contactor is not performed.
- · When the inverter stops the output due to, for example, the Output stop (MRS) signal, the MC1 signal is turned OFF after the time set in Pr.254 has passed.
- During the stop, turning ON the External DC injection brake operation start signal (X13) turns ON the MC1 signal.
- To avoid inverter reset when supplying power to the main circuit is started when power is supplied only to the control circuit, set 100 or more in Pr.30. (For the separated converter type, setting Pr.30 of the converter unit is also required.)
- · When supplying power to the main circuit is started when power is supplied only to the control circuit, there is a little waiting time before starting.
- · Repeated operation of the magnetic contactor due to frequent start and stop or activation of the protective function may shorten the inverter life.
- · Changing the terminal assignment using Pr.190 to Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### # Parameters referred to

Pr.11 DC injection brake operation time page 502

Pr.30 Regenerative function selection page 508


Pr.190 to Pr.196 (output terminal function selection) page 288

#### 5.11.3 **Traverse function**

The traverse operation, which oscillates the frequency at a constant cycle, is available.

Pr.	Name	Initial value	Setting range	Description
592	Traverse function		0	Traverse function invalid
A300	selection	0	1	Traverse function valid only in External operation mode
A300	Selection		2	Traverse function valid regardless of the operation mode
593 A301	Maximum amplitude amount	10%	0 to 25%	Level of amplitude during traverse operation
594 A302	Amplitude compensation amount during deceleration	10%	0 to 50%	Compensation amount during amplitude inversion (from acceleration to deceleration)
595 A303	Amplitude compensation amount during acceleration	10%	0 to 50%	Compensation amount during amplitude inversion (from deceleration to acceleration)
596 A304	Amplitude acceleration time	5 s	0.1 to 3600 s	Time period of acceleration during traverse operation
597 A305	Amplitude deceleration time	5 s	0.1 to 3600 s	Time period of deceleration during traverse operation

- Setting Pr.592 Traverse function selection = "1 or 2" will enable the traverse function.
- Assigning the Traverse function selection (X37) signal to the input terminal will enable the traverse function only when the X37 signal is ON. (When the X37 signal is not assigned, the traverse function is always available.) To input the X37 signal, set "37" in any of Pr.178 to Pr.189 (input terminal function selection) to assign the function to a terminal.



- f0: set frequency
- f1: amplitude amount from the set frequency  $(f0 \times Pr.593/100)$
- f2: compensation amount at transition from acceleration to deceleration  $(f1 \times Pr.594/100)$
- f3: compensation amount at transition from deceleration to acceleration  $(f1 \times Pr.595/100)$
- t1: time from acceleration during traverse operation (Time from (f0 - f1) to (f0 + f1)) (Pr.596)
- t2: time from deceleration during traverse operation (Time from (f0 + f1) to (f0 - f1)) (Pr.597)
- The motor accelerates to the set frequency f0 according to the normal Pr.7 Acceleration time at turn ON of the start command (STF or STR).
- · When the output frequency reaches f0 and the X37 signal turns ON, the inverter begins traverse operation and accelerates to f0 + f1. The acceleration time at this time is according to the Pr.596 setting. (If the X37 signal turns ON before the output frequency reaches f0, traverse operation begins after the output frequency reaches f0.)
- After the inverter accelerates to f0 + f1, this is compensated with f2 (f1 × Pr.594), and the inverter decelerates to f0 f1. The deceleration time at this time is according to the Pr.597 setting.
- After the inverter decelerates to f0 f1, this is compensated with f3 (f1 × Pr.595), and the inverter accelerates again to f0 +
- · When the X37 signal turns OFF during traverse operation, the inverter accelerates/decelerates to f0 according to the normal acceleration/deceleration time (Pr.7, Pr.8). If the start command (STF or STR) is turned OFF during traverse operation, the inverter decelerates to a stop according to the normal deceleration time (Pr.8).

## • NOTE

- If the set frequency (f0) and traverse operation parameters (**Pr.598 to Pr.597**) are changed during traverse operation, this is applied in operations after the output frequency reaches f0 before the change was made.
- If the output frequency exceeds **Pr.1 Maximum frequency** or **Pr.2 Minimum frequency** during traverse operation, the output frequency is clamped at the maximum/minimum frequency when the set pattern exceeds the maximum/minimum frequency.
- When the traverse function and S-pattern acceleration/deceleration (**Pr.29** ≠ "0") are selected, S-pattern acceleration/ deceleration operation occurs only in the range operated at the normal acceleration/deceleration time (**Pr.7**, **Pr.8**). Acceleration/deceleration during traverse operation is performed linearly.
- If stall prevention activates during traverse operation, traverse operation stops and normal operation begins. When stall prevention operation is completed, the inverter accelerates/decelerates to f0 at the normal acceleration/deceleration time (Pr.7, Pr.8). After the output frequency reaches f0, the traverse operation begins again.
- If the value of the amplitude inversion compensation amount (**Pr.594**, **Pr.595**) is too large, an overvoltage trip or stall prevention occurs, and pattern operation cannot be performed as set.
- Changing the terminal assignment using **Pr.178 to Pr.189 (input terminal function selection)** may affect the other functions. Set parameters after confirming the function of each terminal.

#### « Parameters referred to »

Pr.3 Base frequency page 497

Pr.180 to Pr.186 (input terminal function selection) page 329

Pr.190 to Pr.195 (output terminal function selection) page 288


#### 5.11.4 **Cleaning function**

This is a function to remove stains or foreign matter on the impellers or fans of pumps by setting a forward/reverse rotation sequence.

Pr.	Name	Initial value	Setting range	Description
1469 A420	Number of cleaning times monitor	0	0 to 255	Displays the number of cleaning times. (Read-only)
1470 A421	Number of cleaning times setting	0	0 to 255	Set the number of cleaning times.
1471 A422	Cleaning trigger selection	0	0 to 15	Select the condition to start cleaning.
1472 A423	Cleaning reverse rotation frequency	30 Hz	0 to 590 Hz	Set the reverse rotation frequency for cleaning operation.
1473 A424	Cleaning reverse rotation operation time	5 s	0 to 3600 s	Set the operating time after the cleaning reverse rotation frequency is reached.
1474	Cleaning forward rotation	9999	0 to 590 Hz	Set the forward rotation frequency for cleaning operation.
A425	frequency		9999	As set in <b>Pr.1472</b> .
1475 A426	Cleaning forward rotation	9999	0 to 3600 s	Set the operating time after the cleaning forward rotation frequency is reached.
A426	operation time		9999	As set in <b>Pr.1473</b> .
1476 A427	Cleaning stop time	5 s	0 to 3600 s	Set the stop time when the rotation is switched from forward to reverse or from reverse to forward.
1477	Cleaning acceleration time	0000	0 to 3600 s	Set the acceleration time during cleaning.
A428	Cleaning acceleration time	9999	9999	Acceleration time for normal operation
1478	Cleaning decoloration time	9999	0 to 3600 s	Set the deceleration time during cleaning.
A429	Cleaning deceleration time		9999	Deceleration time for normal operation
1479	Cleaning time trigger	0	0	Time trigger disabled
A430	Oleaning time trigger		0.1 to 6000 h	Cleaning is performed at a set time interval.


## **♦**Outline of the cleaning operation

- Setting a number in **Pr.1470 Number of cleaning times setting** enables the cleaning function.
- The cleaning operation is started when the trigger set in Pr.1471 or Pr.1479 occurs, or when X98 signal turns ON. When the cleaning is started initially, the operation in the opposite direction to the start command is performed.



· When the number of times of cleaning operation is an odd number, the operation in the opposite direction to the start command is performed. When the number of cleaning times is an even number, the operation in the start command direction is performed.

• When the motor rotation direction is restricted in Pr.78 Reverse rotation prevention selection, rotation is performed not in the prohibited direction but in the permitted direction.



- Use Pr.1472 Cleaning reverse rotation frequency and Pr.1474 Cleaning forward rotation frequency to set the running frequency for cleaning operation, and use Pr.1473 Cleaning reverse rotation operation time and Pr.1475 Cleaning forward rotation operation time to set the operating time after the cleaning running frequency is reached.
- Use Pr.1477 Cleaning acceleration time and Pr.1478 Cleaning deceleration time to set the acceleration/deceleration time during cleaning operation.
- Y215 signal turns ON during cleaning operation. For the Y215 signal, assign the function by setting "215 (forward action)" or "315 (reverse action)" in any of Pr.190 to Pr.196 (output terminal function selection).

#### ◆Cleaning trigger selection (Pr.1471, Pr.1479, X98 signal)


• Use Pr.1471 Cleaning trigger selection the trigger to start cleaning operation. As set in Pr.1471, cleaning operation is started when any of the applicable trigger conditions is satisfied.

Pr.1471	Trigger factor	Value in	each bit	Remarks
setting	ingger lactor	0 1		Remarks
Bit 0	Start trigger	Trigger disabled	Trigger enabled	Turning ON of the start command is defined as a trigger. *1*6*7
Bit 1	Output current	Trigger disabled	Trigger enabled	Turning ON of Y12 signal is defined as a trigger. *2*5
Bit 2	PID upper/lower limit	Trigger disabled	Trigger enabled	Turning ON of FUP, FDN, FUP2, or FDN2 signal is defined as a trigger. *3*5
Bit 3	Load warning	Trigger disabled	Trigger enabled	Turning ON of LUP or LDN signal is defined as a trigger. *4*5
_	X98 signal input	_		Turning ON of X98 signal is defined as a trigger. (This trigger is always enabled by assigning X98 signal to an input terminal.)
_	Time trigger	_		When <b>Pr.1479</b> ≠ "0", the trigger is enabled.


- The ON state at power-ON or inverter reset is not regarded as a trigger.
- Use Pr.150 and Pr.151 to set the detection level. (Refer to page 296.)
- Use Pr.131, Pr.132, Pr.1143, and Pr.1144 to set the detection level. When the frequency reflection is not provided for the PID setting, or when the function is disabled, a trigger does not occur. (Refer to page 378.)
- Set the load characteristics fault detection function. When the function is disabled, a trigger does not occur. (Refer to page 255.)
- The output signal can be used as a trigger if the signal is not assigned to a terminal.
- When the automatic restart after instantaneous power failure is set for every start, or when the online auto tuning is enabled, cleaning is started upon completion of the set operations.
- \*7 While the self power management is enabled, the start trigger is disabled.
- Convert a bit image (binary) of the trigger factor into a decimal value, and set the value in Pr.1471.

Pr.1471		bit 3	bit 2	bit 1	bit 0
Decimal	Binary	DIL 3	DIL Z	DIL I	DIL 0
15	1111	0	0	0	0
14	1110	0	0	0	×
13	1101	0	0	×	0
12	1100	0	0	×	×
11	1011	0	×	0	0
10	1010	0	×	0	×
9	1001	0	×	×	0
8	1000	0	×	×	×
7	0111	×	0	0	0
6	0110	×	0	0	×
5	0101	×	0	×	0
4	0100	×	0	×	×
3	0011	×	×	0	0
2	0010	×	×	0	×
1	0001	×	×	×	0
0	0000	×	×	×	×

O: Trigger enabled, x: Trigger disabled



- Turning ON of X98 signal can be used as a trigger to start the cleaning operation. For the X98 signal input, set "98" in any of Pr.178 to Pr.189 to assign the function.
- · When using the cleaning function for the purpose of periodic maintenance in such applications that require continuous pump operation for a long time, use a time trigger. The time trigger is enabled by setting a time period before starting the cleaning operation in Pr.1479 Cleaning time trigger. The timer starts when the timer starting condition is satisfied, and the cleaning operation is performed at a time interval set in **Pr.1479**.
- · Starting conditions of the timer for a time trigger
  - When the start command turns ON
  - When the cleaning ends



#### Cleaning operation by the cleaning signal (X97 signal)

- · When X97 signal is assigned to an input terminal, the cleaning operation can be finished when the cleaning signal (X97) is turned from ON to OFF.
- For the X97 signal input, set "97" in any of Pr.178 to Pr.189 to assign the function.

Pr.1470	X97 signal		Cleaning	Cleaning end condition	
setting	Assignment	ON/OFF	operation	Cleaning end Condition	
0	Optional	Optional	Invalid	-	
	Not assigned	-	Enabled	After cleaning is performed for the number of times set in <b>Pr.1470</b>	
Other	Assigned	OFF	Invalid	-	
than 0		ON	Enabled	After cleaning is performed for the number of times set in <b>Pr.1470</b> When X97 signal turns OFF	

## NOTE:

- When a trigger occurs during the following operations, the cleaning operation is started upon completion of the following operations
- Automatic restart after instantaneous power failure, online auto tuning at startup
- The following functions are disabled during cleaning operation. PID control automatic switchover frequency, PID control SLEEP function, pre-charge fault, determination of pre-charge ending with parameters, PID gain tuning, electronic bypass with the automatic switchover frequency of the inverter (Pr.139), automatic switchover of auxiliary motors of the multi-pump function, output stop function (Pr.522), restart at every start during
- · When the stall prevention is activated during acceleration of the cleaning function, the operation is shifted to the cleaning deceleration operation.
- · If the number of cleaning times set in Pr.1470 is an even number, the operation is shifted to the normal operation after the cleaning forward/reverse operation time (Pr.1473/Pr.1475) of the final cleaning operation has elapsed.
- · Changing the terminal assignment with Pr.178 to Pr.189 and Pr.190 to Pr.196 may affect other functions. Set parameters after confirming the function of each terminal.

#### Parameters referred to

Pr.178 to Pr.189 (input terminal function selection) \*page 329 Pr.190 to Pr.196 (output terminal function selection) page 288 Pr.7 Acceleration time, Pr.8 Deceleration time page 187

## 5.11.5 PID control

Process control such as flow rate, air volume or pressure are possible on the inverter.

A feedback system can be configured and PID control can be performed using the terminal 2 input signal or parameter setting value as the set point, and the terminal 4 input signal as the feedback value.

Pr.	Name	Initial value	Setting range	Description	
127 A612	PID control automatic switchover frequency	9999	0 to 590 Hz	Set the value at which control is automatically switched to PID control.	
A012	Switchover frequency		9999	Without PID control automatic switchover function	
128 A610	PID action selection	0	0, 10, 11, 20, 21, 50, 51, 60, 61, 70, 71, 80, 81, 90, 91, 100, 101, 1000, 1001, 1010, 1011, 2000, 2001, 2010, 2011	Select how to input the deviation value, measured value and set point, and forward and reverse action.	
129 A613	PID proportional band	100%	0.1 to 1000%	If a narrow proportional band is set (small parameter setting value), the manipulated amount changes considerably by slight changes in the measured value. As a result, response improves as the proportional band becomes narrower, though stability worsens as shown by the occurrence of hunting. Gain Kp=1/proportional band	
			9999	Without proportional band	
130 A614	PID integral time		0.1 to 3600 s	With deviation step input, this is the time (Ti) used for obtaining the same manipulated amount as proportional band (P) by only integral (I) action. Arrival to the set point becomes quicker the shorter an integral time is set, though hunting is more likely to occur.	
			9999	Without integral control	
131 A601	Pill linner limit		0 to 100%	Sets the upper limit. The FUP signal is output when the feedback value exceeds this setting. The maximum input (20 mA/5 V/10 V) of the measured value (terminal 4) is equivalent to 100%.	
			9999	No function	
132 A602	PID lower limit	9999	0 to 100%	Set the lower limit. The FDN signal is output when the measured value falls below the setting range. The maximum input (20 mA/5 V/10 V) of the measured value (terminal 4) is equivalent to 100%.	
			9999	No function	
133	PID action set point	9999	0 to 100%	Set the set point during PID control.	
A611	1 1D action set point	3333	9999	Set point set by <b>Pr.128</b> .	
134 A615	PID differential time	9999	0.01 to 10 s	With deviation ramp input, this is the time (Td) used for obtaining the manipulated amount only by proportional action (P). Response to changes in deviation increase greatly as the differential time increases.	
			9999	Without differential control	
553 A603	PID deviation limit	9999	0 to 100%	The Y48 signal is output when the absolute value of the deviation exceeds the deviation limit value.	
554 A604	PID signal operation selection	0	9999 0 to 3, 10 to 13	No function  The action when the upper or lower limit for a measured value input is detected or when a limit for the deviation is detected can be selected. The operation for PID output	
				suspension function can be selected.	
575 A621	Output interruption detection time	1 s	0 to 3600 s	If the status where the output frequency after PID calculation is less than the <b>Pr.576</b> setting is continuously the <b>Pr.575</b> set time or more, inverter running is suspended.	
			9999	Without output interruption function	
576 A622	Output interruption detection level	0 Hz	0 to 590 Hz	Set the frequency at which output interruption is performed.	
577 A623	Output interruption cancel level	1000%	900 to 1100%	Level at which the PID output suspension function is released. Set "Pr.577 -1000%".	


GROUP	
۸	

Pr.	Name	Initial value	Setting range		Description
753 A650	Second PID action selection	0	0, 10, 11, 20, 21, 50, 51, 60, 61, 70, 71, 80, 81, 90, 91, 100, 101, 1000, 1001, 1010, 1011, 2000, 2001, 2010, 2011	Refer to <b>Pr.128</b> .	
754 A652	Second PID control automatic switchover frequency	9999	0 to 600 Hz, 9999	Refer to <b>Pr.127</b> .	
755 A651	Second PID action set point	9999	0 to 100%, 9999	Refer to Pr.133.	
756 A653	Second PID proportional band	100	0.1 to 1000%, 9999	Refer to Pr.129.	
757 A654	Second PID integral time	1 s	0.1 to 3600 s, 9999	Refer to Pr.130.	
758 A655	Second PID differential time	9999	0.01 to 10 s, 9999	Refer to Pr.134.	
1140 A664	Second PID set point/ deviation input selection	2	1 to 5	Refer to <b>Pr.609</b> .	Set the second PID control. For how to enable the second PID
1141 A665	Second PID measured value input selection	3	1 to 5, 101 to 105	Refer to Pr.610.	control, refer to page 392.
1143 A641	Second PID upper limit	9999	0 to 100%, 9999	Refer to Pr.131.	
1144 A642	Second PID lower limit	9999	0 to 100%, 9999	Refer to Pr.132.	
1145 A643	Second PID deviation limit	9999	0 to 100%, 9999	Refer to <b>Pr.553</b> . (Y205 signal is output.)	
1146 A644	Second PID signal operation selection	0	0 to 3, 10 to 13	Refer to Pr.554.	
1147 A661	Second output interruption detection time	1 s	0 to 3600 s, 9999	Refer to <b>Pr.575</b> .	
1148 A662	Second output interruption detection level	0 Hz	0 to 600 Hz	Refer to <b>Pr.576</b> .	
1149 A663	Second output interruption cancel level	1000%	900 to 1100%	Refer to Pr.577.	

## 5


#### Basic configuration of PID control

• Pr.128 ="10, 11" (deviation value signal input)



Kp: Proportionality constant Ti: Integral time S: Operator Td: Differential time

- \*1 Set "0" to Pr.868 Terminal 1 function assignment. When Pr.868 ≠ "0", PID control is invalid.
- Pr.128 = "20, 21" (measured value input)



Kp: Proportionality constant Ti: Integral time S: Operator Td: Differential time


- \*2 Note that the input of terminal 1 is added to the set point of terminal 2 as a set point.
- Set "0" to Pr.858 Terminal 4 function assignment. When Pr.858 ≠ "0", PID control is invalid.

#### ▶PID action outline

#### PI action

PI action is a combination of proportional action (P) and integral action (I), and applies a manipulated amount according to the size of the deviation and transition or changes over time.

[Example of action when the measured value changes in a stepped manner] (Note) PI action is the result of P and I actions being added together.




#### PD action

PD action is a combination of proportional action (P) and differential action (D), and applies a manipulated amount according to the speed of the deviation to improve excessive characteristics.

[Example of action when the measured value changes proportionately]


(Note) PD action is the result of P and D actions being added together.



#### · PID action


PID action is a combination of PI and PD action, which enables control that incorporates the respective strengths of these actions.

(Note) PID action is the result of all P, I and D actions being added together.




#### · Reverse action

When deviation X = (set point - measured value) is a plus value, the manipulated amount (output frequency) is increased, and when the deviation is a minus value, the manipulated amount is decreased.



#### · Forward action


When deviation X = (set point - measured value) is a minus value, the manipulated amount (output frequency) is increased, and when the deviation is a plus value, the manipulated amount is decreased.



Relationship between deviation and manipulated amount (output frequency)

PID action setting	Deviation		
FID action setting	Plus	Minus	
Reverse action	7	n	
Forward action	ĸ	7	

## **◆**Connection diagram



- Prepare a power supply matched to the power supply specification of the detector.
- \*2 The output signal terminal to be used differs according to the Pr.190 to Pr.196 (output terminal function selection) setting.
- The input signal terminal to be used differs according to the Pr.178 to Pr.189 (input terminal function selection) setting.
- The AU signal need not be input.

## ◆ Selection of deviation value, measured value and set point input method, and PID action method (Pr.128, Pr.609, Pr.610)

- Using Pr.128, select the input method for the PID set point, measured value detected by the meter, and externally calculated deviation. Also, select forward or reverse action.
- Switch the power voltage/current specifications of terminals 2 and 4 by Pr.73 Analog input selection or Pr.267 Terminal 4 input selection to match the specification of the input device. After changing the Pr.73 and Pr.267 settings, check the voltage/current input selection switch. Incorrect setting may cause a fault, failure or malfunction. (Refer to page 306 for the setting.)

Pr.128 setting	Pr.609 Pr.610	PID action	Set point input	Measured value input	Deviation input
0		PID invalid	_	_	_
10		Reverse action			Terminal 1
11	Invalid	Forward action	7-	_	Terminal I
20		Reverse action	Terminal 2 or <b>Pr.133</b> *1	Terminal 4	
21		Forward action	Tellilliai 2 Of <b>P1.133</b> *1	Terminal 4	_
50		Reverse action			CC-Link communication*2,
51		Forward action	7-	_	BACnet communication
60		Reverse action	CC-Link communication*2,	CC-Link communication*2,	
61		Forward action	BACnet communication	BACnet communication	_
70		Reverse action			PLC function
71		Forward action	7-	_	(with frequency reflected)
80	Invalid	Reverse action	PLC function	PLC function	
81	inivana	Forward action	(with frequency reflected)*3	(with frequency reflected)*3	_
90		Reverse action			PLC function
91		Forward action	]-	_	(without frequency reflected)*3
100		Reverse action	PLC function	PLC function	
101		Forward action	(without frequency reflected)*3	(without frequency reflected)*3	_


#### (A) Application parameters

Pr.128 setting	Pr.609 Pr.610	PID action	Set point input	Measured value input	Deviation input
1000		Reverse action	According to Pr.609 *1	According to Pr.610	
1001		Forward action	According to F1.009 *1	According to F1.610	_
1010		Reverse action			According to Pr.609
1011		Forward action	] —	_	According to F1.609
2000		Reverse action (without			
2000	Valid	frequency reflected)	According to Pr.609 *1	According to Pr.610	_
2001		Forward action (without	According to 1 1.000 *1		
2001		frequency reflected)			
2010		Reverse action (without			
2010		frequency reflected)		_	According to Pr.609
2011		Forward action (without			
2011		frequency reflected)			

- \*1 When  $Pr.133 \neq "9999"$ , the Pr.133 setting is valid.
- \*2 For the details of CC-Link communication, refer to the Instruction Manual of the option FR-A8NC, FR-A8NCE.
- \*3 For the details of the PLC function, refer to the PLC Function Programming Manual.
- The set point/deviation input method can also be flexibly selected by Pr.609 PID set point/deviation input selection and the measured value input method can be selected by Pr.610 PID measured value input selection. Selection by Pr.609 and Pr.610 is valid when Pr.128 = "1000 to 2011".

Setting	g value	Command source	Input method	
Pr.609	Pr.610	Command Source	input inethou	
1	1	Terminal 1*4		
2	2	Terminal 2*4		
3	3	Terminal 4*4	Direct input	
4 4		CC-Link communication		
5	5	PLC function		
_	101	Terminal 1*4		
_	102	Terminal 2*4		
_	103	Terminal 4*4	Square root input	
— 104		CC-Link communication		
_	105	PLC function		

- \*4 When the same command source has been selected for the set point and measured value using Pr.609 and Pr.610, set point input is invalid. (The inverter runs at set point 0%)
- When Pr.610 PID measured value input selection = "101 to 105", the square root of the input value is used as the measured value.





When terminals 2 and 4 are selected for deviation input, perform bias calibration using C3 and C6 to prevent a minus voltage from being entered as the deviation input signal. Input of a minus voltage might damage devices and the inverter.

• The following shows the relationship between the input values of the analog input terminals and set point, measured value and deviation. (Calibration parameter initial values)

Input	Inspect	Rela	ationship with analog	input	Colibration parameter	
terminal	specification*5	Set point	Result	Deviation	- Calibration parameter	
	0 to 5 V	0 V=0% 5 V=100%	0 V=0% 5 V=100%	0 V=0% 5 V=100%		
Terminal 2	0 to 10 V	0 V=0% 10 V=100%	0 V=0% 10 V=100%	0 V=0% 10 V=100%	Pr.125, C2 to C4	
	0 to 20 mA	0 mA=0% 20 mA=100%	0 mA=0% 20 mA=100%	0 V=0% 20 mA=100%		
Terminal 1	0 to ±5 V	-5 V to 0 V=0% 5 V=+100%	-5 V to 0 V=0% 5 V=+100%	-5 V=-100% 0 V=0% 5 V=+100%	When Pr.128 = "10", Pr.125, C2 to C4.	
Terminar	0 to ±10 V	-10 V to 0 V=0% 10 V=+100%	-10 V to 0 V=0% 10 V=+100%	-10 V=-100% 0 V=0% 10 V=+100%	When <b>Pr.128</b> ≥ "1000", <b>C12 to C15</b> .	
	0 to 5 V	0 V to 1 V=0% 5 V=100%	0 Vto 1 V=0% 5 V=100%	0 V=-20% 1 V=0% 5 V=100%		
Terminal 4	0 to 10 V 0 V to 2 V=0% 10 V=100%		0 V to 2 V=0% 10 V=100%	0 V=-20% 1 V=0% 10 V=100%	Pr.126, C5 to C7	
	0 to 20 mA 0 to 4 mA=0% 20 mA=100%		0 to 4 mA=0% 20 mA=100%	0 V=-20% 4 mA=0% 20 mA=100%		

<sup>\*5</sup> Can be changed by Pr.73 and Pr.267 and the voltage/current input switch. (Refer to page 306.)



· Always perform calibration after changing the voltage/input specification with Pr.73, Pr.267, and the voltage/current input selection switch.

#### ◆Multistage set point input (Pr.1460 to Pr.1466)

- The set point can be selected by combining the ON/OFF status of the PDI1 to PDI3 signals. Up to eight set points can be selected. Use Pr.1460 PID multistage set point 1 to Pr.1466 PID multistage set point 7 to set the target values for selection.
- · When "9999" is set in the selected multistage set point parameter, PID control is performed according to the Pr.128, Pr.609, and Pr.133 settings.

Selected set point	PDI1*1	PDI2*1	PDI3*1	Parameter for setting
_	OFF	OFF	OFF	As set in the <b>Pr.128</b> and <b>Pr.609</b> PID settings. As set <b>Pr.133</b> when <b>Pr.133</b> ≠"9999".
Multistage set point 1	ON	OFF	OFF	Pr.1460
Multistage set point 2	OFF	ON	OFF	Pr.1461
Multistage set point 3	ON	ON	OFF	Pr.1462
Multistage set point 4	OFF	OFF	ON	Pr.1463
Multistage set point 5	ON	OFF	ON	Pr.1464
Multistage set point 6	OFF	ON	ON	Pr.1465
Multistage set point 7	ON	ON	ON	Pr.1466

\*1 When functions are not assigned to the input terminals, the signals are treated as OFF.



- The multistage set point input is not available for the second PID.
- The priority of the set point input is as follows: Pr.1460 to Pr.1466 > Pr.133 > Pr.128.

# ♦Input/output signals

- Assigning the PID control valid terminal signal (X14) to the input terminal by Pr.178 to Pr.189 (input terminal function selection) enables PID control to be performed only when the X14 signal is turned ON. When the X14 signal is OFF, regular inverter running is performed without PID action.
- · Input signal

Signal	Function	Pr.178 to Pr.189 setting	Description
X14	PID control valid terminal	14	When the signal is assigned to the input terminal, PID control is enabled
X80	Second PID control valid terminal	80	when the signal is assigned to the input terminal, FID control is enabled when the signal is ON.
PDI1	PID multistage set point setting 1	38	
PDI2	PID multistage set point setting 2	39	The set point set in <b>Pr.1460 to Pr.1466</b> can be selected by combining the ON/OFF status of the signals.
PDI3	PID multistage set point setting 3	40	
X64	PID forward/reverse action switchover	64	PID control is switched between forward and reverse action without
X79	Second PID forward/ reverse action switchover	79	changing parameters by turning ON the signal.
X72	PID integral value reset	72	
X73	Second PID P control switchover	73	Integral and differential values can be reset by turning the signal ON.

· Output signal


		Pr.190 to Pr.196 setting value		
Signal	Function	positive		Description
		logic	negative logic	
FUP	PID upper limit	15 15	115	Output when the measured value signal avecade Pr 424 PID was an limit
_	''			Output when the measured value signal exceeds Pr.131 PID upper limit
FUP2	Second PID upper limit	201	301	(Pr.1143 Second PID upper limit).
FDN	PID lower limit	14	114	Output when the measured value signal exceeds Pr.132 PID lower limit
FDN2	Second PID lower limit	200	300	(Pr.1144 Second PID lower limit).
RL	PID forward/reverse rotation output	16	116	"Hi" is output when the output display of the parameter unit is forward
RL2	Second PID forward/ reverse rotation output	202	302	rotation (FWD), and "Low" is output when the display is reverse rotation (REV) and stop (STOP).
PID	During PID control activated	47	147	Turns ON during PID control.  When the PID calculation result is not reflected to the output frequency
PID2	Second During PID control activated	203	303	( <b>Pr.128</b> < "2000"), the PID signal turns OFF at turn OFF of the start signal. When the PID calculation result is reflected to the output frequency ( <b>Pr.128</b> ≥ "2000"), the PID signal turns ON regardless of the start signal status during PID calculation.
SLEEP	PID output interruption	70	170	Set Pr.575 Output interruption detection time (Pr.1147 Second output
SLEEP2	During second PID output shutoff	204	304	interruption detection time) ≠ "9999". This signal turns ON when the PID output suspension function is activated.

# NOTE

• Changing the terminal functions with Pr.178 to Pr.189 and Pr.190 to Pr.196 may affect other functions. Set parameters after confirming the function of each terminal.

#### ◆PID automatic switchover control (Pr.127)

- The system can be started up more quickly by starting up without PID control activated.
- When Pr.127 PID control automatic switchover frequency is set, the startup is made without PID control until the output frequency reaches the Pr.127 setting. Once the PID control starts, the PID control is continued even if the output frequency drops to Pr.127 setting or lower.



# ◆ Selection of action at a communication error and SLEEP function stop selection (FUP signal, FDN signal, Y48 signal, Pr.554)


- Using Pr.554 PID signal operation selection, set the action when the measured value input exceeds the upper limit (Pr.131 PID upper limit) or lower limit (Pr.132 PID lower limit), or when the deviation input exceeds the permissible value (Pr.553 PID deviation limit).
- · Choose whether to output the signals (FUP, FDN, Y48) only or to activate the protective function to output the inverter shutoff.
- The stop action when the inverter output is shut off by the SLEEP function can be selected.

Dr EE4 cotting	Inverter operation						
Pr.554 setting	At FUP signal, FDN signal output*1	At Y48 signal output+1	At SLEEP operation start				
0 (Initial value)	Signal output only	Signal output only					
1	Signal output + output shutoff (E.PID)	Signal output only	- Coasts to stop				
2	Signal output only	Signal output + output shutoff					
3	Signal output + output shutoff (E.PID)	(E.PID)					
10	Signal output only	Signal output only					
11	Signal output + output shutoff (E.PID)	Signal output only	Deceleration atom				
12	Signal output only	Signal output + output shutoff	Deceleration stop				
13	Signal output + output shutoff (E.PID)	(E.PID)					

When each of Pr.131, Pr.132 and Pr.553 corresponding to each of the FUP, FDN and Y48 signals is set to "9999" (function not activated), signal output and protective function are disabled.

# ◆PID output suspension function (SLEEP function) (SLEEP signal, Pr.575 to Pr.577)

- When a status where the output frequency after PID calculation is less than **Pr.576 Output interruption detection level** has continued for the time set in **Pr.575 Output interruption detection time** or longer, inverter running is suspended. This allows the amount of energy consumed in the inefficient low-speed range to be reduced.
- When the deviation (for instance, the set point measured value) reaches the PID output shutoff release level (**Pr.577** setting value -1000%) while the PID output suspension function is activated, the PID output suspension function is released, and PID control operation is automatically restarted.
- Whether to allow motor to coast to a stop or perform a deceleration stop when SLEEP operation is started can be selected using **Pr.554**.
- While the PID output suspension function is activated, the PID output interruption signal (SLEEP) is output. During this time, the inverter running signal (RUN) turns OFF and the During PID control activated signal (PID) turns ON.
- For the terminal used for the SLEEP signal, set "70 (positive logic)" or "170 (negative logic)" in any of **Pr.190 to Pr.196** (output terminal function selection).



\*1 When the PID output shutoff release level is reached during a deceleration stop, output shutoff is released, operation is re-accelerated and PID control is continued. During deceleration **Pr.576 Output interruption detection level** is invalid.

#### ◆Integral stop selection at limited frequency (Pr.1015)

- The operation for the integral term can be selected when the frequency is restricted by the upper/lower limit, or the manipulated amount is limited to ±100% during PID control.
- The operation during output shutoff can be selected for the integral term using the PID output suspension function (SLEEP function).

Pr.1015 setting	Operation at limited frequency	Operation during output interruption	
0 (initial value)	Integral stop	Integral clear	
1	Integral continuation	Integral clear	
10	Integral stop	Integral stop	
11	Integral continuation	Integral stop	

#### PID monitor function


- · This function displays the PID control set point, measured value and deviation on the operation panel, and can output these from the terminals FM, AM and CA.
- An integral value indicating a negative % can be displayed on the deviation monitor. 0% is displayed as 1000. (These values cannot be output on the deviation monitor from terminals FM and CA.)
- Set the following values to Pr.52 Operation panel main monitor selection, Pr.774 to Pr.776 (Operation panel monitor selection), Pr.992 Operation panel setting dial push monitor selection, Pr.54 FM/CA terminal function selection and Pr.158 AM terminal function selection for each monitor.

Parameter	Monitor	Minimum increment	N	lonitor rang	je		
settings	description		Terminal FM/CA	Terminal AM	Operation panel	Remarks	
52	PID set point						
92	Second PID set point	0.1%	0 to 100%*1				
53	PID measured value					"0" is displayed at all times when PID control is based in deviation input.	
93	Second PID measured value	0.1%	0 to 100%*1				
67	PID measured value 2		0 to 100%*1			The measured value is also displayed when PID control is invalid.	
95	Second PID measured value 2	0.1%				"0" is displayed at all times when PID control is based in deviation input.	
54	PID deviation	0.40/	Setting not	-100% to	900% to 1100% or	Using Pr.290 Monitor negative output	
94	Second PID deviation	0.1%	available	100%*1*2	-100% to 100%*1	selection, minus values can be output to the terminal AM and displayed on the operation	
91	PID manipulated variable	0.49/	Setting not	900% to Setting not -100% to 1100% or		panel. Even if minus display is enabled, the display range is 900% to 1100% in monitors on the	
96	Second PID manipulated variable	- 0.1%	available	100%*2	-100% to 100%	operation panel. (0% is offset and displayed as 1000%.)	

<sup>\*1</sup> When C42(Pr.934) and C44(Pr.935) are set, the minimum increment changes from unit % to no unit, and the monitor range can be changed. (Refer to page 399.)


<sup>\*2</sup> When the minus value display is set disabled using Pr.290, the terminal AM output becomes "0".

# **♦**Adjustment procedure



#### Calibration example

Adjust room temperature to 25°C by PID control using a detector that outputs 4 mA at 0°C and 20 mA at 50°C.)



When calibration is required

Calibrate detector output and set point input by Pr.125, C2 (Pr.902) to C4 (Pr.903) (terminal 2) or Pr.126, C5 (Pr.904) to C7 (Pr.905) (terminal 4). (Refer to page 314.)

When both C42 (Pr.934) and C44 (Pr.935) are other than "9999", calibrate the detector output and set point input by Pr.934 and Pr.935 (terminal 4). (Refer to page 399.)

Make calibration in the PU operation mode during an inverter stop.

- \*2 For the PID gain tuning, refer to page 394.
- · Calibrating set point input

(Example: To enter the set point on terminal 2)

- 1) Apply the input (for example, 0 V) of set point setting 0% across terminals 2 and 5.
- 2) Using **C2** (**Pr.902**), enter the frequency (for example, 0 Hz) to be output by the inverter when the deviation is 0%.
- 3) Using C3 (Pr.902), set the voltage value at 0%.
- 4) Apply the input (for example, 5 V) of set point setting 100% across terminals 2 and 5.
- 5) Using Pr.125, enter the frequency (for example, 60 Hz) to be output by the inverter when the deviation is 100%.
- 6) Using C4 (Pr.903), set the voltage value at 100%.

### NOTE


· When the set point is set at Pr.133, the setting frequency of C2 (Pr.902) is equivalent to 0% and the setting frequency of Pr.125 (Pr.903) is equivalent to 100%.

#### (A) Application parameters

- · Calibrating measured value input
  - 1) Apply the input (for example, 4 mA) of measured value 0% across terminals 4 and 5.
  - 2) Perform calibration by C6 (Pr.904).
  - 3) Apply the input (for example, 20 mA) of measured value 100% across terminals 4 and 5.
  - 4) Perform calibration by C7 (Pr.905).

#### NOTE :

- Set the frequencies set at C5 (Pr.904) and Pr.126 to each of the same values set at C2 (Pr.902) and Pr.125.
- The display unit for analog input can be changed from "%" to "V" or "mA". (Refer to page 316.)
- The figure below shows the results of having performed the calibration above.



#### Setting multiple PID functions

• When the second PID function is set, two sets of PID functions can be switched for use. The PID setting is selected as shown in the table below.

Pr.128 setting (First PID setting)	Pr.753 setting (Second PID setting)	Pr.155 setting *1	RT signal	PID setting applied to the output frequency
"0" or not applied to the frequency	"0" or not applied to the frequency	_	_	Control other than PID control
"0" or not applied to the frequency	Applied to the frequency	_	_	Second PID setting
Applied to the frequency	"0" or not applied to the frequency	_	_	First PID setting
		0	OFF	First PID setting
Applied to the frequency	Applied to the frequency	0	ON	Second PID setting
		10	_	First PID setting

While Pr.155 = "0", the second function is enabled immediately after RT signal turns ON. While Pr.155 = "10", the second function is enabled only during constant speed operation when RT signal turns ON. (Refer to page 333 for the details.)

• The second PID function parameters and signals function in the same way as the following parameters and signals of the first PID function. Refer to the first PID function when setting the second PID functions.

Classification	Fi	irst PID function parameters	5	Second PID function parameters	
Classification	Pr.	Name	Pr.	Name	
	127	PID control automatic switchover frequency	754	Second PID control automatic switchover frequency	
	128	PID action selection	753	Second PID action selection	
	129	PID proportional band	756	Second PID proportional band	
	130	PID integral time	757	Second PID integral time	
	131	PID upper limit		Second PID upper limit	
	132	PID lower limit	1144	Second PID lower limit	
	133	PID action set point	755	Second PID action set point	
Parameter	134	PID differential time	758	Second PID differential time	
	553	PID deviation limit	1145	Second PID deviation limit	
	554	PID signal operation selection	1146	Second PID signal operation selection	
	575	Output interruption detection time	1147	Second output interruption detection time	
	576	Output interruption detection level	1148	Second output interruption detection level	
	577	Output interruption cancel level	1149	Second output interruption cancel level	
	609	PID set point/deviation input selection	1140	Second PID set point/deviation input selection	
	610	PID measured value input selection	1141	Second PID measured value input selection	

Classification	Fir	st PID function parameters	Second PID function parameters		
Ciassilication	signal	Name	signal	Name	
	X14	PID control valid terminal	X80	Second PID control valid terminal	
Input signal	X64	PID forward/reverse action switchover	X79	Second PID forward/reverse action switchover	
	X72	PID integral value reset	X73	Second PID P control switchover	
	FUP	PID upper limit	FUP2	Second PID upper limit	
	FDN	PID lower limit	FDN2	Second PID lower limit	
Output signal	RL	PID forward/reverse rotation output	RL2	Second PID forward/reverse rotation output	
Output signal	PID	During PID control activated	PID2	Second During PID control activated	
	SLEEP	PID output interruption	SLEEP2	During second PID output shutoff	
	Y48	PID deviation limit	Y205	Second PID deviation limit	

#### NOTE:


- Even if the X14 signal is ON, PID control is stopped and multi-speed or JOG operation is performed when the RH, RM, RL, or REX signal (multi-speed operation) or JOG signal (JOG operation) is input.
- · PID control is invalid under the following settings.

#### Pr.79 Operation mode selection = "6" (Switchover mode)

- Note that input to the terminal 1 is added to the terminals 2 and 4 inputs. For example when Pr.128 = "20 or 21", the terminal 1 input is considered as a set point and added to the set point of the terminal 2.
- To use terminal 4 and 1 inputs in PID control, set "0" (initial value) to Pr.858 Terminal 4 function assignment and Pr.868 Terminal 1 function assignment. When a value other than "0", PID control is invalid.
- · Changing the terminal assignment using Pr.178 to Pr.189 or Pr.190 to Pr.196 may affect other functions. Set parameters after confirming the function of each terminal.
- · When PID control is selected, the minimum frequency becomes the frequency of Pr.902 and the maximum frequency becomes the frequency of Pr.903.

(The Pr.1 Maximum frequency and Pr.2 Minimum frequency settings also are valid.)

- · During PID operation, the remote operation function is invalid.
- · When control is switched to PID control during normal operation, the frequency during that operation is not carried over, and the value resulting from PID calculation referenced to 0 Hz becomes the command frequency.



Operation when control is switched to PID control during normal operation

#### Parameters referred to

Pr.59 Remote function selection page 194

Pr.73 Analog input selection page 306

Pr.79 Operation mode selection page 200

Pr.178 to Pr.189 (input terminal function selection) page 329

Pr.190 to Pr.196 (output terminal function selection) \* page 288

Pr.290 Monitor negative output selection page 273

C2 (Pr.902) to C7 (Pr.905) Frequency setting voltage (current) bias/gain page 314

# 5.11.6 PID gain tuning


Changing the PID control manipulated amount and measuring the PID control response enable automatic setting of the constant optimal for PID control.

For tuning, use the step response method or the limit cycle method.

Pr.	Name	Initial value	Setting range	Description
1211 A690	PID gain tuning timeout time	100 s	1 to 9999 s	Set the time after the PID gain tuning starts until a timeout error occurs.
1212 A691	Step manipulated amount	1000%	900 to 1100%	Set the step manipulated amount when using the step response method to perform the PID gain tuning.
1213 A692	Step responding sampling cycle	1 s	0.01 to 600 s	Set the cycle for sampling of measurement values when using the step response method to perform the PID gain tuning.
1214 A693	Timeout time after the maximum slope	10 s	1 to 9999 s	Set the time after the measurement of the maximum slope until the completion of the tuning when using the step response method to perform the PID gain tuning.
1215 A694	Limit cycle output upper limit	1100%	900 to 1100%	Set the upper limit value of the two-position output when using the limit cycle method to perform the PID gain tuning.
1216 A695	Limit cycle output lower limit	1000%	900 to 1100%	Set the lower limit value of the two-position output when using the limit cycle method to perform the PID gain tuning.
1217 A696	Limit cycle hysteresis	1%	0.1 to 10%	Set the hysteresis of the set point when using the limit cycle method to perform the PID gain tuning.
1218 A697	PID gain tuning setting	0	0, 100 to 102, 111, 112, 121, 122, 200 to 202, 211, 212, 221, 222	Select the target loop, method, and control adjustment method for the PID gain tuning.
			0	PID gain tuning function disabled
1219	PID gain tuning start/		1	PID gain tuning start
A698	status	0	2	During PID gain tuning (read only)
	omino		8	PID gain tuning forced end
			9, 90 to 96	Tuning error (read only)

## **♦**Step response method

• In the step response method, the manipulated amount is changed step by step for the real system. From the change in the measured values, the maximum slope (R) and the equivalent waste time (L) are calculated to determine each constant.




- The step manipulated amount (Pr.1212 1000) is added to the present manipulated amount.
- The measured value is taken for every sampling cycle of step response (**Pr.1213**). From the variation between the measured values (Y) and the time (t), the maximum slope (R) is calculated.

- The measurement ends when the timeout time after the maximum slope (**Pr.1214**) elapsed after the maximum slope is obtained.
- After the integral term is cleared, PID control is performed with the constant to which the change has been applied (the constant used before PID gain tuning when a fault occurs).

#### **◆Limit cycle method**

- In the limit cycle method, the two-position ON/OFF operation is performed three times for output of the manipulated amount for the real system. From the vibration waveform data of the measured values, the vibration amplitude (Xc) and the vibration cycle (Tc) are measured. Based on the measured values, each constant is determined.
- In the limit cycle method, less influence of the noise of the measured values is given as compared in the step response method, and a stable tuning result can be obtained.



\*1 Details of the two-position ON/OFF operation

PID control operation	Initial output of the manipulated amount	Two-position ON/OFF operation
Reverse action	When measured value ≤ set point Manipulated amount = Upper limit of the output (Pr.1215- 1000) When measured value > set point Manipulated amount = Lower limit of the output (Pr.1216- 1000)	Using measured value ≥ set point + hysteresis (Pr.1217) Manipulated amount = Lower limit of the output (Pr.1216- 1000) Using measured value ≤ set point - hysteresis (Pr.1217) Manipulated amount = Upper limit of the output (Pr.1215- 1000)
Forward action	When measured value ≤ set point Manipulated amount = Lower limit of the output (Pr.1216- 1000) When measured value > set point Manipulated amount = Upper limit of the output (Pr.1215- 1000)	Using measured value ≥ set point + hysteresis (Pr.1217) Manipulated amount = Upper limit of the output (Pr.1215- 1000) Using measured value ≤ set point - hysteresis (Pr.1217) Manipulated amount = Lower limit of the output (Pr.1216- 1000)

- The manipulated amount is output at the limit cycle output upper limit (**Pr.1215** 1000). (When measured value > set point, the manipulated amount is once output at the limit cycle lower limit (**Pr.1216** 1000), and then after set point > measured value is achieved, the manipulated amount is output at the limit cycle output upper limit (**Pr.1215** 1000).)
- The two-position ON/OFF operation is repeated three times. From the waveform data of the values measured for output of the second and third two-position operation, the vibration amplitude (Xc) and the vibration cycle (Tc) are measured.
- From the vibration amplitude (Xc) and the vibration cycle (Tc), the threshold sensitivity (Ku) and the threshold cycle (Tu) are calculated.
- Each constant is calculated using a formula depending on the Pr.1218 setting, and PID gain tuning is finished.
- After the integral term is cleared, PID control is performed with the constant to which the change has been applied (the constant used before PID gain tuning when a fault occurs).



- Confirm that the measured values are stable when performing PID gain tuning with the step response method. When the measured values are unstable, the tuning result may not be accurate.
- · Accurate measurement of the maximum slope may not be achieved if the Pr.1213 setting is small in the step response method.

#### **♦PID** gain tuning operation setting (Pr.1218)

• Set the PID gain tuning operation in this parameter. The digit in the hundreds place represents the target PID loop. The digit in the tens place represents the tuning method. The digit in the ones place represents the control adjustment method.

Pr.1218 setting value	Target PID	Tuning method	Control adjustment method
0 (initial value)	PID gain tuning function disabled		
100			P control adjustment
101		Step response method	PI control adjustment
102			PID control adjustment
111	First PID	Limit cycle method (set-point control)	PI control adjustment
112			PID control adjustment
121		Limit cycle method (follow-up control)	PI control adjustment
122			PID control adjustment
200		Step response method	P control adjustment
201			PI control adjustment
202			PID control adjustment
211	Second PID		PI control adjustment
212		Limit cycle method (set-point control)	PID control adjustment
221		Limit avala mantha d'éallavvva acontral)	PI control adjustment
222		Limit cycle method (follow-up control)	PID control adjustment

#### **◆Parameter setting for each PID gain tuning method**


• Set the following parameters according to the selected tuning method (step response method / limit cycle method).

	Tuning	method		
Pr.	Step response method	Limit cycle method	ltem	Description
128 (753)	0	0	PID action selection	Select the PID action.
1218	0	0	PID gain tuning setting	Select the PID gain tuning operation.
1211	0	0	PID gain tuning timeout time	Set the timeout time for PID gain tuning. A timeout error occurs when the elapsed time exceeds the setting.
1212	0	-	Step manipulated amount	Set the step manipulated amount for PID gain tuning.
1213	0	-	Step responding sampling cycle	Set the cycle for sampling of measurement values for PID gain tuning.
1214	0	-	Timeout time after the maximum slope	Set the timeout time after the maximum slope measurement for PID gain tuning. The measurement for tuning is completed when the elapsed time exceeds the setting.
1215	-	0	Limit cycle output upper limit  Set the upper limit value of the two-position outpain tuning.	
1216	-	0	Limit cycle output lower limit	Set the lower limit value of the two-position output for PID gain tuning. (When the setting exceeds the <b>Pr.1215</b> setting, a tuning error occurs.)
1217	-	0	Limit cycle hysteresis	Set the hysteresis of the set point for PID gain tuning.

O: Parameter to set

#### ◆Execution of PID gain tuning (Pr.1219, PGT signal)

- While the PID gain tuning function is enabled (Pr.1218 ≠ "0"), PID gain tuning is started when any of the following operations is performed during PID control.
  - Turn ON the PID gain tuning start/forced end signal (PGT).
  - Set Pr.1219 PID gain tuning start/status = "1".
  - Select the PID gain tuning start (1.RUN) in the function menu on the operation panel (FR-DU08).



- To use the PGT signal, set "81" in any of Pr.178 to Pr.189 (input terminal function selection) to assign the function to an input terminal.
- The PID gain tuning status can be checked with the read value of Pr.1219 or the PID gain tuning status monitor. The PID gain tuning status monitor is displayed instead of the output voltage monitor.

Status monitor	PID gain tuning status
2	During tuning
3	Tuning completed
8	Tuning forced end

• When PID gain tuning is completed, the following parameters are automatically set.

Pr.	Name	Step response method			Limit cycle method	
FI.	Ivallie	P control	PI control	PID control	PI control	PID control
129 (756)	PID proportional band	0	0	0	0	0
130 (757)	PID integral time	-	0	0	0	0
134 (758)	PID differential time	-	-	0	-	0

O: The calculation result is applied. -: "9999" is set.

- To forcibly terminate the tuning during PID gain tuning, perform any of the following operations.
  - Turn OFF the PID gain tuning start/forced end signal (PGT).
  - Set Pr.1219 PID gain tuning start/status = "8".
  - Select the PID gain tuning forced end (8.END) in the function menu on the operation panel (FR-DU08).
  - Turn the power supply OFF, reset the inverter, or turn OFF the start command.

- · By PID gain tuning, the settings of the PID constant parameters (Pr.129, Pr.130, Pr.134, Pr.756 to Pr.758) are automatically changed. Before performing PID gain tuning, record the PID constant parameter settings before tuning as required.
- PID gain tuning also requires setting of the PID upper limit (Pr.131 or Pr.1143), PID lower limit (Pr.132 or Pr.1144), PID deviation limit (Pr.553 or Pr.1145).
- · Changing the terminal assignment with Pr.178 to Pr.189 may affect other functions. Set parameters after confirming the function of each terminal.
- · By PID gain tuning, the manipulated amount is changed considerably. In some applications such as a winding machine, materials may be affected.

#### ◆PID gain tuning error

• When the read value of Pr.1219 or the PID gain tuning status monitor display is "9, 90 to 96", tuning has not been properly completed due to a tuning error. Remove the cause of the tuning error, and perform tuning again.

Monitor value	Error definition	Cause of tuning error	Corrective action for error
9	Termination of tuning due to activation of an inverter protective function	An inverter protective function is activated.	Remedy the cause. (Refer to page 535.)
90	Input upper limit error	The measured value is higher than the PID upper limit (Pr.131 or Pr.1143).	Change the <b>Pr.131</b> or <b>Pr.1143</b> setting as appropriate.
91	Input lower limit error	The measured value is lower than the PID lower limit (Pr.132 or Pr.1144).	Change the <b>Pr.132</b> or <b>Pr.1144</b> setting as appropriate.
92	Deviation limit error	The deviation exceeded the PID deviation limit ( <b>Pr.553</b> or <b>Pr.1145</b> ).	Change the <b>Pr.553</b> or <b>Pr.1145</b> setting as appropriate.
93	Timeout error	Tuning is not terminated within the time set in <b>Pr.1211</b> after the start of PID gain tuning.	Change the <b>Pr.1211</b> setting as appropriate.
94	Calculation error	The tuning calculation is inconsistent.	In the step response method, change the Pr.1212 and Pr.1213 settings as appropriate. In the limit cycle method, change the Pr.1217 setting as appropriate.
95	Setting error	<ul> <li>PID control is disabled during tuning.</li> <li>The PID control setting has been changed during tuning.</li> <li>In the limit cycle method, the Pr.1215 setting is equal to or lower than the Pr.1216 setting.</li> </ul>	Enable PID control.     Change the Pr.1215 and Pr.1216 settings as appropriate.
96	PID mode error	<ul> <li>PID gain tuning has been started during automatic switchover or pre-charge operation.</li> <li>A stall prevention or regeneration avoidance operation occurred during PID gain tuning.</li> <li>A condition for output shutoff by the SLEEP function was satisfied during PID gain tuning.</li> <li>Frequency fluctuation occurred because of the frequency jump, maximum frequency, or minimum frequency during PID gain tuning.</li> </ul>	Change the setting of each function as appropriate.

# ◆Fine adjustment after PID gain tuning

• If fine adjustment is required after completion of PID gain tuning, adjust the proportional band (Pr.129 or Pr.756), integral time (Pr.130 or Pr.757), and differential time (Pr.134 or Pr.758).

Status of measurement values	Adjustment method
The response is fast, but vibrations are observed.  Measured value[%]  Set point[%]  Tin	Increase the proportional band (Pr.129 or Pr.756).     (Smaller proportional effect)     Increase the integral time (Pr.130 or Pr.757).     (Smaller integral effect)
Optimal	
Measured value[%]  Set point[%]  Tin	ne
Response is slow.  Measured value[%]  Set point[%]  Tin	Decrease the proportional band (Pr.129 or Pr.756).     (Larger proportional effect)     Decrease the integral time (Pr.130 or Pr.757).     (Larger integral effect)



· When the differential operation is used, adjust the differential time (Pr.134 or Pr.758) while checking the stability and the response. (Increasing the differential time makes the differential effect larger, and decreasing the differential time makes the differential effect smaller.)

#### 5.11.7 Changing the display increment of the numerical values used in PID control


When the LCD operation panel (FR-LU08) or the parameter unit (FR-PU07) is used, the display unit of parameters and monitored items related to PID control can be changed to various units.

Pr.	Name	Initial value	Setting range		Description	
759 A600	Operation mode selection	0	0 to 43	Change the PID control-related display unit that is displayed on the LCD operation panel (FR-LU08) or the parameter unit (FR-PU07).		
			9999	Without display unit switching		
C42 A630	PID display bias	9999	0 to 500	Set the coefficient of to value input.	the bias side (minimum) of measured	
(934) <del>*</del> 1	coefficient		9999	Displayed in %.		
C43 A631 (934)*1	PID display bias analog value	20%	0 to 300%	Set the converted % of the bias side (minimum) current/ voltage of measured value input.		
C44 A632	PID display gain	9999	0 to 500	Set the coefficient of the gain side (maximum) of measured value input.		
(935) <del>*</del> 1	coefficient		9999	Displayed in %.		
C45 A633 (935)*1	PID display gain analog value	100%	0 to 300%	Set the converted % of the gain side (maximum) current/voltage of measured value input.		
1136 A670	Second PID display bias coefficient	9999	0 to 500 9999	Refer to C42 (934)		
1137 A671	Second PID display bias analog value	20%	0 to 300%	Refer to C43 (934)		
1138 A672	Second PID display gain coefficient	9999	0 to 500 9999	Refer to <b>C44 (935)</b>	Second PID control	
1139 A673	Second PID display gain analog value	100%	0 to 300%	Refer to <b>C45 (935)</b>	1	
1142 A640	Second PID unit selection	9999	0 to 43, 9999	Refer to Pr.759	1	

<sup>\*1</sup> The parameter number in parentheses is the one for use with the LCD operation panel and the parameter unit.

# ◆ Calibration of PID display bias and gain(C42 (Pr.934) to C45 (Pr.935))

- When both C42 (Pr.934) and C44 (Pr.935) ≠ "9999", the bias and gain values for the set point, measured value and deviation in PID control can be calibrated.
- "Bias"/"gain" function can adjust the relation between PID displayed coefficient and measured value input signal that is externally input.
  - Examples of these measured value input signals are 0 to 5 VDC, 0 to 10 VDC, or 4 to 2 mADC.
- Set the value that is displayed when the PID measured value (control amount) is 0% to C42 (Pr.934) and the value that is displayed when the PID measured value (control amount) is 100% to C44 (Pr.935).
- When both of C42 (Pr.934) and C44 (Pr.935) ≠"9999" and Pr.133 is set as the set point, the setting of C42 (Pr.934) is treated as 0%, and C44 (Pr.935) as 100%



#### (A) Application parameters

- There are three methods to adjust the PID display bias/gain.
  - (a) Method to adjust any point by application of a current (voltage) to the measured value input terminal
  - (b) Method to adjust any point without application of a current (voltage) to the measured value input terminal
  - (c) Method to adjust only the display coefficient without adjustment of current (voltage)

(Refer to page 314 for details on (a) to (c), and make the necessary adjustments by considering C7 (Pr.905) as C45 (Pr.935) and Pr.126 as C44 (Pr.935).



- Always calibrate the input after changing the voltage/current input specification with Pr.73 and Pr.267, and the voltage/current input selection switch.
- Take caution when the following condition is satisfied because the inverter recognizes the deviation value as negative (positive) value even though a positive (negative) deviation is given: Pr.934 (PID bias coefficient) > Pr.935 (PID gain coefficient)

To perform a reverse action, set **Pr.128 PID action selection** to forward action. Alternatively, to perform a forward action, set **Pr.128** to reverse action.


Pr.934 < Pr.935	(normal setting)	Pr.934 ≥ Pr.935	
Reverse action	Reverse action setting to Pr.128	Reverse action	Forward action setting to Pr.128
Forward action	Forward action setting to Pr.128	Forward action	Reverse action setting to Pr.128
PID output shutoff release level	Pr.577 -1000	PID output shutoff release level	1000 -Pr.577

(Example) Set the following: **Pr.934**="500", 20% (4 mA is applied), **Pr.935**="100", 100% (20 mA is applied).

When the set point=400 and the measured value=360, the deviation is +40 (>0), but the inverter recognizes the deviation as -10% (<0). Because of this, operation amount does not increase in the reverse operation setting.

The operation amount increases when the forward operation is set.

To perform PID output shutoff release at deviation of +40 or higher, set **Pr.577**="960".



• The display of the following parameters is changed according to the C42 (Pr.934)), C44 (Pr.935), Pr.1136, and Pr1138 settings.

Pr.	Name			
131	PID upper limit			
132	PID lower limit			
133	PID action set point			
553	PID deviation limit			
577	Output interruption cancel level			
761	Pre-charge ending level			
763	Pre-charge upper detection level			

Pr.	Name
1143	Second PID upper limit
1144	Second PID lower limit
755	Second PID action set point
1145	Second PID deviation limit
1149	Second output interruption cancel level
766	Second pre-charge ending level
768	Second pre-charge upper detection level

# ♦ Changing the PID display coefficient of the LCD operation panel (FR-LU08), parameter unit (FR-PU07) (Pr.759)

• Use Pr.759 PID unit selection to change the unit displayed on FR-LU08 or FR-PU07. For the coefficient set in C42(Pr.934) to C44(Pr.935), the displayed units can be changed to the following units.

Pr.759 setting	Displayed unit	Unit name
9999	%	%
0	_	Not displayed
1	K	Kelvin
2	С	Degree Celsius
3	F	Degree Fahrenheit
4	PSI	Pound-force per Square Inch
5	MPa	Mega Pascal
6	kPa	Kilo Pascal
7	Pa	Pascal
8	bar	Bar
9	mbr	Millibar
10	GPH	Gallon per Hour
11	GPM	Gallon per Minute
12	GPS	Gallon per Second
13	L/H	Liter per Hour
14	L/M	Liter per Minute
15	L/S	Liter per Second
16	CFH	Cubic Feet per Hour
17	CFM	Cubic Feet per Minute
18	CFS	Cubic Feet per Second
19	CMH	Cubic Meter per Hour
20	CMM	Cubic Meter per Minute
21	CMS	Cubic Meter per Second

Pr.759	Displayed	
setting	unit	Unit name
22	ftM	Feet per Minute
23	ftS	Feet per Second
24	m/M	Meter per Minute
25	m/S	Meter per Second
26	lbH	Pound per Hour
27	IbM	Pound per Minute
28	lbS	Pound per Second
29	iWC	Inch Water Column
30	iWG	Inch Water Gauge
31	fWG	Feet of Water Gauge
32	mWG	Meter of Water Gauge
33	iHg	Inches of Mercury
34	mHg	Millimeters of Mercury
35	kgH	Kilograms per Hour
36	kgM	Kilograms per Minute
37	kgS	Kilograms per Second
38	ppm	Pulse per Minute
39	pps	Pulse per Second
40	kW	Kilo Watt
41	hp	Horse Power
42	Hz	Hertz
43	rpm	Revolutions per Minute

# 5.11.8 PID pre-charge function

This function drives the motor at a certain speed before starting PID control. This function is useful for a pump with a long hose. Without this function, PID control would start before the pump is filled with water, and proper control would not be performed.

Pr.	Name	Initial value	Setting range		Description	
760	Pre-charge fault	0	0	Fault indication with output shutoff immediately after pre- charge fault occurs.		
A616	selection	0	1	Fault indication with de occurs.	eceleration stop after pre-charge fault	
761	Pre-charge ending level	9999	0 to 100%	Set the measured amo	unt to end the pre-charge operation.	
A617	Tre-charge enamy level	3333	9999	Without pre-charge end	•	
762	Pre-charge ending time	9999	0 to 3600 s	Set the time to end the		
A618	1 10-charge chang time	0000	9999	Without pre-charge end	ding time	
763 A619			0 to 100%		he pre-charged amount. A pre-charge neasured value exceeds the setting	
			9999	Without pre-charge upper limit level		
764	Pre-charge time limit	9999	0 to 3600 s		e pre-charged amount. A pre-charge ore-charge time exceeds the setting.	
A620			9999	Without pre-charge time limit		
1132	Pre-charge change	9999	0 to 100%	Set the change increment amount per second after the automatic switchover frequency is reached. (for vertical pumps).		
A626	increment amount		9999	Constant-speed operation after the automatic switchover frequency is reached (for horizontal pumps).		
765 A656	Second pre-charge fault selection	0	0, 1	Refer to Pr.760.		
766 A657	Second pre-charge ending level	9999	0 to 100%, 9999	Refer to Pr.761.		
767 A658	Second pre-charge ending time	9999	0 to 3600 s, 9999	Refer to Pr.762.	Set the second pre-charge function.	
768 A659	Second pre-charge upper detection level	9999	0 to 100%, 9999	Refer to Pr.763.	The second pre-charge function is valid when the RT signal is ON.	
769 A660	Second pre-charge time limit	9999	0 to 3600 s, 9999	Refer to Pr.764.		
1133 A666	Second pre-charge change increment amount	9999	0 to 100%, 9999	Refer to <b>Pr.1132</b> .		

### ◆Operation selection for the pre-charge function

- To enable the pre-charge function when PID control is enabled, set the pre-charge end conditions at **Pr.761 Pre-charge** ending level and at **Pr.762 Pre-charge ending time**, or set "77" to **Pr.178 to Pr.189 (input terminal function selection)**. When operation is started, the inverter runs at the frequency set to **Pr.127 PID control automatic switchover frequency** to enter the pre-charge state.
- · Pre-charge ends and PID control starts after a pre-charge ending condition is satisfied.
- The pre-charge function is also activated at a start after release of a PID output suspension (SLEEP) state or MRS (output shutoff). The PID output suspension (SLEEP) function is not activated until the started pre-charge operation ends.
- During pre-charge operation, the During pre-charge operation (Y49) signal is output. For the terminal used for Y49 signal output, set "49 (positive logic)" or "149 (negative logic)" in any of **Pr.190 to Pr.196 (Output terminal function selection)** to assign the function.
- The pre-charge function valid/invalid settings and pre-charge ending conditions are as follows:

Pr.127 setting	Pre-char	rge ending condition	Pre-charge	Valid pre-charge ending			
Pi.127 Setting	Pr.761 setting	Pr.762 setting	X77 signal	function	condition∗1		
9999	-	-	-	Disabled	-		
		9999	Not assigned	Disabled			
Other than 9999	9999	9999	Assigned		-	-	X77
		Other than 9999	Not assigned		-	Time	-
		Other than 9999	Assigned		-	Time	X77
		9999	Not assigned	Enabled	Result	-	-
	Oth th 0000	9999	Assigned		Result	-	X77
	Other than 9999	Other than 9999	Not assigned		Result	Time	-
		Other than 9999	Assigned		Result	Time	X77


\*1 When two or more ends conditions are satisfied, the pre-charge operation ends by the first-satisfied condition.

### NOTE


- During the pre-charge operation, it is regarded as integrated value=estimated value. The motor speed may drop shortly from the automatic switchover frequency depending on the parameter settings.
- Parameter changes and switchover to the second PID control are applied immediately. If PID control has not started when the settings were changed, PID control starts with changed settings. (If PID control has already started, these settings do not apply. If the changed settings already satisfies a condition to start PID control, the PID control starts as soon as these are changed.)
- The pre-charge also ends when PID control is set to invalid, the start command has been turned OFF, and output has been shut off.

#### Example of pre-charge operation

- When the measured amount reaches the pre-charge ending level (**Pr.761 Pre-charge ending level**  $\neq$  "9999") The pre-charge operation ends when the measured value reaches the Pr.761 setting or higher, then the PID control is performed.
  - When **Pr.1132 Pre-charge change increment amount = "9999"** (horizontal pumps)




- When Pr.1132 Pre-charge change increment amount ≠ "9999" (vertical pumps), PID control is performed so that the change increment amount of the set point equals the Pr.1132 setting after the automatic switchover frequency is reached until the pre-charge ending condition is satisfied. (Although PID control is performed after the automatic switchover frequency is reached until the pre-charge ends, the status is regarded as the one during pre-charge.)




#### (A) Application parameters

When the elapsed time reaches the pre-charge ending time (Pr.762 Pre-charge ending time ≠ "9999")
 The pre-charge operation ends when the pre-charge time reaches the Pr.762 setting or higher, then the PID control is performed.



 When the signal is input to end the pre-charge operation
 When the X77 signal turns ON, the pre-charge operation ends, and the PID control starts. (If a start command is given while the X77 signal is ON, the pre-charge operation is not performed, and PID control starts.)



### • NOTE

- When the PID output suspension (SLEEP) function is in use, and the X77 signal is set to valid after this function is released, set the X77 signal to OFF after checking that the during pre-charge operation signal (Y49) is OFF.
- When the PID output suspension (SLEEP) function is in use, and PID control is to be performed immediately after this function is released, leave the X77 signal ON until PID control ends.
- When the pre-charge operation is valid, the pre-charge operation is performed at the output shutoff cancellation (MRS signal, etc.). (The pre-charge operation is also performed in the case of instantaneous power failure when the automatic restart after instantaneous power failure is valid.)
- When the control method is changed to PID control from a control with higher priority in frequency command (multi-speed setting, Jog operation, etc.), the motor is accelerated/decelerated until its speed reaches the automatic switchover frequency (Pr.127), and the pre-charge is performed.


# ◆Operation setting at pre-charge fault

- The protective function can be activated when limit values are exceeded if the time limit is set at **Pr.764 Pre-charge time**limit and the measured value limit level is set at **Pr.762 Pre-charge ending time**.
- Whether to shut off output immediately after the protective function is activated or after a deceleration stop can be selected by **Pr.760 Pre-charge fault selection**.
- When the time limit is exceeded, the Pre-charge time over (Y51) signal is output. When the measured value limit level is exceeded, the Pre-charge level over (Y53) signal is output. For the Y51 signal, set "51 (forward action)" or "151 (reverse action)" to Pr.190 to Pr.196 (output terminal function selection), and for the Y53 signal, set "53 (forward action)" or "153 (reverse action)" in Pr.190 to Pr.196 (output terminal function selection) to assign the functions to terminals.


### • NOTE

- For Pr.764 Pre-charge time limit, set a value greater than Pr.762 Pre-charge ending time.
- For Pr.763 Pre-charge upper detection level, set a value greater than Pr.761 Pre-charge ending level.

• Example of protective function by time limit (Pr.760 = "0")



• Example of protective function measured value limit (Pr.760 = "1")



## **♦** Setting multiple PID pre-charge functions

- When the second pre-charge function is set, two sets of pre-charge functions can be switched for use. The second precharge function is enabled by turning ON the RT signal.
- The second pre-charge function parameters and signals function in the same way as the following parameters and signals of the first pre-charge function. Refer to the first pre-charge function when setting the second pre-charge functions.

Classification	First	pre-charge function parameters	Second pre-charge function parameters		
Classification	Pr.	Name	Pr.	Name	
	760	Pre-charge fault selection	765	Second pre-charge fault selection	
	761	Pre-charge ending level	766	Second pre-charge ending level	
	762	Pre-charge ending time	767	Second pre-charge ending time	
Parameter	763	Pre-charge upper detection level	768	Second pre-charge upper detection level	
	764	Pre-charge time limit	769	Second pre-charge time limit	
	1132	Pre-charge change increment amount	1133	Second pre-charge change increment amount	

Classification	First	ore-charge function parameters	Second pre-charge function parameters		
Classification	Signal	Name	Signal	Name	
Input signal	X77	Pre-charge end command	X78	Second pre-charge end command	
Y49		During pre-charge operation	Y50	During second pre-charge operation	
Output signal	Y51	Pre-charge time over	Y52	Second pre-charge time over	
	Y53	Pre-charge level over	Y54	Second pre-charge level over	

- The second PID pre-charge function is valid also when the first pre-charge function is set to invalid and the second precharge function is set.
- · When "10" (second function enabled only during constant-speed operation) is set to Pr.155, the second PID function is not selected even if the RT signal turns ON.

# 5.11.9 Multi-pump function (Advanced PID function)

PID control function can adjust the volume of water, etc. by controlling pumps. When the motor output is insufficient, auxiliary motors can be driven by the commercial power supply. Up to three auxiliary motors can be connected.

Pr.	Nama	Initial	value	Setting	Description
Pr.	Name	FM	CA	range	Description
578	Auxiliary motor	0		0	No auxiliary motor operation
A400	operation selection	U		1 to 3	Set the number of auxiliary motors to be run.
				0	Basic system
579	79 Motor connection			1	Alternative system
A401	function selection	0		2	Direct system
				3	Alternative direct system
580 A402	MC switching interlock time	1 s		0 to 100 s	Set the MC switchover interlock time.
581 A403	Start waiting time	1 s		0 to 100 s	Set the time from when the MC is switched until it starts. Set this time a little longer than the MC switching time.
582 A404	Auxiliary motor connection-time	1 s		0 to 3600 s	Used to decrease the output frequency of the inverter when a motor connection occurs. Set the deceleration time for decreasing the output frequency.
A404	deceleration time			9999	The output frequency is not decreased when a motor connection occurs.
583 A405	Auxiliary motor disconnection-time			0 to 3600 s	Used to increase the output frequency of the inverter when a motor connection occurs. Set the acceleration time for increasing the output frequency.
A405	acceleration time			9999	The output frequency is not increased when a motor connection occurs.
584 A406	Auxiliary motor 1 starting frequency	60 Hz	50 Hz	0 to 590 Hz	
585 A407	Auxiliary motor 2 starting frequency	60 Hz	50 Hz	0 to 590 Hz	Set the frequency to start the auxiliary motor.
586 A408	Auxiliary motor 3 starting frequency	60 Hz	50 Hz	0 to 590 Hz	
587 A409	Auxiliary motor 1 stopping frequency	0 Hz		0 to 590 Hz	
588 A410	Auxiliary motor 2 stopping frequency	0 Hz		0 to 590 Hz	Set the frequency to stop the auxiliary motor.
589 A411	Auxiliary motor 3 stopping frequency			0 to 590 Hz	
590 A412	Auxiliary motor start detection time	5 s		0 to 3600 s	Set the delay time until the auxiliary motor is started.
591 A413	Auxiliary motor stop detection time	5 s	_	0 to 3600 s	Set the delay time until the auxiliary motor is stopped.


# POINT)

- Refer to page 378 to set PID control.
- When using the SLEEP function, refer to page 388 to set the function.

#### ◆Multi-pump function control method

• Use Pr.579 Motor connection function selection to select the control method for the multi-pump function. Use Pr.578 Auxiliary motor operation selection to set the number of auxiliary motors.

Pr.579 setting	Control method	Description
0	Basic system	The motor driven by the inverter is always fixed. Commercial power supply operation of auxiliary motors is available by turning on and off the MC between the power supply and the motor depending on the output frequency of the inverter.
1	Alternative system	The motor driven by the inverter is fixed during operation. Commercial power supply operation of auxiliary motors is available by turning on and off the MC between the power supply and the motor depending on the output frequency of the inverter.  When output is shut off by the SLEEP function, the MC between the inverter and the motor is switched to switch the motor to be driven by the inverter.
2	Direct system	When the start signal is turned ON, the motor is started by the inverter. When the conditions to start the next motor are established, MCs between the inverter and the motor and the power supply and the motor are switched to change the operation of the motor driven by the inverter to commercial power supply operation, and the next motor is started by the inverter.  When conditions to stop motors are established while auxiliary motors are running, the motor started first (currently driven by the commercial power supply) is stopped first, and then the other motors are stopped.
3	Alternative direct system	When the start signal is turned ON, the motor is started by the inverter. When the conditions to start the next motor are established, MCs between the inverter and the motor and the power supply and the motor are switched to change the operation of the motor driven by the inverter to commercial power supply operation, and the next motor is started by the inverter.  When conditions to stop motors are established while auxiliary motors are running, the motor driven by the inverter is decelerated to stop, and operation of a motor currently driven by the commercial power supply is switched to the inverter-driven operation after frequency search. To perform frequency search when the motor operation is switched from commercial power supply operation to inverter-driven operation, set <b>Pr.57 Restart coasting time</b> ≠ "9999".




- \*1 The starting order of motors is M2  $\rightarrow$  M3  $\rightarrow$  M1 if the previous order was M1  $\rightarrow$  M2  $\rightarrow$  M3.
- \*2 The motor starts in the order of elapsed time after completion of the previous inverter-driven operation, from the longest to the shortest. (The motor that has not been driven by the inverter for the longest time starts first.)

### NOTE:

- The motor 1 (M1) starts first when power is turned ON for the first time or after inverter reset.
- When the Pr.578 or Pr.579 setting has been changed, The motor 1 (M1) starts first.

# **♦**Connection diagram


- · Basic system (Pr.579="0")
  - Sink logic
  - **Pr.183**=14
  - Pr.185=64
  - Pr.194=72
  - **Pr.193**=73
  - Pr.194=74



- Prepare the power supply in accordance with the power supply specifications of the detector.
- \*2 The applied output signal terminals differ by the settings of Pr.190 to Pr.196 (output terminal function selection).
- \*3 The applied input signal terminals differ by the settings of Pr.178 to Pr.189 (input terminal function selection).
- There is no need to input AU signal.

- 5

- Alternative system (Pr.579="1"), direct system (Pr.579="2"), alternative direct system (Pr.579="3")
  - Sink logic
  - Pr.183=14, Pr.185=64, Pr.194=75, Pr.193=71, Pr.192=76, Pr.191=72, Pr.190=77
  - Pr.320=73, Pr.321=78, Pr.322=74



- \*1 When driving three or more motors, use the plug-in option (FR-A8AR).
- Always provide mechanical interlocks for the MC.
- The applied output signal terminals differ by the settings of Pr.190 to Pr.196 (output terminal function selection). \*3
- \*4 The applied input signal terminals differ by the settings of Pr.178 to Pr.189 (input terminal function selection).
- \*5 The applied output signal terminals differ by the settings of Pr.320 to Pr.322 (RA output selection).
- There is no need to input AU signal.
- Prepare the commercial power supply in accordance with the power supply specifications of the detector.

# ♦I/O signals


- When the PID control valid (X14) signal is assigned to the input terminal by setting Pr.178 to Pr.189 (input terminal function selection), the multi-pump function is enabled only at turn-ON of the X14 signal.
- Use Pr.190 to Pr.196 (output terminal function selection) or plug-in option (FR-A8AR) to assign functions of motor control signal to Pr.320 to Pr.322 (RA output selection). (Only positive logic is available.)

Output signal	Pr.190 to Pr.196 and	Pr.320 to Pr.322 settings	Function
Output signal	Positive logic	Negative logic	Function
SLEEP	70	170*1	PID output interruption
RO1	71	<b></b> *2	Commercial power supply side motor 1 connection RO1
RO2	72	<b></b> *2	Commercial power supply side motor 2 connection RO2
RO3	73	<b></b> *2	Commercial power supply side motor 3 connection RO3
RO4	74	<b></b> *2	Commercial power supply side motor 4 connection RO4
RIO1	75	<del>*</del> 2	Inverter side motor 1 connection RIO1
RIO2	76	<b></b> *2	Inverter side motor 2 connection RIO2
RIO3	77	<del></del> *2	Inverter side motor 3 connection RIO3
RIO4	78	<del>*</del> 2	Inverter side motor 4 connection RIO4


- \*1 The value cannot be set in Pr.320 to Pr.322.
- \*2 Negative logic cannot be set.

#### **◆**Motor switchover timing

• Switchover timing at a start (stop) of an auxiliary motor 1 in the basic system (**Pr.579=**"0") and alternative system (**Pr.579=**"1")



• Switchover timing at a start (stop) of an auxiliary motor 1 in the direct system (**Pr.579=**"2") and alternative direct system (**Pr.579=**"3")




#### ◆Waiting time setting at MC switchover (Pr.580, Pr.581)

- Set a waiting time for switchover of MC for the direct system (Pr.579="2") or alternative direct system (Pr.579="3").
- · Set the MC switching time (for example, the time after RIO1 turns OFF until RO1 turns ON) in Pr.580 MC switching interlock time.
- Set the time after the MC switchover until the motor starts (for example, the time after RIO1 turns OFF and RIO2 turns ON until the inverter output starts) in Pr.581 Start waiting time. Set this time a little longer than the MC switching time.

# Acceleration/deceleration time when an auxiliary motor is connected and disconnected (Pr.582, Pr.583)

- Use Pr.582 Auxiliary motor connection-time deceleration time to set the deceleration time for forcibly decreasing the output frequency of the inverter when an auxiliary motor connection occurs. Set the deceleration time in Pr.582 from Pr.20 Acceleration/deceleration reference frequency to stop. The output frequency is not forcibly changed when Pr.582="9999".
- Use Pr.583 Auxiliary motor disconnection-time acceleration time to set the acceleration time for forcibly increasing the output frequency of the inverter when an auxiliary motor disconnection occurs. Set the acceleration time in Pr.583 from stop to Pr.20 Acceleration/deceleration reference frequency. The output frequency is not forcibly changed when Pr.583="9999".



### ◆Starting auxiliary motors (Pr.584 to Pr.586, Pr.590)


- Use Pr.584 to Pr.586 to set the output frequency of the inverter at which the commercial power supply operation motors are started. When output frequency equals to or higher than the setting continues for longer than the time set in Pr.590 Auxiliary motor start detection time, auxiliary motors driven by the commercial power supply are started.
- To set the starting frequency, use Pr.584 Auxiliary motor 1 starting frequency for the first auxiliary motor, and use Pr.585 Auxiliary motor 2 starting frequency for the second motor, and use Pr.586 Auxiliary motor 3 starting frequency for the third motor.
- The starting sequence depends on the Pr.579 Motor connection function selection setting.

### ◆Stopping auxiliary motors (Pr.587 to Pr.589, Pr.591)


- Use Pr.587 to Pr.589 to set the output frequency of the inverter at which the commercial power supply operation motors are stopped. When output frequency equals to or lower than the setting continues for longer than the time set in Pr.591 Auxiliary motor stop detection time, auxiliary motors driven by the commercial power supply are stopped.
- To set the stopping frequency, use Pr.587 Auxiliary motor 1 stopping frequency for the first auxiliary motor, and use Pr.588 Auxiliary motor 2 stopping frequency for the second motor, and use Pr.589 Auxiliary motor 3 stopping frequency for the third motor.
- The stopping sequence depends on the Pr.579 Motor connection function selection setting.

# **◆Timing diagram**


• When using four motors in the basic system (Pr.579="0")




• When using two motors in the alternative system (Pr.579="1")




GROUP





#### NOTE:

- When a start signal is turned OFF while running, MC (RO1 to RO4) turns OFF and the motor decelerates.
- · When a protective function is activated while running, MC (RO1 to RO4) turns OFF and the inverter output is shut off.
- When using two motors in the alternative direct system (Pr.579="3")



# NOTE:

- When the start signal is turned OFF during operation, the inverter-driven motor is decelerated to stop. The motors under commercial power supply operation are switched over to inverter-driven operation one at a time and decelerated to stop after frequency search in order from the longest operation time.
- · When a protective function is activated while running, MC (RO1 to RO4) turns OFF and the inverter output is shut off.
- When the MRS signal is turned ON during operation, the inverter output is shut off and the running motors coast to a stop. Although the motor with the longest operating time of the commercial power supply operation is switched to the inverter operation after elapse of time set in Pr.591 Auxiliary motor stop detection time, the output shutoff status remains. When the MRS signal is turned OFF, the inverter-driven operation starts after frequency search.
- If the starting signal is turned ON during deceleration regardless of the Pr.579 setting, the multi-pump operation is performed again.

#### Parameters referred to

Pr.20 Acceleration/deceleration reference frequency, Pr.21 Acceleration/deceleration time increments 🖙 page 187 Pr.57 Restart coasting time, Pr.58 Restart cushion time page 414

Pr.178 to Pr.189 (input terminal function selection) page 329

Pr.190 to Pr.196 (output terminal function selection) page 288

# 5.11.10 Automatic restart after instantaneous power failure/flying start with an induction motor

Magnetic flux

The inverter can be restarted without stopping the motor in the following conditions:


- · When switching from commercial power supply operation over to inverter running
- · When an instantaneous power failure occurs during inverter running
- · When the motor is coasting at start

Pr.	Name	Initial	value	Setting	Description
FI.	Name	FM	CA	range	Description
				0 (2)	Frequency search only performed at the first start
	Automatic restart after	0		1	Reduced voltage start only at the first start (no frequency search)
162 A700	instantaneous power			3	Frequency search only performed at the first start (reduced impact restart)
	lanure selection			10 (12)	Frequency search at every start
				11	Reduced voltage start at every start (no frequency search)
				13	Frequency search at every start (reduced impact restart)
	Rotation direction			0	Without rotation direction
299	detection selection at	0		1	With rotation direction
A701	restarting	U		9999	When <b>Pr.78</b> ="0", with rotation direction When <b>Pr.78</b> ="1, 2" without rotation direction
		9999		0	Coasting time differs according to the inverter capacity.*1
57 A702	Restart coasting time			0.1 to 30 s	Set the waiting time for the inverter to perform a restart at power restoration after an instantaneous power failure.
				9999	No restart
58 A703	Restart cushion time	1 s		0 to 60 s	Set the voltage cushion time for restart.
163 A704	First cushion time for restart	0 s		0 to 20 s	Set the voltage cushion time for restart.  Consider this matched to the size of the load (moment of
164 A705	First cushion voltage for restart	0%		0 to 100%	inertia/torque)
165 A710	Stall prevention operation level for restart	120%	110%	0 to 400%	Set the stall prevention operation level at a restart operation on the assumption that the inverter rated current is 100%.
611	Acceleration time at a	9999		0 to 3600 s	Set the acceleration time that takes to reach Pr.20 Acceleration/deceleration reference frequency setting at a restart.
F003	restart			9999	Standard acceleration time (for example, <b>Pr.7</b> ) is applied as the acceleration time at restart.

<sup>\*1</sup> The coasting time when **Pr.57** = "0" is as shown below. (When **Pr.162**, **Pr.570** are set to the initial value.) FR-F820-00077(1.5K) or lower and FR-F840-00038(1.5K) or lower: 0.5 s
FR-F820-00105(2.2K) to FR-F820-00340(7.5K) and FR-F840-00052(2.2K) to FR-F840-00170(7.5K): 1 s
FR-F820-00490(11K) to FR-F820-02330(55K), FR-F840-00250(11K) to FR-F840-01160(55K): 3.0 s
FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher: 5.0 s


### 5

#### Automatic restart after instantaneous power failure function



- · The inverter output is shut off at the activation of the instantaneous power failure protection (E.IPF) or undervoltage
- · When E.IPF or E.UVT is activated, the instantaneous power failure (IPF)/undervoltage signal is output.
- The IPF signal is assigned to terminal IPF in the initial setting. To assign the IPF signal to a different terminal, set "2 (positive logic) or 102 (negative logic)" to any of Pr.190 to Pr.196 (Output terminal function selection).
- When the automatic restart after instantaneous power failure an instantaneous power failure or undervoltage. (E.IPF and E.UVT are not activated.)


### Connection (CS signal)



With electronic bypass sequence

For use for only automatic restart after instantaneous SD power failure or flying start, turn ON the CS signal in advance.

Only with restart after instantaneous power failure



Separated converter type

- protection (E.UVT). (Refer to page 535 for E.IPF or E.UVT.)
- function is selected, motor restarts at the power restoration after
- · When the automatic restart after instantaneous power failure / flying start signal (CS) is assigned to the input terminal by setting Pr.178 to Pr.189 (input terminal function selection), restart operation is enabled at turn-ON of the CS signal.
- When the CS signal is assigned to an input terminal and Pr.57 **Restart coasting time** ≠ "9999" (with restart), the inverter cannot be operated while the CS signal remains OFF.

- Separated converter types detect the instantaneous power failure on the converter unit side. Perform wiring so that the IPF signal transmitted from the converter unit is input to the terminal to which the X11 signal is assigned.
- On the converter unit side, enable the restart operation. (For setting the converter unit, refer to the Instruction Manual of the converter unit.)
- For the terminal to be used for the X10 and X11 signal, set "10" (X10), "11" (X11) in Pr.178 to Pr.189 and assign the function. (For separated converter types, the X10 signal is assigned to the terminal MRS in the initial setting.)
- For the X10 signal of separated converter types, NC contact input specification is selected in the initial setting. Set Pr.599 = "0" to change the input specification to NO contact.



- · Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect other functions. Set parameters after confirming the function of each terminal.
- If the CS signal is not assigned to any input terminal, solely setting Pr.57 will enable the restart operation at all times.

# ◆ Setting for the automatic restart after instantaneous power failure operation (Pr.162)

• The **Pr.162** settings and the instantaneous power failure automatic restart operation under each operation mode are as shown below.

Pr.162 setting	Restart operation	V/F control, Advanced magnetic flux vector control	PM motor control
0 (initial value), (2)*1	At first start	Frequency search	
1	At first start	Reduced voltage start	_
3	At first start	Frequency search (reduced impact restart)	Frequency search for PM motor
10, (12)*1	At every start	Frequency search	(Refer to page
11	At every start	Reduced voltage start	420)
13	At every start	Frequency search (reduced impact restart)	

<sup>\*1</sup> The same operation is performed for the both settings.

# **♦**Restart operation with frequency search (Pr.162 = "0, 2, 3, 10, 12, 13", Pr.299)

- When **Pr.162** = "0 (initial value), 2, 3, 10, 12, 13", the motor speed is detected at a power restoration so that the motor can re-start smoothly.
- The encoder also detects the rotation direction so that the motor can re-start smoothly even during the reverse rotation.
- Whether or not to detect the rotation direction can be selected by Pr.299 Rotation direction detection selection at restarting.

If the motor capacity is different from the inverter capacity, set Pr.299 = "0 (no rotation direction detection)".


• When the rotation direction is detected, the following operation is performed according to the **Pr.78 Reverse rotation** prevention selection setting.

Pr.299 setting	Pr.78 setting								
F1.233 Setting	0	1	2						
9999	0	×	×						
0 (initial value)	×	×	×						
1	0	0	0						

O: With rotation direction detection ×: Without rotation direction detection

• By setting "3, 13" in **Pr.162**, the restart can be made smoother with even less impact than when "0, 2, 10, 12" is set in **Pr.162**. When the inverter is restarted with "3, 13" set to **Pr.162**, offline auto tuning is required. (For details on offline auto tuning of Advanced magnetic flux vector control, refer to **page 341**, and for details on offline auto tuning of V/F control, refer to **page 423**.)

#### V/F control, Advanced magnetic flux vector control




### NOTE:

- The rotation speed detection time (frequency search) changes according to the rotation speed of the motor. (maximum 1 s)
- · When the inverter capacity is two ranks or greater than the motor capacity, the overcurrent protective function (E.OC[]) is sometimes activated and prevents the inverter from restarting.
- · If two or more motors are connected to one inverter, this function operates abnormally. (The inverter does not restart
- · Because a DC injection brake is applied instantaneously at speed detection during a restart, the speed might drop if the moment of inertia (J) of the load is small.
- If reverse operation is detected when "1" (reverse rotation disabled) is set to Pr.78, operation decelerates by reverse rotation and then changes to forward rotation when the start command is forward rotation. The inverter does not restart when the start command is reverse rotation.
- When "3, 13" is set to Pr.162, limit the wiring length to within 100 m.

#### ◆Restart operation without frequency search (Pr.162 = "1, 11")

• When Pr.162 = "1 or 11", reduced voltage start is used for the restart operation. In this method, the voltage is raised gradually while keeping the output frequency level at the level before the instantaneous failure, regardless of the motor's coasting speed.

#### V/F control, Advanced magnetic flux vector control



\* The output shut off timing differs according to the load condition.

# • NOTE

· This restart method uses the output frequency that was active before the instantaneous power failure stored in memory. If the instantaneous power failure time is 0.2 s or more, the output frequency can no longer be stored and held in memory, so the restart is performed from Pr.13 Starting frequency (initial value is 1.5 Hz).

## ◆Restart at every start (Pr.162 ="10 to 13")

· When "10 to 13" is set in Pr.162, a restart operation is performed at each start and automatic restart after instantaneous power failure (Pr.57 start after the reset time has elapsed). When "0 (initial value) to 3" is set in Pr.162, a restart operation is performed at the first start after a power-ON, and from the second power-ON onwards, a start from the starting frequency is performed.

### ◆Automatic restart operation of MRS (X10) signal

• The restart operation after restoration from output shutoff by the MRS (X10) signal is as shown in the table below according to the Pr.30 setting.

Pr. 30 setting	Operation after restoration from output shutoff by the MRS (X10) signal					
2, 10, 11, 102, 110, 111	Restart operation (starting from the coasting speed)					
Other than the above	Starting from Pr.13 Starting frequency.					



When output is shut off using safety stop function (terminals S1 and S2), the inverter restarts in the same way as when output is shut off by MRS (X10) signal.



#### Adjustment of restart coasting time (Pr.57)

- Coasting time is the time from the motor speed detection to the restart operation start.
- To enable restart operation, set "0" to **Pr.57 Restart coasting time**. If "0" is set to **Pr.57**, the coasting time is automatically set to the following value (Unit: s). Generally, this setting does not interfere with inverter operation.


	200 V class FR-F820-[]														
															03160
	00046	00077	00105	00167	00250	00340	00490	00630	00770	00930	01250	01540	01870	02330	(75K)
	(0.75K)	(1.5K)	(2.2K)	(3.7K)	(5.5K)	(7.5K)	(11K)	(15K)	(18.5K)	(22K)	(30K)	(37K)	(45K)	(55K)	or
Pr.162															higher
setting	etting 400 V class FR-F840-[]														
															01800
	00023	00038	00052	00083	00126	00170	00250	00310	00380	00470	00620	00770	00930	01160	(75K)
	(0.75K)	(1.5K)	(2.2K)	(3.7K)	(5.5K)	(7.5K)	(11K)	(15K)	(18.5K)	(22K)	(30K)	(37K)	(45K)	(55K)	or
															higher
Other						3									
than 3,	0.5			5											
13															
3, 13	1 2				3							5			

- Inverter operation is sometimes hindered by the size of the moment of inertia (J) of the load or running frequency. Adjust this coasting time within the range 0.1 s to 30 s to match the load specification.
- Set the waiting ti,e when the sine wave filter is used (Pr.72 PWM frequency selection = "25") to 3 s or more.

#### **♦**Restart cushion time (Pr.58)

- The cushion time is the time takes to raise the voltage to the level required for the specified speed after the motor speed detection (output frequency before instantaneous power failure when **Pr.162** = "1 or 11").
- Normally, the motor runs at the initial value as it is. However, adjust to suit the moment of inertia (J) of the load or the size of the torque.

### ◆Adjustment of restart operation (Pr.163 to Pr.165, Pr.611)



- The voltage cushion time at a restart can be adjusted by Pr.163 and Pr.164 as shown in the figure on the left.
- The stall prevention operation level at a restart operation can be set at Pr.165.
- Using Pr.611, the acceleration time to reach Pr.20 Acceleration/ deceleration reference frequency after a restart operation can be set.
   This can be set individually from the normal acceleration time.

# • NOTE

- · Changing the Pr.21 setting does not affect the Pr.611 setting increment.
- Changing the terminal assignment using **Pr.178 to Pr.189 (input terminal function selection)** may affect the other functions. Set parameters after confirming the function of each terminal.
- When the restart operation is selected, undervoltage (E.UVT) and instantaneous power failure (E.IPF) of the fault output signals become invalid.
- The SU and FU signals are not output during the restart. These signals are output after the restart cushion time passes.
- Restart operation is also performed after the inverter reset is released or after the retry by the retry function occurs.



- Provide a mechanical interlock for MC1 and MC2. The inverter will be damaged if power supply is input to the inverter output section.
- When the automatic restart after instantaneous power failure function is selected, the motor suddenly starts (after reset time passes) when an instantaneous power failure occurs. Stay away from the motor and machinery.

Apply the supplied CAUTION stickers to easily visible places when automatic restart after instantaneous power failure has been selected.

#### Parameters referred to

Pr.7 Acceleration time, Pr.21 Acceleration/deceleration time increments page 187

Pr.13 Starting frequency page 197, page 198

Pr.65, Pr.67 to Pr.69 retry function page 236

Pr.78 Reverse rotation prevention selection page 217

Pr.178 to Pr.189 (input terminal function selection) page 329

# 5.11.11 Automatic restart after instantaneous power failure/flying start with an IPM motor


When using the IPM motor MM-EFS/MM-THE4, the inverter operation can be restarted without stopping the motor operation.

When the automatic restart after instantaneous power failure function is selected, the motor driving is resumed in the following situations:

- · When power comes back ON during inverter driving after an instantaneous power failure
- · When the motor is coasting at start

Pr.	Name	Initial value	Setting range	Description
			0	No coasting time
57 A702	Restart coasting time	9999	0.1 to 30 s	Set the waiting time for the inverter to perform a restart after restoring power due to an instantaneous power failure.
		9999	No restart	
162	Automatic restart after		0, 1, 2, 3	Frequency search only performed at the first start
A700	instantaneous power failure selection	0	10, 11, 12, 13	Frequency search at every start
611	Acceleration time at a restart	on time at a	0 to 3600 s	Set the acceleration time to reach Pr.20 Acceleration/ deceleration reference frequency at restart.
F003			9999	Standard acceleration time (for example, <b>Pr.7</b> ) is applied as the acceleration time at restart.

#### **◆**Automatic restart after instantaneous power failure function



- The inverter output is shut off at the activation of the instantaneous power failure protection (E.IPF) or undervoltage protection (E.UVT). (Refer to page 535 for E.IPF or E.UVT.)
- When E.IPF or E.UVT is activated, the instantaneous power failure/ undervoltage (IPF) signal is output.
- The IPF signal is assigned to terminal IPF in the initial status. By setting
  "2 (positive logic) or 102 (negative logic)" in any of Pr.190 to Pr.196
  (output terminal function selection), the IPF signal can be assigned to another terminal.
- When the automatic restart after instantaneous power failure function is selected, motor driving is resumed at the power restoration after an instantaneous power failure or undervoltage. (E.IPF and E.UVT are not activated.)


## **◆**Connection (CS signal)

- When the automatic restart after instantaneous power failure / flying start signal (CS) is assigned to the input terminal by setting Pr.178 to Pr.189 (input terminal function selection), restart operation is enabled at turn-ON of the CS signal.
- When the CS signal is assigned to an input terminal and **Pr.57 Restart coasting time** ≠ "9999" (with restart), the inverter cannot be operated while the CS signal remains OFF.

## • NOTE

- Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect other functions.
   Set parameters after confirming the function of each terminal.
- If the CS signal is not assigned to any input terminal, solely setting Pr.57 will enable the restart operation at all times.
- If the restart operation is selected, instantaneous power failure protection (E.IPF) is disabled while the fault output signal is output at an instantaneous power failure.
- The SU and FU signals are not output during the restart. These signals are output after the restart cushion time passes.
- Restart operation is also performed after the inverter reset is released or after the retry by the retry function occurs.

#### ◆ Selection of restart operation (Pr.162)



- At a power restoration, the encoder detects the motor speed by a frequency search so that the inverter can re-start smoothly.
- · The encoder also detects the rotation direction so that the inverter can re-start smoothly even during the reverse rotation.
- When "10 (11, 12, 13)" is set in Pr.162, a restart operation is performed at each start and automatic restart after instantaneous power failure. When "0 (1, 2)" is set to Pr.162, a restart operation is performed at the first start after a power-ON, and from the second power-ON onwards, a start from the starting frequency is performed.

#### • NOTE

- · Because a DC injection brake is applied instantaneously at speed detection during a restart, the speed might drop if the moment of inertia (J) of the load is small.
- Restart operation with reduced voltage is not available for PM motor control.

#### ◆Restart coasting time (Pr.57)

- · The coasting time is the time up till detection of the motor speed and start of restart control.
- To enable restart operation, set "0" (no coasting time) in Pr.57 Restart coasting time. Generally, this setting does not interfere with inverter operation.
- · Inverter operation is sometimes hindered by the size of the moment of inertia (J) of the load or running frequency. Adjust this coasting time within the range 0.1 s to 30 s to match the load specification.

#### Adjustment of restart operation (Pr.611)

· Using Pr.611, the acceleration time to reach Pr.20 Acceleration/deceleration reference frequency after a restart operation can be set. This can be set individually from the normal acceleration time.

# NOTE

- · Changing the Pr.21 Acceleration/deceleration time increments setting does not affect the Pr.611 setting increment.
- · A PM motor is a motor with interior permanent magnets. Regression voltage is generated when the motor coasts at an instantaneous power failure or at a flying start. The inverter's DC bus voltage rises if the motor coasts fast or makes a flying

When using the automatic restart after instantaneous power failure function (Pr.57 ≠ "9999"), it is recommended to also use the regenerative avoidance function (Pr.882 Regeneration avoidance operation selection = "1") to make startups stable. If the overvoltage protective function (E.OV[]) still occurs with the regeneration avoidance function, also use the retry function

- During PM motor control, the automatic restart after instantaneous power failure function operates only when an MM-EFS/ MM-THE4 IPM motor is connected
  - When a regeneration unit is used, the frequency search may not be available if the rotation speed is about 10% higher than the rating

# Caution

- An IPM motor is a motor with interior permanent magnets. High voltage is generated at motor terminals while the motor is running.
  - Do not touch motor terminals and other parts until the motor stops to prevent an electric shock.
- When the automatic restart after instantaneous power failure function is selected, the motor suddenly starts (after reset time passes) when an instantaneous power failure occurs. Stay away from the motor and machinery.
  - Apply the supplied CAUTION stickers to easily visible places when automatic restart after instantaneous power failure has been selected.

#### Parameters referred to

Pr.13 Starting frequency page 197, page 198 Pr.65, Pr.67 to Pr.69 retry function page 236 Pr.78 Reverse rotation prevention selection page 217 Pr.178 to Pr.189 (input terminal function selection) Pr.178 to Pr.189 (input terminal function selection) Pr.882 Regeneration avoidance operation selection page 514

# 5.11.12 Offline auto tuning for a frequency search

V/F PM

During V/F control or when driving the IPM motor MM-EFS/MM-THE4, the accuracy of the "frequency search", which is used to detect the motor speed for the automatic restart after instantaneous power failure and flying start, can be improved.

Pr.	Name	Initial value	Setting range	Description
			0 (2)	Frequency search only performed at the first start
			1	Reduced voltage start only at the first start (no frequency search)
162	Automatic restart after instantaneous power failure	0	3	Frequency search only performed at the first start (reduced impact restart)
A700	selection	U	10 (12)	Frequency search at every start
			11	Reduced voltage start at every start (no frequency search)
			13	Frequency search at every start (reduced impact restart)
298			0 to 32767	The offline auto tuning automatically sets the gain required for the frequency search.
A711	Frequency search gain	9999	9999	Uses the constant value of Mitsubishi motor (SF-PR, SF-JR, SF-HR, SF-JRCA, SF-HRCA, MM-EFS, MM-THE4 and so on).
560	Second frequency search gain	9999	0 to 32767	The offline auto tuning automatically sets the gain required for the frequency search of the second motor.
A712			9999	Uses the constant value of Mitsubishi motor (SF-PR, SF-JR, SF-HR, SF-JRCA, SF-HRCA, MM-EFS, MM-THE4 and so on).
		0	0	No offline auto tuning.
96	Auto tuning setting/status		1, 101	Perform offline auto tuning for the Advanced magnetic flux vector control. (Refer to page 341.)
C110	Auto turning setting/status		11	Performs offline auto tuning without rotating the motor (V/F control, PM motor control (IPM motor MM-EFS/MM-THE4)).
			0 to 50 Ω, 9999*1	Tuning data
90 C120	Motor constant (R1)	9999	0 to 400 mΩ, 9999*2	(The value measured by offline auto tuning is automatically set.) 9999: Uses the constant value of Mitsubishi motor (SF-PR, SF-JR, SF-HR, SF-JRCA, SF-HRCA and so on).
			0	No auto tuning for the second motor.
463	Second motor auto tuning		1, 101	Performs offline auto tuning for the second motor.
C210	setting/status	0	11	Performs offline auto tuning without rotating the second motor (V/F control, PM motor control (IPM motor MM-EFS/MM-THE4)).
458	Second motor constant (R1)	9999	0 to 50 Ω, 9999*1	Tuning data of the second motor
C220	Coolid motor constant (K1)	3333	0 to 400 mΩ, 9999*2	(same as Pr.90)

<sup>\*1</sup> For the FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower.

<sup>\*2</sup> For the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.

## Offline auto tuning when performing a frequency search by V/F control (reduced impact restart)

• When the frequency search (reduced impact restart) is selected by setting Pr.162 Automatic restart after instantaneous power failure selection = "3 or 13", perform offline auto tuning.

#### Before executing offline auto tuning

Check the following points before performing offline auto tuning:

- V/F control or PM motor control (IPM motor MM-EFS/MM-THE4) is selected.
- A motor is connected. (The motor should not be rotated by the external force applied from outside during the tuning.)
- The motor with the rated motor current equal to or less than the rated inverter current is used. (It must be 0.4 kW or higher.) If a motor with substantially low rated current compared with the rated inverter current is used, speed and torque accuracies may deteriorate due to torque ripples, etc. Set the rated motor current to about 40% or higher of the rated inverter current.
- The target motor is other than a high-slip motor, a high-speed motor, or a special motor.
- The motor may run slightly without actually turning during offline auto-tuning (Pr.96 Auto tuning setting/status = "11"), so either firmly secure the motor by the mechanical brake or check to see if turning the motor will cause any safety problems. (Attention is required for lifts, in particular.) The motor turning slightly will not affect tuning performance.
- · Offline auto tuning is not performed correctly when the surge voltage suppression filter (FR-ASF-H/FR-BMF-H) and sine wave filter (MT-BSL/BSC) are inserted between the inverter and motor. Be sure to remove them before performing tuning.

#### Setting

- 1) Set Pr.96 Auto tuning setting/status = "11".
- 2) Set the rated motor current (initial value is inverted rated current) to Pr.9 Electronic thermal O/L relay. (Refer to page
- 3) Set Pr.71 Applied motor according to the motor to be used.

	Motor	Pr.71 setting
	SF-JR and SF-TH	0 (3, 4)
Mitsubishi standard motor	SF-JR 4P 1.5 kW or lower	20 (23, 24)
Mitsubishi high-efficiency motor	SF-HR	40 (43, 44)
	Others	0 (3, 4)
Mitsubishi constant-torque	SF-JRCA 4P SF-TH (constant-torque)	1 (13, 14)
motor	SF-HRCA	50 (53, 54)
	Other (SF-JRC, etc.)	1 (13, 14)
Mitsubishi high-performance energy-saving motor	SF-PR	70 (73, 74)
Other manufacturer's standard motor	1	0 (3, 4)
Other manufacturer's constant- torque motor	-	1 (13, 14)

# ◆Performing tuning



- · Before performing tuning, check the monitor display of the operation panel or the parameter unit if the inverter is in the state ready for tuning. Turning ON the start command while tuning is unavailable starts the motor.
- In the PU operation mode, press | WD / REV on the operation panel. For External operation, turn ON the start command (STF signal or STR signal). Tuning will start. (At this time, excitation noise occurs.)

5

## NOTE :

- · It takes about 10 seconds for tuning to complete. (The time depends on the inverter capacity and motor type.)
- · Satisfy the required inverter start conditions to start offline auto tuning. For example, stop the input of MRS signal.
- To force tuning to end, use the MRS or RES signal or press on the operation panel.
- (Turning the start signal (STF signal or STR signal) OFF also ends tuning.) · During offline auto tuning, only the following I/O signals are valid. (Initial value)
- Input terminals <valid signals> STP (STOP), OH, MRS, RT, RES, STF, STR, S1 and S2
- Output terminals: RUN, OL, IPF, FM/CA, AM, A1B1C1 and SO
- · When the rotation speed and the output frequency are selected for terminals FM/CA and AM, the progress status of offline auto tuning is output in fifteen steps from FM/CA and AM.
- During execution of offline auto tuning, do not switch the second function selection signal (RT) ON or OFF. Auto tuning is not executed properly.
- · Since the RUN signal turns ON when tuning is started, caution is required especially when a sequence which releases a mechanical brake by the RUN signal has been designed
- · When executing offline auto tuning, input the run command after switching ON the main circuit power (R/L1, S/L2, T/L3) of
- While Pr.79 Operation mode selection = "7", turn the PU operation external interlock (X12) signal ON to tune in the PU operation mode.
- · Monitor is displayed on the operation panel (FR-DU08) and the parameter unit (FR-PU07) during tuning as below.

status	Parameter unit (FR-PU07) display	Operation panel (FR-DU08) display
Setting	READ:List 11 STOP PU	THE SHAPE SH
Tuning in progress	TUNE 12 STF FWD PU	THE SHAPE SH
Normal end	TUNE 13 COMPLETION STF STOP PU	Flickering  SET ESC OWD  Flickering
Forced end	IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	PU MON M -EXT PRAM SM -NET PAUN MODE SET ESC TWO

• When offline auto tuning ends, press sign on the operation panel during PU operation. For External operation, turn OFF the start signal (STF signal or STR signal).

This operation resets the offline auto tuning, and the PU's monitor display returns to the normal indication. (Without this operation, next operation cannot be started.)

· At tuning completion, the tuning results are set in the following parameters:

Parameter	Name		
90	Motor constant (R1)		
298	Frequency search gain		
96	Auto tuning setting/status		



The motor constants measured once in the offline auto tuning are stored as parameters and their data are held until the offline auto tuning is performed again. However, the tuning data is cleared when performing all parameter clear.

· If offline auto tuning has ended in error (see the table below), motor constants are not set. Perform an inverter reset and restart tuning.

Error display	Error cause	Countermeasures
8	Forced end	Set "11" to <b>Pr.96</b> and retry.
9	Inverter protective function operation	Make the setting again.
91	The current limit (stall prevention) function is activated.	Set the acceleration/deceleration time longer. Set Pr.156 Stall prevention operation selection = "1".
92	The converter output voltage fell to 75% of the rated value.	Check for the power supply voltage fluctuation.
93	Calculation error The motor is not connected.	Check the motor wiring and make the setting again.
94	Rotation tuning frequency setting error (The frequency command for the tuning was given to exceed the maximum frequency setting, or to be in the frequency jump range.)	Check the <b>Pr.1 Maximum frequency</b> and <b>Pr.31</b> to <b>Pr.36</b> Frequency jump settings.

- When tuning is ended forcibly by pressing or turning OFF the start signal (STF or STR) during tuning, offline auto tuning does not end properly. (The motor constants have not been set.) Perform an inverter reset and restart tuning.
- If using a motor falling under the following conditions, set the value of Pr.9 Electronic thermal O/L relay as shown below after tuning is complete.
  - If the rated power supply of the motor is 200/220 V(400/440 V) 60 Hz, set the rated motor current multiplied by 1.1 in Pr.9.
  - For a motor with a PTC thermistor, thermal protector or other thermal detection, set "0" (motor overheat protection by inverter invalid) in Pr.9 to protect the motor from overheating.

# • NOTE

- · An instantaneous power failure occurring during tuning will result in a tuning error. After power is restored, the inverter goes into the normal operation. Therefore, when STF (STR) signal is ON, the motor runs in the forward (reverse) rotation.
- · Any alarm occurring during tuning is handled as in the normal operation. Note that even if a retry operation has been set, retry is not performed.
- The set frequency monitor displayed during the offline auto tuning is 0 Hz.

## ◆Tuning the second applied motor (Pr.463)

- · When performing operation where two motors are switched between one inverter, set the second motor in Pr.450 Second applied motor, set Pr.463 Second motor auto tuning setting/status = "11", and perform tuning of the second motor.
- Turning ON the RT signal will enable the parameter settings for the second motor as shown below.

Function	RT signal ON (second motor)	RT signal OFF (first motor)
Motor constant (R1)	Pr.458	Pr.90
Auto tuning setting/status	Pr.463	Pr.96
Frequency search gain	Pr.560	Pr.298

## NOTE :

- The RT signal is assigned to the terminal RT in the initial status. Set "3" in any of Pr.178 to Pr.189 (input terminal function selection) to assign the RT signal to another terminal.
- · Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.



#### Caution

- Note that the motor may start running suddenly.
- For the offline auto tuning in vertical lift applications, etc., caution is required to avoid falling due to insufficient torque.

#### Parameters referred to

Pr.9 Electronic thermal O/L relay page 225 Pr.65, Pr.67 to Pr.69 retry function page 236

Pr.71 Applied motor page 337

Pr.79 Operation mode selection (18)\*

Pr.156 Stall prevention operation selection page 248

Pr.178 to Pr.189 (input terminal function selection) Pr.178 to Pr.189 (input terminal function selection)

GROUP


# 5.11.13 Power failure time deceleration-to-stop function

At instantaneous power failure or undervoltage, the motor can be decelerated to a stop or to the set frequency for the re-acceleration.

Pr.	Name	Initial value		Setting	Description
Pr.	Name	FM	CA	range	Description
				0	Power failure time deceleration-to-stop function disabled
261 A730	Power failure stop selection	0		1, 2, 11, 12, 21, 22	Power failure time deceleration-to-stop function enabled Select action at an undervoltage or when an power failure occurs.
262 A731	Subtracted frequency at deceleration start	3 Hz		0 to 20 Hz	Normally, the motor runs at the initial value as it is. However, adjust to suit the size of the load specification (moment of inertia, torque).
263 A732	Subtraction starting frequency	starting 60 Hz 50 Hz		0 to 590 Hz	When output frequency ≥ <b>Pr.263</b> The motor decelerates from the "output frequency - <b>Pr.262</b> ". When output frequency < <b>Pr.263</b> Deceleration from the output frequency
				9999	The motor decelerates from the "output frequency - Pr.262".
264 A733	Power-failure deceleration time 1	5 s		0 to 3600/ 360 s*1	Set the slope applicable from the deceleration start to the <b>Pr.266</b> set frequency.
265 A734	Power-failure	Power-failure deceleration time 2		0 to 3600/ 360 s*1	Set the slope applicable for the frequency range starting at <b>Pr.266</b> and downward.
A/34	deceleration time 2			9999	Same as Pr.264.
266 A735	Power failure deceleration time switchover frequency	60 Hz	50 Hz	0 to 590 Hz	Set the frequency at which the slope during deceleration switches from the <b>Pr.264</b> setting to the <b>Pr.265</b> setting.
294 A785	UV avoidance voltage gain	100%		0 to 200%	Adjust the response at undervoltage avoidance operation. Setting a large value improves the response to changes in the bus voltage.
668 A786	Power failure stop frequency gain	100%		0 to 200%	Adjust the response level for the operation where the deceleration time is automatically adjusted.
606 T722	Power failure stop external signal input	1		0	Normally open input (NO contact input specification)
1722	selection			1	Normally closed input (NC contact input specification)

<sup>\*1</sup> When the **Pr.21 Acceleration/deceleration time increments** setting is "0" (initial value), the setting range is "0 to 3600 s" and the setting increment is "0.1 s", and when it is "1", the setting range is "0 to 360 s" and the setting increment is "0.01 s".

## **♦**Connection and parameter setting



Separated converter type


- Remove the jumpers across terminal R/L1-R1/L11 and terminal S/L2-S1/L21, and connect terminal R1/L11 to terminal P/+, and terminal S1/L21 to terminal N/-.
- If an undervoltage, power failure or input phase loss occurs when **Pr.261 Power failure stop selection** ≠ "0", the motor decelerates to a stop.

• The power failure time deceleration stop function operates as follows at an input phase loss.

Pr.261	Pr.872	Operation when an input phase loss occurs
0	0	Continuous operation
ľ	1	Input phase loss (E.ILT)
1, 2		Continuous operation
1, 2	1	Deceleration stop
21, 22	_	Deceleration stop

· For the separated converter type, connect the terminal to which PWF signal of the converter unit is assigned and the terminal to which X48 signal of the inverter is assigned. Also, set Pr.261 of the converter unit in accordance with the inverter setting. (Refer to the Instruction Manual of the converter unit.)

#### Outline of operation of deceleration stop at a power failure




- If an undervoltage or power failure occurs, the output frequency is turned OFF only for the frequency set to Pr.262 Subtracted frequency at deceleration start.
- The motor decelerates for the time set to Pr.264 Power-failure deceleration time 1. (The deceleration time setting is the time it takes for the motor to stop from Pr.20 Acceleration/deceleration reference frequency.)
- · Change the deceleration time (slope) to stop using Pr.265 Power-failure deceleration time 2 when the frequency is too low to obtain the regenerative energy or in other instances.

#### Action setting at undervoltage and power failure

• Set Pr.261 to select the action at an undervoltage and power failure.

Pr.261 Setting	Action at undervoltage and power failure	Power restoration during deceleration at occurrence of power failure	Deceleration stop time	Undervoltage avoidance function
0	Coasts to stop	Coasts to stop	_	_
1		Deceleration stop		Not used
2		Re-acceleration	According to Pr.262 to Pr.266	Not used
11	Deceleration stop	Deceleration stop	setting	With
12	— Deceleration stop	Re-acceleration		With
21		Deceleration stop	Automatic adjustment of	Not used
22		Re-acceleration	deceleration time	Not used


## ◆Power failure stop function (Pr.261 ="1, 11, 21")



· Even if power is restored during deceleration triggered by a power failure, deceleration stop is continued after which the inverter stays stopped. To restart operation, turn the start signal OFF then ON again.

## NOTE


- · If the automatic restart after instantaneous power failure is selected (Pr.57 Restart coasting time ≠ "9999") while the power failure time deceleration-to-stop function is set enabled (Pr.261 = "1, 11, or 21"), the power failure time deceleration-to-stop function is disabled.
- · When the power failure time deceleration-to-stop function is enabled (Pr.261 = "1, 11 or 21"), the inverter will not start even if the power is turned ON or inverter reset is performed with the start signal (STF/STR) ON. Turn OFF the start signal once and then ON again to make a start.



# Continuous operation function at instantaneous power failure (Pr.261) ="2, 12, 22")

- The motor re-accelerates to the set frequency if the power restores during the deceleration to stop.
- · Combining with the automatic restart after instantaneous power failure function enables a power failure time deceleration stop and re-acceleration at a power restoration.

If the power is restored after stoppage by a power failure, a restart operation is performed when automatic restart after instantaneous power failure (Pr.57 ≠ "9999") is selected.




#### ◆Undervoltage avoidance function (Pr.261 = "11, 12" Pr.294)

- If "11, 12" is set to Pr.261, the deceleration time is adjusted (shortened) to prevent an undervoltage from occurring during deceleration at occurrence of power failure.
- · Adjust the downward frequency slope and the response level using Pr.294 UV avoidance voltage gain. Setting a large value improves the response to the bus voltage.

# ◆Automatic adjustment of deceleration time (Pr.261 ="21, 22", Pr.294, **Pr.668**)

- When "21, 22" is set to Pr.261, the deceleration time is automatically adjusted to keep (DC bus) voltage constant in the converter when the motor decelerates to a stop at a power failure. Setting of Pr.262 to Pr.266 is not required.
- If a phenomenon such as motor vibration occurs during operation of the deceleration time automatic adjustment function, adjust the response level by setting the Pr.668 Power failure stop frequency gain. Increasing the setting improves the response to change in the bus voltage. However, the output frequency may become unstable.
- If setting Pr.294 UV avoidance voltage gain lower also does not suppress the vibration, set Pr.668 lower.



#### ◆Deceleration stop by the power failure stop external signal (X48)

- By turning OFF X48 signal, the power failure time deceleration-to-stop function is activated. This function is used, for example, when an external power failure detection circuit is installed.
- To use the power failure time deceleration-to-stop function for the separated converter type, use X48 signal. Connect the terminal to which PWF signal of the converter unit is assigned and the terminal to which X48 signal of the inverter is assigned.
- In the initial setting, X48 signal is used with the normally closed (NC contact) input specification. Use Pr.606 Power failure stop external signal input selection to change the specification to the normally open (NO contact) input.
- To use the X48 signal, set "48" in any of Pr.178 to Pr.189 (Input terminal function selection) to assign the function to an input terminal.

# During deceleration at occurrence of power failure signal (Y46)

- · After deceleration by a power failure, the inverter is not restarted even though the start command is input. Check the during deceleration at occurrence of power failure signal (Y46) at a power failure. (for example, when input phase loss protection (E.ILF) occurs)
- The Y46 signal is turned ON during deceleration at occurrence of power failure and in a stop status after deceleration at occurrence of power failure.
- For the Y46 signal, assign the function by setting "46 (positive logic)" or "146 (negative logic)" in any of Pr.190 to Pr.196 (Output terminal function selection).

#### **◆Power failed signal (Y67 signal)**

- Y67 signal turns ON when the output is shut off due to detection of power failure (power supply fault) or undervoltage, or the power failure time deceleration-to-stop function is activated.
- For Y67 signal, assign the function by setting "67 (positive logic)" or "167 (negative logic)" in any of **Pr.190 to Pr.196** (output terminal function selection).

## NOTE

- When "2" is set to **Pr.30 Regenerative function selection** (for instance, when FR-HC2, FR-CV is used), the deceleration-to-stop function is invalid at a power failure.
- If the "output frequency **Pr.262**" at undervoltage or at power failure is a negative value, it is regarded as 0 Hz. (DC injection brake operation is performed without deceleration.)
- The power failure time deceleration stop function is disabled during a stop or when the breaker is tripped.
- The Y46 signal turns ON if an undervoltage occurs even if a deceleration at a power failure has not occurred. For this reason, the Y46 signal is sometimes output instantaneously when the power supply is turned OFF. This is not a fault.
- When the power failure time deceleration-to-stop function is selected, undervoltage protection (E.UVT), instantaneous power failure protection (E.IPF) and input phase loss protection (E.ILF) are not invalid.
- · When the load is high during PM motor control, an undervoltage sometimes causes the inverter to coast to a stop.
- Changing the terminal assignment using **Pr.178 to Pr.189 (input terminal function selection)** or **Pr.190 to Pr.196 (output terminal function selection)** may affect the other functions. Set parameters after confirming the function of each terminal.



#### **Caution**

• Even if the power failure time deceleration-to-stop function is set, some loads might cause the inverter to trip and the motor to coast.

The motor will coast if sufficient regenerative power is not obtained from the motor.

#### Parameters referred to

Pr.12 DC injection brake operation voltage page 502

Pr.20 Acceleration/deceleration reference frequency, Pr.21 Acceleration/deceleration time increments 😭 page 187

Pr.30 Regenerative function selection page 508

Pr.57 Restart coasting time page 414, page 420

Pr.190 to Pr.196 (output terminal function selection) page 288

Pr.872 Input phase loss protection selection page 235

# 5.11.14 PLC function

The inverter can be run in accordance with a sequence program.

In accordance with the machine specifications, a user can set various operation patterns: inverter movements at signal inputs, signal outputs at particular inverter statuses, and monitor outputs, etc.

Pr.	Name	Initial value	Setting range	Description		
			0	PLC function disa	abled	
414 A800	PLC function operation selection	0	1	PLC function	The SQ signal is enabled by input from command source (external input termin communication).	nal/
			2	Chabica	The SQ signal is enabled by input from external input terminal.	n an
415	Inverter operation lock	0	0		command is enabled regardless of the of the sequence program.	
A801	mode setting	0	1	The inverter start program is runnir	command is enabled only while the seq	uence
416 A802	Pre-scale function selection	0	0 to 5	Unit scale factor 0: No function 1: ×1 2: ×0.1 3: ×0.01 4: ×0.001 5: ×0.0001	When the pulse train is input from terminal JOG, the number of sampled pulses can be converted.  The result of conversion is stored to SD1236.  "Number of sampled pulses" = "input pulses value per count cycle" × "pre-scale setting value (Pr.417)" × "unit scale factor (Pr.416)"	
417 A803	Pre-scale setting value	1	0 to 32767	Pre-scale setting value		
				0: Clears the flash memory fault display (no operation after writing while the flash memory is in normal operation).		
				9696: Clears the flash memory (no operation Write after writing during flash memory fault).		Write
498	PLC function flash	0	0, 9696		9696: Outside of the setting range	
A804	memory clear		(0 to 9999)	0: Normal display		
				The flash memory has not been cleared because the PLC function is enabled.		Read
				9696: During flas memory fault	h memory clearing operation or flash	
1150 to 1199 A810 to A859	User parameters 1toUser parameters 50	0	0 to 65535	Desired values can be set.  Because devices D206 to D255 used by the PLC function can be mutually accessed, the values set to <b>Pr.1150 to Pr.1199</b> can be used by the sequence program. The result of performing calculation by a sequence program can also be monitored by <b>Pr.1150 to Pr.1199</b> .		99 can ng

#### Outline of PLC function


- To enable the PLC function, set "1" or "2" in Pr.414 PLC function operation selection. When "2" is set in Pr.414, the sequence startup (SQ) signal from the external input terminal is valid regardless of the setting of the Pr.338 Communication operation command source.
- Switch the execution key (RUN/STOP) of the sequence program by turning the SQ signal ON/OFF. The sequence program can be executed by turning the SQ signal ON. To input the SQ signal, set "50" in any of Pr.178 to Pr.189 (input terminal function selection) to assign the function to a terminal.
- When "1" is set in Pr.415 Inverter operation lock mode setting, the inverter can be operated only when the sequence program is running. By changing the PLC program status from RUN to STOP during inverter operation, the motor decelerates to stop.
  - To stop the inverter operation at the STOP status of the PLC program while performing auto operation using SD1148 (or SM1200 to 1211) of the PLC program, set **Pr.415** = "1".
- To write sequence programs, use FR Configurator2 on a personal computer connected to the inverter through RS-485 communication or USB.



 For the details of the PLC function, refer to the PLC Function Programming Manual and the Instruction Manual of FR Configurator2.

#### **◆**Copying the PLC function project data to USB memory

- This function copies the PLC function project data to a USB memory device.
   The PLC function project data copied in the USB memory device can be copied to other inverters.
   This function is useful in backing up the parameter setting and for allowing multiple inverters to operate by the same sequence programs.
- Refer to page 61 for an outline of the USB communication function.



• The following data can be copied by copying the project data via USB memory.

Extension	File type	Copy from inverter to USB memory	Copy from USB memory to inverter
.QPA	Parameter file	Supported	Supported
.QPG	Program file	Supported	Supported
.C32	Function block source information	Supported	Supported
.QCD	Global text comment information	Supported	Supported
.DAT	Project management information	Supported	Not available
.TXT	Copy information	Supported	Not available

## NOTE

• If the project data of the PLC function is locked with a password using FR Configurator 2, copying to the USB memory device and verification are disabled. Also if set to write-disabled, writing to the inverter is disabled. For the details of the PLC function, refer to the PLC Function Programming Manual and the Instruction Manual of FR Configurator 2.

#### Parameters referred to

Pr.338 Communication operation command source page 210

# **5.11.15 Trace function**

- The operating status of the inverter can be traced and saved on a USB memory device.
- Saved data can be monitored by FR Configurator 2, and the status of the inverter cam be analyzed.


Pr.	Name	Initial value	Setting range	Description					
			0	Without trace operation					
1020			1	Sampling start					
A900	Trace operation selection	0	2	Forced trigger					
7300			3	Sampling stop					
			4	Transfer of data to USB memory divice					
1021			0	Memory mode					
A901	Trace mode selection	0	1	Memory mode (automatic transfer)					
AJUI			2	Recorder mode					
1022 A902	Sampling cycle	2	0 to 9	Set the sampling cycle. 0: 0.125 ms, 1: 0.252 ms, 2: 1 ms, 3: 2 ms, 4: 5 ms, 5: 10 ms, 6: 50 ms, 7: 100 ms, 8: 500 ms, 9: 1 s (Regarding the setting value "0 and 1", the cycle varies by the control mode.)					
1023 A903	Number of analog channels	4	1 to 8	Select the number of analog channels to be sampled.					
1024			0	Manual sampling start					
A904	Sampling auto start	0	1	Sampling starts automatically when the power supply is turned ON or at a reset					
			0	Fault trigger					
1025			1	Analog trigger					
A905	Trigger mode selection	0	2	Digital trigger					
A303			3	Analog or digital trigger (OR logic)					
			4	Both analog and digital trigger (AND logic)					
1026 A906	Number of sampling before trigger	0 to 100%	90%	Set the percentage of the pre-trigger sampling time with respect to the overall sampling time.					
1027 A910	Analog source selection (1ch)	201							
1028 A911	Analog source selection (2ch)	202	1 to 3,						
1029 A912	Analog source selection (3ch)	203	5 to 14, 17, 18, 20, 23, 24, 34,						
A1030 A913	Analog source selection (4ch)	204	40 to 42, 52 to 54,	Select the analog data (monitor) to be sampled on each					
1031 A914	Analog source selection (5ch)	205	61, 62, 64, 67, 68, 81 to 96, 98,	channel.					
1032 A915	Analog source selection (6ch)	206	201 to 213, 230 to 232,						
1033 A916	Analog source selection (7ch)	207	237, 238						
1034 A917	Analog source selection (8ch)	208							
1035 A918	Analog trigger channel	1	1 to 8	Select the analog channel to be the trigger.					
1036	Analog trigger operation	0	0	Sampling starts when the value of the analog monitor exceeds the value set at the trigger level ( <b>Pr.1037</b> )					
A919	selection	0	1	Sampling starts when the value of the analog monitor falls below the value set at the trigger level ( <b>Pr.1037</b> )					
1037 A920	Analog trigger level	1000	600 to 1400	Set the level at which the analog trigger turns ON. The trigger level is the value obtained by subtracting 1000 from the set value.					

#### (A) Application parameters

Pr.	Name	Initial value	Setting range	Description			
1038 A930	Digital source selection (1ch)	1					
1039 A931	Digital source selection (2ch)	2					
1040 A932	Digital source selection (3ch)	3					
1041 A933	Digital source selection (4ch)	4	1 to 255	Select the digital data (I/O signal) to be sampled on each			
1042 A934	Digital source selection (5ch)	5	1 10 255	channel.			
1043 A935	Digital source selection (6ch)	6					
1044 A936	Digital source selection (7ch)	7					
1045 A937	Digital source selection (8ch)	8					
1046 A938	Digital trigger channel	1	1 to 8	Select the digital channel to be the trigger.			
1047 A939	Digital trigger operation selection	0	1	Trace starts when the signal turns ON Trace starts when the signal turns OFF			

#### Operation outline

- · This function samples the status (analog monitor and digital monitor) of the inverter, traces the sampling data when a trigger (trace start condition) is generated, and saves the resulting trace data.
- When the trace function is set enabled, samplings are collected and the inverter goes into the pre-trigger status.
- In the pre-trigger status, samples are collected, and the trigger standby status is entered when sufficient samples for the number of pre-trigger samples have been collected.
- · When the trigger is generated in the trigger standby status, the trace is started and the trace data is saved.



#### ◆ Selection of trace mode (Pr.1021)

- Select how to save the trace data which results from sampling the inverter status.
- There are two trace data save methods, memory mode and recorder mode.

Pr.1021 setting	Mode	Description
0	Memory mode	In this mode, trace data is saved sequentially to internal RAM on the inverter.  If automatic transfer is set, the trace data in internal RAM is transferred to USB memory device when the
1	Memory mode (automatic transfer)	trigger is being generated.  Data can be transferred to a USB memory device as long as data is held in internal RAM.  Trace data in internal RAM is cleared when the power supply is turned OFF or when the inverter is reset.
2	Recorder mode	In this mode, trace data is saved directly to USB memory device.  Sampling data is fixed at eight analog channels and eight digital channels.  The sampling cycle in this mode is longer than in the memory mode. (1 ms or longer)

#### • NOTE

- · When the trace function is used in the recorder mode, use a USB memory device having at least 1 GB of free space.
- Data transferred to USB is saved in the "TRC" folder under the "FR\_INV" folder.
- Up to 99 sets of trace data can be saved in the USB memory device. When data transfer to USB memory device reaches 99 sets of trace data, data is successively overwritten starting with the older data.

## Setting of sampling cycle (interval) and number of sampling channels (Pr.1022, Pr.1023)

- · Set the sampling cycle (interval). The shortest cycle in the recorder mode is 1 ms. When the recorder mode is set, sampling is performed at a sampling cycle of 1 ms even if "0, 1" is set to Pr.1022 Sampling cycle.
- When the memory mode is set, the number of analog channels to sample can be set in the Pr.1023 Number of analog channels. Start setting from the smaller channel number. Up to eight channels can be set. The sampling time becomes shorter the more channels are set.

The number of channels is always 8 when the recorder mode is used or when digital channels are used.

• The sampling time differs according to the sampling cycle and number of sampling channels.

Number of	Memory mode sampling time								
channels	Minimum (Pr.1022 = "0")	Maximum (Pr.1022 = "9")							
1	213 ms	1704 s							
2	160 ms	1280 s							
3	128 ms	1024 s							
4	106.5 ms	852 s							
5	91.8 ms	728 s							
6	80.0 ms	640 s							
7	71.8 ms	568 s							
8	60 ms	512 s							

# ◆Analog source (monitored item) selection

• Select the analog sources (monitored items) to be set to Pr.1027 to Pr.1034 from the table below.

			8				
Setting value	Monitored item∗1	Minus sign display*2	Trigger level criterion∗				
1	Output frequency/speed		*4				
2	Output current		*4				
3	Output voltage		*4				
5	Frequency setting value/speed setting		*4				
6	Running speed		*4				
7	Motor torque		*4				
8	Converter output voltage		*4				
9*5	Regenerative brake duty		*4				
10	Electronic thermal O/L relay load factor		*4				
11	Output current peak value		*4				
12	Converter output voltage peak value	*4					
13	Input power		*4				
14	Output power		*4				
17	Load meter		*4				
18	Motor excitation current		*4				
20	Cumulative energization time		65535				
23	Actual operation time		65535				
24	Motor load factor		*4				
34	Motor output		*4				
40	PLC function user monitor 1	0	*4				
41	PLC function user monitor 2	0	*4				
42	PLC function user monitor 3	0	*4				
52	PID set point		*4				
53	PID measured value		*4				
54	PID deviation	0	*4				
61	Motor thermal load factor		*4				
62	Inverter thermal load factor		*4				
64	PTC thermistor resistance		Pr.561				
67	PID measured value 2		*4				
68	Emergency drive status		65535				
81	BACnet reception status		65535				
82	BACnet token pass counter		65535				
83	BACnet valid APDU counter		65535				
84	BACnet communication error counter		65535				

Setting value	Monitored item∗ı	Minus sign display*2	Trigger level criterion*3	
85	BACnet terminal FM/CA output level		100%	
86	BACnet terminal AM output level		100%	
87	Remote output value 1	0	*4	
88	Remote output value 2	0	*4	
89	Remote output value 3	0	*4	
90	Remote output value 4	0	*4	
91	PID manipulated variable	0	*4	
92	Second PID set point		*4	
93	Second PID measured value		*4	
94	Second PID deviation	0	*4	
95	Second PID measured value 2		*4	
96	Second PID manipulated variable	0	*4	
98	Control circuit temperature	0	*4	
201	*Output frequency		Pr.84	
202	*U Phase Output Current	0	*7	
203	*V Phase Output Current	0	*7	
204	*W Phase Output Current	0	*7	
205	*Converter Output Voltage		400 V/800 V	
206	*Output Current (all three phases)		*7	
207	*Excitation Current(A)		*7	
208	*Torque Current(A)		*7	
209	Terminal 2		100%	
210	Terminal 4		100%	
211	Terminal 1	0	100%	
212	*Excitation Current (%)	0	100%	
213	*Torque Current (%)	0	100%	
230	*Output Frequency (signed)	0	Pr.84	
231	*Motor Speed	0	*6	
232	*Speed Command	0	*6	
237	*Excitation Current Command	0	100%	
238	*Torque Current Command	0	100%	

- \*1 "\*" shows a monitored item with a high-speed sampling cycle.
- \*2 "O" shows that the display with a minus sign is available.
- \*3 Indicates a criterion at 100% when the analog trigger is set.
- \*4 Refer to Terminal FM, CA, AM Full-scale value (page 274).
- \*5 Monitoring is available only for standard models.
- \*6 Rated motor frequency × 120 / number of motor poles
- \*7 The reference current for the trigger level is as follows.

Model FR-F820-II	00046	00077	00105	00167	00250	00340	00490	00630	00770	00930	01250	01540	01870	02330	03160	03800	04750
woder FK-F020-[]	0.75K	1.5K	2.2K	3.7K	5.5K	7.5K	11K	15K	18.5K	22K	30K	37K	45K	55K	75K	90K	110K
Trigger level reference current (A)	3	5	8	11	17.5	24	33	46	61	76	90	115	145	175	215	288	346

Model FR-F840-[]	00023	00038	00052	00083	00126	00170	00250	00310	00380	00470	00620	00770	00930	01160	01800	02160	02600	03250	03610	04320	04810	05470	06100	06830
Model 1 K-1 040-[]	0.75K	1.5K	2.2K	3.7K	5.5K	7.5K	11K	15K	18.5K	22K	30K	37K	45K	55K	75K	90K	110K	132K	160K	185K	220K	250K	280K	315K
rigger level reference urrent (A)	1.5	2.5	4	6	9	12	17	23	31	38	44	57	71	86	110	144	180	216	260	325	361	432	481	547

Model FR-F842-II	07700	08660	09620	10940	12120	
Woder r K-r 042-[]	355K	400K	450K	500K	560K	
Trigger level reference current (A)	610	683	770	866	962	

# **◆**Digital source (monitored item) selection

• Select the digital sources (input/output signals) to be set to Pr.1038 to Pr.1045 from the table below. When a value other than the below, 0 (OFF) is applied for display.

Setting	Signal						
value	name	Remarks					
0	_	_					
1	STF						
2	STR						
3	AU						
4	RT						
5	RL						
6	RM	For the details of the signals, refer to					
7	RH	page 329.					
8	JOG	page 525.					
9	MRS						
10	STP						
	(STOP)						
11	RES						
12	CS						
21	X0						
22	X1						
23	X2						
24	X3						
25	X4						
26	X5						
27	X6						
28	X7	For the details of the signals, refer to					
29	X8	the Instruction Manual of FR-A8AX					
30	X9	(option).					
31	X10						
32	X11						
33	X12						
34	X13						
35	X14						
36	X15						
37	DY						

Setting value	Signal name	Remarks					
101	RUN						
102	SU						
103	IPF						
104	OL	For the details of the signals, refer to page 288.					
105	FU	page 200.					
106	ABC						
107	ABC2	1					
121	DO0						
122	DO1						
123	DO2	For the details of the signals, refer to					
124	DO3	the Instruction Manual of FR-A8AY					
125	DO4	(option).					
126	DO5						
127	DO6						
128	RA1	For the details of the signals, refer to					
129	RA2	the Instruction Manual of FR-A8AR					
130	RA3	(option).					

# ◆Trigger setting (Pr.1025, Pr.1035 to Pr.1037, Pr.1046, Pr.1047)

• Set the trigger generating conditions and trigger target channels.

Pr.1025 setting	Trigger generating conditions	Selection of trigger target channel				
0	Trace starts when inverter enters an fault status (protective function activated)	_				
1	Trace starts when analog monitor satisfies trigger conditions	Pr.1035				
2	Trace starts when digital monitor satisfies trigger conditions	Pr.1046				
3	Trace starts when either of analog or digital monitor satisfies trigger conditions (OR)	Pr.1035, Pr.1046				
4	Trace starts when both of analog or digital monitor satisfies trigger conditions (AND)	Pr.1035, Pr.1046				

<sup>•</sup> Set the trigger generation conditions for the analog monitor.

Pr.1036 setting	Trigger generation conditions	Trigger level setting
0	Sampling starts when the analog data targeted for the trigger exceeds the value specified at the trigger level	Set the trigger level by
1	Sampling starts when the analog data targeted for the trigger has fallen below the value specified at the trigger level	<b>Pr.1037</b> (-400% to 400%)*1

<sup>\*1</sup> For **Pr.1037**, set the number obtained by adding 1,000 to the trigger level.

• Set the trigger generation conditions for the digital monitor.


Pr.1047 setting	Trigger generation conditions
0	Trace starts when the digital data targeted for the trigger turns ON
1	Trace starts when the digital data targeted for the trigger turns OFF

#### ◆Start of sampling and copying of data (Pr.1020, Pr.1024)

- Set the trace operation. The trace operation is set by one of two ways, by setting Pr.1020 Trace operation selection and by setting in the trace mode on the operation panel.
- When "1" is set in Pr.1020, sampling is started.
- When "2" is set in Pr.1020, a trigger is regarded as having been generated (for instance, a forced trigger), sampling is stopped and the trace is started.
- When "3" is set in Pr.1020, sampling is stopped.
- When "4" is set in Pr.1020, the trace data in internal RAM is transferred to a USB memory device. (Trace data cannot be transferred during sampling.)
- To automatically start sampling when the power supply is turned ON or at a recovery after an inverter reset, set "1" to Pr.1024 Sampling auto start.

Pr.1020 setting	Setting by trace mode	Operation	
0	<u> </u>	Sampling standby	
1	IRUN	Sampling start	
2	2FRG	Forced trigger (sampling stop)	
3	BENd	Sampling stop	
4	HEPH	Data transmission	

• Trace operation can also be set in the trace mode on the operation panel.



## ◆ Selection of trace operation by input terminal (TRG signal, TRC signal)


- Trace operation can be selected by signal inputs.
- A forced trigger can be applied when the Trace trigger input (TRG) signal is ON.
- · Sampling is started and stopped by the Trace sampling start/end (TRC) signal turning ON and OFF, respectively.
- To input the TRG signal, set "46" in any of Pr.178 to Pr.189 (input terminal function selection), and to input the TRC signal, set "47" to assign the function to a terminal.



· Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### Monitoring the trace status

• The trace status can be monitored on the operation panel by setting "38" in Pr.52 Operation panel main monitor selection, Pr.774 to Pr.776 (Operation panel monitor selection), or Pr.992 Operation panel setting dial push monitor selection.



Monitor	Trace status					
value	1000s place	100s place	10s place	1s place		
0 or no display*1	No trace data in internal RAM	USB memory not accessed	Trigger not detected	Trace stopped		
1	Trace data in internal RAM	USB memory being accessed	Trigger detected	Trace operation		
2	_	USB memory transfer error	_	_		
3	_	USB buffer overrun	_	_		

- The "0(s)" to the left of the leftmost non-zero digit is(are) not shown in the monitor display. For example, if no trace data is in internal RAM, the USB memory is not accessed, no trigger is detected, and the trace operation is performed, "1" appears (not "0001").
- · When copying the traced data to a USB memory device, the operating status of the USB host can be checked with the inverter LED. For the overview of the USB communication function, refer to page 61.

LED status	Operating status	
OFF	No USB connection.	
ON	The communication is established between the inverter and the USB device.	
Flickering rapidly	Traced data is being transmitted. (In the memory mode, transmission command is being issued. In the recorder mode, sampling is being performed.)	
Flickering slowly	Error in the USB connection.	

• During trace operation, the trace status signal (Y40) can be output. To use the Y40 signal, set "40 (positive logic) or 140 (negative logic)" in any of Pr.190 to Pr.196 (output terminal function selection) to assign the function to the output terminal.



· Changing the terminal assignment using Pr.190 to Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### # Parameters referred to

Pr.52 Operation panel main monitor selection page 263 Pr.178 to Pr.189 (input terminal function selection) page 329

# **5.12** (N) Operation via communication and its settings


Purpose	Parameter to set			
To start operation via communication	Initial setting of operation via communication	P.N000, P.N001, P.N013, P.N014	Pr.549, Pr.342, Pr.502, Pr.779	446
To operate via communication from PU connector	Initial setting of computer link communication (PU connector)	P.N020 to P.N028	Pr.117 to Pr.124	440
	Initial setting of computer link communication (RS-485 terminals)	P.N030 to P.N038	Pr.331 to Pr.337, Pr.341	449
To operate via communication from RS-485 terminals	Modbus-RTU communication specification	P.N002, P.N030, P.N031, P.N034, P.N080,	Pr.539, Pr.331, Pr.332, Pr.334, Pr.343,	465
	BACnet MS/TP protocol	P.N030, P.N031, P.N050 to P.N054	Pr.331, Pr.332, Pr.390, Pr.726 to Pr.729	
To Communicate using USB (FR Configurator2)	USB communication	P.N040, P.N041	Pr.547, Pr.548	449
To connect a GOT	GOT automatic recognition	P.N020, P.N030	Pr.117, Pr.331	494

#### 5.12.1 Wiring and configuration of PU connector

Using the PU connector enables communication operation from a personal computer, etc.

When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program can run and monitor the inverter or read and write to parameters.

## **♦PU** connector pin-outs




Pin number	Name	Description
1	SG	Earth (ground) (connected to terminal 5)
2	_	Operation panel power supply
3	RDA	Inverter receive+
4	SDB	Inverter send-
5	SDA	Inverter send+
6	RDB	Inverter receive-
7	SG	Earth (ground) (connected to terminal 5)
8	_	Operation panel power supply

## NOTE


- Pins No. 2 and 8 provide power to the operation panel or the parameter unit. Do not use these pins during RS-485
- Do not connect the PU connector to the computer's LAN board, FAX modem socket or telephone modular connector. The product could be damaged due to differences in electrical specifications.

#### ◆Wiring and configuration of PU connector communication system

· System configuration



· Wiring of computer by RS-485



Make connection in accordance with the Instruction Manual of the computer to be used with. Fully check the terminal numbers of the computer since they vary with the model.

#### NOTE

- · When performing RS-485 communication with multiple inverters, use the RS-485 terminals. (Refer to page 444.)
- · Computer-inverter connection cable

Refer to the following for the connection cable (RS-232C  $\Leftrightarrow$  RS-485 converter) between the computer with an RS-232C interface and an inverter. Commercially available products (as of Novemver 2013)

Model	Manufacturer
Interface embedded cable	
DAFXIH-CAB (D-SUB25P for personal computer side)	
DAFXIH-CABV (D-SUB9P for personal computer side)	
+	Diatrend Corp.
Connector conversion cable DINV-485CAB (for inverter side) *2	
Interface embedded cable dedicated for inverter	
DINV-CABV *2	


- The conversion cable cannot connect multiple inverters. (The computer and inverted are connected in a 1:1 pair.) This product is a RS-232C  $\Leftrightarrow$ RS-485 conversion cable that has a built-in converter. No additional cable or connector is required. For the product details, contact the manufacturer.
  - · Refer to the following table when fabricating the cable on the user side. Commercially available products (as of November 2013)

Name	Model	Manufacturer
Communication cable	SGLPEV-T (Cat5e/300m) 24AWG × 4P*3	Mitsubishi Cable Industries, Ltd.
RJ-45 connector	5-554720-3	Tyco Electronics

\*3 Do not use pins No. 2 and 8 of the communication cable.

# 5.12.2 Wiring and configuration of RS-485 terminals

#### **♦RS-485** terminal layout




Name	Description
RDA1 (RXD1+)	Inverter receive +
RDB1 (RXD1-)	Inverter receive -
RDA2 (RXD2+)	Inverter receive + (for branch)
RDB2 (RXD2-)	Inverter receive - (for branch)
SDA1 (TXD1+)	Inverter send +
SDB1 (TXD1-)	Inverter send -
SDA2 (TXD2+)	Inverter send + (for branch)
SDB2 (TXD2-)	Inverter send - (for branch)
P5S (VCC)	5V Permissible load current 100 mA
SG (GND)	Earthing (grounding) (connected to terminal SD)

#### ◆Connection of RS-485 terminals and wires

• The size of RS-485 terminal block is the same as the control circuit terminal block.Refer to page 52 for the wiring method.


- To avoid malfunction, keep the RS-485 terminal wires away from the control circuit board.
- When the FR-F820-01250(30K) or lower, or the FR-F840-00620(30K) or lower is used with a plug-in option, lead the wires through the hole on the side face of the front cover for wiring of the RS-485 terminals.



· When the FR-F820-01540(37K) of higher, or the FR-F840-00770(37K) or higher is used with a plug-in option, lead the wires on the left side of the plug-in option for wiring of the RS-485 terminals.


# **♦**System configuration of RS-485 terminals

• Computer and inverter connection (1:1)




\*Set the terminating resistor switch to the "100  $\Omega$ " position.

• Combination of computer and multiple inverters (1:n)




#### ♦ How to wire RS-485 terminals

• 1 inverter and 1 computer with RS-485 terminals




· Multiple inverters and 1 computer with RS-485 terminals



- Make connection in accordance with the Instruction Manual of the computer to be used with. Fully check the terminal numbers of the computer since they vary with the model.
- For the inverter farthest from the computer, set the terminating resistor switch to ON (100  $\Omega$  side).




· For branching, connect the wires as shown below.



# **◆Two-wire type connection**

• If the computer is 2-wire type, a connection from the inverter can be changed to 2-wire type by passing wires across reception terminals and transmission terminals of the RS-485 terminals.



NOTE

· A program should be created so that transmission is disabled (receiving state) when the computer is not sending and reception is disabled (sending state) during sending to prevent the computer from receiving its own data.

#### 5.12.3 Initial setting of operation via communication

Set the action when the inverter is performing operation via communication.

- Set the communication protocol. (Mitsubishi inverter protocol/Modbus-RTU protocol)
- · Set the action at fault occurrence or at writing of parameters

Pr.	Name	Initial value	Setting range	Description	
549			0	Mitsubishi inverter protocol (computer link)	
N000	Protocol selection	0	1	Modbus-RTU protocol	
			2	BACnet MS/TP protocol	
342	Communication	0	0	Parameter values written by communication are written to the EEPROM and RAM.	
N001	EEPROM write selection		1	Parameter values written by communication are written to the RAM.	
502 N013	Stop mode selection at communication error	0	0	At fault occurrence	At fault removal
				Coasts to stop E.SER display*1 ALM signal output	Stays stopped (E.SER display*1)
			1	Deceleration stop E.SER display after stop*1 ALM signal output after stop	Stays stopped (E.SER display*1)
			2	Deceleration stop E.SER display after stop*1	Automatic restart function
			3	Operation continued at the set frequency of <b>Pr.779</b>	Normal operation
779 N014	Operation frequency during communication error	9999	0 to 590 Hz	Set the frequency to be run at a communication error occurrence.	
		3333	9999	The motor runs at the frequency used before the communication error.	

<sup>\*1</sup> If in communication by the communication option, E.OP1 is displayed.

## **♦** Setting the communication protocol (Pr.549)

- · Select the communication protocol.
- The Modbus-RTU protocol can be used by communication from the RS-485 terminals.

Pr.549 setting	Communication protocol		
0 (initial value)	Mitsubishi inverter protocol (computer link)		
1	Modbus-RTU protocol		
2	BACnet MS/TP protocol		

## **◆**Communication EEPROM write selection (Pr.342)

- · When parameter write is performed via the inverter PU connector, RS-485 terminal, USB communication, or a communication option, the parameters storage device can be changed from EEPROM + RAM to RAM only. Use this function if parameter settings are changed frequently.
- When changing the parameter values frequently, set "1" in Pr.342 Communication EEPROM write selection to write them to the RAM only. The life of the EEPROM will be shorter if parameter write is performed frequently with the setting unchanged from "0 (initial value)" (EEPROM write).

- Turning OFF the inverter's power supply clears the modified parameter settings when Pr.342 = "1 (write only to RAM)". Therefore, the parameter values at next power-ON are the values last stored in EEPROM.
- The parameter setting written in RAM cannot be checked on the operation panel. (The values displayed on the operation panel are the ones stored in EEPROM.)

GROUF **N** 

# ◆Operation selection at a communication error (Pr.502, Pr.779)


- For communication using RS-485 terminals or a communication option, operation at a communication error can be selected. The operation is active under the Network operation mode.
- Select the stop operation at the retry count excess (Pr.335, only with Mitsubishi inverter protocol) or at a signal loss detection (Pr.336, Pr.539).
- When a communication error is detected while communication with the RS-485 terminals is performed, the alarm (LF) signal is output to an output terminal of the inverter. To use the LF signal, set "98 (positive logic) or 198 (negative logic)" in any of Pr.190 to Pr.196 (output terminal function selection) to assign the function to the output terminal. (While communication is performed with a communication option, LF signal is output only when "3" is set in Pr.502.)

Pr.502	At f	ault occurrence		A	t fault removal	
setting	Operating status	Indication	Fault (ALM) signal	Operating status	Indication	Fault (ALM) signal
0 (initial value)	Coasts to stop	E.SER*1	E.SER*1 ON		E.SER*1	ON
1			ON after stop			
2	Deceleration stop	E.SER after stop*1	OFF	Automatic restart function*2	Normal display	OFF
3	Operation continued at the set frequency of <b>Pr.779</b>	Normal display	OFF	Normal operation	Normal display	OFF

- If in communication by the communication option, E.OP1 is displayed.
- When the communication error is removed during deceleration, the motor re-accelerates.


Pr. 502 setting "0" (initial value)

Pr. 502 setting "1"



Pr. 502 setting "2"

Pr. 502 setting "3"



If in communication by the communication option, E.OP1 is displayed.

#### (N) Operation via communication and its settings



- · Fault output indicates the Fault signal (ALM) and an alarm bit output.
- When the fault output is set enabled, fault records are stored in the faults history. (A fault record is written to the faults history at a fault output.)
- When the fault output is not set enabled, fault record is overwritten to the faults history of the faults history temporarily but not stored.
- After the fault is removed, the fault indication goes back to normal indication on the monitor, and the faults history goes back to the previous status.
- If Pr.502 is set to "1, 2, or 3", the normal deceleration time setting (settings like Pr.8, Pr.44, and Pr.45) is applied as the
  deceleration time. Normal acceleration time setting (settings like Pr.7 and Pr.44) is applied as the acceleration time for
  restart
- When Pr.502 = "2 or 3", the inverter operates with the start command and the speed command, which were used before the
  fault.
- If a communication line error occurs, then the error is removed during deceleration while Pr.502 = "2", the motor reaccelerates from that point.
- The **Pr.502** and **Pr.779** settings are valid when communication is performed via the RS-485 terminals or a communication option.
- These parameters are valid under the Network operation mode. When performing communication with RS-485 terminals, set **Pr.551 PU mode operation command source selection** to "2 (initial value)".
- **Pr.502** is valid for the device that has the command source under the Network operation mode. If a communication option is installed while **Pr.550** = "9999 (initial value)", a communication error in RS-485 terminals occurs and **Pr.502** becomes invalid.
- If the communication error setting is disabled with **Pr.502** = "3", **Pr.335** = "9999", and **Pr.539** = "9999", the inverter does not continue its operation with the frequency set by **Pr.779** at a communication error.
- If a communication error occurs while continuous operation at **Pr.779** is selected with **Pr.502** = "3", the inverter operates at the frequency set in **Pr.779** even though the speed command source is at the external terminals.

  Example) If a communication error occurs while **Pr.339** = "2" and the external terminal RL is ON, the operation is continued at the frequency set in **Pr.779**.

#### # Parameters referred to

Pr.7 Acceleration time, Pr.8 Deceleration time page 187
Pr.335 RS-485 communication retry count page 449
Pr.336 RS-485 communication check time interval page 449
Pr.539 Modbus-RTU communication check time interval page 465
Pr.550 NET mode operation command source selection page 210
Pr.551 PU mode operation command source selection page 210

#### 5.12.4 Initial settings and specifications of RS-485 communication

Use the following parameters to perform required settings for the RS-485 communication between the inverter and a personal computer.

- · There are two types of communication, communication using the inverter's PU connector and communication using the RS-485 terminals.
- · Parameter setting, monitoring, etc. can be performed with the Mitsubishi inverter protocol, Modbus-RTU protocol, and BACnet protocol.
- To make communication between the personal computer and inverter, setting of the communication specifications must be made to the inverter in advance.

Data communication cannot be made if the initial settings are not made or if there is any setting error.

[Parameters related to PU connector communication]

Pr.	Name	Initial value	Setting range	Desc	ription					
117 N020	PU communication station number	0	0 to 31	Specify the inverter station numl Set the inverter station numbers connected to one personal com	when two or more inverters are					
118 N021	PU communication speed	192	48, 96, 192, 384, 576, 768, 1152	Set the communication speed. The setting value × 100 equals t For example, if 192 is set, the cobps.						
E022	PU communication	0	0	Data length 8 bits						
	data length		1	Data length 7 bits						
E023	PU communication	1	0	Stop bit length 1 bit						
	stop bit length		1	Stop bit length 2 bits						
	PU communication		0	Stop bit length 1 bit  Data length 8 bits						
119	stop bit length / data	1	1	Stop bit length 2 bits						
	length		10	Stop bit length 1 bit	Data length 7 bits					
			11	Stop bit length 2 bits	Tata isingan r Site					
120	PU communication		0	Without parity check						
N024	parity check	2	1	With parity check at odd number						
	parray care car		2	With parity check at even number						
121 N025	Number of PU communication retries	1	0 to 10	Set the permissible number of reception. If the number of cons permissible value, the inverter w	ecutive errors exceeds the					
			9999	If a communication error occurs	, the inverter will not trip.					
			0	No PU connector communicatio	n					
122 N026	PU communication check time interval	9999	0.1 to 999.8 s	Set the interval of the communic detection) time.  If a no-communication state perpermissible time, the inverter will	sists for longer than the					
			9999	No communication check (signa	I loss detection)					
123 N027	PU communication waiting time setting	9999	0 to 150 ms	Set the waiting time between da and the response.	ta transmission to the inverter					
14027	waiting time setting		9999	Set with communication data.						
124	PU communication CR/	CR/	Without CR/LF							
N028	LF selection		1	With CR						
14020	Li Jeiectivii		2	With CR/LF						

#### (N) Operation via communication and its settings

[Parameters related to communication with the RS-485 terminals]

Parameter number	Name	Initial value	Setting range	Description
331 N030	RS-485 communication station number	0	0 to 31 (0 to 247) *1*2	Set the inverter station number. (Same specifications as <b>Pr.117</b> )
332 N031	RS-485 communication speed	96	3, 6, 12, 24, 48, 96, 192, 384, 576, 768, 1152*3	Select the communication speed. (Same specifications as <b>Pr.118</b> )
N032	RS-485 communication data length	0	0, 1	Select the data length. (Same specifications as <b>P.E022</b> )*4
N033	RS-485 communication stop bit length	1	0, 1	Select the stop bit length. (Same specifications as <b>P.E023</b> )*5
333	RS-485 communication stop bit length / data length	1	0, 1, 10, 11	Select the stop bit length and data bit length. (Same specifications as <b>Pr.119</b> )*4*5
334 N034	RS-485 communication parity check selection	2	0, 1, 2	Select the parity check specifications. (Same specifications as <b>Pr.120</b> )
335 N035*6	RS-485 communication retry count	1	0 to 10, 9999	Set the permissible number of retries for unsuccessful data reception. (Same specifications as <b>Pr.121</b> )
336	RS-485		0	RS-485 communication is available, but the inverter trips in the NET operation mode.
N036*6	communication check time interval	0 s	0.1 to 999.8 s	Set the interval of the communication check (signal loss detection) time. (Same specifications as <b>Pr.122</b> )
			9999	No communication check (signal loss detection)
337 N037*6	RS-485 communication waiting time setting	9999	0 to 150 ms, 9999	Set the waiting time between data transmission to the inverter and the response. (Same specifications as <b>Pr.123</b> )
341 N038*6	RS-485 communication CR/LF selection	1	0, 1, 2	Select the presence/absence of CR/LF. (Same specifications as <b>Pr.124</b> )

- \*1 When "1" (Modbus-RTU protocol) is set in **Pr.549**, the setting range within parentheses is applied.
- \*2 When a value outside the setting range is set, the inverter operates at the initial value.
- \*3 When **Pr.549** = "2" (BACnet MS/TP protocol), the setting range is "96 to 1152".
- \*4 In the Modbus-RTU protocol, the data length is fixed at 8 bits.
- \*5 In the Modbus-RTU protocol, **Pr.334** setting is applied as the stop bit length. (Refer to page 465.)
- \*6 In the Modbus-RTU protocol, this is invalid.

## NOTE

- The monitored items and parameter settings can be read during communication with the **Pr.336 RS-485 communication check time interval** = "0 (initial value)" setting, but such operation will become faulty once the operation mode is changed to the NET operation mode. When the NET operation mode is selected as the start-up operation mode, communication is performed once, then a Communication fault (inverter) (E.SER) occurs. To perform operation or parameter writing via communication, set "9999" or a large setting value in **Pr.336**. (The setting value is determined by the computer program.)(Refer to page 457.)
- Always reset the inverter after making the initial settings of the parameters. After changing the communication-related parameters, communication cannot be made until the inverter is reset.

#### 5.12.5 Mitsubishi inverter protocol (computer link communication)

Parameter settings and monitoring are possible by using the Mitsubishi inverter protocol (computer link communication) via inverter PU connector and the RS-485 terminals.


#### Communication specifications

· The communication specifications are given below.

	Item	Description	Related Parameter
Communication pr	otocol	Mitsubishi protocol (computer link)	Pr.551
Conforming standa	ard	EIA-485 (RS-485)	_
Connectable units		1:N (maximum 32 units), setting is 0 to 31 stations	Pr.117 Pr.331
Communication	PU connector	Selected among 4800/9600/19200/38400 bps	Pr.118
Speed	RS-485 terminals	Selected among 300/600/1200/2400/4800/9600/19200/38400/38400/ 57600/76800/115200 bps	Pr.332
Control procedure		Asynchronous system	_
Communication m	ethod	Half-duplex system	_
	Character system	ASCII (7 bits or 8 bits can be selected.)	Pr.119 Pr.333
	Start bit	1 bit	_
Communication	Stop bit length	1 bit or 2 bits can be selected.	Pr.119 Pr.333
specifications	Parity check	Check (at even or odd numbers) or no check can be selected.	Pr.120 Pr.334
	Error check	Sum code check	_
	Terminator	CR/LF (presence/absence selectable)	Pr.124 Pr.341
Waiting time settin	g	Selectable between presence and absence	Pr.123 Pr.337

## Communication procedure

- · Data communication between the computer and inverter is made in the following procedure.
  - (a) Request data is sent from the computer to the inverter. (The inverter will not send data unless requested.)
  - (b) After waiting for the waiting time,
  - (c) The inverter sends reply data to the computer in response to the computer request.
  - (d) After waiting for the inverter data processing time,
  - (e) An answer from the computer in response to reply data (c) of the inverter is transmitted. (Even if (e) is not sent, subsequent communication is made properly.)



- \*1 If a data error is detected and a retry must be made, perform retry operation with the user program. The inverter trips if the number of consecutive retries exceeds the parameter setting.
- \*2 On receipt of a data error occurrence, the inverter returns reply data (c) to the computer again. The inverter trips if the number of consecutive data errors reaches or exceeds the parameter setting.

#### **◆**Communication operation presence/absence and data format types

- Data communication between the computer and inverter is made in ASCII code (hexadecimal code).
- · Communication operation presence/absence and data format types are as follows.

Symbol	Opera	tion	Operation command	Operation frequency	Multi command	Parameter write	Inverter reset	Monitor	Parameter read
а	accordance with	sent to the inverter in accordance with the user program in the computer.		А	A2	A	А	В	В
b	Inverter data pro	verter data processing time		With	With With		Without	With	With
С	Reply data from the inverter (Data	No error *1 (Request accepted)	С	С	C1*3	С	C*2	E, E1, E2, E3	E
	(a) is checked for an error)	With error (Request rejected)	D	D	D	D	D*2	D	D
d	Computer proce- time	ssing delay	10 ms or more						
	Answer from computer in response to	No error *1 (No inverter processing)	Without	Without	Without (C)	Without	Without	Without (C)	Without (C)
е	reply data c (Data c is checked for error) With error (Inverter outputs of again.)		Without	Without	F	Without	Without	F	F

<sup>\*1</sup> In the communication request data from the computer to the inverter, 10 ms or more is also required after "no data error (ACK)". (Refer to page 455.)

- \*2 Reply from the inverter to the inverter reset request can be selected. (Refer to page 460.)
- \*3 At mode error, and data range error, C1 data contains an error code. (Refer to page 464) Except for those errors, the error is returned with data format D.
- · Data writing format
  - a. Communication request data from the computer to the inverter

Format								Num	ber of	char	acters	3							
1 Office	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
А		Inverter No. *2		Instruc code	ction	*3	Data				Sum	check	*4						
A1	ENQ *1	Inverter No. *2		Instruc code	ction	*3	Data		Sum c	heck	*4								
A2	ENQ *1	Inverter No. *2		Instruc	ction	*3	Send data type	Receive data type	Data1				Data2				Sum c	heck	*4

c. Reply data from the inverter to the computer (No data error detected)

Format								Num	ber o	f chai	acter	'S							
Format	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
С	ACK *1	Inverter No. *2	station	*4															
C1	STX *1	Inverter No. *2		Send data type	IVECEIVE	Error code 1	Error code 2					Data2				ETX *1	Sum c	heck	*4

c. Reply data from the inverter to the computer(Data error detected)

Format		Numbe	r of cha	racters	
1 Office	1	1 2 3		4	5
D	NAK*1	Inverter	station	Error	a.4
	INAIX*I	No. *2		code	*4

- \*1 Indicates a control code.
- \*2 Specifies the inverter station numbers in the range of H00 to H1F (stations 0 to 31) in hexadecimal.
- \*3 When **Pr.123** or **Pr.337** (Waiting time setting) ≠ 9999, create a communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)
- \*4 CR, LF code: When data is transmitted from the computer to the inverter, codes CR (carriage return) and LF (line feed) are automatically set at the end of a data group on some computers. In this case, setting must be also made on the inverter according to the computer. Whether the CR and LF codes will be present or absent can be selected using **Pr.124 or Pr.341 (CR/LF selection)**.

- · Data reading format
  - a. Communication request data from the computer to the inverter

Format				Numbe	r of cha	racters			
Format	1	2	3	4	5	6	7	8	9
В	ENQ *1	Inverter No. *2	station	Instruct code	ion	*3	Sum ch	eck	*4

c. Reply data from the inverter to the computer (No data error detected)

Format						Numbe	r of cha	racters		Number of characters													
Format	1	2	3	4	5	6	7	8	9	10	11	12	13										
E	STX*1	Inverter No. *2	station	Read da	ata			ETX*1	Sum ch	eck	*4												
E1	STX*1	Inverter No. *2	station	Read da	ata	ETX*1	Sum ch	eck	*4														
E2	STX*1	Inverter No. *2	station	Read da	ata					ETX*1	Sum ch	eck	*4										

	Format				Number of characters				
	Format	1	2	3	4 to 23	24	25	26	27
E3	3	STX*1	Inverter No. *2	station	Read data (Inverter model information)	ETX*1	Sum ch	eck	*4

c. Reply data from the inverter to the computer (Data error detected)

Format		Numbe	r of cha	racters	
1 Offilat	1	2	3	4	5
D	NAK*1	Inverter	station	Error	m.4
0	INAK*I	No. *2		code	*4

e. Transmission data from the computer to the inverter when reading data

Format	Number of characters			
Tomat	1	2	3	4
C (No data error detected)	ACK*1	Inverter station No. *2		*4
F (Data error detected)	NAK*1	Inverter No. *2	station	*4

- \*1 Indicates a control code.
- \*2 Specifies the inverter station numbers in the range of H00 to H1F (stations 0 to 31) in hexadecimal.
- \*3 When **Pr.123 or Pr.337 (Waiting time setting)** ≠ 9999, create a communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)
- \*4 CR, LF code: When data is transmitted from the computer to the inverter, codes CR (carriage return) and LF (line feed) are automatically set at the end of a data group on some computers. In this case, setting must be also made on the inverter according to the computer. Whether the CR and LF codes will be present or absent can be selected using Pr.124 or Pr.341 (CR/LF selection).

#### Data definitions

Control code

Signal name	ASCII Code	Description
STX	H02	Start Of Text (Start of data)
ETX	H03	End Of Text (End of data)
ENQ	H05	Enquiry (Communication request)
ACK	H06	Acknowledge (No data error detected)
LF	H0A	Line Feed
CR	H0D	Carriage Return
NAK	H15	Negative Acknowledge (Data error detected)

Inverter station number

Specify the station number of the inverter which communicates with the computer.

· Instruction code


Specify the processing request, for example, operation or monitoring, given by the computer to the inverter. Hence, the inverter can be run and monitored in various ways by specifying the instruction code appropriately. (Refer to page 460.)

• Data

Indicates the data such as frequency and parameters transferred to and from the inverter. The definitions and ranges of set data are determined in accordance with the instruction codes. (Refer to page 460.)

· Waiting time


Specify the waiting time between the receipt of data at the inverter from the computer and the transmission of reply data. Set the waiting time in accordance with the response time of the computer in the range of 0 to 150 ms in 10 ms increments. (For example; 1=10 ms, 2= 20 ms)




# NOTE :

- · When Pr.123 or Pr.337 (Waiting time setting) ≠ "9999", create a communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)
- The data check time varies depending on the instruction code. (Refer to page 455.)
- · Sum check code

The sum check code is a 2-digit ASCII (hexadecimal) representing the lower 1 byte (8 bits) of the sum (binary) derived from the checked ASCII data.



\*When the Pr.123 or Pr.337 (Waiting time setting) ≠ "9999", create the communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)




· Error code

If any error is found in the data received by the inverter, its error definition is sent back to the computer together with the NAK code.

Error Code	Error Item	Error Description	Inverter Operation	
Н0	Computer NAK error	The number of errors consecutively detected in communication request data from the computer is greater than the permissible number of retries.		
H1	Parity error	The parity check result does not match the specified parity.	]	
H2	Sum check error	The sum check code in the computer does not match that of the data received by the inverter.	Trips (E.PUE/E.SER) if error occurs continuously more	
НЗ	Protocol error	The data received by the inverter has a grammatical mistake. Or, data receive is not completed within the predetermined time. CR or LF is not as set in the parameter.	than the permissible number of retries.	
H4	Framing error	The stop bit length differs from the initial setting.		
H5	Overrun error	New data has been sent by the computer before the inverter completes receiving the preceding data.		
H6		_		
H7	Character error	The character received is invalid (other than 0 to 9, A to F, control code).	Does not accept the received data, burt the inverter does not trip.	
H8		_		
H9				
НА	Mode error	Parameter write was attempted in other than the computer link operation mode, when operation command source is not selected or during inverter operation.	Does not accept the received data, but the inverter does not trip.	
НВ	Instruction code error	The specified instruction code does not exist.		
НС	Data range error	Invalid data has been specified for parameter writing, running frequency setting, etc.		
HD	_			
HE				
HF	Normal (no error)			

## ◆Response time



#### [Formula for data transmission time]

Communication specifications Number of data characters × (Total number of bits) = data transmission time (s) (Refer to page 452.) Communication speed (bps) (Refer to the following.)

#### Communication specifications

Name		Number of bits	
Stop bit length		1 bit 2 bits	
Data Length		7 bits 8 bits	
Parity check	With	1 bit	
	Without	0	

In addition to the above, 1 start bit is necessary. Minimum number of total bits.9 bits Maximum number of total bits12 bits


#### Data check time

Item	Check time
Various monitors, operation command, Frequency setting (RAM)	<12 ms
Parameter read/write, Frequency setting (EEPROM)	<30 ms
Parameter clear / all clear	<5 s
Reset command	No answer


#### **♦**Retry count setting (Pr.121, Pr.335)

- Set the permissible number of retries at data receive error occurrence. (Refer to page 455 for data receive error for retry.)
- When the data receive errors occur consecutively and the number of retries exceeds the permissible number setting, a communication fault (PU connector communication: E.PUE, RS-485 terminal communication: E.SER) occurs and the inverter trips.
- When a data transmission error occurs while "9999" is set, the inverter does not trip but outputs the alarm (LF) signal. To use the LF signal, set "98 (positive logic) or 198 (negative logic)" in any of **Pr.190 to Pr.196 (output terminal function selection)** to assign the function to an output terminal.

Example: PU connector communication, Pr. 121 = "1" (initial value)



Example: PU connector communication, Pr. 121 = "9999"




### NOTE

• For the RS-485 terminal communication, the operation at a communication error occurrence depends on the **Pr.502 Stop** mode selection at communication error setting. (Refer to page 446)

# ◆Signal loss detection (Pr.122, Pr.336 RS-485 communication check time interval)

- If a signal loss (communication stop) is detected between the inverter and computer as a result of a signal loss detection, a communication fault (PU connector communication: E.PUE, RS-485 terminal communication: E.SER) occurs and the inverter trips.
- When the setting is "9999", communication check (signal loss detection) is not made.
- When the setting is "0", communication from the PU connector is not possible. In the case of communication by RS-485 terminals, reading, etc. of monitors and parameters is possible, though a communication error (E.SER) occurs instantly when the Network operation mode is switched to.
- A signal loss detection is made when the setting is any of "0.1 s to 999.8 s". To make a signal loss detection, it is necessary
  to send data (for details on control codes, refer to page 454) from the computer within the communication check time
  interval. (The inverter makes a communication check (clearing of communication check counter) regardless of the station
  number setting of the data sent from the master).
- Communication check is started at the first communication in the operation mode having the operation source (PU
  operation mode for PU connector communication in the initial setting or Network operation mode for RS-485 terminal
  communication).

Example: PU connector communication, Pr. 122 = "0.1 to 999.8s"




#### **♦Instructions for the program**

- When data from the computer has any error, the inverter does not accept that data. Hence, in the user program, always insert a retry program for data error.
- All data communication, for example, run command or monitoring, are started when the computer gives a communication request. The inverter does not return any data without the computer's request. Hence, design the program so that the computer gives a data read request for monitoring, etc. as required.
- · Program example: To switch to the Network operation mode

Microsoft® Visual C++® (Ver.6.0) programming example

```
#include <stdio.h>
#include <windows.h>
void main(void){
     HANDI F
                       hCom:
                                        // Communication handle
                                        // Structure for setting communication settings
     DCB
                       hDcb:
     COMMTIMEOUTS
                                hTim;
                                        // Structure for setting timeouts
                                                 // Send buffer
     char
                       szTx[0x10]:
                                                 // Receive buffer
     char
                       szRx[0x10];
                       szCommand[0x10];// Command
     char
     int
                       nTx,nRx;
                                                 // For storing buffer size
                       nSum;
                                                 // For calculating sum code
     int
     BOOL
                       bRet;
     int
                       nRet:
     //**** Open COM1 port ****
     hCom = CreateFile("COM1", (GENERIC_READ | GENERIC_WRITE), 0, NULL, OPEN_EXISTING, FILE_ATTRIBUTE_NORMAL, NULL);
     if(hCom != NULL) {
              //****Set COM1 port communication ****
              GetCommState(hCom,&hDcb);
                                                                                    // Get current communication information
              hDcb.DCBlength = sizeof(DCB);
                                                                                     // Structure size setting
              hDcb.BaudRate = 19200;
                                                                                    // Communication speed = 19200 bps
              hDcb.ByteSize = 8;
                                                                                    // Data length = 8 bits
              hDcb.Parity = 2:
                                                                                    // Parity check at even numbers
              hDcb.StopBits = 2;
                                                                                    // Stop bit = 2 bits
              bRet = SetCommState(hCom,&hDcb);
                                                                                    // Setting of changed communication information
              if(bRet == TRUE) {
                       //**** Set COM1 port timeout ****
                       GetCommTimeouts(hCom,&hTim);
                                                                                    // Get current timeout values
                       hTim.WriteTotalTimeoutConstant = 1000;
                                                                                    // Write timeout 1 second
                       hTim.ReadTotalTimeoutConstant = 1000;
                                                                                    // Read timeout 1 second
                       hTim.ReadTotalTimeoutConstantSetCommTimeouts(hCom,&hTim);// Setting of changed timeout values
                       //**** Setting of command for switching the station number 1 inverter to the Network operation mode ****
                       sprintf(szCommand,"01FB10000");
                                                                                    // Send data (NET operation write)
                       nTx = strlen(szCommand);
                                                                                    // Send data size
                       //**** Generate sum code ****
                       nSum = 0;
                                                                                    // Initialize sum data
                       for(i = 0; i < nTx; i++) {
                                nSum += szCommand[i];
                                                                                     // Calculate sum code
                                nSum &= (0xff);
                                                                                    // Mask data
                       //**** Generate send data ****
                                                                                    // Initialize send buffer
                       memset(szTx,0,sizeof(szTx));
                       memset(szRx,0,sizeof(szRx));
                                                                                    // Initialize receive buffer
                       sprintf(szTx,"\5%s%02X",szCommand,nSum);// ENQ code + send data + sum code
                       nTx = 1 + nTx + 2:
                                                                                    // ENQ code + number of send data + number of sum codes
                       nRet = WriteFile(hCom,szTx,nTx,&nTx,NULL);
                       //**** Send ****
                       if(nRet != 0) {
                                nRet = ReadFile(hCom,szRx,sizeof(szRx),&nRx,NULL);
                       //**** Receive ****
                                if(nRet != 0) {
                                        //**** Display receive data ****
                                        for(i = 0; i < nRx; i++) {
                                                 printf("%02X ",(BYTE)szRx[i]);// Output received data to console
                                                 // Display ASCII code in Hexadecimal' In case of 0', "30" is displayed.
                                        printf("\n\r");
                               }
              CloseHandle(hCom);
                                                                                     // Close communication port
     }
```

General flowchart





### Caution

- Always set the communication check time interval before starting operation to prevent hazardous conditions.
- Data communication is not started automatically but is made only once when the computer provides a communication request. If communication is disabled during operation due to signal cable breakage etc., the inverter cannot be stopped. When the communication check time interval has elapsed, the inverter will trip (E.PUE, E.SER).
  - The inverter can be coasted to a stop by switching ON the RES signals or by switching the power
- If communication is broken due to signal cable breakage, computer fault etc., the inverter does not detect such a fault. This should be fully noted.

### ◆Setting items and set data

• After completion of parameter settings, set the instruction codes and data, then start communication from the computer to allow various types of operation control and monitoring.

	Item	Read/ Write	Instruction code	Data description	Number of data digits (Format)*1		
One	ration mode	Read	Н7В	H0000: Network operation H0001: External operation H0002: PU operation, External/PU combined operation, PUJOG operation	4 digits (B.E/D)		
Орс	ration mode	Write	HFB	H0000: Network operation H0001: External operation H0002: PU operation (RS-485 communication operation via PU connector)	4 digits (A,C/D)		
	Output frequency /speed	Read	H6F	H0000 to HFFFF: Output frequency in 0.01Hz increments (The display can be changed to the rotations per minute using <b>Pr.37</b> and <b>Pr.144</b> . (Refer to page 261))	4 digits (B.E/D)		
	Output current	Read	H70	H0000 to HFFFF: Output current (hexadecimal) Increment 0.01 A (FR-F820-02330(55K) or lower, FR-F840-01160(55K) or lower) Increment 0.1 A (FR-F820-03160(75K) or higher, FR-F840-01800(75K) or higher)	4 digits (B.E/D)		
	Output voltage	Read	H71	H0000 to HFFFF: Output voltage (hexadecimal) in 0.1 V increments	4 digits (B.E/D)		
	Special monitor	Read	H72	H0000 to HFFFF: Monitor data selected in the instruction code HF3	4 digits (B.E/D)		
	Special monitor	Read	H73	Monitor selection data (Refer to page 263 for details on selection No.)	2 digits (B.E1/D)		
	selection No.	Write	HF3	Monitor selection data (Neler to page 200 for details on selection No.)	2 digits (A1,C/D)		
Monitor	Fault record	Read	H74 to H77	H0000 to HFFFF: Two latest fault records  b15	4 digits (B.E/D)		
com (exte	eration mand ended)	Write	HF9	Control input commands such as forward rotation signal (STF) and reverse rotation signal (STR) can be set. (For the details, refer to page 463.)	4 digits (A,C/D)		
com	ration mand	Write	HFA		2 digits (A1,C/D) 4 digits		
mon	erter status hitor (extended) erter status	Read	H79	The states of the output signals such as forward rotation, reverse rotation and inverter running (RUN) can be monitored. (For the details, refer to			
mon		Read	H7A page 463.)  Read the set frequency/speed from the RAM or EEPROM.		2 digits (B.E1/D)		
(RA		- Read	H6D H6E	H0000 to HFFFF: Set frequency in 0.01Hz increments (The display can be changed to the rotations per minute using <b>Pr.37</b> and <b>Pr.144</b> . (Refer to <b>page 261</b> ))	4 digits (B.E/D)		

	Item	Read/ Write	Instruction code	Data description	Number of data digits (Format)*1
Set (RA	frequency M)		HED	Write the set frequency/speed into the RAM or EEPROM. H0000 to HE678 (0 to 590.00Hz): frequency in 0.01Hz increments (The display can be changed to the rotations per minute using <b>Pr.37</b> and	4 digits
	frequency M, EEPROM)	Write	HEE	Pr.144. (Refer to page 261)) • To change the set frequency consecutively, write data to the inverter RAM. (Instruction code: HED)	(A,C/D)
Inve	erter reset	Write	HFD	H9696: Inverter reset  • As the inverter is reset at the start of communication by the computer, the inverter cannot send reply data back to the computer.	4 digits (A,C/D)
IIIVC	itel reset	vviite	1110	H9966: Inverter reset  • When data is sent normally, ACK is returned to the computer, and then the inverter is reset.	4 digits (A,D)
	lts history ch clear	Write	HF4	H9696: Faults history batch clear	4 digits (A,C/D)
Parameter clear All clear Write HF0		HFC	All parameters return to initial values.  Whether to clear communication parameters or not can be selected according to the data.  • Parameter clear  H9696: Communication parameters are cleared.  H5A5A: Communication parameters are not cleared.  • All parameter clear  H9966: Communication parameters are cleared.  H55AA: Communication parameters are cleared.  H55AA: Communication parameters are not cleared.  *2  For the details of whether or not to clear parameters, refer to page 597.  When a clear is performed with H9696 or H9966, communication related parameter settings also return to the initial values. When resuming the operation, set the parameters again.  Performing a clear will clear the instruction code HEC, HF3, and HFF settings.  Only H9966 and H55AA (all parameter clear) are valid during the password lock (refer to page 171).	4 digits (A,C/D)	
Para	ameter	Read H00 to H63		Refer to the instruction code (page 597) and write and/or read parameter values as required.	4 digits (B.E/D)
, are		Write	H80 to HE3	When setting <b>Pr.100</b> and later, the link parameter extended setting must be set.	4 digits (A,C/D)
Link	parameter	Read	H7F	Parameter settings are switched according to the H00 to H0D settings.	2 digits (B.E1/D)
Exte	ended setting	Write	HFF	For details of the settings, refer to the instruction code (page 597).	2 digits (A1,C/D)
	ond parameter	Read	H6C	When setting the calibration parameters *3 H00: Frequency *4	2 digits (B.E1/D)
	truction code = 1, 9)	Write	HEC	H01: Parameter-set analog value H02: Analog value input from terminal	2 digits (A1,C/D)
Multi command Write/ Read HF0		HF0	Available for writing 2 commands, and monitoring 2 items for reading data (refer to page 464 for detail)	10 digits (A2,C1/D)	
jo Inverter model Read H7C		Н7С	Reading inverter model in ASCII code. "H20" (blank code) is set for blank area Example of "FR-F840-1 (FM type)" H46, H52, H2D, H46, H38, H34, H30, H2D, H31, H20, H20 H20	20 digits (B,E3/D)	
Inverter model  Capacity		Read H7D		Reading inverter ND rated capacity in ASCII code. Data is read in increments of 0.1kW, and rounds down to 0.01kW increments "H20" (blank code) is set for blank area Example 0.75K"7" (H20, H20, H20, H20, H20, H37)	6 digits (B,E2/D)

- \*1 Refer to **page 452** for data formats (A, A1, A2, B, C, C1, D, E, E1, E2, E3, F)
- \*2 Turning OFF the power supply while clearing parameters with H5A5A or H55AA returns the communication parameter settings to the initial
- \*3 Refer to the calibration parameter list below for details on calibration parameters.
- \*4 The gain frequency can be also written using Pr.125 (instruction code: H99) or Pr.126 (instruction code: H9A).



- Set 65520 (HFFF0) as a parameter value "8888" and 65535 (HFFFF) as "9999".
- For the instruction codes HFF, HEC and HF3, their values are held once written but cleared to zero when an inverter reset or all clear is performed.
- When a 32-bit parameter setting or monitored value is read and the read value exceeds HFFFF, the reply data will be HFFFF.

Example) When reading the C3 (Pr.902) and C6 (Pr.904) settings from the inverter of station No. 0.

	Computer send data	Inverter send data	Description
а	ENQ 00 FF 0 01 7D	ACK 00	Set "H01" in the extended link parameter
b	ENQ 00 EC 0 01 79	ACK 00	Set "H01" in second parameter changing
С	ENQ 00 5E 0 0A	STX 00 0000 ETX 20	C3 (Pr.902) is read. 0% is read.
d	ENQ 00 60 0 F6	STX 00 0000 ETX 20	C6 (Pr.904) is read. 0% is read.

To read/write C3 (Pr.902) or C6 (Pr.904) after inverter reset or parameter clear, execute from (a) again.

### **♦**List of calibration parameters

		In	structi code	on
Pr.	Name	Read	Write	Extended
C2 (902)	Terminal 2 frequency setting bias frequency	5E	DE	1
C3 (902)	Terminal 2 frequency setting bias	5E	DE	1
125 (903)	Terminal 2 frequency setting gain frequency	5F	DF	1
C4 (903)	Terminal 2 frequency setting gain	5F	DF	1
C5 (904)	Terminal 4 frequency setting bias frequency	60	E0	1
C6 (904)	Terminal 4 frequency setting bias	60	E0	1
126 (905)	Terminal 4 frequency setting gain frequency	61	E1	1
C7 (905)	Terminal 4 frequency setting gain	61	E1	1
C12 (917)	Terminal 1 bias frequency (speed)	11	91	9
C13 (917)	Terminal 1 bias (speed)	11	91	9
C14 (918)	Terminal 1 gain frequency (speed)	12	92	9
C15 (918)	Terminal 1 gain (speed)	12	92	9
C16 (919)	Terminal 1 bias command (torque)	13	93	9

		Ins	structi code	on
Pr.	Name	Read	Write	Extended
C17 (919)	Terminal 1 bias (torque)	13	93	9
C18 (920)	Terminal 1 gain command (torque)	14	94	9
C19 (920)	Terminal 1 gain (torque)	14	94	9
C8 (930)	Current output bias signal	1E	9E	9
C9 (930)	Current output bias current	1E	9E	9
C10 (931)	Current output gain signal	1F	9F	9
C11 (931)	Current output gain current	1F	9F	9
C38 (932)	Terminal 4 bias command (torque)	20	A0	9
C39 (932)	Terminal 4 bias (torque)	20	A0	9
C40 (933)	Terminal 4 gain command (torque)	21	A1	9
C41 (933)	Terminal 4 gain (torque)	21	A1	9
C42 (934)	PID display bias coefficient	22	A2	9
C43 (934)	PID display bias analog value	22	A2	9
C44 (935)	PID display gain coefficient	23	A3	9
C45 (935)	PID display gain analog value	23	A3	9

### **♦**Operation command

Item	Instruction code	Bit length	Description*1*3	Example
Operation command	HFA	8 bits	b0: AU (Terminal 4 input selection) b1: Forward rotation command b2: Reverse rotation command b3: RL (Low-speed operation command) b4: RM (Middle-speed operation command) b5: RH (High-speed operation command) b6: RT (Second function selection) b7: MRS (Output stop)	[Example 1] H02 Forward rotation b7 b0 0 0 0 0 1 0 1 0    [Example 2] H00 Stop b7 b0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Operation command (extended)	HF9	16 bits	b0: AU (Terminal 4 input selection) b1: Forward rotation command b2: Reverse rotation command b3: RL (Low-speed operation command) b4: RM (Middle-speed operation command) b5: RH (High-speed operation command) b6: RT (Second function selection) b7: MRS (Output stop) b8: JOG (Jog operation selection) *2 b9: CS (No function) *2 b10: STP (STOP) (Start self-holding selection) *2 b11: RES (Inverter reset) *2 b12 to b15: -	[Example 1] H0002 Forward rotation b15

- \*1 The signal within parentheses ( ) is the initial status. The description changes depending on the setting of Pr.180 to Pr.184, Pr.187 (Input terminal function selection) (page 329).
- \*2 JOG operation/automatic restart after instantaneous power failure/start self-holding selection/reset cannot be controlled over a network, so in the initial status bit8 to bit11 are invalid. To use bit8 to bit11, change the signal by Pr.185, Pr.186, Pr.188, or Pr.189 (Input terminal function selection) (page 329) (A reset can be executed by the instruction code HFD.)
- \*3 In RS-485 communication from the PU connector, only the forward rotation command and reverse rotation command can be used.

#### ◆Inverter status monitor

Item	Instruction code	Bit length	Description*1	Example
Inverter status monitor	H7A	8 bits	b0: RUN (Inverter running) b1: During forward rotation b2: During reverse rotation b3: SU (Up to frequency) b4: OL (Overload warning) b5: IPF (Instantaneous power failure/ undervoltage) b6: FU (Output frequency detection) b7: ABC1 (Fault)	[Example 1]       H02 ··· During forward rotation       b0         0       0       0       0       0       1       0         [Example 2]       H80 ··· Stop at fault occurrence       b7       b0         1       0       0       0       0       0       0
Inverter status monitor (extended)	H79	16 bits	b0: RUN (Inverter running) b1: During forward rotation b2: During reverse rotation b3: SU (Up to frequency) b4: OL (Overload warning) b5: IPF (iInstantaneous power failure/ undervoltage) b6: FU (Output frequency detection ) b7: ABC1 (Fault) b8: ABC2 (—) b9: Safety monitor output b10 to b14: - b15: Fault occurrence	[Example 1] H0002 ··· During forward rotation         b15       b0         0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0

<sup>\*1</sup> The signal within parentheses ( ) is the initial status. The description changes depending on the setting of Pr.190 to Pr.196 (output terminal function selection).

### ◆Multi command (HF0)

· Sending data format from computer to inverter

Format		Number of characters																	
Format	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
A2	ENQ	Inverte		Instruc Code (HF0)	ction	Waiting time	type	Receive data type*2	Data1	*3			Data2	*3			Sum c	heck	CR/ LF

• Reply data format from inverter to computer (No data error detected)

Format	Number of characters									ers									
Format	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
C1	STX	Inverte		type	Receive data type*2	code		Data1	*4			Data2	*4			ETX	Sum c	heck	CR/ LF

- \*1 Specify the data type of sending data (from computer to inverter).
- \*2 Specify the data type of reply data (from inverter to computer).
- \*3 Combination of data 1 and data 2 for sending

Data type	Data 1	Data 2	Remarks
0	Operation command (extended)	Set frequency (RAM)	Run command (extended) is same as instruction code HF9
1	Operation command (extended)	Set frequency (RAM, EEPROM)	(Refer to page 463)

\*4 Combination of data 1 and data 2 for reply

Da	ata type	Data 1	Data 2	Remarks
0		Inverter status monitor (extended)	Output frequency (speed)	Inverter status monitor (extended) is same as instruction code H79 (Refer to page 463)
1		Inverter status monitor (extended)	Special monitor	Replys the monitor item specified in instruction code HF3 for special monitor.(Refer to page 263)

<sup>\*5</sup> Error code for sending data 1 is set in error code 1, and error code for sending data 2 is set in error code 2. Mode error (HA), instruction code error (HB), data range error (HC) or no error (HF) is replied. (Refer to page 533 for the details of the error codes.)

#### 5.12.6 **Modbus-RTU communication specification**

Operation by Modbus-RTU communication or parameter setting is possible by using the Modbus-RTU communication protocol from the RS-485 terminals of the inverter.

Pr.	Name	Initial value	Setting range	Description			
331	RS-485 communication		0	Broadcast communication			
N030	station number	0	1 to 247	Inverter station number specification Set the inverter station numbers when two or more inverters are connected to one personal computer.			
332 N031	RS-485 communication speed	96	3, 6, 12, 24, 48, 96, 192, 384, 576, 768, 1152	Set the communication speed. The setting value × 100 equals the communication speed. For example, if 96 is set, the communication speed is 9600 bps.			
			0	Without parity check Stop bit length 2 bits			
334 N034	RS-485 communication parity check selection	2	1	With parity check at odd numbers Stop bit length 1 bit			
			2	With parity check at even numbers Stop bit length 1 bit			
343 N080	Communication error count	0	_	Displays the communication error count during Modbus-RTU communication. Read-only.			
539	Modbus-RTU		0	Modbus-RTU communication, but the inverter trips in the NET operation mode.			
N002	communication check time interval	9999	0.1 to 999.8 s	Set the interval of the communication check (signal loss detection) time. (same specifications as <b>Pr.122</b> )			
			9999	No communication check (signal loss detection)			
549			0	Mitsubishi inverter protocol (computer link)			
N000	Protocol selection	0	1	Modbus-RTU protocol			
			2	BACnet MS/TP protocol			

### NOTE

- To use the Modbus-RTU protocol, set "1" to Pr.549 Protocol selection.
- If Modbus-RTU communication is performed from the master to the address 0 (station number 0), the data is broadcasted, and the inverter does not send any reply to the master. To obtain replies from the inverter, set Pr.331 RS-485 communication station number ≠ "0 (initial value)". Some functions are disabled in broadcast communication. (Refer to page 467.)
- If a communication option is mounted with Pr.550 NET mode operation command source selection = "9999 (initial value)", commands (operation commands) transmitted via RS-485 terminals become invalid. (Refer to page 210.)

### Communication specifications

· The communication specifications are given below.

Item		Description	Related parameter
Communication protocol		Modbus-RTU protocol	Pr.549
Conforming stand	dard	EIA-485 (RS-485)	_
Connectable unit	S	1:N (maximum 32 units), setting is 0 to 247 stations	Pr.331
Communication Speed		Selected among 300/600/1200/2400/4800/9600/19200/38400/57600/76800/ 115200 bps	Pr.332
Control procedure		Asynchronous system	_
Communication method		Half-duplex system	_
	Character system	Binary (fixed at 8 bits)	_
	Start bit	1 bit	_
Communication	Stop bit length	Select from the following three types: No parity check, stop bit length 2 bits	Pr.334
specifications	Parity check	Odd parity check , stop bit length 1 bit Even parity check, stop bit length 1 bit	11.004
	Error check	CRC code check	_
	Terminator	Not used	_
Waiting time sett	ing	Not used	_


#### **◆**Outline

- The Modbus communication protocol was developed by Modicon for programmable controllers.
- The Modbus protocol uses exclusive message frames to perform serial communication between a master and slaves. These exclusive message frames are provided with a feature called "functions" that allows data to be read or written. These functions can be used to read or write parameters from the inverter, write input commands to the inverter or check the inverter's operating status, for example. This product classifies the data of each inverter into holding register area (register address 40001 to 49999). The master can communicate with inverters (for instance,. slaves) by accessing pre-assigned holding register addresses.

#### • NOTE

• There are two serial transmission modes, the ASCII (American Standard Code for Information Interchange) mode and the RTU (Remote Terminal Unit) mode. However, this product supports only the RTU mode, which transfers 1 byte data (8 bits) as it is. Also, only communication protocol is defined by the Modbus protocol. Physical layers are not stipulated.

#### ◆Message format



#### · Data check time

Item	Check time
Various monitors, operation command, Frequency setting (RAM)	<12 ms
Parameter read/write, frequency setting (EEPROM)	<30 ms
Parameter clear / all clear	<5 s
Reset command	No answer

#### Query

A message is sent to the slave (for instance, the inverter) having the address specified by the master.

#### · Normal Response

After the query from the master is received, the slave executes the request function, and returns the corresponding normal response to the master.

#### · Error Response

When an invalid function code, address or data is received by the slave, the error response is returned to the master. This response is appended with an error code that indicates the reason why the request from the master could not be executed.

This response cannot be returned for errors, detected by the hardware, frame error and CRC check error.

#### Broadcast

The master can broadcast messages to all slaves by specifying address 0. All slaves that receive a message from the master execute the requested function. With this type of communication, slaves do not return a response to the master.



· During broadcast communication, functions are executed regarded of the set inverter station number (Pr.331).


### **♦**Message frame (protocol)

#### · Communication method

Basically, the master sends a Query message (question), and slaves return the Response message (response). At normal communication, the Device Address and Function Code are copied as they are, and at erroneous communication (illegal function code or data code), bit7 (= 80 h) of the Function Code is turned ON, and the error code is set at Data Bytes.

Query message from Master

Ξ.	iory moodage nom mass						
	Device Address						
	Function Code						
	Eight-Bit Data Bytes						
	Error Check						



Device Address	
Function Code	
Eight-Bit Data Bytes	
Error Check	

Message frames comprise of the four message fields shown in the figures above.

A slave recognizes message data as a message by the message data being prefixed and appended with a no data time of 3.5 characters (T1: start/end).

· Details of protocol

The following table explains the four message fields.

Start	ADDRESS	FUNCTION	DATA	CRC C	HECK	End
T1	8 bits	8 bits	n × 8 bits	L 8 bits	H 8 bits	T1

Message field	Description
ADDRESS field	0 to 247 can be set in single byte lengths (8 bits). Set "0" when sending broadcast messages (instructions to all addresses), and "1 to 247" to send messages to individual slaves.  The address set by the master is also returned when the response from the slave is.  The value set to <b>Pr.331 RS-485 communication station number</b> is the slave address.
FUNCTION field	1 to 255 can be set in single byte lengths (8 bits) for the function code. The master sets the function to be sent to the slave as the request, and the slave performs the requested operation. "Function code list" summarizes the supported function codes. An error response is generated when a function code other than "Function code list" is set.  At a response from the slave, the function code set by the master is returned in the case of a normal response. At an error response, H80 + the function code is returned.
DATA field	The format changes according to the function code. (Refer to page 468.) The data, for example, includes the byte count, number of bytes and accessing content of holding registers.
CRC CHECK field	Errors in the received message frame are detected. Errors are detected in the CRC check, and the message is appended with data 2 bytes long. When the message is appended with the CRC, the lower bytes are appended first, followed by the upper bytes.  The CRC value is calculated by the sender that appends the message with the CRC. The receiver recalculates the CRC while the message is being received, and compares the calculation result against the actual value that was received in the error check field. If the two values do not match, the result is treated as an error.

## **♦**Function code list

Function name	Read/ Write	Code	Outline	Broadcast communication	Message format reference page
Read Holding Register	Read	Н03	The data of the holding registers is read. The various data of the inverter can be read from Modbus registers. System environmental variable (Refer to page 475.) Real time monitor (Refer to page 264.) Faults history (Refer to page 477.) Model information monitor (Refer to page 477.) Inverter parameters (Refer to page 476.)	Not available	page 469.
Preset Single Register	Write	H06	Data is written to holding registers.  Data can be written to Modbus registers to output instructions to the inverter or set parameters.  System environmental variable (Refer to page 475.) Inverter parameters (Refer to page 476.)	Available	page 470.
Diagnostics	Read	H08	Functions are diagnosed. (communication check only) A communication check can be made since the query message is sent and the query message is returned as it is as the return message (subfunction code H00 function). Subfunction code H00 (Return Query Data)	Not available	page 471.
Preset Multiple Registers Read		H10	Data is written to consecutive multiple holding registers. Data can be written to consecutive multiple Modbus registers to output instructions to the inverter or set parameters. System environmental variable (Refer to page 475.) Inverter parameters (Refer to page 476.)	Available	page 472.
Read holding register access log	Read	H46	The number of registers that were successfully accessed by the previous communication is read. Queries by function codes H03 and H10 are supported. The number and start address of holding registers successfully accessed by the previous communication are returned.  "0" is returned for both the number and start address for queries other than function code H03 and H10.	Not available	page 473.

### ◆Read Holding Register (reading of data of holding registers) (H03 or 03)

#### · Query message

a. Slave Address	b. Function	c. Starting Address		d. No. of Points		CRC Check	
(8 bits)	H03	H	L	H	L	L	H
	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)

#### • Normal response (Response message)

a. Slave Address	b. Function	e. Byte Count	f. Data		CRC Check		
(8 bits)	H03 (8 bits)	(8 bits)	H (8 bits)	L (8 bits)	 (n × 16 bits)	L (8 bits)	H (8 bits)

#### · Query message setting

	Message	Description
а	Slave Address	Set the address to send messages to. Broadcast communication is not possible. (Invalid when "0" is set.)
b	Function	Set H03.
С	Starting Address	Set the address from which to start reading of data from the holding register.  Start address = start register address (decimal) - 40001  For example, when start register address 0001 is set, the data of holding register address 40002 is read.
d	No. of Points	Set the number of holding registers to read. Data can be read from up to 125 registers.

#### · Content of normal response

	Message	Description
е	Byte Count	The setting range is H02 to HFA (2 to 250). Twice the number of reads specified by (d) is set.
f	Data	The amount of data specified by (d) is set. Read data is output Hi bytes first followed by Lo bytes, and is arranged as follows: data of start address, data of start address+1, data of start address+2, and so forth.

Example) Read the register values of 41004 (Pr.4) to 41006 (Pr.6) from slave address 17 (H11).

#### Query message

Slave Address	Function	Starting Address		No. of Points		CRC Check	
H11	H03	H03	HEB	H00	H03	H77	H2B
(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)

#### Response message

Slave Address	Function	Byte Count			CRC	Check				
H11	H03	H06	H17	H70	H0B	HB8	H03	HE8	H2C	HE6
(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)

Read value

Register 41004 (Pr.4): H1770 (60.00 Hz) Register 41005 (Pr.5): H0BB8 (30.00 Hz) Register 41006 (Pr.6): H03E8 (10.00 Hz)

### ◆Preset Single Register (writing of data to holding registers) (H06 or 06)

- The content of the "system environmental variables" and "inverter parameters" assigned to the holding register area (refer to the register list (page 475)) can be written.
- · Query message

a. Slave Address	b. Function	· ·	gister ress	d. Pres	et Data	CRC (	Check
(8 bits)	H06	H	L	H	L	L	H
	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)

• Normal response (Response message)

a. Slave Address	b. Function	·	gister ress	d. Preset Data		CRC Check	
(8 bits)	H06	H	L	H	L	L	H
	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)

· Query message setting

	Message	Description
а	Slave Address	Set the address to send messages to. Setting "0" enables broadcast communication.
b	Function	Set H06.
С	Register Address	Set the address from data is written to the holding register.  Register address = holding register address (decimal) - 40001  For example, when register address 0001 is set, data is written to holding register address 40002.
d	Preset Data	Set the data to write to the holding register. Write data is fixed at 2 bytes.

· Content of normal response

With a normal response, the content is the same as a to d (including the CRC check) query messages. In the case of broadcast communication, no response is returned.

Example) Write 60Hz (H1770) to 40014 (running frequency) of slave address 5 (H05).

#### Query message

Slave Address	Function	Register A	Address	Preset Data		CRC Check	
H05	H06	H00	H0D	H17	H70	H17	H99
(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)

Normal response (Response message)

Same data as query message



· With broadcast communication, no response is generated even if a query is executed, so when the next query is made, it must be made after waiting for the inverter data processing time after the previous query is executed.

### **◆**Diagnostics (diagnosis of functions) (H08 or 08)

- A communication check can be made since the query message is sent and the query message is returned as it is as the return message (subfunction code H00 function). Subfunction code H00 (Return Query Data)
- · Query message

a. Slave Address	b. Function	c. Subf	unction	d. E	ata	CRC	Check	
(8 bits)	H08	H00	H00	H	L	L	H	
	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	

• Normal response (Response message)

a. Slave Address	b. Function	c. Subf	unction	d. D	ata	CRC (	Check	
(8 bits)	H08	H00	H00	H	L	L	H	
	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	

· Query message setting

	Message	Description
а	Slave Address	Set the address to send messages to. Broadcast communication is not possible. (Invalid when "0" is set.)
b	Function	Set H08.
С	Subfunction	Set H0000.
d	Data	Any data 2 bytes long can be set. Setting range is H0000 to HFFFF.

· Content of normal response

With a normal response, the content is the same as a to d (including the CRC check) query messages.



· With broadcast communication, no response is generated even if a query is executed, so when the next query is made, it must be made after waiting for the inverter data processing time after the previous query is executed.

### ◆Preset Multiple Registers (writing of data to multiple holding registers) (H10 or 16)

- Data can be written to multiple holding registers.
- · Query message

a. Slave Address	b. Function		arting ress		o. of sters	e. ByteCount	f. Data			CRC Check	
(8 bits)	H10 (8 bits)	H (8 bits)	L (8 bits)	H (8 bits)	L (8 bits)	(8 bits)	H (8 bits)	L (8 bits)		L (8 bits)	H (8 bits)

• Normal response (Response message)

a. Slave Address	b. Function	ion c. Starting Address		d. No. of	Registers	CRC Check		
(8 bits)	H10	H	L	H	L	L	H	
	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	

· Query message setting

	Message	Description
а	Slave Address	Set the address to send messages to. Setting "0" enables broadcast communication.
b	Function	Set H10.
С	Starting Address	Set the address from which to start writing of data to the holding register.  Start address = start register address (decimal) - 40001  For example, when start register address 0001 is set, the data of holding register address 40002 is read.
d	No. of Points	Set the number of holding registers to write to. Data can be written to up to 125 registers.
е	Byte Count	The setting range is H02 to HFA (2 to 250). Set twice the value specified by <b>d</b> .
f	Data	Set the amount of data specified by <b>d</b> . Set write data Hi bytes first followed by Lo bytes, and arrange it as follows: data of start address, data of start address+1, data of start address+2, and so forth.

· Content of normal response

With a normal response, the content is the same as **a to d** (including the CRC check) query messages.

Example) Write 0.5 s(H05) to 41007 (Pr.7) and 1 s (H0A) to 41008 (Pr.8) of slave address 25 (H19).

Query message

Slave Address	Function		Address		No. of Points		Data			CRC Check		
H19	H10	H03	HEE	H00	H02	H04	H00	H05	H00	H0A	H86	H3D
(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)

Normal response (Response message)

Slave Address	Function	Starting	Address	No. of	Points	CRC (	Check
H19	H10	H03	HEE	H00	H02	H22	H61
(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)

### ◆Read Holding Register access Log (H46 or 70)

• Queries by function codes H03 and H10 are supported.

The number and start address of holding registers successfully accessed by the previous communication are returned. "0" is returned for both the number and start address for queries other than the function codes.

· Query message

a. Slave Address	b. Function	CRC Check		
(8 bits)	H46	L	H	
	(8 bits)	(8 bits)	(8 bits)	

• Normal response (Response message)

a. Slave Address	b. Function	c. Starting Address		d. No. of Points		CRC Check	
(8 bits)	H46	H	L	H	L	L	H
	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)

· Query message setting

	Message	Description
а	Slave Address	Set the address to send messages to. Broadcast communication is not possible. (Invalid when "0" is set.)
b	Function	Set H46.

· Content of normal response

	Message	Description
С	Starting Address	The start address of the holding register that was successfully accessed is returned.  Start address = start register address (decimal) - 40001  For example, when start address 0001 is returned, the holding register address that was successfully accessed is 40002.
d	No. of Points	The number of holding registers that were successfully accessed is returned.

Example) Read the successful register start address and number of successful accesses from slave address 25 (H19).

Query message

Slave Address	Function CRC Ch		Check
H19	H46	H8B	HD2
(8 bits)	(8 bits)	(8 bits)	(8 bits)

Normal response (Response message)

Slave Address	Function		ting ress	No. of	Points	CRC	Check
H19	H10	H03	HEE	H00	H02	H22	H61
(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)	(8 bits)

Two successful reads of start address 41007 (Pr.7) are returned.

#### **♦**Error response

• An error response is returned if the query message received from the master contains an illegal function, address or data. No response is returned for parity, CRC, overrun, framing, and Busy errors.

### • NOTE

- No response is also returned in the case of broadcast communication.
- Error response (Response message)

	a. Slave b. Function		c. Exception Code	CRC Check	
(8 bits) H80 + Function (8 bits)		(8 bits)	L (8 bits)	H (8 bits)	

Message Description		Description	
а	Slave Address	Set the address received from the master.	
b	Function	The function code requested by the master + H80 is set.	
С	Exception Code	The codes in the following table are set.	

#### · Error code list

Code	Error Item	Error description
01	ILLEGAL FUNCTION	The query message from the master is set with a function code that cannot be handled by the slave.
02	ILLEGAL DATA ADDRESS *1	The query message from the master is set with a register address that cannot be handled by the inverter.  (No parameter, parameter cannot be read, parameter cannot be written)
03	ILLEGAL DATA VALUE	The query message from the master is set with data that cannot be handled by the inverter.  (Out of parameter write range, a mode is specified, other error)

- \*1 An error does not occur in the following cases:
  - Function code H03 (read data of holding register)
    - When there are 1 or more number of reads (No. of Points) and there is 1 or more holding register from where data can be read
  - Function code H10 (write data to multiple holding registers)

When there are 1 or more number of writes (No. of Points) and there is 1 or more holding registers to which data can be written. In other words, when function code H03 or H10 is used and multiple holding registers are accessed, an error will not occur even if a non-existent holding register or holding register that cannot be read or written is accessed.

### NOTE

- An error will occur if all accesses holding registers do not exist. The data read value of non-existent holding registers is 0, and data is invalid when written to non-existent holding registers.
- · Error detection of message data

The following errors are detected in message data from the master. The inverter is not tripped even if an error is detected.

#### Error check items

Error item	Error description	Inverter operation
Parity error	The data received by the inverter is different from the specified parity ( <b>Pr.334</b> setting).	
Framing error	The data received by the inverter is different from the stop bit length ( <b>Pr.334</b> ) setting.	Whom this arran accura Bu 242 is
Overrun error	The next data has been sent by the master before the inverter completes receiving the preceding data.	When this error occurs, <b>Pr.343</b> is incremented by one. When this error occurs, the LF signal is
Message frame error	The data length of the message frame is checked, and an error is generated if the received data length is less than 4 bytes.	output.
CRC check error	An error is generated if the data in the message frame does not match the calculation result.	

### NOTE

• The LF signal can be assigned to an output terminal by setting **Pr.190 to Pr.196 (output terminal function selection)**.

Changing the terminal assignment may affect other functions. Set parameters after confirming the function of each terminal.

### **♦** Modbus register

· System environmental variables

Register	Definition	Read/Write	Remarks
40002	Inverter reset	Write	Any value can be written
40003	Parameter clear	Write	Set H965A for the write value.
40004	All parameter clear	Write	Set H99AA for the write value.
40006	Parameter clear *1	Write	Set H5A96 for the write value.
40007	All parameter clear *1	Write	Set HAA99 for the write value.
40009	Inverter status/control input command *2	Read/Write	Refer to the following.
40010	Operation mode/inverter setting *3	Read/Write	Refer to the following.
40014	Running frequency (RAM value)	Read/Write	The display can be changed to the rotations per minute using <b>Pr.37</b> and <b>Pr.144</b> . (Refer to
40015	Running frequency (EEPROM value)	Write	page 261)

- \*1 Communication parameter settings are not cleared.
- \*2 At a write, the data is set as the control input command. At a read, the data is read as the inverter running status.
- st 3 At a write, the data is set as the operation mode setting. At a read, the data is read as the operation mode setting.

<Inverter status/control input command>

D:4	Defir	nition				
Bit	Control input command	Inverter status				
0	Stop command	RUN (Inverter running) *5				
1	Forward rotation command	During forward rotation				
2	Reverse rotation command	During reverse rotation				
3	RH (High-speed operation command) *4	SU (Up to frequency) *5				
4	RM (Middle-speed operation command) *4	OL (Overload warning) *5				
5	RL (Low-speed operation command) *4	IPF (Instantaneous power failure/ undervoltage) *5				
6	JOG (Jog operation selection) *4	FU (Output frequency detection) *5				
7	RT (Second function selection) *4	ABC1 (Fault) *5				
8	AU (Terminal 4 input selection) *4	ABC2 (-) *5				
9	CS (No function) *4	Safety monitor output				
10	MRS (Output stop) *4	0				
11	STP (STOP) (Start self-holding selection) *4	0				
12	RES (Inverter reset) *4	0				
13	0	0				
14	0	0				
15	0	Fault occurrence				

- \*4 The signal within parentheses ( ) is the initial status. The description changes depending on the setting of Pr.180 to Pr.189 (input terminal function selection) (page 329).
  - For each of the assigned signals, some signals are enabled by NET and some are disabled. (Refer to page 215.)
- \*5 The signal within parentheses ( ) is the initial status. The description changes depending on the setting of Pr.190 to Pr.196 (output terminal function selection) (page 288).

<Operation mode/inverter setting>

Mode	Read value	Write value		
EXT	H0000	H0010*6		
PU	H0001	H0011*6		
EXT JOG	H0002	_		
PU JOG	H0003	_		
NET	H0004	H0014		
PU+EXT	H0005	_		

\*6 Enable/disable parameter writing by **Pr.79 and Pr.340** settings. For the details, refer to page 209. Restrictions in each operation mode conform with the computer link specification.

### (N) Operation via communication and its settings

- Real-time monitor
   Refer to page 263 for the register numbers and monitored items of the real time monitor.
- Parameters

Pr.	Register	Name	Read/ Write	Remarks
0 to 999	41000 to 41999	For details on parameter names, refer to the parameter list (page 112).	Read/ Write	The parameter number + 41000 is the register number.
C2 (902)	41902	Terminal 2 frequency setting bias (frequency)	Read/ Write	
C3 (902)	42092	Terminal 2 frequency setting bias (analog value)	Read/ Write	Analog value (%) set to C3 (902)
00 (002)	43902	Terminal 2 frequency setting bias (terminal analog value)	Read	Analog value (%) of voltage (current) applied to terminal 2
125 (903)	41903	Terminal 2 frequency setting gain (frequency)	Read/ Write	
C4 (903)	42093	Terminal 2 frequency setting gain (analog value)	Read/ Write	Analog value (%) set to C4 (903)
04 (000)	43903	Terminal 2 frequency setting gain (terminal analog value)	Read	Analog value (%) of voltage (current) applied to terminal 2
C5 (904)	41904	Terminal 4 frequency setting bias (frequency)	Read/ Write	
C6 (904)	42094	Terminal 4 frequency setting bias (analog value)	Read/ Write	Analog value (%) set to <b>C6 (904)</b>
00 (304)	43904	Terminal 4 frequency setting bias (terminal analog value)	Read	Analog value (%) of current (voltage) applied to terminal 4
126 (905)	41905	Terminal 4 frequency setting gain (frequency)	Read/ Write	
C7 (905)	42095	Terminal 4 frequency setting gain (analog value)	Read/ Write	Analog value (%) set to C7 (905)
07 (303)	43905	Terminal 4 frequency setting gain (terminal analog value)	Read	Analog value (%) of current (voltage) applied to terminal 4
C12 (917)	41917	Terminal 1 bias frequency (speed)	Read/ Write	
C13 (917)	42107	Terminal 1 bias (speed)	Read/ Write	Analog value (%) set to C13 (917)
010 (011)	43917	Terminal 1 bias (speed) (terminal analog value)	Read	Analog value (%) of voltage applied to terminal 1
C14 (918)	41918	Terminal 1 gain frequency (speed)	Read/ Write	
C15 (918)	42108	Terminal 1 gain (speed)	Read/ Write	Analog value (%) set to C15 (918)
010 (010)	43918	Terminal 1 gain (speed) (terminal analog value)	Read	Analog value (%) of voltage applied to terminal 1
C16 (919)	41919	Terminal 1 bias command (torque)	Read/ Write	
C17 (919)	42109	Terminal 1 bias (torque)	Read/ Write	Analog value (%) set to C17 (919)
011 (010)	43919	Terminal 1 bias (torque) (terminal analog value)	Read	Analog value (%) of voltage applied to terminal 1
C18 (920)	41920	Terminal 1 gain command (torque)	Read/ Write	
C19 (920)	42110	Terminal 1 gain (torque)	Read/ Write	Analog value (%) set to C19 (920)
010 (020)	43920	Terminal 1 gain (torque) (terminal analog value)	Read	Analog value (%) of voltage applied to terminal 1
C9 (930)	42120	Current output bias current	Read/ Write	Analog value (%) set to C9 (930)
C11 (931)	42121	Current output gain current	Read/ Write	Analog value (%) set to C11 (931)
C38 (932)	41932	Terminal 4 bias command (torque)	Read/ Write	
C39 (932)	42122	Terminal 4 bias (torque)	Read/ Write	Analog value (%) set to C39 (932)
009 (80Z)	43932	Terminal 4 bias (torque) (terminal analog value)	Read	Analog value (%) of current (voltage) applied to terminal 4

Pr.	Register	Name	Read/ Write	Remarks
C40 (933)	41933	Terminal 4 gain command (torque)	Read/ Write	
C41 (933)	42123	Terminal 4 gain (torque)	Read/ Write	Analog value (%) set to C41 (933)
041 (933)	43933	Terminal 4 gain (torque) (terminal analog value)	Read	Analog value (%) of current (voltage) applied to terminal 4
C42 (934)	41934	PID display bias coefficient	Read/ Write	
C43 (934)	42124	PID display bias analog value	Read/ Write	Analog value (%) set to C43 (934)
C43 (934)	43934	PID display bias analog value (terminal analog value)	Read	Analog value (%) of current (voltage) applied to terminal 4
C44 (935)	41935	PID display gain coefficient	Read/ Write	
C4E (02E)	42125	PID display gain analog value	Read/ Write	Analog value (%) set to C45 (935)
C45 (935)	43935	PID display gain analog value (terminal analog value)	Read	Analog value (%) of current (voltage) applied to terminal 4
1000 to 1999	45000 to 45999	For details on parameter names, refer to the parameter list (page 112).	Read/ Write	The parameter number + 44000 is the register number.

#### Faults history

Register	Definition	Read/Write	Remarks
40501	Faults history 1	Read/Write	
40502	Faults history 2	Read	Data is 2 bytes and so is stored in "H00OO".
40503	Faults history 3	Read	The lowest 1 byte can be referred to for the error code.
40504	Faults history 4	Read	(For details on error codes, refer to page 533.)
40505	Faults history 5	Read	The faults history is batch-cleared by writing to register
40506	Faults history 6	Read	40501.
40507	Faults history 7	Read	Set any value for the data.
40508	Faults history 8	Read	

#### · Model information monitor

Register	Definition	Read/Write	Remarks			
44001	Model (First and second characters)	Read				
44002	Model (Third and fourth characters)	Read				
44003	Model (Fifth and sixth characters)	Read				
44004	Model (Seventh and eighth characters)	Read	Reading inverter type in ASCII code.			
44005	Model (Ninth and tenth characters)	Read	"H20" (blank code) is set for blank area.			
44006	Model (Eleventh and twelfth characters)	Read	Example of FR-F840-1 (FM type) H46, H52, H2D, H46, H38, H34, H30,			
44007	Model (Thirteenth and fourteenth characters)	Read	H2D, H31, H20H20			
44008	Model (Fifteenth and sixteenth characters)	Read				
44009	Model (Seventeenth and eighteenth characters)	Read				
44010	Model (Nineteenth and twentieth characters)	Read				
44011	Capacity (First and second characters)	Read	Reading inverter capacity in ASCII code. Data is read in increments of 0.1 kW, and			
44012	Capacity (Third and fourth characters)	Read	rounds down to 0.01 kW increments. "H20" (blank code) is set for blank area. Example 0.75K"7" (H20, H20, H20, H20, H37)			
44013	Capacity (Fifth and sixth characters)	Read				



• When a 32-bit parameter setting or monitored value is read and the read value exceeds HFFFF, the reply data will be HFFFF.

GROUP N

#### ◆Pr.343 Communication error count

• The communication error occurrence count can be checked.


Parameter	Setting range	Minimum setting range	Initial value
343	(Read only)	1	0

### • NOTE

The communication error count is temporarily stored in the RAM memory. The value is not stored in EEPROM, and so is cleared to 0 when power is reset and the inverter is reset.

### ◆Output signal LF "alarm output (communication error warning)"

• During a communication error, the alarm signal (LF signal) is output by open collector output. Assign the terminal to be used using any of Pr.190 to Pr.196 (output terminal function selection).




### NOTE


The LF signal can be assigned to an output terminal by setting Pr.190 to Pr.196. Changing the terminal assignment may affect other functions. Set parameters after confirming the function of each terminal.

### ◆Signal loss detection (Pr.539 Modbus-RTU communication check time interval)

- If a signal loss (communication) is detected between the inverter and the master as a result of a signal loss detection, an inverter communication fault (E.SER) occurs and the inverter trips.
- When the setting is "9999", communication check (signal loss detection) is not made.
- · When the setting is "0", reading, etc. of monitors and parameters is possible, though a Communication fault (inverter) (E.SER) occurs instantly when the Network operation mode is switched to.
- A signal loss detection is made when the setting is any of "0.1 s to 999.8 s". To make a signal loss detection, it is necessary to send data from the master within the communication check time interval. (The inverter makes a communication check (clearing of communication check counter) regardless of the station number setting of the data sent from the master).
- The communication check is made from the first communication in the Network operation mode (can be changed by Pr.551 PU mode operation command source selection).
- The communication check time by query communication includes a no data time (3.5 bytes). This no data time differs according to the communication speed, so take this time no data time into consideration when setting the communication check time.

Example: RS-485 terminal communication, Pr. 539 = "0.1 to 999.8 s"





NOTE

For the RS-485 terminal communication, the operation at a communication error occurrence depends on the Pr.502 Stop mode selection at communication error setting. (Refer to page 446)

# 5.12.7 BACnet MS/TP protocol

Using BACnet MS/TP protocol, communication operation and parameter setting are available from the RS-485 terminals of the inverter.

D.,	N	Initial	value	0-44	Decembries				
Pr.	Name	FM	CA	Setting range	Description				
52 M100	Operation panel main monitor selection	0		0, 5 to 14, 17, 18, 20, 23 to 25, 34, 38, 40 to 45, 50 to 57, 61, 62, 64, 67, 68, 81 to 96, 98, 100	81: BACnet reception status 82: BACnet token pass counter (Displays the count of received token) 83: BACnet valid APDU counter (Displays the count of valid APDU detection)				
774 M101	Second motor inertia (integer)			1 to 3, 5 to 14, 17,	84: BACnet communication error counter (Displays the count of communication error) 85: Terminal FM/CA output level (Same display as Analog				
775 M102	Second motor inertia (exponent)	9999		18, 20, 23 to 25, 34, 38, 40 to 45, 50 to 57, 61, 62, 64,	Output 0) 86: Terminal AM output level (Same display as Analog Output				
776 M103	Second motor protection current level			67, 68, 81 to 96, 98,	1) The count of the setting values "82" and "83" returns to "0" if the count exceeds "9999". The upper limit of the count of the setting value "84" is "9999".				
331 N030	RS-485 communication station number	0		0 to 127 *1	Set the inverter station number (node).				
332 N031	RS-485 communication speed	96		96, 192, 384, 576, 768, 1152 *1*2	Set the communication speed.  The setting value × 100 equals the communication speed.  For example, the communication speed is 9600 bps when the setting value is "96".				
390 N054	% setting reference frequency	60 Hz	50 Hz	1 to 590 Hz	Set a reference frequency of the set frequency.				
549				0	Mitsubishi inverter (computer link) protocol				
N000	Protocol selection	0		1	Modbus-RTU protocol				
11000				2	BACnet MS/TP protocol				
726 N050	Auto Baudrate/Max Master	255		255		255		0 to 255	Auto baud rate (bit 7) 0: inactive, 1: active  Max Master (bit 0 to bit 6) setting range: 0 to 127
11000	indoto:				Maximum address for master node				
727 N051	Max Info Frames	1		1 to 255	Set the maximum number of frames that the inverter can transmit while it owns the token.				
728 N052	Device instance number (Upper 3 digits)	0		0 to 419 (0 to 418)	Device identifier When the combination of <b>Pr.728 and Pr.729</b> is not within "0 to 4194302", the setting is out of range. When <b>Pr.728</b> ="419", the setting range of <b>Pr.729</b> is "0 to				
729 N053	Device instance number (Lower 4 digits)	0		0 to 9999 (0 to 4302)	when <b>Pr.728</b> ="419", the setting range of <b>Pr.729</b> is "0 to 4302".  When <b>Pr.729</b> ="4303" or more, the setting range of <b>Pr.728</b> is "0 to 418".				

<sup>\*1</sup> When the set value is outside of the setting range, the initial value is applied.

<sup>\*2</sup> When the Auto baudrate is used, the communication speed is changed to the detected communication speed.

### **◆**Communication specifications

• The specifications conform to the BACnet standard of physical medium EIA-485.


Item		Description				
Physical r	medium	EIA-485 (RS-485)				
	Connection port	RS-485 terminals (PU connector is not available.)				
	Data transfer method	NRZ encoding				
	Baud rate	9600 bps, 19200 bps, 38400 bps, 57600 bps, 76800 bps, 115200 bps				
	Start bit	Fixed to 1 bit				
	Data length	Fixed to 8 bits				
	Parity bit	Fixed to none				
	Stop bit	Fixed to 1 bit				
Network t	opology	Bus topology				
Communi	cation method	Token passing (token bus)				
Commun	cation method	Master-slave (Only the master is available for this product.)				
Communi	cation protocol	MS/TP (master-slave/token passing LAN)				
Maximum	connection	255 (up to 32 for one segment, addition with a repeater available)				
Node nun	nber	0 to 127				
	Master	0 to 127 (This product is the master.)				
	d property of BACnet object type	Refer to page 483.				
Supported	d BIBBs (Annex K)	Refer to page 491.				
BACnet standard device profile (Annex L)		Refer to page 491.				
Segmenta	ation	Not supported				
Device ac	ddress binding	Not supported				

### NOTE

- This product conforms to BACnet Application Specific Controller (B-ASC).
- This product is designed for multiple master network, therefore 2-wire type connection is supported.

#### Node with network bias resistors

- This product is a node with local bias resistors. Therefore at least one node must be a node with network bias resistors in the network configuration.
- When configuring the network with only this products, refer to the following, and make the node with network bias resistors. (When using two sets in one segment, insert them into both ends of the network.)



#### **◆BACnet reception status monitor (Pr.52)**


• Set Pr.52="81" to monitor the BACnet communication status on the operation panel.

Monitor value	Status	Description	LF signal output
0	Idle	Never had BACnet communication	OFF
1	Automatic baud rate recognition	Automatic baud rate recognition (Communication error during automatic baud rate recognition is not counted.)	OFF
2	Not joined the network	Waiting for a token to own node	OFF
10		Received a token to own node	OFF
11	Data to own node Received a supported request to own node (including broadcasting)		OFF
12		Received an unsupported request to own node (including broadcasting)	OFF
20	Data to other node	Received a token to other nodes	OFF
30	Node separated	Separated from token passing after joined in it	OFF
90		Detected a communication error	ON
91	Error data	Protocol error (LPDU, NPDU, APDU are not following the format regulations.)	ON

### **♦**% setting reference frequency (Pr.390)

• Set a reference frequency of the set frequency. The setting value of **Pr.390** % **setting reference frequency** is 100% reference. The ratio of the frequency command is converted to the set frequency in the following formula.

Set frequency = % setting reference frequency × Speed scale (Refer to page 485)



### • NOTE

- · The % setting reference frequency cannot be set at less than the minimum frequency resolution of the inverter.
- The set frequency is written to RAM.
- The set frequency is applied at the writing of Speed scale. (The set frequency is not applied at the setting of Pr.390.)

### Automatic baud rate recognition (Pr.726 Auto Baudrate/Max Master)

Automatic changing of baud rate is available with Pr.726 setting. When Pr.726="128 to 255", turn the power ON from OFF
or reset the inverter to start automatic baud rate recognition.

Pr.726 setting	Operation
0 to 127	Automatic baud rate recognition is invalid. (The <b>Pr.332</b> setting is used as the baud rate.)
128 to 255	The inverter monitors the data on the communication bus, and automatically switches the baud rate.  The recognized baud rate is written to <b>Pr.332</b> .

### • NOTE

- After the baud rate recognition, the recognized baud rate is written in EEPROM as the Pr.332 setting regardless of the Pr.342
   Communication EEPROM write selection setting.
- The BACnet status monitor displays "1" during automatic baud rate recognition.
- The communication error monitor count is not performed during automatic baud rate recognition.
- During automatic baud rate recognition, the inverter does not transmit data, but only accepts data.
- The baud rate switching operation cannot be finished if the inverter is not connected to the communication bus. (BACnet protocol will not be established.)
- The baud rate switching operation cannot be finished if the inverter is continuously receiving abnormal data during automatic baud rate switching. (BACnet protocol will not be established.)

### **♦** Supported property of BACnet standard object type

R: Read only, W: Read/Write (Commandable values not supported), C: Read/Write (Commandable values supported)

	Object support condition			n			
Property	Analog Input	Analog Output	Analog Value	Binary Input	Binary Output	Binary Value	Device
APDU Timeout							R
Application Software Version							R
Database Revision							R
Device Address Binding							R
Event State	R	R	R	R	R	R	
Firmware Revision							R
Max APDU Length Accepted							R
Max Info Frames							W
Max Master							W
Model Name							R
Number of APDU Retries							R
Object Identifier	R	R	R	R	R	R	R
Object List							R
Object Name	R	R	R	R	R	R	R
Object Type	R	R	R	R	R	R	R
Out Of Service	R	R	R	R	R	R	
Polarity				R	R		
Present Value	R	С	C*1	R	С	C*1	
Priority Array		R	R*2		R	R*2	
Protocol Object Types Supported							R
Protocol Revision							R
Protocol Services Supported							R
Protocol Version							R
Relinquish Default		R	R*2		R	R*2	
Segmentation Supported							R
Status Flags	R	R	R	R	R	R	
System Status							R
Unit	R	R	R				
Vendor Identifier							R
Vendor Name							R

- \*1 This property is commandable for some instances of this object. Otherwise it is read/write.
- \*2 This property is supported only for instances of this object where the Present Value property is commandable.

### **♦**Supported BACnet object

#### **+ ANALOG INPUT**

Object identifier	Object name	Present value Description		Unit
0	Terminal 1	R	Represents actual input voltage of terminal 1. (The range varies depending on the <b>Pr.73 and Pr.267</b> settings10 to +10 V (-100% to +100%), -5 to +5 V (-100% to +100%))	percent (98)
1	Terminal 2	R	Represents actual input voltage (or input current) of terminal 2.  (The range varies depending on the Pr.73 and Pr.267 settings.  0 to 10 V (0% to 100%),  0 to 5 V (0% to 100%),  0 to 20 mA (0% to 100%))	percent (98)
2	Terminal 4	R	Represents actual input voltage (or input current) of terminal 4.  (The range varies depending on the Pr.73 and Pr.267 settings. 2 to 10 V (0% to 100%), 1 to 5 V (0% to 100%), 4 to 20 mA (0% to 100%))	percent (98)

<sup>\*1</sup> R: Read only, W: Read/Write (Commandable values not supported), C: Read/Write (Commandable values supported)

#### ANALOG OUTPUT

Object identifier	Object name	Present value access type*1		Unit
0	Terminal FM (CA)	С	Controls actual output current level of terminal FM/CA. Control is available when <b>Pr.54 FM/CA terminal function selection=</b> "85"*2. (Setting range: 0 to 200%)	percent (98)
1	Terminal AM	С	Controls actual output voltage level of terminal AM. Control is available when <b>Pr.158 AM terminal function selection=</b> "86"*2. (Setting range: -200 to 200%)	percent (98)

<sup>\*1</sup> R: Read only, W: Read/Write (Commandable values not supported), C: Read/Write (Commandable values supported) Values written to the objects that support the commandable values are stored in the Priority Array, even when "Write Access Denied" is returned due to inconsistency of the writing requirements such as the operating mode, on condition that the values are written within the setting range.

#### **\* ANALOG VALUE**

Object identifier	Object name	Present value access type*1	Description	Unit
1	Output frequency	R	Represents the output frequency monitor.	hertz (27)
2	Output current	R	Represents the output current monitor.	amperes (3)
3	Output voltage	R	Represents the output voltage monitor.	volts (5)
6	Running speed	R	Represents the running speed monitor.	revolution- per-minute (104)
8	Converter output voltage	R	Represents the converter output voltage monitor.	volts (5)
14	Output power	R	Represents the output power monitor.	kilowatts (48)
17	Load meter	R	Represents the load meter monitor.	percent (98)
20	Cumulative energization time	R	Represents the cumulative energization time monitor.	hours (71)
23	Actual operation time	R	Represents the actual operation time monitor.	hours (71)

<sup>\*2</sup> Available regardless of the operation mode, operation command source, and speed command source.

Object identifier	Chiect name		Description	Unit	
25	Cumulative power	R	Represents the cumulative power monitor.	kilowatt- hours (19)	
52	PID set point	R	Represents the PID set point monitor.		
54	PID deviation	R	Represents the PID deviation monitor. (Minus display is available with reference to 0%, in 0.1% increment.)	no-units (95)	
67	PID measured value 2	R	Represents the PID measured value 2 monitor.	no-units (95)	
92	Second PID set point	R	Represents the second PID set point monitor.	no-units (95)	
94	Second PID deviation	R	Represents the second PID deviation monitor. (Minus display is available with reference to 0%, in 0.1% increment.)	no-units (95)	
95	Second PID measured value 2	R	Represents the second PID measured value 2 monitor.	no-units (95)	
200	Alarm history 1	R	Represents the fault history 1 (the latest fault) monitor.	no-units (95)	
201	Alarm history 2	R	Represents the fault history 2 (second fault in past) monitor.	no-units (95)	
202	Alarm history 3	R	Represents the fault history 3 (third fault in past) monitor.	no-units (95)	
203	Alarm history 4	R	Represents the fault history 4 (fourth fault in past) monitor.	no-units (95)	
300	Speed scale *2	С	Controls the ratio of the frequency command. (Setting range: 0.00 to 100.00) (Refer to page 482.)		
310	PID set point CMD *2	С	Set the PID action set point.  This object is the set point during PID operation if <b>Pr.128</b> = "60 or 61". (Setting range: 0.00 to 100.00)*3		
311	PID measured value CMD *2	С	Set the PID measured value.  This object is the measured value during PID operation if  Pr.128 = "60 or 61". (Setting range: 0.00 to 100.00)*3	no-units (95)	
312	PID deviation CMD *2	С	Set the PID deviation. (0.01 increment) This object is the deviation during PID operation if <b>Pr.128</b> = "50 or 51". (Setting range: -100.00 to 100.00)	percent (98)	
320	Second PID set point CMD	С	Set the second PID action set point.  This object is the set point during PID operation if <b>Pr.753</b> = "60 or 61". (Setting range: 0.00 to 100.00)*3	no-units (95)	
321	Second PID measured value CMD	С	Set the second PID measured value.  This object is the measured value during PID operation if Pr.753 = "60 or 61". (Setting range: 0.00 to 100.00)*3		
322	Second PID deviation CMD	С	Set the second PID deviation. (0.01 increment) This object is the deviation during PID operation if <b>Pr.753</b> = "50 or 51". (Setting range: -100.00 to 100.00)		
398	Mailbox parameter	W	Access to the properties which are not defined as objects	no-units (95)	
399	Mailbox value	W	are available. (Refer to page 488.)	no-units (95)	
10007	Acceleration time	W	Set Pr.7 Acceleration time.	seconds (73)	
10008	Deceleration time	W	Set Pr.8 Deceleration time.	seconds (73)	

<sup>\*1</sup> R: Read only, W: Read/Write (Commandable values not supported), C: Read/Write (Commandable values supported) Values written to the objects that support the commandable values are stored in the Priority Array, even when "Write Access Denied" is returned due to inconsistency of the writing requirements such as the operating mode, on condition that the values are written within the setting range.

<sup>\*2</sup> If communication speed command source is other than NET, the setting value can be written, but not to be applied.

<sup>\*3</sup> When both C42 (Pr.1136) and C44 (Pr.1138) ≠ "9999", the setting range is from the smaller coefficient to the Inarger coefficiet of C42 (Pr.1136) and C44 (Pr.1138). Depending on the setting, the writing value and the reading value may not be the same at the minimum digit.

#### **+ BINARY INPUT**

Object identifier	Object name	Present value access type+1	Description (0: Inactive, 1: Active)
0	Terminal STF	R	Represents actual input of terminal STF.
1	Terminal STR	R	Represents actual input of terminal STR.
2	Terminal AU	R	Represents actual input of terminal AU.
3	Terminal RT	R	Represents actual input of terminal RT.
4	Terminal RL	R	Represents actual input of terminal RL.
5	Terminal RM	R	Represents actual input of terminal RM.
6	Terminal RH	R	Represents actual input of terminal RH.
7	Terminal JOG	R	Represents actual input of terminal JOG.
8	Terminal MRS	R	Represents actual input of terminal MRS.
9	Terminal STOP	R	Represents actual input of terminal STOP.
10	Terminal RES	R	Represents actual input of terminal RES.
11	Terminal CS	R	Represents actual input of terminal CS.
100	Terminal RUN	R	Represents actual output of terminal RUN.
101	Terminal SU	R	Represents actual output of terminal SU.
102	Terminal IPF	R	Represents actual output of terminal IPF.
103	Terminal OL	R	Represents actual output of terminal OL.
104	Terminal FU	R	Represents actual output of terminal FU.
105	Terminal ABC1	R	Represents actual output of terminal ABC1.
106	Terminal ABC2	R	Represents actual output of terminal ABC2.
107	Terminal SO	R	Represents actual output of terminal SO.

<sup>\*1</sup> R: Read only, W: Read/Write (Commandable values not supported), C: Read/Write (Commandable values supported)

#### **\*BINARY OUTPUT**

Object identifier	Object name	Present value access type*1	Description (0: Inactive, 1: Active)
0	Terminal RUN CMD	С	Represents actual output of terminal RUN. Available when <b>Pr.190 RUN terminal function selection=</b> "82 or 182".*2
1	Terminal SU CMD	С	Controls actual output of terminal SU. Available when <b>Pr.191 SU terminal function selection=</b> "82 or 182".*2
2	Terminal IPF CMD	С	Controls actual output of terminal IPF. Available when <b>Pr.192 IPF terminal function selection=</b> "82 or 182".*2
3	Terminal OL CMD	С	Controls actual output of terminal OL. Available when <b>Pr.193 OL terminal function selection=</b> "82 or 182".*2
4	Terminal FU CMD	С	Controls actual output of terminal FU. Available when <b>Pr.194 FU terminal function selection=</b> "82 or 182".*2
5	Terminal ABC1 CMD	С	Controls actual output of terminal ABC1. Available when <b>Pr.195 ABC1 terminal function selection=</b> "82 or 182".*2
6	Terminal ABC2 CMD	С	Controls actual output of terminal ABC2. Available when <b>Pr.196 ABC2 terminal function selection=</b> "82 or 182".*2

<sup>\*1</sup> R: Read only, W: Read/Write (Commandable values not supported), C: Read/Write (Commandable values supported) Values written to the objects that support the commandable values are stored in the Priority Array, even when "Write Access Denied" is returned due to inconsistency of the writing requirements such as the operating mode, on condition that the values are written within the setting range.

<sup>\*2</sup> Available regardless of the operation mode, operation command source, and speed command source.

#### **+ BINARY VALUE**

Object	211	Present value		
identifier	Object name	access type*1	Description (DUN) size (No. 44.44)	
0	Inverter running	R	Represents inverter running (RUN signal) status.	
11	Inverter operation ready	R	Represents inverter operation ready (RY signal) status.	
98	Alarm output	R	Represents alarm output (LF signal) status.	
99	Fault output	R	Represents fault output (ALM signal) status.	
200	Inverter running reverse	R	Represents inverter reverse running status.	
300	Control input instruction AU	С	Controls the function assigned to terminal AU. Setting 1 in this object turns ON the signal assigned to <b>Pr.184 AU terminal</b> function selection.	
301	Control input instruction RT	С	Controls the function assigned to terminal RT. Setting 1 in this object turns ON the signal assigned to <b>Pr.183 RT terminal</b> function selection.	
302	Control input instruction RL	С	Controls the function assigned to terminal RL. Setting 1 in this object turns ON the signal assigned to <b>Pr.180 RL terminal function selection</b> .	
303	Control input instruction RM	С	Controls the function assigned to terminal RM. Setting 1 in this object turns ON the signal assigned to <b>Pr.181 RM terminal</b> function selection.	
304	Control input instruction RH	С	Controls the function assigned to terminal RH. Setting 1 in this object turns ON the signal assigned to <b>Pr.182 RH terminal</b> function selection.	
305	Control input instruction JOG *2	С	Controls the function assigned to terminal JOG. Setting 1 in this object turns ON the signal assigned to <b>Pr.185 JOG terminal function selection</b> .	
306	Control input instruction MRS	С	Controls the function assigned to terminal MRS. Setting 1 in this object turns ON the signal assigned to <b>Pr.187 MRS terminal function selection</b> .	
307	Control input instruction STOP *2	С	Controls the function assigned to terminal STOP. Setting 1 in this object turns ON the signal assigned to <b>Pr.188 STOP terminal function selection</b> .	
308	Control input instruction RES *2	С	Controls the function assigned to terminal RES. Setting 1 in this object turns ON the signal assigned to <b>Pr.189 RES</b> terminal function selection.	
309	Control input instruction CS *2	С	Controls the function assigned to terminal CS. Setting 1 in this object turns ON the signal assigned to <b>Pr.186 CS terminal function selection</b> .	
400	Run/Stop	С	Controls the start/stop command. The start command is written after the Speed scale is applied. *3  1: Start  0: Stop	
401	Forward/Reverse	С	Controls the forward/reverse rotation. *3  1: Reverse rotation  0: Forward rotation	
402	Fault reset	С	Clears fault output status. (Release of an inverter fault without inverter reset is available.)	

- \*1 R: Read only, W: Read/Write (Commandable values not supported), C: Read/Write (Commandable values supported) Values written to the objects that support the commandable values are stored in the Priority Array, even when "Write Access Denied" is returned due to inconsistency of the writing requirements such as the operating mode, on condition that the values are written within the setting range.
- \*2 The following signals cannot be controlled by the network: Jog operation, selection of automatic restart after instantaneous power failure, start self-holding, and reset. Therefore control input instruction JOG, STOP, RES, and CS are invalid in the initial status. To use the control input instruction JOG, STOP, RES, and CS, change the signals with Pr.185, Pr.186, Pr.188, Pr.189 (input terminal function selection). (Refer to page 329.) (Reset is available with ReinitializeDevice.)
- \*3 If communication operation command source is other than NET, the setting value can be written, but not to be applied.

### **♦** Mailbox parameter / Mailbox value (BACnet registers)

- Access to the properties which are not defined as objects are available by using "Mailbox parameter" and "Mailbox value".
- To read a property, write the register of the intended property to "Mailbox parameter", and then read "Mailbox value". To write a property, write the register of the intended property to "Mailbox parameter", and then write a value to "Mailbox value".
- · System environment variable

Register	Definition	Read/ write	Remarks
40010	Operation mode / inverter setting	Read/write	For write, set data as the operation mode setting. For read, data is read as the operation mode status.

#### <Operation mode / inverter setting>

Mode	Read value	Write value
EXT	H0000	H0010 *1
PU	H0001	H0011 *1
EXT JOG	H0002	-
PU JOG	H0003	-
NET	H0004	H0014
PU + EXT	H0005	-

<sup>\*1</sup> Writing is available depending on the Pr.79 and Pr.340 settings. For the details, refer to page 209. The restrictions depending on the operation mode changes according to the computer link specifications.

· Real time monitor

The register numbers and the monitor items are the same as those of the Modbus-RTU real time monitor. Refer to the Modbus-RTU real time monitor on page 263.

Parameter

Pr.	Register	Parameter name	Read/ write	Remarks
0 to 999	41000 to 41999	Refer to the parameter list (page 112) for parameter names.	Read/write	The parameter number + 41000 is the register number.
C2 (902)	41902	Terminal 2 frequency setting bias (frequency)	Read/write	
C2 (002)	42092	Terminal 2 frequency setting bias (analog value)	Read/write	Analog value (%) set to C3 (902)
C3 (902)	43902	Terminal 2 frequency setting bias (terminal analog value)	Read	Analog value (%) of the voltage (current) applied to the terminal 2
125(903)	41903	Terminal 2 frequency setting gain (frequency)	Read/write	
C4 (903)	42093	Terminal 2 frequency setting gain (analog value)	Read/write	Analog value (%) set to C4 (903)
C4 (903)	43903	Terminal 2 frequency setting gain (terminal analog value)	Read	Analog value (%) of the voltage (current) applied to the terminal 2
C5 (904)	41904	Terminal 4 frequency setting bias (frequency)	Read/write	
C6 (904)	42094	Terminal 4 frequency setting bias (analog value)	Read/write	Analog value (%) set to C6 (904)
C6 (904)	43904	Terminal 4 frequency setting bias (terminal analog value)	Read	Analog value (%) of the current (voltage) applied to the terminal 4
126(905)	41905	Terminal 4 frequency setting gain (frequency)	Read/write	
C7 (905)	42095	Terminal 4 frequency setting gain (analog value)	Read/write	Analog value (%) set to C7 (905)
O7 (800)	43905	Terminal 4 frequency setting gain (terminal analog value)	Read	Analog value (%) of the current (voltage) applied to the terminal 4
C12 (917)	41917	Terminal 1 bias frequency (speed)	Read/write	

Pr.	Register	Parameter name	Read/ write	Remarks
	42107	Terminal 1 bias (speed)	Read/write	Analog value (%) set to C13 (917)
C13 (917)	43917	Terminal 1 bias (speed) (terminal analog value)	Read	Analog value (%) of the voltage applied to the terminal 1
C14 (918)	41918	Terminal 1 gain frequency (speed)	Read/write	
	42108	Terminal 1 gain (speed)	Read/write	Analog value (%) set to C15 (918)
C15 (918)	43918	Terminal 1 gain (speed) (terminal analog value)	Read	Analog value (%) of the voltage applied to the terminal 1
C16 (919)	41919	Terminal 1 bias command (torque)	Read/write	
	42109	Terminal 1 bias (torque)	Read/write	Analog value (%) set to C17 (919)
C17 (919)	43919	Terminal 1 bias (torque) (terminal analog value)	Read	Analog value (%) of the voltage applied to the terminal 1
C18 (920)	41920	Terminal 1 gain command (torque)	Read/write	
	42110	Terminal 1 gain (torque)	Read/write	Analog value (%) set to C19 (920)
C19 (920)	43920	Terminal 1 gain (torque) (terminal analog value)	Read	Analog value (%) of the voltage applied to the terminal 1
C9 (930)	42120	Current output bias current	Read/write	Analog value (%) set to C9 (930)
C11 (931)	42121	Current output gain current	Read/write	Analog value (%) set to C11 (931)
C38 (932)	41932	Terminal 4 bias command (torque)	Read/write	
	42122	Terminal 4 bias (torque)	Read/write	Analog value (%) set to C39 (932)
C39 (932)	43932	Terminal 4 bias (torque) (terminal analog value)	Read	Analog value (%) of the current (voltage) applied to the terminal 4
C40 (933)	41933	Terminal 4 gain command (torque)	Read/write	
	42123	Terminal 4 gain (torque)	Read/write	Analog value (%) set to C41 (933)
C41 (933)	43933	Terminal 4 gain (torque) (terminal analog value)	Read	Analog value (%) of the current (voltage) applied to the terminal 4
C42 (934)	41934	PID display bias coefficient	Read/write	
	42124	PID display bias analog value	Read/write	Analog value (%) set to C43 (934)
C43 (934)	43934	PID display bias analog value (terminal analog value)	Read	Analog value (%) of the current (voltage) applied to the terminal 4
C44 (935)	41935	PID display gain coefficient	Read/write	
	42125	PID display gain analog value	Read/write	Analog value (%) set to C45 (935)
C45 (935)	43935	PID display gain analog value (terminal analog value)	Read	Analog value (%) of the current (voltage) applied to the terminal 4
1000 to 1999	45000 to 45999	Refer to the parameter list (page 112) for parameter names.	Read/write	The parameter number + 44000 is the register number.

#### Faults history

Register	Definition	Read/write	Remarks
40501	Faults history 1	Read/write	
40502	Faults history 2	Read	Being 2 bytes in length, the data is stored as "H00OO".
40503	Faults history 3	Read	Refer to the lowest 1 byte for the error code. (Refer to page 533
40504	Faults history 4	Read	for the error codes.)
40505	Faults history 5	Read	Performing write using the register 40501 batch-clears the faults
40506	Faults history 6	Read	history.
40507	Faults history 7	Read	Set any value as data.
40508	Faults history 8	Read	

### (N) Operation via communication and its settings

#### · Model information monitor

Register	Definition	Read/write	Remarks
44001	Inverter type (1st and 2nd characters)	Read	Reading inverter type in ASCII code. "H20" (blank code) is set for blank area. Example) For the "FR-F840-1 (FM type)", H46, H52, H2D, H46, H38, H34, H30, H2D, H31, H20H20
44002	Inverter type (3rd and 4th characters)	Read	
44003	Inverter type (5th and 6th characters)	Read	
44004	Inverter type (7th and 8th characters)	Read	
44005	Inverter type (9th and 10th characters)	Read	
44006	Inverter type (11th and 12th characters)	Read	
44007	Inverter type (13th and 14th characters)	Read	
44008	Inverter type (15th and 16th characters)	Read	
44009	Inverter type (17th and 18th characters)	Read	
44010	Inverter type (19th and 20th characters)	Read	
44011	Capacity (1st and 2nd characters)	Read	Reading inverter capacity in ASCII code.  Data is read in increments of 0.1 kW, and rounds down to 0.01 kW increments.
44012	Capacity (3rd and 4th characters)	Read	
44013	Capacity (5th and 6th characters)	Read	"H20" (blank code) is set for blank area.  Example) 0.75K" 7" (H20, H20, H20, H20, H20, H37)



• When a 32-bit parameter setting or monitor item is read and the value to be read exceeds HFFFF, HFFFF is returned.

### **♦** ANNEX A - PROTOCOL IMPLEMENTATION CONFORMANCE **STATEMENT (NORMATIVE)**

(This annex is part of this Standard and is required for its use.)

#### **BACnet Protocol Implementation Conformance Statement**

Date: 1st Jul 2014	
Vendor Name: Mitsubishi Electric Corpor	ration
Product Name: Inverter	
Product Model Number: FR-F820-1, FR-	F820-2, FR-F840-1, FR-F840-2, FR-F842-1, FR-F842-2
Application Software Version: 8463*	
Firmware Revision: 1.00	
BACnet Protocol Revision: 4	
Product Description:	
BACnet Standardized Device Pr	rofile (Annex L):
☐ BACnet Operator Workstation (B-OWS	3)
☐ BACnet Building Controller (B-BC)	
☐ BACnet Advanced Application Controll	ler (B-AAC)
☑ BACnet Application Specific Controller	(B-ASC)
☐ BACnet Smart Sensor (B-SS)	
☐ BACnet Smart Actuator (B-SA)	
List all BACnet Interoperability	Building Blocks Supported (Annex K):
DS-RP-B, DS-WP-B, DM-DDB-B, DM-DC	DB-B, DM-DCC-B, DM-RD-B
Segmentation Capability:	
☐ Segmented requests supported Wi	indow Size
☐ Segmented responses supported Wi	ndow Size

#### (N) Operation via communication and its settings

#### **Standard Object Types Supported:**

An object type is supported if it may be present in the device. For each standard Object Type supported provide the following data:

- 1) Whether objects of this type are dynamically creatable using the CreateObject service
- 2) Whether objects of this type are dynamically deletable using the DeleteObject service
- 3) List of the optional properties supported
- 4) List of all properties that are writable where not otherwise required by this standard
- 5) List of all properties that are conditionally writable where not otherwise required by this standard
- 6) List of proprietary properties and for each its property identifier, datatype, and meaning
- 7) List of any property range restrictions

Dynamic object creation and deletion is not supported.

For the object types supported by the FR-F800 series, refer to page 484.
Data Link Layer Options:
☐ BACnet IP, (Annex J)
☐ BACnet IP, (Annex J), Foreign Device
☐ ISO 8802-3, Ethernet (Clause 7)
☐ ANSI/ATA 878.1, 2.5 Mb. ARCNET (Clause 8)
☐ ANSI/ATA 878.1, RS-485 ARCNET (Clause 8), baud rate(s)
☑ MS/TP master (Clause 9), baud rate(s): <u>9600, 19200, 38400, 76800</u>
☐ MS/TP slave (Clause 9), baud rate(s):
☐ Point-To-Point, EIA 232 (Clause 10), baud rate(s):
☐ Point-To-Point, modem, (Clause 10), baud rate(s):
☐ LonTalk, (Clause 11), medium:
□ Other:
Device Address Binding:
Is static device binding supported? (This is currently necessary for two-way communication with MS/TP slaves and certain
other devices.) ☐ Yes   ☑ No
Networking Options:
☐ Router, Clause 6 - List all routing configurations, e.g., ARCNET-Ethernet, Ethernet-MS/TP, etc.
☐ Annex H, BACnet Tunneling Router over IP
☐ BACnet/IP Broadcast Management Device (BBMD)
Does the BBMD support registrations by Foreign Devices? ☐ Yes ☐ No
Character Sets Supported:
• •
Indicating support for multiple character sets does not imply that they can all be supported simultaneously.
☑ ANSI X3.4 ☐ IBM™/Microsoft™ DBCS ☐ ISO 8859-1
☐ ISO 10646 (UCS-2) ☐ ISO 10646 (UCS-4) ☐ JIS C 6226
If this product is a communication gateway, describe the types of non-BACnet equipment networks(s) that the gateway supports:

#### 5.12.8 **USB** device communication

A personal computer and an inverter can be connected with a USB cable. Setup of the inverter can be easily performed with FR Configurator2.


The inverter can be connected simply to a personal computer by a USB cable.

Pr.	Name	Initial value	Setting range	Description
547*1 N040	USB communication station number	0	0 to 31	Inverter station number specification
E40 .1	548 •1 USB communication N041 check time interval		0	USB communication is possible, however the inverter will trip (E.USB) when the mode changes to the PU operation mode.
N041		9999	0.1 to 999.8 s	Set the communication check time interval.  If a no-communication state persists for longer than the permissible time, the inverter will trip (E.USB).
			9999	No communication check

<sup>\*1</sup> Changed setting value becomes valid at power ON or the inverter reset.

#### **♦USB** communication specifications

Interface	Conforms to USB1.1 (USB2.0 full speed)
Transmission speed	12 Mbps
Wiring length	Maximum 5 m
Connector	USB mini B connector (receptacle)
Power supply	Self-powered
Recommended USB cable	MR-J3USBCBL3M (cable length 3 m)



- At the initial setting (Pr.551 PU mode operation command source selection = "9999"), communication with FR Configurator2 can be made in the PU operation mode simply by connecting a USB cable. To fix the command source to the USB connector in the PU operation mode, set "3" to Pr.551.
- · Parameter setting and monitoring can be performed by FR Configurator2. For details, refer to the Instruction Manual of FR Configurator2.

#### Parameters referred to

Pr.551 PU mode operation command source selection page 210


#### 5.12.9 **Automatic connection with GOT**

When the automatic connection is enabled in the GOT2000 series, the inverter can communicate with the GOT2000 series with only setting the station number and connecting the GOT. This eliminates the need for the communication parameter setting.

Pr.	Name	Initial value	Setting range	Description
117 N020	PU communication station number	0	0 to 31	Set the inverter station numbers.  The inverter station number setting is required when multiple inverters are connected to one GOT (PU connector communication).
331 N030	RS-485 communication station number	0	0 to 31 (0 to 247)*1*2	Set the inverter station numbers.  The inverter station number setting is required when multiple inverters are connected to one GOT (RS-485 terminal communication).

- When Pr.549 Protocol selection = "1" (Modbus-RTU protocol), the setting range is as shown in the parentheses.
- \*2 When the set value is outside of the setting range, the initial value is applied.

#### Automatic connection system configuration



## **♦GOT2000** series automatic recognition

- When the GOT2000 series is connected, the parameters required for the GOT connection are automatically changed by setting the automatic recognition on the GOT2000 series side.
- Set the station number (Pr.117 or Pr.331) of the inverter before the automatic recognition is performed.
- · Connect all the stations of inverters with GOT before the automatic recognition is performed. The inverter newly added after automatic recognition will not be recognized automatically. (When an inverter is added, perform the initial setting in Pr.999 Automatic parameter setting or set the automatic recognition on the GOT side again.)

Automotic change item	Automatic ch	Automatic change parameter				
Automatic change item	PU connector connection	RS-485 terminal connection	change			
Communication speed	Pr.118	Pr.332				
Data length/stop bit	Pr.119	Pr.333	Depending on the setting			
Parity	Pr.120	Pr.334	of the connected device			
Waiting time setting	Pr.123	Pr.337	on the GOT side.			
CR/LF selection	Pr.124	Pr.341	7			
Number of communication retries	Pr.121	Pr.335	9999 (fixed)			
Communication check time interval	Pr.122	Pr.336	9999 (fixed)			
Protocol selection	— (Pr.549 holds the value before	Pr.549	0 (fixed to Mitsubishi			
Protocol selection	the automatic recognition.)	F1.545	inverter protocol)			

## NOTE:

- · If the automatic recognition cannot be performed, initial setting in Pr.999 is required.
- For connecting the inverter to the GOT2000 series using the RS-485 terminal block, set Pr.549 Protocol selection = "0 (initial value) or 1".
- For connection to a device other than the GOT2000 series, initial setting in Pr.999 is required.
- For details, refer to the GOT2000 Series Connection Manual (Mitsubishi Product).

#### # Parameters referred to

Pr.999 Automatic parameter setting page 173

#### 5

# **5.13** (G) Control parameters

Purpose		Parameter to set				
To set the starting torque manually	Manual torque boost	P.G000, P.G010	Pr.0, Pr.46	496		
To set the motor constant	Base frequency, base frequency voltage	P.G001, P.G002, P.G011	Pr.3, Pr.19, Pr.47	497		
To select the V/F pattern matching the application	Load pattern selection	P.G003	Pr.14	499		
To perform energy saving operation	Energy saving operation	P.G030	Pr.60	500		
To use a special motor	Adjustable 5 points V/F	P.C100, P.G040 to P.G049	Pr.71, Pr.100 to Pr.109	501		
To compensate the motor slip amount when replacing an SF-JR motor with an SF-PR motor	SF-PR slip amount adjustment mode	P.G060, P.G061	Pr.673, Pr.674	502		
To adjust the motor braking torque	DC injection brake	P.G100, P.G101, P.G110	Pr.10 to Pr.12	502		
	Output stop function	P.G105	Pr.522	505		
To coast the motor to a stop	Selection of motor stop method	P.G106	Pr.250	507		
To use the regeneration unit to increase the motor braking torque	Regenerative brake selection	P.E300, P.T721	Pr.30, Pr.599	508		
To operate the inverter with DC power supply	DC feeding mode	P.E300	Pr.30	508		
To avoid overvoltage alarm due to regenerative driving by automatic adjustment of the output frequency	Regeneration avoidance function	P.G120 to P.G125	Pr.882 to Pr.886, Pr.665	514		
To decrease the deceleration time of the motor	Increased magnetic excitation deceleration	P.G130 to P.G132	Pr.660 to Pr.662	517		
To select the control method	Control method selection	P.G200	Pr.800	143		
To secure the low-speed torque by compensating the slip of the motor	Slip compensation	P.G203 to P.G205	Pr.245 to Pr.247	518		
To adjust the speed control gain	Speed control gain	P.G211, P.G212 P.G311, P.G312	Pr.820, Pr.821, Pr.830, Pr.831	154		
To adjust the torque control gain	Torque control gain	P.G213, P.G214, P.G313, P.G314	Pr.824, P.825, Pr.834, P.835	154		
To stabilizes torque feedback signal	Torque detection filter	P.G216, P.G316	Pr.827, Pr.837	158		
To suppress the machine resonance	Speed smoothing control	P.G410, P.G411	Pr.653, Pr.654	519		
To adjust the speed gain for Advanced magnetic flux vector control	Speed control gain	P.G932, P.G942	Pr.89, Pr.569	147		

## 5.13.1 Manual torque boost

Voltage drop in the low-frequency range can be compensated, improving reduction of the motor torque in the low-speed range.


- Motor torque in the low-frequency range can be adjusted according to the load, increasing the motor torque at the start up.
- · By using the RT signal, it is possible to switch between 2 types of torque boost.

Pr.	Name	Initial value	Setting range	Description
		6%*1		
		4%*2		
0	Torque boost	3%*3	0 to 30%	Set the output voltage at 0 Hz in %.
G000	Torque boost	2%*4		Set the output voltage at 0 Hz III %.
		1.5%*5		
		1%*6		
46	Second torque boost 9999	0000	0 to 30%	Set the torque boost value at when RT signal is ON.
G010		8888	9999	Without second torque boost

- \*1 Initial value for the FR-F820-00046(0.75K) or lower and FR-F840-00023(0.75K) or lower.
- \*2 Initial values for the FR-F820-00077(1.5K) to FR-F820-00167(3.7K), FR-F840-00038(1.5K) to FR-F840-00083(3.7K).
- \*3 Initial values for the FR-F820-00250(5.5K), FR-F820-00340(7.5K), FR-F840-00126(5.5K), FR-F840-00170(7.5K).
- \*4 Initial values for the FR-F820-00490(11K) to FR-F820-01540(37K), FR-F840-00250(11K) to FR-F840-00770(37K).
- \*5 Initial value for the FR-F820-01870(45K), FR-F820-02330(55K), FR-F840-00930(45K), FR-F840-01160(55K).
- \*6 Initial value for the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.

#### **♦**Starting torque adjustment

- Assuming Pr.19 Base frequency voltage is 100%, set the output voltage at 0 Hz to Pr.0 (Pr.46, Pr.112) in percentage.
- Perform the adjustment of the parameter little by little (approximately 0.5%), and confirm the status of the motor each time. The motor may overheat when the value is set too high. Do not use more than 10% as a guideline.



## ◆Setting multiple torque boosts (RT signal, Pr.46)

- When changing the torque boost depending on the usage or when using single inverter switching between multiple motors, use the second torque boost.
- Pr.46 Second torque boost will become enabled when the RT signal turns ON.

## NOTE

- The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 333.)
- The RT signal is assigned to the terminal RT in the initial status. Set "3" in any of **Pr.178 to Pr.189 (input terminal function selection)** to assign the RT signal to another terminal.
- Set a larger value when the distance between the inverter and the motor is long or when there is not enough motor torque in the low-speed range. It may cause overcurrent trip when it is set too large.
- Setting for Pr.0 and Pr.46 becomes enabled only when the V/F control is selected.
- When the initial value is set in **Pr.0**, the **Pr.0** setting is automatically changed by changing the **Pr.71 Applied motor** setting. (Refer to page 337)
- Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### **« Parameters referred to »**

Pr.3 Base frequency, Pr.19 Base frequency voltage page 497

Pr.71 Applied motor \*\*page 337

Pr.178 to Pr.182 (input terminal function selection) page 329


## 5.13.2 Base frequency, voltage we

Use this function to adjust the inverter outputs (voltage, frequency) to match with the motor rating.

Pr.	Name		value	Setting	Description
PI.	Name	FM CA		range	Description
3 G001	Base frequency	60 Hz	50 Hz	0 to 590 Hz	Set the frequency at the rated motor torque. (50 Hz/60 Hz)
19				0 to 1000 V	Set the base voltage.
G002	Base frequency voltage	9999	8888	8888	95% of the power supply voltage
0002				9999	Same as the power supply voltage
47	Second V/F (base	0000		0 to 590 Hz	Set the base frequency at the RT signal ON.
G011	frequency)	9999		9999	Second V/F disabled

#### Setting of base frequency (Pr.3)

- When operating a standard motor, generally set the rated frequency of the motor in Pr.3 Base frequency. When the motor operation require switching to the commercial power supply, set the power supply frequency in Pr.3.
- When the frequency on the motor rating plate is only "50 Hz", make sure to set to "50 Hz". When it is set to "60 Hz", the voltage will drop too much, causing insufficient torque. As a result, the inverter may trip due to overload. A caution is required especially in case of Pr.14 Load pattern selection = "1" (variable torque load).
- When using the Mitsubishi constant torque motor, set Pr.3 to 60 Hz.



## ◆Setting multiple base frequencies (Pr.47)

- To change the base frequency when using single inverter switching between multiple motors, use Pr.47 Second V/F (base frequency).
- Pr.47 will become enabled when the RT signal turns ON.

## NOTE :

- The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 333.)
- The RT signal is assigned to the terminal RT in the initial status. It is also possible to assign the RT signal to other terminal by setting "3" on Pr.178 to Pr.189 (input terminal function selection).

#### ◆ Setting of base frequency voltage (Pr.19)

- For Pr.19 Base frequency voltage, set the base voltage (rated motor voltage, etc.).
- When it is set lower than the power supply voltage, maximum output voltage of the inverter will be the voltage set in Pr.19.
- Pr.19 can be used in following cases.
  - (a) Regenerative driving (continuous regeneration, etc.) is performed often

    Output voltage will get higher than the specification during the regenerative driving, which may cause overcurrent trip (E.OC[]) by the increase in motor current.
  - (b) When the fluctuation of power supply voltage is high When the power supply voltage exceeds the rated voltage of the motor, fluctuation of rotation speed or overheating of motor may occur due to excessive torque or increase in motor current.

#### • NOTE

- When the Advanced magnetic flux vector control or PM motor control is selected, **Pr.3**, **Pr.47** and **Pr.19** will become disabled, and **Pr.83** and **Pr.84** will become enabled.
- However, S-pattern curve with **Pr.29 Acceleration/deceleration pattern selection** = "1" (S-pattern acceleration/deceleration A) will make **Pr.3** or **Pr.47** enabled. (S-pattern curve at the time of the PM motor control is the rated frequency of the motor.)
- When **Pr.71 Applied motor** = "2" (adjustable 5 points V/F), setting for **Pr.47** will become disabled. Also, **Pr.19** cannot be set to "8888" or "9999".
- Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### # Parameters referred to

Pr.14 Load pattern selection page 499

Pr.29 Acceleration/deceleration pattern selection page 191

Pr.71 Applied motor page 337

Pr.83 Rated motor voltage, Pr.84 Rated motor frequency page 341

Pr.178 to Pr.189 (input terminal function selection) page 329

## 5


# 5.13.3 Load pattern selection

Optimal output characteristics (V/F characteristics) for application or load characteristics can be selected.

Pr.	Name	Initial value	Setting range	Description
14	Load pattern selection	1	0	For constant-torque load
G003	Load pattern selection	'	1	For variable-torque load

## ◆Application for constant-torque load (Pr.14 = "0")

- The output voltage will change linearly against the output frequency at the base frequency or lower.
- Set this parameter when driving a load that has constant load torque even when the rotation speed is changed, such as conveyor, dolly, or roll drive.




## POINT)

- Select for constant-torque load (setting value "0") even for fan and pump in following cases.
- When accelerating a blower with large moment of inertia (J) in a short period of time.
- When it is a constant-torque load such as rotary pump or gear pump.
- When the load torque increases in low speed such as screw pump.

## ◆Application for variable-torque load (Pr.14 = "1", initial value)

- The output voltage will change in square curve against the output frequency at the base frequency or lower. (1.75th-power curve for FR-F820-01540(37K) or higher, and FR-F840-00770(37K) or higher)
- Set this parameter when driving a load with load torque change proportionally against the square of the rotation speed, such as fan and pump.





• Pr.14 will become enabled at the time of V/F control.

#### Parameters referred to

Pr.0 Torque boost page 496
Pr.3 Base frequency page 497

Pr.178 to Pr.182 (input terminal function selection) page 329

## 5.13.4 Energy saving control Magneticities

Inverter will perform energy saving control automatically even when the detailed parameter settings are made. It is appropriate for applications such as fan and pump.

Pr.	Name	Initial value	Setting range	Description
60	Energy saving control selection	0	0	Normal operation
G030			4	Energy saving operation
3030			9	Optimum excitation control

#### ◆Energy saving operation (setting "4")

- Setting **Pr.60** = "4" will select the energy saving operation.
- With the energy saving operation, the inverter will automatically control the output voltage so the inverter output power during the constant-speed operation will become minimal.
- Energy saving operation will be enabled under V/F control.

#### ◆Optimum excitation control (setting "9")

- Setting **Pr.60** = "9" will select the Optimum excitation control.
- The Optimum excitation control is a control method to decide the output voltage by controlling the excitation current so the efficiency of the motor is maximized.
- · Optimum excitation control will be enabled under V/F control and Advanced magnetic flux vector control.

#### NOTE


- An energy saving effect is not expected with the energy saving operation mode for applications with high load torque or with the equipment with frequent acceleration and deceleration.
- An energy saving effect is not expected with the Optimum excitation control mode when the motor capacity is extremely small
  compared with the inverter capacity or when multiple motors are connected to a single inverter.
- When the energy saving operation mode or Optimum excitation control mode is selected, the deceleration time may become longer than setting value. Also, it may cause overvoltage more often compared to constant-torque load characteristics, so set the deceleration time longer.
- When the motor becomes unstable during the acceleration, set the acceleration time longer.
- Output current may increase slightly with the energy saving operation mode or the Optimum excitation control mode since the output voltage is controlled.

#### 5.13.5 Adjustable 5 points V/F

By setting a desired V/F characteristic from the start up to the base frequency or base voltage with the V/F control (frequency voltage/frequency), a dedicated V/F pattern can be generated.

Optimal V/F pattern matching the torque characteristics of the facility can be set.

Pr.	Name	Initial value	Setting range	Description
71 C100	Applied motor	0	2	Standard motor (such as SF-JR) Adjustable 5 points V/F
C 100			Others	Refer to page 337.
100 G040	V/F1 (first frequency)	9999	0 to 590 Hz, 9999	
101 G041	V/F1 (first frequency voltage)	0 V	0 to 1000 V	
102 G042	V/F2 (second frequency)	9999	0 to 590 Hz, 9999	
103 G043	V/F2 (second frequency voltage)	0 V	0 to 1000 V	
104 G044	V/F3 (third frequency)	9999	0 to 590 Hz, 9999	Set each point of the V/F pattern (frequency,
105 G045	V/F3 (third frequency voltage)	0 V	0 to 1000 V	voltage). 9999: Do not set V/F
106 G046	V/F4 (fourth frequency)	9999	0 to 590 Hz, 9999	
107 G047	V/F4 (fourth frequency voltage)	0 V	0 to 1000 V	
108 G048	V/F5 (fifth frequency)	9999	0 to 590 Hz, 9999	
109 G049	V/F5 (fifth frequency voltage)	0 V	0 to 1000 V	



- By setting the V/F1 (first frequency voltage/first frequency) to V/F5 parameters in advance, a desired V/F characteristic can be obtained.
- · For an example, with the equipment with large static friction factor and small dynamic friction factor, large torque is required only at the start up, so a V/F pattern that will raise the voltage only at the low-speed range is set.
- · Setting procedure
  - 1) Set the rated motor voltage in Pr.19 Base frequency voltage. (No function at the setting of "9999" or "8888".)
  - 2) Set Pr.71 Applied motor = "2" (adjustable 5 points V/F).
  - 3) Set frequency and voltage to be set in Pr.100 to Pr.109.



#### Caution

Make sure to set this parameter correctly according to the motor used. Incorrect setting may cause the motor to overheat and burn.

- Adjustable 5 points V/F will become enabled at the time of V/F control.
- At the time of Pr.19 Base frequency voltage = "8888, 9999", setting of Pr.71 = "2" cannot be made. When setting Pr.71 = "2", set the rated motor voltage in Pr.19.
- Read only error ( $\digamma r$   $\ifmmode f$ ) is generated when the frequency value for each point is same.
- Set each point for Pr.100 to Pr.109 (frequency, voltage) within the range of Pr.3 Base frequency and Pr.19 Base frequency
- When Pr.71 = "2", Pr.47 Second V/F (base frequency) will not function.
- When Pr.71 = "2", electronic thermal O/L relay will make calculations assuming a standard motor.
- By simultaneously using Pr.60 Energy saving control selection and the adjustable 5 points V/F, further energy saving effect is expected.
- The Pr.0 Torque boost and Pr.12 DC injection brake operation voltage settings are automatically changed according to the Pr.71 setting. (Refer to page 340)

GROUP

#### (G) Control parameters

#### Parameters referred to >>>

Pr.0 Torque boost page 496

Pr.3 Base frequency, Pr.19 Base frequency voltage page 497

Pr.12 DC injection brake operation voltage page 502

Pr.47 Second V/F (base frequency) page 501

Pr.60 Energy saving control selection page 500

Pr.71 Applied motor, Pr.450 Second applied motor page 337

## 5.13.6 SF-PR slip amount adjustment mode we

- As compared to our conventional SF-JR motor, the slip amount is small for the high-performance energy-saving SF-PR motor. When replacing the SF-JR to the SF-PR, the slip amount is reduced and the rotations per minute increases.
   Therefore, when the SF-PR is used with the same frequency setting as that of the SF-JR, power consumption may increase as compared to the SF-JR.
- By setting the slip amount adjustment mode, the frequency command can be adjusted to keep the rotations per minute of the SF-PR equivalent to those of the SF-JR for power consumption reduction.

Pr.	Name	Initial value	Setting range	Description
673 G060	SF-PR slip amount adjustment operation	9999	2, 4, 6	Set the number of SF-PR motor poles.  Slip amount adjustment mode invalid
674 G061	SF-PR slip amount adjustment gain	100%	0 to 500%	Setting is available for fine adjustment of the slip amount.

- By setting the number of SF-PR motor poles in **Pr.673 SF-PR slip amount adjustment operation selection**, the SF-PR slip amount adjustment mode is activated.
- The SF-PR slip amount adjustment mode is available only under V/F control.
- Use **Pr.674 SF-PR slip amount adjustment gain** to fine-tune the rotations per minute. To reduce the rotations per minute (to increase the compensation frequency), set a larger value in **Pr.674**. To increase the rotations per minute (to reduce the compensation frequency), set a smaller value in **Pr.674**.

## • NOTE

The slip amount adjustment mode is not available in the following cases.
 During acceleration/deceleration, during DC injection brake operation, during PID control, during stall prevention operation, during regeneration avoidance operation, during traverse operation, and while the slip compensation is valid (Pr.245).

## 5.13.7 DC injection brake

• Timing to stop or braking torque can be adjusted by applying DC injection brake at the time of stopping motor.

By the DC injection brake operation, the DC voltage is applied to the motor to prevent rotation of the motor shaft. The motor shaft will not return to its original position when it is rotated due to external force.

Pr.	Name	Initial value	Setting range	Description
10	DC injection brake	3 Hz	0 to 120 Hz	Set the operation frequency for the DC injection brake.
G100	operation frequency	3112	9999	Operate at Pr.13 or lower
11	DC injection broke		0	Without DC injection brake
G101	DC injection brake operation time	0.5 s	0.1 to 10 s	Set the operation time for the DC injection brake.
3101	operation time		8888	Operate with X13 signal ON
40	DC injection broke	4%*1		Out the DO in its time had a self-out (to out a) William and the IIOII
12 G110	DC injection brake operation voltage	2%*2	0 to 30%	Set the DC injection brake voltage (torque). When set to "0", there will be without DC injection brake.
	oporation voltage	1%*3	1	,


- \*1 Initial value for the FR-F820-00340(7.5K) or lower and FR-F840-00170(7.5K) or lower.
- \*2 Initial values for the FR-F820-00490(11K) to FR-F820-02330(55K), FR-F840-00250(11K) to FR-F840-01160(55K).
- \*3 Initial value for the FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.

## Setting of operating frequency (Pr.10)

- By setting the frequency to operate the DC injection brake to Pr.10 DC injection brake operation frequency, the DC injection brake will operate when it reaches this frequency at the time of deceleration.
- When Pr.10 = "9999", DC injection brake will start when the frequency reaches Pr.13 Starting frequency.
- The DC injection brake operation frequency depends on the stopping method.


Stopping method	Parameter setting	DC injection brake operation frequency
Press the STOP key on the	0.5 Hz or higher in <b>Pr.10</b>	Pr.10 setting
operation panel Turning OFF of the STF/STR	Lower than 0.5 Hz in <b>Pr.10</b> , and 0.5 Hz or higher in <b>Pr.13</b>	0.5 Hz
signal	Lower than 0.5 Hz in both Pr.10 and Pr.13	Pr.10 or Pr.13 setting, whichever larger
Set the frequency to 0 Hz	_	Pr.13 setting or 0.5 Hz, whichever larger

• DC injection brake operation frequency will be fixed to 0 Hz at the time of PM motor control.



## ◆ Setting of operation time (X13 signal, Pr.11)

- Set the time applying the DC injection brake to Pr.11 DC injection brake operation time.
- When the motor does not stop due to large load moment (J), increasing the setting produces an effect.
- When **Pr.11** = "0 s", DC injection brake will not operate. (The motor will coast to stop.)
- When Pr.11 = "8888", DC injection brake will operate when the X13 signal is turned ON. DC injection brake will operate when the X13 signal is turned ON even while operating.
- For the X13 signal input, set "13" in any of Pr.178 to Pr.189 to assign the function.





• The X13 signal is disabled during PM motor control.

## ◆Setting of operation voltage (torque) (Pr.12)

- Pr.12 DC injection brake operation voltage will set the percent against the power supply voltage.
- DC injection brake will not operate with setting of Pr.12 = "0%". (The motor will coast to stop.)

#### • NOTE

· When the initial value is set in Pr.12, the setting corresponding to the motor is set according to the Pr.71 Applied motor setting. (Refer to page 340)

However, when an energy saving motor (SF-HR or SF-HRCA) is used, change the Pr.12 setting as shown below.

Inverter	Pr.12 setting
FR-F820-00167(3.7K) or lower FR-F840-00083(3.7K) or lower	4%
FR-F820-00250(5.5K), FR-F820-00340(7.5K) FR-F840-00126(5.5K), FR-F840-00170(7.5K)	3%
FR-F820-00490(11K) to FR-F820-00930(22K), FR-F820-01540(37K) or higher FR-F840-00250(11K) to FR-F840-00470(22K), FR-F840-00770(37K) or higher	2%
FR-F820-01250(30K) FR-F840-00620(30K)	1.5%

• Even if the setting value of Pr.12 is made larger, braking torque will be limited so the output current will be within the rated current of the inverter.



#### Caution

Install a mechanical brake to make an emergency stop or to stay stopped for a long time.

#### Parameters referred to

Pr.13 Starting frequency page 197, page 198

Pr.71 Applied motor page 337 Pr.80 Motor capacity page 341

Pr.178 to Pr.182 (input terminal function selection) page 329

## GROUP


#### 5.13.8 **Output stop function**

The motor coasts to a stop (inverter output shutoff) when inverter output frequency falls to Pr. 522 setting or lower.

Pr.	Name	Initial value	Setting range	Description
522	Output stop frequency	9999	0 to 590 Hz	Set the frequency to start coasting to a stop (output shutoff).
G105	Output stop frequency	9999	9999	No function

- · When both of the frequency setting signal and output frequency falls to the frequency set in Pr. 522 or lower, the inverter stops the output and the motor coasts to a stop.
- At a stop condition, the motor starts running when the frequency setting signal exceeds Pr.522 + 2 Hz. The motor is accelerated at the Pr.13 Starting frequency (0.01 Hz under PM motor control) at the start.

Example of when target frequency>Pr.522+2Hz, and start signal is ON/OFF




\*1 The output frequency before the slip compensation is compared with the Pr.522 setting

## • NOTE

• When the output stop function is valid (Pr.522 ≠ "9999"), the DC injunction brake becomes invalid and the motor coasts to stop when the output frequency drops to the Pr.522 setting or lower.

Example of: target frequency = analog input command, start signal always ON



- \*1 At a stop condition, the motor is accelerated at the Pr.13 Starting frequency (0.01 Hz under PM motor control).
- The output frequency to be compared with the Pr.522 setting is the output frequency before slip compensation (V/F control and Advanced magnetic flux vector control), or the speed command value converted into the frequency (PM motor control).
- Steepness of the slope depends on the acceleration/deceleration time settings such as Pr.7.

#### (G) Control parameters



- · Motor coasts when the command value drops to Pr.522 or lower while the start signal is ON. If the command value exceeds Pr.522+2 Hz again while coasting, the motor starts running at Pr.13 Starting frequency (0.01 Hz under PM motor control). When the motor re-accelerates after coasting, the inverter may trip in some parameter settings. (Activation of the restart function is recommended especially for an PM motor.)
- The output stop frequency function is disabled during PID control, JOG operation, power failure stop, traverse function operation, or offline auto tuning.
- · Output stop function does not operate during reverse rotation deceleration. However, when the frequency setting signal and output frequency falls to Pr.522 or lower, the inverter coasts to a stop.
- · During the output stop due to the output stop function (when forward/reverse command is given, but frequency command is not given), FWD/REV LED indication on the operation panel flickers fast.



#### Caution

 A PM motor is a motor with interior permanent magnets. High voltage is generated at motor terminals while the motor is running. Do not touch motor terminals and other parts until the motor stops to prevent an electric shock.

#### # Parameters referred to

Pr.10 DC injection brake operation frequency, Pr.11 DC injection brake operation time, Pr.12 DC injection brake operation voltage (1) page 502 Pr.13 Starting frequency page 197, page 198


#### 5.13.9 **Stop selection**

Select the stopping method (deceleration to stop or casting) at turn-OFF of the start signal.

Use this function to stop a motor with a mechanical brake at turn-OFF of the start signal.


Selection of start signal (STF/STR) operation can also be selected. (For start signal selection, refer to page 335.)

		Initial	Setting	Description		
Pr.	Name	value	range	Start signal (STF/STR) (Refer to page 335.)	Stop operation	
250 G106			0 to 100 s	STF signal: Forward rotation start STR signal: Reverse rotation start	It will coast to stop after set time when the start signal is turned OFF.	
	Stop selection	9999	op selection 9999 11		STF signal: Start signal STR signal: Forward/reverse rotation signal	It will coast to stop after ( <b>Pr.250</b> - 1000) s when the start signal is turned OFF.
			9999	STF signal: Forward rotation start STR signal: Reverse rotation start	It will perform deceleration stop when the start signal is	
			8888	STR signal: Reverse rotation start  o STF signal: Start signal STR signal: Forward/reverse rotation signal  STF signal: Forward rotation start STR signal: Reverse rotation start  STF signal: Start signal Start signal	turned OFF.	



## Make the motor perform deceleration stop

- Set Pr.250 = "9999 (initial value) or 8888".
- It will perform deceleration stop when the start signal (STF/STR) is turned OFF.



#### ◆Make the motor perform coast to stop

- Set the time from the time the start signal is turned OFF to when the output is shutoff in Pr.250. When set to "1000 to 1100", output is shutoff after (Pr.250 - 1000) s.
- · The output is shutoff after the set time of Pr.250 has elapsed after the start signal is turned OFF. The motor will coast to stop.
- The RUN signal will be turned OFF at the time of output stop.

## • NOTE

- · Stop selection is disabled when following functions are operating.
- Power failure stop function (Pr.261)
- PU stop (Pr.75)
- Deceleration stop due to communication error (Pr.502)
- Offline auto tuning (with motor rotation)
- When Pr.250 ≠ "9999 or 8888", acceleration/deceleration is performed in accordance to the frequency command until the output is shutoff by turning OFF the start signal.
- · When the restart signal is turned ON during the motor coasting, the operation is resumed from Pr.13 Starting frequency.

#### Parameters referred to

Pr.7 Acceleration time, Pr.8 Deceleration time page 187

Pr.13 Starting frequency page 197, page 198

Pr.75 Reset selection/disconnected PU detection/PU stop selection page 162

Pr.261 Power failure stop selection page 426

Pr.502 Stop mode selection at communication error page 446

# 5.13.10 Regenerative brake selection and DC feeding mode

- When performing frequent start and stop operation, usage rate of the regenerative brake can be increased by using the optional high-duty brake resistor (FR-ABR) or the brake unit (FR-BU2, BU, FR-BU).
- When using continuously in regenerative condition, use the power regeneration common converter (FR-CV) or
  power regeneration converter (MT-RC). The high power factor converter (FR-HC2) can be used also to reduce
  harmonics, improve power factor, and operate continuously in the regenerative status.
- It is possible to choose between the DC feeding mode 1, which will operate with DC power supply (terminals P and N), and DC feeding mode 2, which will normally operate in AC power supply (terminals R, S, and T) and operate in DC power supply (terminal P and N), such as batteries, at the time of power failure.
- While the power is supplied only to the control circuit, the reset operation when the power is supplied to the main circuit can be selected.

Pr.	Name	Initial value	Setting range	Description
30 E300	Regenerative function selection	0*1 10*2	0 to 2, 10, 11, 20, 21, 100 to 102, 110, 111, 120, 121*1 2, 10, 11, 102, 110, 111*2	First digit: Regeneration unit selection ("0" for FR-BU2 (GZG/GRZG/FR-BR), "1" for FR-BU2 (MT-BR5), "2" for FR-HC2 or FR-CV) Second digit: Selection of the power supply terminal to the inverter ("0" for AC, "1" for DC, "2" for AC and DC) Third digit: Reset when the power is supplied to the main circuit ("0" for reset, "1" for no reset) For details, refer to the table below.
599	X10 terminal input	0*1	0	Normally open input
T721	selection	1*2	1	Normally closed input (NC contact input specification)

- \*1 The initial value or setting range for the standard model
- \*2 The initial value or setting range for the separated converter type.

#### Details of the setting value

• FR-F820-02330(55K) or lower, FR-F840-01160(55K) or lower

Regeneration unit	Power supply terminals of inverter	Pr.30 Setting*1
Brake unit	R, S, T	0 (initial value), 100
(FR-BU2 (GZG/GRZG/FR-BR), FR-BU, BU)	P, N	10, 110
(1 K-B02 (020/0K20/1 K-BK), 1 K-B0, B0)	R, S, T/P, N	20, 120
High power factor converter (FR-HC2), Power regeneration common converter (FR-CV)	P, N	2, 102
For manufacturer setting. Do not set.		1, 11, 21, 101, 111, 121

• FR-F820-03160(75K) or higher, FR-F840-01800(75K) or higher

Regeneration unit	Power supply terminals of inverter	Pr.30 Setting*1
	R, S, T	0 (initial value), 100
Without regenerative function	P, N	10, 110
	R, S, T/P, N	20, 120
	R, S, T	1, 101
Brake unit (FR-BU2 (MT-BR5))	P, N	11, 111
	R, S, T/P, N	21, 121
Power regeneration converter (MT-RC)	R, S, T	1, 101
High power factor converter (FR-HC2)	P, N	2, 102

• FR-F842-07700(355K) or higher

Regeneration unit	Pr.30 Setting*1
Without regenerative function (FR-CC2)	10 (initial value), 110
Brake unit (FR-CC2+FR-BU2 (MT-BR5))	11, 111
High power factor converter (FR-HC2)	2, 102

<sup>\*1</sup> While the power is supplied only to the control circuit with **Pr.30** = "100 or higher", the inverter reset is not performed when the power is supplied to the main circuit.

• When using FR-BU2 in combination with GZG/GRZG/FR-BR, or using BU or FR-BU, set **Pr.30** = "0 (initial value), 10, 20, 100, 110, 120".

# ♦When using brake unit (FR-BU2) (FR-F820-03160(75K) or higher, FR-F840-01800(75K) or higher)

- To use FR-BU2 in combination with MT-BR5, set as follows.
- Set Pr.30 = "1, 11, 21".
- Set the brake unit FR-BU2, Pr.0 Brake mode selection = "2".

#### • NOTE

• When Pr.30 = "1, 11, 21", oL (stall prevention (overvoltage)) does not operate.

#### ♦When using power regeneration converter (MT-RC)

• Set Pr.30 = "1. 11. 21".

## ◆When using the high power factor converter (FR-HC2), the power regeneration common converter (FR-CV), or the converter unit (FR-CC2)

- To use FR-HC2 or FR-CV, set Pr.30="2".
- When using FR-CC2, set **Pr.30**="10" (initial value of separated converter type).
- Assign the following signal to a contact input terminal using any of Pr.178 to Pr.189 (input terminal function selection).
  - (a) Inverter run enable signal (X10): FR-HC2 connection, FR-CV connection, FR-CC2connection

    To have coordinated protection with FR-HC2, FR-CV or FR-CC2, shutoff the inverter output by the X10 signal.

    Input the RDY signal of the FR-HC2 (RDYB signal of FR-CV or RDA signal of FR-CC2).
  - (b) FR-HC2/FR-CC2 connection, instantaneous power failure detection signal (X11): FR-HC2 connection, FR-CC2 connection
    - During the operation using RS-485 communication, with the remote output and analog remote output functions enabled, the X11 signal is used to store the status when the inverter is set to store the status before an instantaneous power failure.
    - Input the IPF signal (instantaneous power failure detection signal) of the FR-HC2 or FR-CC2.
- For the terminal to be used for the X10 and X11 signal, set "10" (X10), "11" (X11) in **Pr.178 to Pr.189** and assign the function. (For separated converter types, the X10 signal is assigned to the terminal MRS in the initial setting.)


## • NOTE

- For details of brake unit, high power factor converter (FR-HC2), power regeneration common converter (FR-CV) connections, refer to page 63 to 67. Also, for details of each option, refer to instruction manual of each option.
- When changed to Pr.30 = "2", inverter will reset, so "Err" is displayed on the operation panel.

5

GROUP

## **♦**Logic reversing of inverter run enable signal (X10 signal, Pr.599)



- Use Pr.599 X10 terminal input selection to select the X10 signal input specification between normally open (NO contact) and normally closed (NC contact). With the normally closed (NC contact) input specification, the inverter output is shut off by turning OFF (opening) the X10 signal.
- Changing the inverter logic (NO/NC contact) with the Pr.599 setting is required according to the logic of the inverter operation enable signal sent from the option unit.
- The response time of the M10 signal is within 2 ms.
- · Relationship between Pr.599 and the inverter operation enable signal of each option unit

Pr.599 setting	Corresponding	g signals of the o	Operation according to the	
F1.599 Setting	FR-HC2	FR-CV	FR-CC2	X10 signal status
0 (Initial value of standard models)	RDY (negative logic) (initial setting)	RDYB	RDB	X10-ON: Inverter output shutoff (NO contact)
1 (Initial value of separated converter types)		RDYA	RDA	X10-OFF: Inverter output shutoff (NC contact)

#### • NOTE

- If the X10 signal is unassigned while **Pr.30** = "2" (FR-HC2/FR-CV connection) or "10 or 11" (DC feeding mode 1), the MRS signal can be used as the X10 signal. At this time, logic setting for the signal will follow **Pr.17 MRS input selection**.
- MRS signal is enabled from any of the communication or external input, but when using the MRS signal as Inverter run enable signal (X10), it can be used as input from external.
- When FR-HC or MT-HC is connected, set Pr.599 = "0 (initial value)".
- When the terminal assignment is changed with **Pr.178 to Pr.189 (input terminal function selection)**, wiring may be mistaken due to different terminal name and signal contents, or may affect other functions. Set parameters after confirming the function of each terminal.

# ◆Reset when the power is supplied to the main circuit (Pr.30 = "100, 101, 102, 110, 111, 120 or 121")


- While the power is supplied only to the control circuit (R1/L11, S1/L12 input or 24 V external power supply) with **Pr.30** = "100 or higher", the inverter reset is not performed when the power is supplied (R/L1, S/L2, T/L3 input) to the main circuit.
- When a communication option, etc. is used, communication interruption due to the inverter reset can be avoided.

## NOTE

• When the power is supplied to the main circuit while the inverter protective function is activated, the inverter reset is performed even if it the setting is "No reset" at power ON.

#### ◆DC feeding mode 1 (Pr.30 = "10, 11") (Standard models)

- For standard models, setting **Pr.30**="10 or 11" allows operation with a DC power supply.
- Do not connect anything to the AC power supply connecting terminals R/L1, S/L2, and T/L3, and connect the DC power supply to the terminals P/+ and N/-. Also, remove the jumpers between terminal R/L1 and R/L11as well as between S/L2 and S1/L21, and connect the terminals R1/L11 and S1/L21 to the terminals P/+ and N/-.
- · Following is a connection example.





#### Caution

Do not connect a separated converter type inverter to a DC power supply. Doing so may damage the inverter.


#### **◆DC** feeding mode 2 (Pr.30 = "20, 21") (Standard models)

- When Pr.30 = "20, 21", it will normally operate with AC power supply and operate with DC power supply such as batteries at the time of power failure.
- Connect the AC power supply to the AC power supply connecting terminals R/L1, S/L2, and T/L3, and connect the DC power supply to the terminals P/+ and N/-. Also, remove the jumpers between terminal R/L1 and R/L11as well as between S/L2 and S1/L21, and connect the terminals R1/L11 and S1/L21 to the terminals P/+ and N/-.
- · Operation with DC current is possible by turning ON the DC feeding operation permission signal (X70). For details on I/O signal, refer to following table.


Signal Name Description		Description	Parameter setting	
Input	To operate with DC feeding, turn ON the X70 signal. When the inverter output is shutoff due to power failure, it will be possible to start up 200 ms after turning ON the X70 signal. (Automatic restart after instantaneous power failure can start after the time set in <b>Pr.57</b> has elapsed.)  When the X70 signal is turned OFF while operating the inverter, output shutoff ( <b>Pr.261</b> = 0) or deceleration stop ( <b>Pr.261</b> ≠ 0) will occur.		Set "70" to either of Pr.178 to Pr.189.	
	X71 DC feeding cancel signal		Turn ON when stopping the DC feeding. When the X71 signal is turned ON during the operation of the inverter and X70 signal is ON, output shutoff ( <b>Pr.261</b> = 0) or deceleration stop ( <b>Pr.261</b> ≠ 0) will occur, and Y85 signal will turn OFF after stopping. After turning ON the X71 signal, operation is not possible even if the X70 signal is turned ON.	Set "71" to either of Pr.178 to Pr.189.
Output	This will turn ON during power failure or undervoltage of the AC power supply. It will turn OFF when the X71 signal turns ON or power restoration		Set "85 (positive logic) or 185 (negative logic)" to one of Pr.190 to Pr.196.	

#### (G) Control parameters


• Following is the connection diagram of switching to DC power supply using the power failure detection of the inverter.




- Assign the function by setting Pr.178 to Pr.189 (input terminal function selection).
- Assign the function by setting Pr.190 to Pr.196 (output terminal function selection).
- · Operation example at the time of power failure occurrence 1



· Operation example at the time of power failure occurrence 2 (when the AC power supply is restored)





## **◆Power supply specification for DC feeding (Standard models)**

200 V class	Rated input DC voltage	283 V DC to 339 V DC
200 V Class	Permissible fluctuation	240 V DC to 373 V DC
400 V class	Rated input DC voltage	537 V DC to 679 V DC
400 V Class	Permissible fluctuation	457 V DC to 740 V DC

#### NOTE:

- The voltage between P and N will temporarily increase to 415 V (830 V) or higher during the regenerative driving, so take caution on the selection of the DC power supply.
- When an AC power supply is connected to the R/L1, S/L2, and T/L3 terminals during the DC feeding with Pr.30 = "2, 10, 11" (DC feeding), an option fault (E.OPT) will occur.
- When set to Pr.30 = "2, 10, 11, 20, 21" (DC feeding) and operated by DC feeding, detection of undervoltage (E.UVT) and instantaneous power failure (E.IPF) is not performed.
- When DC power is switched on, a larger inrush current flows than in AC power. The number of power-on times should be minimized.
- · Changing the terminal assignment using Pr.178 to Pr.189 (input terminal function selection) or Pr.190 to Pr.196 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

#### Parameters referred to

Pr.17 MRS input selection page 332

Pr.57 Restart coasting time page 414, page 420

Pr.178 to Pr.189 (input terminal function selection) page 329

Pr.190 to Pr.196 (output terminal function selection) \* page 288

Pr.261 Power failure stop selection page 426

## 5.13.11 Regeneration avoidance function

The regenerative status can be avoided by detecting the regenerative status and raising the frequency.


Continuous operation is possible by increasing the frequency automatically so it will not go into regenerative
operation even when the fan is turned forcefully by other fans in the same duct.


Pr.	Name	Initial value		Setting range	Description
				0	Disables regeneration avoidance function
882	Regeneration avoidance	0		1	Constantly enables regeneration avoidance function
G120	operation selection			2	Enables regeneration avoidance function only during constant-speed operation
883	Regeneration avoidance operation level	200 V Class	380 VDC	300 to 800 V	Set the bus voltage level to operate the regeneration avoidance operation. When the bus voltage level is set low, it will be harder to generate overvoltage error, but actual deceleration time will be longer. Set the setting value higher than power supply voltage $\times \sqrt{2} \ .$
G121		400 V Class	760 VDC	300 to 800 V	
	Regeneration avoidance at deceleration detection sensitivity	0		0	Disables regeneration avoidance due to bus voltage change rate
884					Set the sensitivity to detect the bus voltage change rate
G122				1 to 5	Setting value 1 → 5
					Detection sensitivity Low → High
885	Regeneration avoidance compensation frequency limit value	6 Hz		0 to 590 Hz	Set the limit value for frequency to rise when the regeneration avoidance function operates.
G123				9999	Disables frequency limit
886 G124	Regeneration avoidance voltage gain	100%		0 to 200%	Adjust the response at the time of regeneration avoidance operation. When the setting value is set larger, response against the bus voltage change will
665 G125	Regeneration avoidance frequency gain	100%		0 to 200%	improve, but the output frequency may become unstable.  When the vibration cannot be stabilized even if the setting value of <b>Pr.886</b> is made smaller, set the setting value of <b>Pr.665</b> smaller.


## ♦What is regeneration avoidance operation? (Pr.882, Pr.883)

- When the regenerative status is large, DC bus voltage will rise, which may cause overvoltage alarm (E.OV[]).

  Regenerative status can be avoided by detecting this rise of bus voltage, and raising the frequency when the bus voltage level exceeds Pr.883 Regeneration avoidance operation level.
- The regeneration avoidance operation can be selected to operate constantly or operate only during constant speed.
- The regeneration avoidance function is enabled by setting to **Pr.882 Regeneration avoidance operation selection** = "1, 2".









- · The slope of frequency rising or lowering by the regeneration avoidance operation will change depending on the regenerative status.
- The DC bus voltage of the inverter will be approximately  $\sqrt{2}$  times of the normal input voltage. The bus voltage will be approximately 311 V (622 V) DC in case of input voltage of 220 V (440 V) AC. However, it may vary depending on the input power supply waveform.
- · Make sure that the setting value of Pr.883 will not get under DC bus voltage level. The frequency will rise with operation of the regeneration avoidance function even at the time of no regenerative status.
- The stall prevention (overvoltage) (oL) will only operate during deceleration, stopping the lowering of output frequency, but on the other hand, the regeneration avoidance function will constantly operate (Pr.882 = "1") or operate only at constant speed (Pr.882 = "2"), and raise the frequency depending on the amount of regeneration.
- When the motor becomes unstable due to operation of the stall prevention (overcurrent) (OL) during the regeneration avoidance operation, increase the deceleration time or lower the setting of Pr.883.

#### ◆To detect the regenerative status during deceleration faster (Pr.884)

· Since a rapid change in bus voltage cannot be handled by bus voltage level detection during the regeneration avoidance operation, deceleration is stopped by detecting the change in bus voltage and if it is equal or lower than Pr.883 Regeneration avoidance operation level.

Set the detectable bus voltage change rate as the detection sensitivity in Pr.884 Regeneration avoidance at deceleration detection sensitivity. A larger set value increases the detection sensitivity.



· When the setting value is too small (detection sensitivity is not good), detection will not be possible, and regeneration avoidance will operate even with the bus voltage change caused by a change in the input power.


#### **◆Limit regeneration avoidance operation frequency (Pr.885)**

- It is possible to assign a limit to the output frequency corrected (rise) by the regeneration avoidance operation.
- Limit of the frequency is output frequency (frequency before regeneration avoidance operation) + Pr.885 Regeneration avoidance compensation frequency limit value for during acceleration and constant speed.

During deceleration, when the frequency increases due to the regeneration avoidance operation and exceeds the limit value, the limit value will be retained until the output frequency is reduced to be the half the Pr.885 setting.

- · When the frequency that have increased by the regeneration avoidance operation exceeds Pr.1 Maximum frequency, it will be limited to the maximum frequency.
- By setting to **Pr.885** = "9999", regeneration avoidance operation frequency limitation is disabled.
- Set using the motor rated slip frequency as a guideline. Raise the setting value if the overvoltage protection function (E.OV[]) operation at the start of deceleration.

Synchronized speed at the - rated rotation speed time of base frequency Rated motor slip frequency = × Rated motor frequency Synchronized speed at the time of base frequency



## **◆**Adjustment of regeneration avoidance operation (Pr.665, Pr.886)

- When the frequency becomes unstable at the time of regeneration avoidance operation, set the setting value for Pr.886 Regeneration avoidance voltage gain smaller. On the other hand, if an overvoltage fault occurs due to a sudden regeneration, increase the setting.
- · When the vibration cannot be stabilized even if the setting value of Pr.886 is made smaller, set the setting value of Pr.665 Regeneration avoidance frequency gain smaller.

GROUP

#### (G) Control parameters



- During the regeneration avoidance operation, the stall prevention (overvoltage) (oL) is displayed and the overload alarm (OL) signal is output. The operation when the OL signal is output can be set with **Pr.156 Stall prevention operation selection**. The OL signal output timing can be set with **Pr.157 OL signal output timer**.
- The stall prevention is enabled even at the time of regeneration avoidance operation.
- The regeneration avoidance function cannot decrease the actual deceleration time for the motor to stop. The actual deceleration time is determined by the regenerative power consumption performance, so to decrease the deceleration time, consider using a regeneration unit (FR-BU2, BU, FR-BU, FR-CV, FR-HC2).
- When using regeneration unit (FR-BU2, BU, FR-BU, FR-CV, FR-HC2) to consume the regenerative power, set to **Pr.882** = "0 (initial value)" (disables regeneration avoidance function). When consuming the regenerative power at the time of deceleration with the regeneration unit, etc., set to **Pr.882** = "2" (enables regeneration avoidance function only at the time of constant speed).

#### Parameters referred to

Pr.1 Maximum frequency page 245

Pr.8 Deceleration time page 187

Pr.22 Stall prevention operation level page 248

# 5.13.12 Increased magnetic excitation deceleration

Magnetic flux

Increase the loss in the motor by increasing the magnetic flux at the time of deceleration. Deceleration time can be reduced by suppressing the stall prevention (overvoltage) (oL).

It will make possible to reduce the deceleration time without a brake resistor.

Pr.	Name	Initial value	Setting range	Description
660	Increased magnetic		0	Without increased magnetic excitation deceleration
G130	excitation deceleration operation selection	0	1	With increased magnetic excitation deceleration
661	Magnetic excitation	9999	0 to 40%	Set the increase of excitation.
G131	increase rate	9999	9999	Magnetic excitation increase rate 10%
662 G132	Increased magnetic excitation current level	100%	0 to 300%	The increased magnetic excitation rate is automatically lowered when the output current exceeds the setting value at the time of increased magnetic excitation deceleration.

#### Setting of increased magnetic excitation rate (Pr.660, Pr.661)

- To enable the increased magnetic excitation deceleration, set Pr.660 Increased magnetic excitation deceleration operation selection = "1".
- Set the amount of excitation increase in Pr.661 Magnetic excitation increase rate. Increased magnetic excitation deceleration will be disabled when Pr.661 = "0".
- When the DC bus voltage exceeds the increased magnetic excitation deceleration operation level during the deceleration, excitation is increased in accordance with the setting value in Pr.661.
- The increased magnetic excitation deceleration will continue even if the DC bus voltage goes under the increased magnetic excitation deceleration operation level during increased magnetic excitation deceleration.

Inverter	Increased magnetic excitation deceleration operation level
200 V class	340 V
400 V class	680 V
With 500 V input	740 V

- · When the stall prevention (overvoltage) occurs during the increased magnetic excitation deceleration operation, increase the deceleration time or raise the setting value of Pr.661. When the stall prevention (overcurrent) occurs, increase the deceleration time or lower the setting value of Pr.661.
- · Increased magnetic excitation deceleration is enabled with V/F control, Advanced magnetic flux vector control.

## NOTE:

· The increased magnetic excitation deceleration will be disabled in the following conditions: During PM motor control, power failure stop, operation with FR-HC2/FR-CV, energy saving operation, Optimum excitation control.

#### **◆Overcurrent prevention function (Pr.662)**

- The overcurrent prevention function is valid under V/F control and Advanced magnetic flux vector control.
- Increased magnetic excitation rate is lowered automatically when the output current exceeds Pr.662 at the time of increased magnetic excitation deceleration.
- When the inverter protective function (E.OC[], E.THT) operates due to increased magnetic excitation deceleration, adjust with **Pr.662**.
- Overcurrent preventive function will be disabled when Pr.662= "0".

#### • NOTE

• When set to **Pr.662** > **Pr.22 Stall prevention operation level**, overcurrent preventive function will operate at the setting value of **Pr.22**. (Operates at **Pr.622** when **Pr.22** = "0")

#### Parameters referred to

Pr.22 Stall prevention operation level page 248

Pr.30 Regenerative function selection page 508

Pr.60 Energy saving control selection page 500

Pr.162 Automatic restart after instantaneous power failure selection page 414, page 420

Pr.261 Power failure stop selection page 426

## 5.13.13 Slip compensation

Slip of the motor is estimated from the inverter output current at the time of V/F control, and maintain the rotation of the motor constant.

Pr.	Name	Initial value	Setting range	Description
245	Rated slip	9999	0.01 to 50%	Set the rated motor slip.
G203	Nated Slip	9999	0, 9999	Without slip compensation
246 G204	Slip compensation time constant	0.5s	0.01 to 10s	Set the response time of the slip compensation. Response will become faster when the value is lowered, but the regenerative overvoltage (E.OV[]) error will occur more frequently when the load inertia is larger.
247	Constant-power range slip compensation 9999 selection	9999	0	Do not perform slip compensation at constant output range (frequency range higher than the frequency set in <b>Pr.3</b> ).
G205			9999	Perform the slip compensation of the constant output range.

• Slip compensation will become enabled by calculating the rated motor slip, and setting to **Pr.245**. Slip compensation is not performed when **Pr.245** = "0, 9999".

Rated slip = Synchronized speed at the time of base frequency - rated rotation speed

Synchronized speed at the time of base frequency × 100[%]

## • NOTE

- When the slip compensation is performed, the output frequency may become larger than the set frequency. Set Pr.1
   Maximum frequency higher than the set frequency.
- Slip compensation will be disabled in following cases.
   At the times of stall preventive (oL, OL) operation, regeneration avoidance operation, auto tuning

#### Parameters referred to


Pr.1 Maximum frequency page 245
Pr.3 Base frequency page 497

## 5.13.14 Speed smoothing control Magnetic flux

There are times where the vibration due to mechanical resonance affect the inverter, making the output current (torque) unstable. In such case, vibration can be decreased by reducing the deviation in the output current (torque) by changing the output frequency.


Pr.	Name	Initial value	Setting range	Description
653 G410	Speed smoothing control	0%	0 to 200%	Confirm the effect by raising and lowering the value with 100% as a reference.
654 G411	Speed smoothing cutoff frequency	20 Hz	0 to 120 Hz	Set the lower limit of the torque deviation cycle (frequency).

#### Control block diagram



#### Setting method

- When vibration caused by mechanical resonance occurs, set Pr.653 Speed smoothing control to 100%, and operate at the operation frequency with largest vibration, and confirm if the vibration is suppressed after few seconds.
- If there is no effect, gradually raise the setting value of Pr.653, perform the operation and confirmation of the effect repeatedly, and use the value (Pr.653) with most effect as the final setting value.
- If the vibration gets larger by raising Pr.653, lower the value of Pr.653 under 100%, and perform the confirmation of result in a same manner.
- · When the vibration frequency (frequency of torque deviation, speed deviation, or converter output voltage deviation) by the mechanical resonance with a measurement device, etc., set the frequency of 1/2 to 1 times the vibration frequency in Pr.654 Speed smoothing cutoff frequency. (Setting vibrational frequency range can suppress the vibration better.)





· Depending on the equipment, the vibration may not be suppressed sufficiently or the effect is not obtained.

# 5.14 Parameter clear / all parameter clear

## POINT

- Set "1" to **Pr.CLR Parameter clear**, **ALL.CL All parameter clear** to initialize all parameters. (Parameters cannot be cleared when **Pr.77 Parameter write selection** = "1".)
- Pr.CL does not clear calibration parameters or the terminal function selection parameters.
- Refer to the parameter list on page 597 for parameters cleared with this operation.

#### Operation Screen at power-ON 1. The monitor display appears. Changing the operation mode 2. to choose the PU operation mode. [PU] indicator is lit. Parameter setting mode 3. Press MODE to choose the parameter setting mode. (The parameter number read previously appears.) Selecting the parameter number To perform a parameter clear, turn $\{\}$ to $\{\}$ to $\{\}$ and to perform all parameter clear, turn it to $\{\}$ and press 4. SET . "[]" (initial value) appears Parameter clear Turn to change the set value to " \ \ ". Press | SET | alternately after parameters are cleared. 5. • Turn to read another parameter. to show the setting again. Press • Press twice to show the next parameter.

Setting	Description			
Setting	Pr.CLR Parameter clear	ALL.CL All parameter clear		
0	Initial display (Parameters are not cleared.)			
1	Returns parameters excluding calibration parameters and terminal function selection parameters to their initial values.	Returns all parameters which can be cleared including calibration parameters and terminal function selection parameters to their initial values.		

## NOTE

- I and F I are displayed alternately... Why?
- The inverter is not in the PU operation mode.

□PU is lit, and " \ " appears on the monitor. (When Pr.79 ="0" (initial value))

2)Press SET to clear the parameter.

- Stop the inverter first. A writing error occurs if a parameter clear is attempted while the inverter is running. To perform a parameter clear, the inverter must be in the PU operation mode even if "2" is set to **Pr.77**.
- For availability of parameter clear and all parameter clear for each parameter, refer to the parameter list on page 597.

# **5.15** Copying and verifying parameters on the operation panel

Pr.CPY setting value	Description
0	Initial display
1.RD	Copy the source parameters to the operation panel.
2.WR	Write the parameters copied to the operation panel to the destination inverter.
3.VFY	Verify parameters in the inverter and operation panel. (Refer to page 523.)


#### NOTE:

- When the destination inverter is other than the FR-F800 series or when parameter copy is attempted after the parameter copy reading was stopped, "model error (r- - - )" appears.
- Refer to the parameter list on page 597 for the availability of parameter copy.
- · When the power is turned OFF or an operation panel is disconnected, etc. during parameter copy writing, write again or check the setting values by parameter verification.
- · When parameters are copied from a different-capacity inverter, there are parameters with different initial values depending on the inverter capacity, so the setting values of some parameters will be automatically changed. After performing a parameter copy from a different-capacity inverter, check all the parameter settings. (Refer to the parameter list (page 112) for details of parameters with different initial values depending on individual inverter capacity.)
- If parameters are copied from an older inverter to a newer inverter that has additional parameters, out-of-range setting values may be written in some parameters. In that case, those parameters operate as if they were set to their initial values.

#### 5.15.1 Parameter copy

• Inverter parameter settings can be copied to other inverters.

#### Reading the parameter settings of the inverter to the operation panel



- - E | appears... Why?
  - Parameter read error. Perform the operation from step 3 again.

## **◆**Copying parameter settings read to the operation panel to the inverter

	Operation ————
1.	Connect the operation panel to the destination inverter.
2.	Parameter setting mode  Press Mode to choose the parameter setting mode. (The parameter number read previously appears.)
3.	Selecting the parameter number  Turn to
4.	Selecting parameter copy  Turn to change the setting value to " I I I I I I I I I I I I I I I I I I
5.	Copying to the inverter  Press SET to start copying to the inverter. (It takes about 60 seconds to copy all the settings. During copying, the selected parameter group flickers.)  Perform this step while the inverter is stopped. (Parameter settings cannot be copied during operation.)
6.	Ending copying "ニハマ" and "アーテアリ" flicker alternately after copying ends.
7.	When parameters are written to the destination inverter, reset the inverter before operation by, for example, turning the power supply OFF.
	±*************************************

#### • NOTE

- ⊢ E ⊒ appears... Why?
  - Parameter write error. Perform the operation from step 3 again.
- F and F are displayed alternately.
  - Appears when parameter copy is performed between inverters FR-F820-02330(55K) or lower or inverters FR-F840-01160(55K) or lower and inverters FR-F820-03160(75K) or higher or FR-F840-01800(75K) or higher.
  - When CP and 0.00 flicker alternately, set the Pr.989 Parameter copy alarm release as shown below (initial value).

Pr.989 setting	Operation
10	Cancels the alarm of FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower.
100	Cancels the alarm of FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.

<sup>-</sup> After setting Pr.989, perform setting of Pr.9, Pr.30, Pr.51, Pr.56, Pr.57, Pr.72, Pr.80, Pr.82, Pr.90 to Pr.94, Pr.453, Pr.455, Pr.458 to Pr.462, Pr.557, Pr.859, Pr.860, and Pr.893 again.

## 5.15.2 Parameter verification

· Whether the parameter settings of inverters are the same or not can be checked.

#### Operation

- 1. Copy the parameter settings of the verification source inverter to operation panel according to the procedure on page 521.
- 2. Move the operation panel to the inverter to be verified.
- Screen at power-ON 3.

The monitor display appears.

Parameter setting mode

Press MODE to choose the parameter setting mode. (The parameter number read previously appears.)

Selecting the parameter number

5.

"[] -- -- " appears.

Parameter verification

Turn to change to setting value " []," [-] " (parameter copy verification mode).

Press SET . Verification of the parameter settings copied to the operation panel and the parameter settings of the verification destination inverter is started. (It takes about 60 seconds to verify all the settings. During verification, " 🗐 /- 🕒 " flickers.)

- ullet If there are different parameters, the different parameter number and " ullet - ●To continue verification, press SET

#### • NOTE

6.


- - E ∃ flickers... Why?
  - The set frequency may be incorrect. To continue verification, press

# **5.16** Copying and verifying parameters using USB memory

- · Inverter parameter settings can be copied to USB memory.
- Parameter setting data copied to USB memory can be copied to other inverters or verified to see if they differ from the parameter settings of other inverters.
- · Parameter settings can also be imported to a personal computer and edited in FR Configurator 2.

#### **♦**Changes in USB memory copy operation states

• Insert the USB memory in the inverter. The USB memory mode is displayed and USB memory operations are possible.




## • NOTE

- When parameter settings are copied to USB memory without specifying a parameter setting file number in USB memory, numbers are automatically assigned.
- Up to 99 files can be saved on USB memory. When the USB memory device already has 99 files, attempting copying of another file to the USB memory device causes the file quantity error (rE7).
- Refer to the FR Confirurator 2 instruction manual for details on importing files to FR Configurator 2.

#### ◆Procedure for copying parameters to USB memory

Operation 1. Insert the USB memory into the copy source inverter. USB memory mode 2. Press MODE to change to the USB memory mode. Displaying the file selection screen Press | SET | three times to display [ - - - - (file selection screen) and press | SET | . (To overwrite files on USB memory, display the file selection screen, turn to select the file number, and press | SET |.) Copying to USB memory Turn to change to " Turn Press | SET | to copy the parameter settings at the copy source to USB memory. (It takes about 15 seconds to copy all the settings. During copying, " | | "flickers.) " 🖟 🗂 and "file number when the parameter file was copied to USB memory" flicker after copying ends.

#### Procedure for copying parameters from USB memory to inverter



#### • NOTE

- - - | 1, - - appears... Why?
- A fault occurred on USB memory. Check the USB memory connection, then retry.
- F and man are displayed alternately.
  - Appears when parameter copy is performed between inverters FR-F820-02330(55K) or lower or inverters FR-F840-01160(55K) or lower and inverters FR-F820-03160(75K) or higher or FR-F840-01800(75K) or higher.
  - When CP and 0.00 flicker alternately, set the Pr.989 Parameter copy alarm release as shown below (initial value).

Pr.989 setting	Operation
10	Cancels the alarm of FR-F820-02330(55K) or lower and FR-F840-01160(55K) or lower.
100	Cancels the alarm of FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher.

- After setting Pr.989, perform setting of Pr.9, Pr.30, Pr.51, Pr.56, Pr.57, Pr.72, Pr.80, Pr.82, Pr.90 to Pr.94, Pr.453, Pr.455, Pr.458 to Pr.462, Pr.557, Pr.859, Pr.860, and Pr.893 again.
- When the destination inverter is other than the FR-F800 series or when parameter copy is attempted after the parameter copy reading was stopped, "model error (,- = -1)" appears.
- Refer to the parameter list on page 597 for the availability of parameter copy.
- When the power is turned OFF or an operation panel is disconnected, etc. during parameter copy writing, write again or check the setting values by parameter verification.
- When parameters are copied from a different-capacity inverter, there are parameters with different initial values depending on the inverter capacity, so the setting values of some parameters will be automatically changed. After performing a parameter copy from a different-capacity inverter, check all the parameter settings. (Refer to the parameter list (page 112) for details of parameters with different initial values depending on individual inverter capacity.)

#### ◆Procedure for verifying parameters in USB memory

	Operation
1.	Copy the parameter settings of the verification source inverter to USB memory according to the procedure on page 525.
2.	Move the USB memory to the inverter to be verified.
3.	Screen at power-ON
	The monitor display appears.
	USB memory mode
4.	Press MODE to change to the USB memory mode.
	Displaying the file selection screen
5.	Press SET three times to display [ [ (file selection screen).
	Selecting the file number
6.	Turn to select the file number to be verified, and press SET.
	Parameter verification
	Turn to display the setting " ] [ [ ] (parameter copy verification mode), and press [SET].
	" <u> </u>
7.	Press SET. Verification of the parameter settings copied to the USB memory and the parameter settings of the verification
	destination inverter is started. (It takes about 15 seconds to verify all the settings. During verification, " 🗦 . 📙 📙 " flickers.)
	●If there are different parameters, the different parameter number and "٫ — ☐ ☐ " flicker.
	●To continue verification, press SET.
8.	"Verified file number" and " 🚽 🗜 📙 📘 " flicker after verification ends.
	NOTE:

- NOTE:
  - - E = flickers... Why?
    - The set frequency may be incorrect. To continue verification, press SET

# **5.17** Checking parameters changed from their initial values (Initial value change list)

Parameters changed from their initial values can be displayed.

	Operation ————
1.	Screen at power-ON
••	The monitor display appears.
	Parameter setting mode
2.	Press MODE to choose the parameter setting mode. (The parameter number read previously appears.)
	Selecting the parameter number
3.	Turn to F[H5 (Initial value change list), and press SET.
	"
	Checking the initial value change list
	Turn
١.	•If SET is pressed with parameters that have been changed, the parameter settings can be changed as they are. (Parameter
	numbers are no longer displayed in the list when they are returned to their initial values.)
	●Other changed parameters appear by turning .
	" " is returned to when the last changed parameter is displayed.

## NOIE,

- Calibration parameters (C0 (Pr.900) to C7 (Pr.905), C42 (Pr.934) to C45 (Pr.935)) are not displayed even when these are changed from the initial settings.
- Only the simple mode parameters are displayed when the simple mode is set (Pr.160 = "9999").
- Only user groups are displayed when user groups are set (Pr.160 = "1").
- Pr.160 is displayed independently of whether the setting value is changed or not.
- Parameter setting using the initial value change list is also possible.

## **MEMO**

# PROTECTIVE **FUNCTIONS**

This chapter explains the "PROTECTIVE FUNCTION" that operates in this product.

Always read the instructions before using the equipment.

6.1	Inverter fault and alarm indications	530
	Reset method for the protective functions	
	Check and clear of the faults history	
	The list of fault displays	
	Causes and corrective actions	
	Check first when you have a trouble	

## **6.1** Inverter fault and alarm indications

- When the inverter detects a fault, depending on the nature of the fault, the operation panel displays an error message or warning, or a protective function activates to trip the inverter.
- When any fault occurs, take an appropriate corrective action, then reset the inverter, and resume the operation. Restarting the operation without a reset may break or damage the inverter.
- · When a protective function activates, note the following points.

Item	Description	
Fault output signal  Opening the magnetic contactor (MC) provided on the input side of the inverter at a fault of shuts off the control power to the inverter, therefore, the fault output will not be retained.		
Fault or alarm indication When a protective function activates, the operation panel displays a fault indication.		
Operation restart method	While a protective function is activated, the inverter output is kept shutoff. Reset the inverter to restart the operation.	

· Inverter fault or alarm indications are categorized as below.

Displayed item	Description	
Error message  A message regarding an operational fault and setting fault by the operation panel and unit. The inverter does not trip.		
Warning	The inverter does not trip even when a warning. However, failure to take appropriate measures will lead to a fault.	
Alarm The inverter does not trip. An Alarm (LF) signal can also be output with a parameter se		
Fault A protective function activates to trip the inverter and output a Fault (ALM) signal.		



• The past eight faults can be displayed on the operation panel. (Faults history) (For the operation, refer to page 531.)

## **6.2** Reset method for the protective functions

Reset the inverter by performing any of the following operations. Note that the accumulated heat value of the electronic thermal relay function and the number of retries are cleared (erased) by resetting the inverter.

The inverter recovers about 1 s after the reset is released.


On the operation panel, press to reset the inverter.
 (This may only be performed when a fault occurs. (Refer to page 541 of the Instruction Manual for faults.))



• Switch the power OFF once, then switch it ON again.



 Turn ON the reset signal (RES) for 0.1 s or more. (If the RES signal is kept ON, "Err" appears (flickers) to indicate that the inverter is in a reset status.)




#### NOTE

 OFF status of the start signal must be confirmed before resetting the inverter fault. Resetting an inverter fault with the start signal ON restarts the motor suddenly.

#### 6.3 Check and clear of the faults history

The operation panel stores the fault indications which appears when a protective function is activated to display the fault record for the past eight faults. (Faults history)

#### Check for the faults history



- When an overcurrent trip occurs by an instantaneous overcurrent, the monitored current value saved in the faults history may be lower than the actual current that has flowed.
- The cumulative energization time and actual operation time are accumulated from 0 to 65535 hours, then cleared, and accumulated again from

### **♦**Faults history clearing procedure



• Set Err.CL Fault history clear = "1" to clear the faults history.

	Operation —————
1.	Screen at power-ON
١.	The monitor display appears.
	Parameter setting mode
2.	Press MODE to choose the parameter setting mode. (The parameter number read previously appears.)
	Selecting the parameter number
3.	Turn until Fr-r-L (faults history clear) appears. Press SET to read the present set value. "[]" (initial value)
	appears.
	Faults history clear
	Turn to change the set value to " \ \". Press SET to start clear.
	"   and " =
4.	• Turn to read another parameter.
	• Press SET to show the setting again.
	Press SET twice to show the next parameter.

## The list of fault displays

If the displayed message does not correspond to any of the following or if you have any other problem, please contact your sales representative.

#### Error message

· A message regarding operational fault and setting fault by the operation panel and the parameter unit is displayed. The inverter does not trip.

Operation panel indication	Name	
E	Faults history	531
HOLd	Operation panel lock	535
LOEd	Password locked	535
Er I <sub>to</sub> Er4 Er8	Parameter write error	
-E1 <sub>to</sub> -E4 -E6 to	Copy operation error	536
Err.	Error	537

#### Warning

• The inverter does not trip even when a warning is displayed. However, failure to take appropriate measures will lead to a fault.

Operation		Refer
panel indication	Name	to page
OL	Stall prevention (overcurrent)	538
oL	Stall prevention (overvoltage)	538
ГН	Electronic thermal relay function pre-alarm	539
PS	PU stop	539
CP CP	Parameter copy	539
SA	Safety stop	
MF Ito	Maintenance signal output	
LIF	USB host error	540
El	24 V external power supply operation	540
Ed	Emergency drive in operation	540
LdF	Load fault warning 54	

#### **♦**Alarm

• The inverter does not trip. An Alarm (LF) signal can also be output with a parameter setting.

Operation panel	Name	Refer to
indication		page
FN	Fan alarm	541

#### ◆Fault

- · A protective function trips the inverter and outputs a Fault (ALM) signal.
- · The data code is used for checking the fault detail via communication or with Pr.997 Fault initiation.

Or	eration			Refer	
panel		Name	Data	to	
indication		Name	code		
indication				page	
E.		Overcurrent trip during acceleration	16 (H10)	541	
Ш	002	Overcurrent trip during constant speed	17 (H11)	541	
E.	003	Overcurrent trip during deceleration or stop	18 (H12)	542	
E.		Regenerative overvoltage trip during acceleration	32 (H20)	542	
E.	0 V 2	Regenerative overvoltage trip during constant speed	33 (H21)	542	
E.	01/3	Regenerative overvoltage trip during deceleration or stop	34 (H22)	543	
E.	FHF	Inverter overload trip (electronic thermal relay function)	48 (H30)	543	
E.	THM	Motor overload trip (electronic thermal relay function)	49 (H31)	543	
E.	FIN	Heatsink overheat	64 (H40)	543	
E.	1 PF	Instantaneous power failure	80 (H50)	544	
E.	TINE	Undervoltage	81 (H51)	544	
E.	ILF	Input phase loss	82 (H52)	544	
E.	OLF	Stall prevention stop	96 (H60)	544	
E	500	Loss of synchronism detection	97 (H61)	545	
ш	LUP	Upper limit fault detection	98 (H62)	545	
E.	Lan	Lower limit fault detection	99 (H63)	545	
E.	ЬΕ	Internal circuit fault	112 (H70)	549	
E.	6F	Output side earth (ground) fault overcurrent	128 (H80)	545	
E.	LF	Output phase loss	129 (H81)	546	
E.	□НГ	External thermal relay operation	144 (H90)	546	

#### The list of fault displays

Op	eration		5.4	Refer
panel		Name	Data code	to
indication				page
E.	PFE	PTC thermistor operation	145 (H91)	546
Ε.	OPF	Option fault	160 (HA0)	546
E.	OP I	Communication option fault	161 (HA1)	547
E.	15		164 (HA4)	
E.	17		165 (HA5)	
E.	18	User definition error by the PLC function	166 (HA6)	547
E.	19		167 (HA7)	_
Ε.	20		168 (HA8) 176	
Ε.	PE	Parameter storage device fault	(HB0)	547
	PUE	PU disconnection	(HB1)	547
	REF	Retry count excess	(HB2)	547
	PE2	Parameter storage device fault	(HB3)	547
	EPU_		(HC0)	-
Ε.	<u> 5</u>	CPU fault	(HF5)	548
Ε.	5		(HF6)	_
E.	7	Operation panel power supply	(HF7)	
Ε.	CLE	short circuit/RS-485 terminals power supply short circuit	193 (HC1)	548
Ε.	P24	24 VDC power fault	194 (HC2)	548
E.	C90	Abnormal output current detection	196 (HC4)	548
Ε.	I DH	Inrush current limit circuit fault	197 (HC5)	548
Ε.	SER	Communication fault (inverter)	198 (HC6)	549
E.	AI E	Analog input fault	199 (HC7)	549
E.	USЬ	USB communication fault	200 (HC8)	549
E.	SAF	Safety circuit fault	201 (HC9)	549
E.	PBF	Internal circuit fault	202 (HCA)	549
E.	13		253 (HFD)	549
E.	05	Overspeed occurrence	208 (HD0)	550
E.	LEI	4 mA input fault	228 (HE4)	550
E.	PEH	Pre-charge fault	229 (HE5)	550
E.	Pld	PID signal fault	230 (HE6)	550

Operation panel indication	Name	Data code	Refer to page
E. 1		241 (HF1)	
E. 2	Option fault	242 (HF2)	551
E. 3	-	243 (HF3)	

If faults other than the above appear, contact your sales representative.

## **6.5** Causes and corrective actions

#### **♦**Error message

A message regarding operational troubles is displayed. Output is not shut off.

Operation panel indication	HOLD	HOLD	
Name	Operation panel lo	Operation panel lock	
Description	Operation lock is set. Operation other than RESET is invalid. (Refer to page 166.)		
Check point			
Corrective action	Press MODE for 2 s to release the lock.		

Operation panel indication	LOCD	LOEd	
Name	Password locked		
Description	Password function is active. Display and setting of parameters are restricted.		
Check point			
Corrective action	Enter the password in <b>Pr.297 Password lock/unlock</b> to unlock the password function before operating.(Refer to page 173.)		

Operation panel indication	Er1	Er !	
Name	Parameter write er	ror	
Description	<ul> <li>Parameter setting was attempted while Pr.77 Parameter write selection is set to disable parameter write.</li> <li>Overlapping range has been set for the frequency jump.</li> <li>Overlapping range has been set for the adjustable 5 points V/F.</li> <li>The PU and inverter cannot make normal communication.</li> <li>IPM parameter initialization was attempted while Pr.72 = "25".</li> </ul>		
Check point	Check the Pr.77 Parameter write selection setting. (Refer to page 169.) Check the settings of Pr.31 to Pr.36 (frequency jump). (Refer to page 246.) Check the settings of Pr.100 to Pr.109 (adjustable 5 points V/F). (Refer to page 501.) Check the connection of PU and the inverter. Check the Pr.72 PWM frequency selection setting. A sine wave filter cannot be used under PM motor control.		

Operation panel indication	Er2	E-2
Name	Write error during operation	
Description	Parameter write was attempted while <b>Pr.77</b> = "0".	
Check point	Check that the inverter is stopped.	
Corrective action	<ul> <li>After stopping the operation, make parameter setting.</li> <li>When setting Pr.77 = "2", parameter write is enabled during operation. (Refer to page 169.)</li> </ul>	

Operation panel indication	Er3	E-3
Name	Calibration error	
Description	Analog input bias and gain calibration values have been set too close.	
Check point	Check the settings of calibration parameters C3, C4, C6 and C7 (calibration functions). (Refer to page 314.)	

Operation panel indication	Er4	E r- 4
Name	Mode designation error	
Description	Parameter setting was attempted in the External or NET operation mode while <b>Pr.77</b> = "1".  Parameter write was attempted when the command source is not at the operation panel (FR-DU08).	
Check point	Check that operation mode is PU operation mode.     Check that the <b>Pr.551</b> setting is correct.	
Corrective action	<ul> <li>After setting the operation mode to the "PU operation mode", make parameter setting. (Refer to page 200.)</li> <li>When Pr.77 = "2", parameter write is enabled regardless of the operation mode. (Refer to page 169.)</li> <li>Set Pr.551 = "2". (Refer to page 210.)</li> </ul>	

Operation panel indication	Er8	E-8	
Name	USB memory device	ce operation error	
Description  Check point	An operation command was given during the USB memory device operation.  A copy operation (writing) was performed while the PLC function was in the RUN state.  A copy operation was attempted for a password locked project.  Check if the USB memory device is operating.  Check if the PLC function is in the RUN state.		
•	Check if the project data is locked with a password.		
Corrective action	Perform the operation after the USB memory device operation is completed.  Stop the PLC function. (Refer to page 433 and the PLC function programming manual.)  Unlock the password of the project data using FR Configurator2. (Refer to the Instruction Manuals of FR Configurator2 and GX Works2.)		

Operation panel indication	rE1	r-E l	
Name	Parameter read er	Parameter read error	
Description	<ul> <li>A failure has occurred at the operation panel side EEPROM while reading the copied parameters.</li> <li>A failure has occurred in the USB memory device while copying the parameters or reading the PLC function project data.</li> </ul>		
Check point			
Corrective action	<ul> <li>Perform parameter copy again. (Refer to page 521, page 524.)</li> <li>Perform PLC function project data copy again. (Refer to page 433)</li> <li>The USB memory device may be faulty. Replace the USB memory device.</li> <li>The operation panel (FR-DU08) may be faulty. Please contact your sales representative.</li> </ul>		

Operation panel indication	rE2	-E2	
Name	Parameter write er	ror	
Description	<ul> <li>Parameter copy from the operation panel to the inverter was attempted during operation.</li> <li>A failure has occurred at the operation panel side EEPROM while writing the copied parameters.</li> <li>A failure has occurred in the USB memory device while writing the copied parameters or PLC function project data.</li> </ul>		
Check point	Check that the inverter is stopped.		
Corrective action	<ul> <li>After stopping the operation, perform parameter copy again. (Refer to page 521.)</li> <li>The operation panel (FR-DU08) may be faulty. Please contact your sales representative.</li> <li>Perform parameter copy or PLC project data copy again. (Refer to page 433 and page 524)</li> <li>The USB memory device may be faulty. Replace the USB memory device.</li> </ul>		

Operation panel indication	rE3	r-E3
Name	Parameter verificat	ion error
Description	<ul> <li>The data in the inverter are different from the data in the operation panel.</li> <li>A failure has occurred at the operation panel side EEPROM during parameter verification.</li> <li>A failure has occurred in the USB memory device during parameter verification.</li> <li>The data in the inverter are different from the data in the USB memory device or the personal computer (FR Configurator2)</li> </ul>	
Check point	Check the parameter setting of the source inverter against the setting of the destination inverter.	
Corrective action	Continue the verification by pressing SET.  Perform parameter verification again. (Refer to page 523.)  The operation panel (FR-DU08) may be faulty. Please contact your sales representative.  The USB memory device may be faulty. Replace the USB memory device.  Verify the PLC function project data again.(Refer to page 433.)	

Operation panel indication	rE4	r-E -1	
Name	Model error	Model error	
Description	<ul> <li>A different model was used when parameter copy from the operation panel or parameter verification was performed.</li> <li>The data in the operation panel were not correct when parameter copy from the operation panel or parameter verification was performed.</li> </ul>		
Check point	Check that the parameter copy or verification source inverter is of the same model. Check that parameter copy to the operation panel was not interrupted by switching OFF the power or by disconnecting the operation panel.		
Corrective action	<ul> <li>Perform parameter copy and parameter verification between inverters of the same model (FR-F800 series).</li> <li>Perform parameter copy to the operation panel from the inverter again.</li> </ul>		

Operation panel indication	rE6	-E5
Name	File error	
Description	The parameter copy file in the USB memory device cannot be recognized.  An error has occurred in the file system during transfer of the PLC function data or writing to RAM.	
Check point		
Corrective action	Perform parameter copy again.(Refer to page 524.)     Copy the PLC function project data again.(Refer to page 433.)	

Operation panel indication	rE7	r-E7	
Name	File quantity error		
Description	<ul> <li>A parameter copy was attempted to the USB memory device in which the copy files from 001 to 099 had already been saved.</li> </ul>		
Check point	Check if the number of copy files in the USB memory device has reached 99.		
Corrective action	• Delete the copy file in the USB memory device and perform parameter copy again.(Refer to page 524.)		

Operation panel indication	rE8	-58			
Name	No PLC function p	project file			
Description	The specified PLC	PLC function project file does not exist in the USB memory device.			
Check point		le exists in the USB memory device. older name and the file name in the USB memory device is correct.			
Corrective action	The data in the US	B memory device may be damaged.			

Operation panel indication	Err.	Err.			
Description	• This error may oc • When using a sep	is turned ON.  anel and inverter cannot make normal communication (contact faults of the connector).  occur when the voltage at the input side of the inverter drops.  eparate power source for the control circuit power (R1/L11, S1/L21) from the main circuit  L2, T/L3), this error may appear at turning ON of the main circuit. It is not a fault.			
Corrective action		ES signal. ection between the operation panel and the inverter. ge on the input side of the inverter.			

## **♦**Warning

Output is not shut off when a protective function activates.

Operation panel indication	OL		FR-PU07	OL			
Name	Stall prevention (ov	vercurrent)					
		ut current of the inverter increases, the stall prevention (overcurrent) function activates. ection explains about the stall prevention (overcurrent) function.					
	During acceleration	I averiage current decreases to prevent the inverter from resulting in avercurrent tru					
Description	constant-speed						
Check point	Check that the Pr.0 Torque boost setting is not too large. The Pr.7 Acceleration time and Pr.8 Deceleration time settings may be too short. Check that the load is not too heavy. Check for any failures in peripheral devices. Check that the Pr.13 Starting frequency is not too large. Check that Pr.22 Stall prevention operation level is appropriate.						
Corrective action	<ul> <li>Check that Pr.22 Stall prevention operation level is appropriate.</li> <li>Gradually increase or decrease the Pr.0 setting by 1% at a time and check the motor status.(Refer to page 496.)</li> <li>Set a larger value in Pr.7 Acceleration time and Pr.8 Deceleration time. (Refer to page 187.)</li> <li>Reduce the load.</li> <li>Try Advanced magnetic flux vector control.</li> <li>Change the Pr.14 Load pattern selection setting.</li> <li>The stall prevention operation current can be set in Pr.22 Stall prevention operation level. The acceleration/deceleration time may change. Increase the stall prevention operation level with Pr.22 Stall prevention operation level with Pr.22 Stall prevention operation level, or disable stall prevention with Pr.156 Stall prevention operation selection. (Use Pr.156 to set either operation continued or not at OL operation.)</li> </ul>						

Operation panel indication	oL	oL	FR-PU07	oL	
Name	Stall prevention (over	rvoltage)			
Description	When the output voltage of the inverter increases, the stall prevention (overvoltage) function activates.     The regeneration avoidance function activates due to excessive regenerative power of the motor. (Refer to page 514.)     The following section explains the stall prevention (overvoltage) function.    During deceleration   If the regenerative power of the motor becomes excessive to exceed the regenerative power consumption capability, this function stops decreasing the frequency to prevent overvoltage trip. As soon as the regenerative power has reduced, deceleration resumes.				
Check point	<ul> <li>Check for sudden speed reduction.</li> <li>Check if the regeneration avoidance function (Pr.882 to Pr.886) is being used. (Refer to page 514.)</li> </ul>				
Corrective action	The deceleration time	e may change. Increase	the deceleration til	me using Pr.8 Deceleration time.	

Operation panel indication	тн	<sup>-</sup>  -	FR-PU07	тн		
Name	Electronic thermal	relay function pre-alarm				
Description	Appears if the cumulative value of the electronic thermal O/L relay reaches or exceeds 85% of the preset level of <b>Pr.9 Electronic thermal O/L relay</b> . If the value reaches 100% of <b>Pr.9</b> setting, motor overload trip (E.THM) occurs.					
Check point	Check for large load or sudden acceleration.     Check that the <b>Pr.9</b> setting is appropriate. (Refer to page 225.)					
Corrective action		Reduce the load and frequency of operation. Set an appropriate value in <b>Pr.9</b> . (Refer to <b>page 225</b> .)				

Operation panel indication	PS	P5	FR-PU07	PS	
Name	PU stop				
Description	• The motor is stopped using Under the mode other than the PU operation mode. (To enable Under the mode other than the PU operation mode, set Pr.75 Reset selection/disconnected PU detection/PU stop selection. Refer to page 162 for details.)				
Check point	Check for a stop made by pressing				
Corrective action	• Turn the start sign	nal OFF and release with	PU EXT .		

Operation panel indication	СР	[P	FR-PU07	СР			
Name	Parameter copy	Parameter copy					
Description	Appears when parameter copy is performed between inverters FR-F820-02330(55K) or lower, FR-F840-01160(55K) or lower, FR-F820-03160(75K) or higher and FR-F840-01800(75K) or higher						
Check point	Resetting of Pr.9, Pr.30, Pr.51, Pr.56, Pr.57, Pr.72, Pr.80, Pr.82, Pr.90 to Pr.94, Pr.453, Pr.455, Pr.458 to Pr.462, Pr.557, Pr.859, Pr.860 and Pr.893 is necessary.						
Corrective action	Set the initial value	in Pr.989 Parameter co	py alarm release				

Operation panel indication	SA	58	FR-PU07	_	
Name	Safety stop				
Description	Appears when safe	ety stop function is activa	ted (during output	shutoff). (Refer to page 58.)	
Check point	<ul> <li>Check if an emergency stop device is activated.</li> <li>Check if the shorting wire between S1 and PC or between S2 and PC is disconnected when not using the safety stop function.</li> </ul>				
Corrective action	<ul> <li>An emergency stop device is active when using the safety stop function. Identify the cause of emergency stop, ensure the safety and restart the system.</li> <li>When not using the safety stop function, short across terminals S1 and PC and across S2 and PC with shorting wire for the inverter to run.</li> </ul>				
	the safety stop fu	Fig. is indicated when wires across S1 and SIC and across S2 and SIC are both conducted while using afety stop function (drive enabled), internal failure might be the cause. Check the wiring of terminals S2 and SIC and contact your sales representative if the wiring has no fault.			

Operation panel indication	MT1 to MT3	M 1 to	FR-PU07	MT*1	
Name	Maintenance signa	l output 1 to 3			
Description	Appears when the inverter's cumulative energization time reaches or exceeds the parameter set value. Set the time until the MT is displayed using Pr.504 Maintenance timer 1 warning output set time (MT1), Pr.687 Maintenance timer 2 warning output set time (MT2), and Pr.689 Maintenance timer 3 warning output set time (MT3).  MT does not appear when the settings of Pr.504, Pr.687, and Pr.689 are initial values (9999).				
Check point	The set time of maintenance timer has been exceeded. (Refer to page 184.)				
Corrective action		3 Maintenance timer 1,		of the maintenance timer setting. nce timer 2, and Pr.688 Maintenance timer 3	

<sup>\*1</sup> MT appears for all of MT1, MT2 and MT3.

Operation panel indication	UF	LIF	FR-PU07	-		
Name	USB host error					
Description	Appears when an excessive current flows into the USB A connector.					
Check point	Check if a USB device other than a USB memory device is connected to the USB A connector.					
Corrective action	• If a device other than a USB memory device is connected to the USB A connector, remove the device. • Setting <b>Pr.1049 USB host reset</b> = "1" or inverter reset clears the UF indication.					

Operation panel indication	EV	El	FR-PU07	_	
Name	24 V external power supply operation				
Description	Flickers when the main circuit power supply is off and the 24 V external power supply is being input.				
Check point	Power is supplied from a 24 V external power supply.				
Corrective action	<ul> <li>Turning ON the power supply (main circuit) of the inverter clears the indication.</li> <li>If the indication is still displayed after turning ON of the power supply (main circuit) of the inverter, the power supply voltage may be low, or the jumper between the terminals P/+ and P1 may be disconnected.</li> </ul>				

Operation panel indication	ED	Ed	FR-PU07	_		
Name	Emergency drive in	Emergency drive in operation				
Description	Appears during emergency drive operation.					
Check point	Emergency drive operation is performed by turning ON X84 signal.					
Corrective action	The display is clear	• The display is cleared when the emergency drive operation ends. (Refer to page 238.)				

Operation panel indication	LDF	LdF	FR-PU07	_							
Name	Load fault warning										
Description	• • •	Appears when the load is deviated from the detection width set in Pr.1488 Upper limit warning detection width or Pr.1489 Lower limit warning detection width.									
Check point		Check if too much load is applied to the equipment, or if the load is too light.     Check that the load characteristics settings are correct.									
Corrective action	<ul> <li>Inspect the equipment.</li> <li>Set the load characteristics (Pr.1481 to Pr.1487) correctly.</li> </ul>										

#### **♦**Alarm

Output is not shut off when a protective function activates. An alarm can also be output with a parameter setting. (Set "98" in Pr.190 to Pr.196 (output terminal function selection). (Refer to page 288.)

Operation panel indication	FN	FN	FR-PU07	FN								
Name	Fan alarm	Fan alarm										
Description		_		e operation panel when the cooling fan stops e setting of <b>Pr.244 Cooling fan operation</b>								
Check point	Check the cooling	Check the cooling fan for a failure.										
Corrective action	The fan may be fau	ılty. Please contact your	sales representativ	/e.								

#### **♦**Fault

When a protective function activates, the inverter trips and a fault signal is output.

Operation panel indication	E.OC1	E.			FR-PU07	OC During Acc					
Name	Overcurrent trip during acceleration										
Description	When the inverter output current reaches or exceeds approximately 170% (LD rating) / 148% (SLD rating) of the rated current during acceleration, the protection circuit is activated and the inverter trips.										
Check point	<ul> <li>Check for sudden speed acceleration.</li> <li>Check if the downward acceleration time is too long in a lift application.</li> <li>Check for output short-circuit.</li> <li>Check that the Pr.3 Base frequency setting is not 60 Hz when the motor rated frequency is 50 Hz.</li> <li>Check if the stall prevention operation level is set too high. Check if the fast-response current limit operation is disabled.</li> <li>Check that the regenerative driving is not performed frequently. (Check if the output voltage becomes larger than the V/F reference voltage at regenerative driving and overcurrent occurs due to increase in the motor current.)</li> <li>Check that the inverter capacity matches with the motor capacity. (PM motor control)</li> <li>Check if a start command is given to the inverter while the motor is coasting. (PM motor control)</li> </ul>										
Corrective action	If "E.OC1" always If "E.OC1" still appeared the wiring to Set 50 Hz in Pr.3  Lower the stall program (Refer to page 24) Set the base volta (Refer to page 49) Choose inverter a	appears, co to make : Base free evention 48.) age (rated 7.) and motor	s at start, discontact your sa sure that outpequency. (Re- operation level d voltage of the r capacities the er the motor s	conne lles r out s efer to el. A ne m nat m	ect the motor once persentative. hort circuit does to page 497.) activate the fast-rootor, etc.) in Pr.1 match. (PM motor, Alternatively, us	esponse current limit operation.  9 Base frequency voltage.  control) se the automatic restart after instantaneous					

Operation panel indication	E.OC2	E.	002	FR-PU07	Stedy Spd OC							
Name	Overcurrent trip du	Overcurrent trip during constant speed										
Description		When the inverter output current reaches or exceeds approximately 170% (LD rating) / 148% (SLD rating) of the rated current during constant-speed operation, the protection circuit is activated and the inverter trips.										
Check point	<ul> <li>Check for output</li> <li>Check if the stall pis disabled.</li> <li>Check that the investment</li> </ul>	Check for sudden load change. Check for output short-circuit. Check if the stall prevention operation level is set too high. Check if the fast-response current limit operation is disabled. Check that the inverter capacity matches with the motor capacity. (PM motor control) Check if a start command is given to the inverter while the motor is coasting. (PM motor control)										
Corrective action	<ul><li>(Refer to page 24</li><li>Choose inverter a</li><li>Input a start common commo</li></ul>	to make evention 8.) Ind moto after the second contraction in the seco	operation level.  or capacities that ter the motor stop	Activate the fast-rematch. (PM motor	esponse current limit operation.  control) se the automatic restart after instantaneous							

Operation panel indication	E.OC3	E.	003	FR-PU07	OC During Dec							
Name	Overcurrent trip du	Overcurrent trip during deceleration or stop										
Description	When the inverter output current reaches or exceeds approximately 170% (LD rating) / 148% (SLD rating) of the rated current during deceleration (other than acceleration or constant speed), the protection circuit is activated and the inverter trips.											
Check point	Check for sudden speed reduction.  Check for output short-circuit.  Check for too fast operation of the motor's mechanical brake.  Check if the stall prevention operation level is set too high. Check if the fast-response current limit operation is disabled.  Check that the inverter capacity matches with the motor capacity. (PM motor control)											
Corrective action	Check if a start command is given to the inverter while the motor is coasting. (PM motor control)  Set the deceleration time longer.  Check the wiring to make sure that output short circuit does not occur.  Check the mechanical brake operation.  Lower the stall prevention operation level. Activate the fast-response current limit operation. (Refer to page 248.)  Choose inverter and motor capacities that match. (PM motor control)  Input a start command after the motor stops. Alternatively, use the automatic restart after instantaneous power failure/flying start function. (Refer to page 420.) (PM motor control)											

Operation panel indication	E.OV1	E.		1	FR-PU07	OV During Acc		
Name	Regenerative over	voltage t	rip during	accele	ration			
Description	value, the protection	If regenerative power causes the inverter's internal main circuit DC voltage to reach or exceed the specified value, the protection circuit is activated to stop the inverter output. The circuit may also be activated by a surge voltage produced in the power supply system.						
Check point	Check that the Pr	.22 Stall	prevention	n ope	eration level is no	leration in vertical lift load) t set to the no load current or lower. in an application with a large load inertia.		
Corrective action	Set a value larger	tion avoi	dance fun e no load d	urrent	in <b>Pr.22</b> .	(Refer to page 514.) ntion operation = "10, 11". (Refer to page		

Operation panel indication	E.OV2	E.		FR-PU07	Stedy Spd OV							
Name	Regenerative over	Regenerative overvoltage trip during constant speed										
Description	If regenerative power causes the inverter's internal main circuit DC voltage to reach or exceed the specified value, the protection circuit is activated to stop the inverter output. The circuit may also be activated by a surge voltage produced in the power supply system.											
Check point	Check for sudden load change. Check that the Pr.22 Stall prevention operation level is not set to the no load current or lower. Check if the stall prevention operation is frequently activated in an application with a large load inertia. Check that acceleration/deceleration time is not too short.											
Corrective action	Use the brake uniting the set a value larger     Set Pr.154 Voltage 248.)     Set the acceleration.	tion avoid t or power than the ge reduction/decelor eased. I	er regeneration of no load current tion selection ceration time long However, sudder	common converter in <b>Pr.22</b> . luring stall preve ger. (Under Advance	(Refer to page 514.) r (FR-CV) as required. ntion operation = "10, 11". (Refer to page ced magnetic flux vector control, the output y cause an overshoot in speed, resulting in an							

Operation panel indication	E.OV3	E. OV	FR-PU07	OV During Dec					
Name	Regenerative over	voltage trip during d	eceleration or stop						
Description	value, the protection	If regenerative power causes the inverter's internal main circuit DC voltage to reach or exceed the specified value, the protection circuit is activated to stop the inverter output. The circuit may also be activated by a surge voltage produced in the power supply system.							
Check point		<ul> <li>Check for sudden speed reduction.</li> <li>Check if the stall prevention operation is frequently activated in an application with a large load inertia.</li> </ul>							
Corrective action	<ul> <li>Check if the stall prevention operation is frequently activated in an application with a large load inertia.</li> <li>Set the deceleration time longer. (Set the deceleration time which matches the moment of inertia of the load.)</li> <li>Make the brake cycle longer.</li> <li>Use the regeneration avoidance function (Pr.882 to Pr.886). (Refer to page 514.)</li> <li>Use the brake unit or power regeneration common converter (FR-CV) as required.</li> <li>Set Pr.154 Voltage reduction selection during stall prevention operation = "10, 11". (Refer to page 248.)</li> </ul>								

Operation panel indication	E.THT	E.	-    -    -    - - - - - - - - - - -	FR-PU07	Inv. Overload			
Name	Inverter overload to	ip*1						
Description	When the temperature of the output transistor element exceeds the protection level while a current flows at the rated output current level or higher without causing an overcurrent trip (E.OC[]), the inverter output is stopped.(Permissible overload capacity 120% 60 s)							
Check point	Check that acceleration/deceleration time is not too short.  Check that torque boost setting is not too large (small).  Check that load pattern selection setting is appropriate for the load pattern of the using machine.  Check the motor for the use under overload.							
Corrective action	<ul><li>Set the accelerati</li><li>Adjust the torque</li><li>Set the load patte</li><li>Reduce the load.</li></ul>	boost set	tting.		attern of the using machine.			

<sup>\*1</sup> Resetting the inverter initializes the internal cumulative heat value of the electronic thermal O/L relay function.

Operation panel indication	E.THM	E.	<u> </u>	1-114	FR-PU07	Motor Ovrload		
Name	Motor overload trip	*2						
Description	The electronic thermal O/L relay function in the inverter detects motor overheat, which is caused by overload or reduced cooling capability during low-speed operation. When the cumulative heat value reaches 85% of the <b>Pr.9 Electronic thermal O/L relay</b> setting, pre-alarm (TH) is output. When the accumulated value reaches the specified value, the protection circuit is activated to stop the inverter output.							
Check point	Check the motor for the use under overload. Check that the setting of <b>Pr.71 Applied motor</b> for motor selection is correct. (Refer to <b>page 337</b> .) Check that the stall prevention operation setting is correct.							
Corrective action	<ul><li>Reduce the load.</li><li>For a constant-to.</li><li>Set the stall preven</li></ul>	•			•			

<sup>\*2</sup> Resetting the inverter initializes the internal cumulative heat value of the electronic thermal O/L relay function.

Operation panel indication	E.FIN	E.	FI	N	FR-PU07	H/Sink O/Temp	
Name	Heatsink overheat						
Description	The FIN signal can protection operation For the terminal us	be outp n tempe ed for th	out where rature. ne FIN si	the tem	perature becomes put, assign the fun	es, and the inverter output is stopped. approximately 85% of the heatsink overheat ction by setting "26 (positive logic) or 126 ction selection). (Refer to page 288.)	
Check point	Check for too high surrounding air temperature. Check for heatsink clogging. Check that the cooling fan is not stopped. (Check that FN is not displayed on the operation panel.)						
Corrective action	Set the surroundirection     Clean the heatsin     Replace the cooli	k.	mperatu	re to wit	hin the specificatio	ns.	

Operation panel indication	E.IPF	E.	1	PF	FR-PU07	Inst. Pwr. Loss
Name	Instantaneous pow	er failure	(Star	ndard mod	els only)	
Description	If a power failure occurs for longer than 15 ms (this also applies to inverter input shut-off), the instantaneous power failure protective function is activated to trip the inverter in order to prevent the control circuit from malfunctioning. If a power failure persists for 100 ms or longer, the fault warning output is not provided, and the inverter restarts if the start signal is ON upon power restoration. (The inverter continues operating if an instantaneous power failure is within 15 ms.) In some operating status (load magnitude, acceleration/deceleration time setting, etc.), overcurrent or other protection may be activated upon power restoration. When instantaneous power failure protection is activated, the IPF signal is output. (Refer to page 414, page 420.)					
Check point	Find the cause of i	nstantane	ous p	power failu	re occurrence.	
Corrective action	• Remedy the insta • Prepare a backup • Set the function of (Refer to page 41)	power su f automati	ipply	for instant		

Operation panel indication	E.UVT	E.	[], [	FR-PU07	Under Voltage			
Name	Undervoltage (Star	ndard mo	odels only)					
Description	If the power supply voltage of the inverter decreases, the control circuit will not perform normal functions. In addition, the motor torque will be insufficient and/or heat generation will increase. To prevent this, if the power supply voltage decreases to about 150 VAC (300 VAC for the 400 V class) or below, this function shuts off the inverter output.  When a jumper is not connected across P/+ and P1, the undervoltage protective function is activated. When undervoltage protection is activated, the IPF signal is output. (Refer to page 414, page 420.)							
Check point	•	<ul> <li>Check if a high-capacity motor is driven.</li> <li>Check if the jumper is connected across terminals P/+ and P1.</li> </ul>						
Corrective action		e jumpei	r across terminal	s P/+ and P1 exce	er supply.  Ppt when connecting a DC reactor.  Contact your sales representative.			

Operation panel indication	E.ILF	Œ.	1	LF	-	FR-PU07	Input phase loss	
Name	Input phase loss (S	Input phase loss (Standard models only)						
Description	When <b>Pr.872 Input phase loss protection selection</b> is enabled ("1") and one of the three-phase power input is lost, the inverter output is shut off. This protective function is not available when <b>Pr.872</b> is set to the initial value ( <b>Pr.872</b> = "0"). (Refer to <b>page 235</b> )							
Check point	Check for a break	Check for a break in the cable for the three-phase power supply input.						
Corrective action	Wire the cables properly.     Repair a break portion in the cable.							

Operation panel indication	E.OLT	E. OLF	FR-PU07	Stil Prev STP					
Name	Stall prevention sto	pp							
If the output frequency has fallen to 0.5 Hz by stall prevention operation and remains for 3 s, a fault appears and the inverter trips. OL appears while stall prevention is being activated.									
Description	During speed control, a fault (E.OLT) appears and the inverter trips if the frequency value converted from the motor rotation speed drops to 1.5 Hz or lower by stall prevention operation and the output torque exceeds the <b>Pr.874 OLT level setting</b> (refer to <b>page 248</b> ) and remains there for 3 s.								
Check point	Check that the Pr (Check the Pr.22 vector control.)	Check the motor for the use under overload. Check that the Pr.865 and Pr.874 values are correct. (Check the Pr.22 Stall prevention operation level setting under V/F control and Advanced magnetic flux							
Corrective action	<ul> <li>Check if a motor is connected under PM motor control.</li> <li>Reduce the load.</li> <li>Change the Pr.22, Pr.865, and Pr.874 values. (Check the Pr.22 setting under V/F control and Advanced magnetic flux vector control.)</li> <li>For a test run without connecting a motor, select the PM sensorless vector control test operation. (Refer to page 144.)</li> <li>Also check that the stall prevention (overcurrent) warning (OL) or the stall prevention (overvoltage) warning (OL) countermeasure is taken.</li> </ul>								

7		
	•	
	1	

Operation panel indication	E.SOT	E.	50/	FR-PU07	Motor step out				
Name	Loss of synchronis	sm detec	tion						
Description	The inverter trips motor control.)	The inverter trips when the motor operation is not synchronized. (This function is only available under PM motor control.)							
Check point	Check that the PM motor is not driven overloaded. Check if a start command is given to the inverter while the PM motor is coasting. Check if a motor is connected under PM motor control. Check if a PM motor other than the MM-EFS/MM-THE4 series is driven.								
Corrective action	Reduce the load If the inverter res restart after insta Check the conne For a test run wit Drive an IPM mo	<ul> <li>Set the acceleration time longer.</li> <li>Reduce the load.</li> <li>If the inverter restarts during coasting, set Pr.57 Restart coasting time ≠ "9999", and select the automatic restart after instantaneous power failure.</li> <li>Check the connection of the IPM motor.</li> <li>For a test run without connecting a motor, select the PM motor control test operation.(Refer to page 144.)</li> <li>Drive an IPM motor (MM-EFS/MM-THE4)</li> <li>When driving an IPM motor other than MM-EFS/MM-THE4 series, offline auto tuning must be performed.</li> </ul>							

Operation panel indication	E.LUP	E.	LUP	FR-PU07	Fault				
Name	Upper limit fault de	Upper limit fault detection							
Description		When the load exceeds the upper limit fault detection range, the inverter trips. This protective function is not available in the initial setting of <b>Pr.1490</b> ( <b>Pr.1490</b> = "9999").							
Check point		Check if too much load is applied to the equipment.     Check that the load characteristics settings are correct.							
Corrective action	Inspect the equipment of the load characters.		cs (Pr.1481 to Pr	r.1487) correctly.					

Operation panel indication	E.LDN	E.		FR-PU07	Fault				
Name	Lower limit fault de	Lower limit fault detection							
Description		When the load falls below the lower limit fault detection range, the inverter trips. This protective function is not available in the initial setting of <b>Pr.1491</b> ( <b>Pr.1491</b> = "9999").							
Check point		Check if the equipment load is too light.     Check that the load characteristics settings are correct.							
Corrective action	Inspect the equipm     Set the load chara		s ( <b>Pr.1481 to P</b> r	.1487) correctly.					

Operation panel indication	E.GF	E.	GF	FR-PU07	Ground Fault			
Name	Output side earth (	ground) fa	ult overcurren	t				
Description	•	The inverter trips if an earth (ground) fault overcurrent flows due to an earth (ground) fault that occurred on the inverter's output side (load side).						
Check point	Check for an earth	Check for an earth (ground) fault in the motor and connection cable.						
Corrective action	Remedy the earth	ground) fa	ault portion.					

Operation panel indication	E.LF	E.	LF	FR-PU07	E.LF				
Name	Output phase loss								
Description	The inverter trips if	The inverter trips if one of the three phases (U, V, W) on the inverter's output side (load side) is lost.							
Check point	Check that the ca	<ul> <li>Check the wiring. (Check that the motor is normally operating.)</li> <li>Check that the capacity of the motor used is not smaller than that of the inverter.</li> <li>Check if a start command is given to the inverter while the motor is coasting. (PM motor control)</li> </ul>							
Corrective action	• Input a start comr	Wire the cables properly.     Input a start command after the motor stops. Alternatively, use the automatic restart after instantaneous power failure/flying start function (page 420). (PM motor control)							

Operation panel indication	E.OHT	E.		FR-PU07	OH Fault		
Name	External thermal re	lay oper	ration				
Description	The inverter trips if the external thermal relay provided for motor overheat protection or the internally mounted thermal relay in the motor, etc. switches ON (contacts open).  This function is available when "7" (OH signal) is set in any of <b>Pr.178 to Pr.189 (input terminal function selection)</b> . This protective function is not available in the initial status. (OH signal is not assigned.)						
Check point	<ul> <li>Check for motor overheating.</li> <li>Check that the value "7" (OH signal) is set correctly to any of Pr.178 to Pr.189 (input terminal function selection).</li> </ul>						
Corrective action	• Reduce the load a • Even if the relay of		•	atically, the inverte	r will not restart unless it is reset.		

Operation panel indication	E.PTC	E.	PFE	FR-PU07	PTC activated			
Name	PTC thermistor op	eration						
Description	equal to or higher to	The inverter trips if resistance of the PTC thermistor connected between the terminal 2 and terminal 10 is equal to or higher than the <b>Pr.561 PTC thermistor protection level</b> setting for a continuous time equal to or longer than the setting value in <b>Pr.1016 PTC thermistor protection detection time</b> . When the initial value ( <b>Pr.561</b> = "9999") is set, this protective function is not available.						
Check point	Check the connection with the PTC thermistor. Check the Pr.561, Pr.1016 setting. Check the motor for operation under overload.							
Corrective action	Reduce the load.							

Operation panel indication	E.OPT	E.		FR-PU07	Option Fault				
Name	Option fault								
Description	<ul> <li>Appears when the AC power supply is connected to the terminal R/L1, S/L2, or T/L3 accidentally when a high power factor converter (FR-HC2) or power regeneration common converter (FR-CV) is connected (when Pr.30 Regenerative function selection = "2").</li> <li>Appears when the switch for manufacturer setting of the plug-in option is changed.</li> <li>Appears when a communication option is connected while Pr.296 Password lock level = "0 or 100".</li> </ul>								
Check point	Check that the AC power supply is not connected to the terminal R/L1, S/L2, or T/L3 when a high power factor converter (FR-HC2) or power regeneration common converter (FR-CV) is connected (when Pr.30 = "2").      Check for the password lock with a setting of Pr.296 = "0, 100".								
Corrective action	<ul> <li>Check for the password lock with a setting of Pr.296 = "0, 100".</li> <li>Check the Pr.30 setting and wiring.</li> <li>The inverter may be damaged if the AC power supply is connected to the terminal R/L1, S/L2, or T/L3 when a high power factor converter is connected. Please contact your sales representative.</li> <li>Set the switch on the plug-in option, which is for manufacturer setting, back to the initial setting. (Refer to the Instruction Manual of each option.)</li> <li>To apply the password lock when installing a communication option, set Pr.296 ≠ "0, 100". (Refer to page 171.)</li> </ul>								

Operation panel indication	E.OP1	E.		1	FR-PU07	Option1 Fault					
Name	Communication op	Communication option fault									
Description	The inverter trips if	The inverter trips if a communication line error occurs in the communication option.									
Check point	Check that the plu     Check for a break	Check for an incorrect option function setting and operation.  Check that the plug-in option is plugged into the connector properly.  Check for a break in the communication cable.  Check that the terminating resistor is fitted properly.									
Corrective action	Check the option Connect the plug- Check the connect	in optior	n securely.		able.						

Operation panel indication	E.16 to E.20	EE	15 to	FR-PU07	_			
Name	User definition erro	r by the PL	_C function					
Description	The inverter trips we have the protective function in the initial setting	hen the pr tion is activ ( <b>Pr.414</b> = '	otective function of the other other of the	on is activated. PLC function is enal	pecial register SD1214 for the PLC function.  bled. This protective function is not available  by sequence programs.			
Check point	Check if "16 to 20" is set in the special register SD1214.							
Corrective action	• Set a value other than "16 to 20" in the special register SD1214.							

Operation panel indication	E.PE	E.	PE	FR-PU07	Corrupt Memory				
Name	Parameter storage	device fau	ult (control circ	uit board)					
Description	The inverter trips if	a fault oc	curs in the para	ameter stored. (EE	PROM failure)				
Check point	Check for too many	Check for too many number of parameter write times.							
Corrective action		ommunic	ation EEPRO		(write to RAM) for the operation which requires writing to RAM goes back to the initial status at				

Operation panel indication	E.PUE	E.	PLIE	FR-PU07	PU Leave Out							
Name	PU disconnection	PU disconnection										
Description	the parameter uni Reset selection/o • The inverter trips retries when Pr.12	is disconn f comm 1 Numl f comm	onnected, when the connected PU detection errors of the communication is broken ber of PU communication is broken.	the disconnected F tion/PU stop sele occurred consecut nunication retries en within the perio	ively for more than permissible number of ≠ "9999" during the RS-485 communication. d of time set in <b>Pr.122 PU communication</b>							
Check point	Check that the operation panel or the parameter unit is connected properly.     Check the Pr.75 setting.											
Corrective action	Fit the operation pa	nel or th	he parameter uni	t securely.								

Operation panel indication	E.RET	E.	REL	FR-PU07	Retry No Over				
Name	Retry count excess	;							
Description		The inverter trips if the operation cannot be resumed properly within the number of retries set in <b>Pr.67 Number of retries at fault occurrence</b> .							
Check point	Find the cause of the fault occurrence.								
Corrective action	Eliminate the cause of the error preceding this error indication.								

Operation panel indication	E.PE2	E.	PEZ	FR-PU07	PR storage alarm				
Name	Parameter storage	device f	faultParameter s	torage device fault	(main circuit board)				
Description	The inverter trips if	The inverter trips if a fault occurs in the parameter stored. (EEPROM failure)							
Check point									
Corrective action	Please contact your sales representative.								

	CPU	E. (	FU		CPU Fault						
Operation panel	E. 5	E.	U	FR-PU07	Fault 5						
indication	E. 6	E.	8	FR-PUU1	Fault 6						
	E. 7	E.			Fault 7						
Name	CPU fault	PU fault									
Description	The inverter trips if	the commu	nication fault	of the built-in CPU	J occurs.						
Check point	Check for devices producing excess electrical noises around the inverter.										
Corrective action		• Take measures against noises if there are devices producing excess electrical noises around the inverter. • Please contact your sales representative.									

Operation panel indication	E.CTE	E.		ΓE		FR-PU07	E.CTE		
Name	Operation panel po	wer su	oply sh	ort circu	cuit/R	S-485 terminals	power supply short circuit		
Description	the inverter trips. connector are dis the RS-485 termi • When the power s	The use abled. The last, or supply for the last, or munication.	of the or reservent or the Fondard	operation operat	tion par the f OFF term	anel (parameter on RES signal from then ON again. inals are short ci	or) is shorted, the power output is shutoff and unit) and the RS-485 communication via the PU the terminal, reset via communication through reuited, this function shuts off the power output.  ot be made. To reset, use STOP of the then ON again.		
Check point		Check that the PU connector cable is not shorted. Check that the RS-485 terminals are connected correctly.							
Corrective action	Check PU and the Check the connection.		the RS	-485 te	ermin	als.			

Operation panel indication	E.P24	E. Par	FR-PU07	E.P24								
Name	24 VDC power faul	24 VDC power fault										
Description	When the 24 VDC power output from the PC terminal is shorted, this function shuts off the power output. At this time, all external contact inputs switch OFF. The inverter cannot be reset by entering the RES signal. To reset it, use the operation panel, or switch power OFF, then ON again.											
Check point		circuit in the PC terr V external power su	ninal output. pply voltage is correc	t.								
Corrective action		at 24 V. (If the power		e is supplied to the 24V input circuit for a long t correct voltage although it will not damage the								

Operation panel indication	E.CDO	E.	[40	FR-PU07	OC detect level				
Name	Abnormal output current detection								
Description	The inverter trips if the output current exceeds the <b>Pr.150 Output current detection level</b> setting.  This functions is available when <b>Pr.167 Output current detection operation selection</b> is set to "1". When the initial value ( <b>Pr.167</b> = "0") is set, this protective function is not available.								
Check point	Check the settings detection signal r				on signal delay time, Pr.166 Output current 296.)				

Operation panel indication	E.IOH	Щ	1		FR-PU07	Inrush overheat		
Name	Inrush current limit	circuit fa	ault (	Standard me	odels only)			
Description	The inverter trips w circuit failure	The inverter trips when the resistor of the inrush current limit circuit is overheated. The inrush current limit circuit failure						
Check point	• Check if the input F840-03250(132h	<ul> <li>Check that frequent power ON/OFF is not repeated.</li> <li>Check if the input side fuse (5A) in the power supply circuit of the inrush current limit circuit contactor (FR-F840-03250(132K) or higher) is blown.</li> <li>Check that the power supply circuit of inrush current limit circuit contactor is not damaged.</li> </ul>						
Corrective action	•	Configure a circuit where frequent power ON/OFF is not repeated.  If the situation does not improve after taking the above measure, please contact your sales representative.						

Operation panel indication	E.SER	E.	SER	FR-PU07	VFD Comm error						
Name	Communication fac	Communication fault (inverter)									
Description	more when Pr.335	RS-485 The inve	communication erter also trips if	n retry count ≠ "9	ively for the permissible number of retries or 999" during RS-485 communication from the broken for the period of time set in <b>Pr.336 RS</b> -						
Check point	Check the RS-485 terminal wiring.										
Corrective action	Perform wiring of the RS-485 terminals properly.										

Operation panel indication	E.AIE	E.	FI	E	FR-PU07	Analog in error	
Name	Analog input fault	Analog input fault					
Description	The inverter trips when a 30 mA or higher current or a 7.5 V or higher voltage is input to terminal 2 while the current input is selected by <b>Pr.73 Analog input selection</b> , or to terminal 4 while the current input is selected by <b>Pr.267 Terminal 4 input selection</b> .						
Check point	Check the Pr.73, Pr.267, and the voltage/current input switch settings.(Refer to page 306)						
Corrective action	Either give a currer input and input a vo		an 30 m	nA, or se	t <b>Pr.73</b> , <b>Pr.267</b> , an	d the voltage/current input switch to the voltage	

Operation panel indication	E.USB	E.	USE	FR-PU07	USB comm error		
Name	USB communication	USB communication fault					
Description	The inverter trips w time interval.	The inverter trips when the communication is cut off for the time set in <b>Pr.548 USB communication check</b> time interval.					
Check point	Check that the US	Check that the USB communication cable is connected securely.					
Corrective action	• Check the Pr.548 • Connect the USB • Increase the Pr.54	commu		,	3.)		

Operation panel indication	E.SAF	Ε.	SAF	FR-PU07	E.SAF Fault		
Name	Safety circuit fault						
Description	<ul> <li>The inverter trips when a safety circuit fault occurs.</li> <li>The inverter trips if the either of the wire between S1 and SIC or S2 and SIC becomes non-conductive while using the safety stop function.</li> <li>When not using the safety stop function, the inverter trips when the shorting wire between terminals S1 and PC or across S2 and PC is disconnected.</li> </ul>						
Check point	Check if the short	Check that the safety relay module or the connection has no fault when using the safety stop function.     Check if the shorting wire between S1 and PC or between S2 and PC is disconnected when not using the safety stop function.					
Corrective action	stop input signal s function instruction the manual.)	source s n manu ne safet	such as a safety and for causes and sy stop function, s	relay module is oped countermeasures	minal S1, S2 and SIC is correct and the safety erating properly. Refer to the Safety stop s. (Please contact your sales representative for als S1 and PC and across S2 and PC with		

	E.PBT	E. Pbf		Fault		
Operation panel indication	E.13	E. III	FR-PU07	Fault 13		
	E.BE	E. 5E		Br.Cct.Fault		
Name	Opposite rotation d	leceleration fault				
Description	The inverter trips w	The inverter trips when an internal circuit fault occurs.				
Corrective action	Please contact you	ır sales representative.				

#### **Causes and corrective actions**

Operation panel indication	E.OS	E.	05	FR-PU07	E.OS		
Name	Overspeed occurre	Overspeed occurrence					
Description		The inverter trips when the motor speed exceeds the <b>Pr.374 Overspeed detection level</b> under PM motor control. This protective function is not available in the initial status.					
Check point	Check that the Pr	.374 settir	ng is correct.				
Corrective action	• Set the Pr.374 co	rrectly.					

Operation panel indication	E.LCI	E. L		FR-PU07	Fault	
Name	4 mA input fault					
Description	The inverter trips when the analog input current is 2 mA or less for the time set in <b>Pr.778 4 mA input check filter</b> . This function is available when <b>Pr.573 4 mA input check selection</b> = "2 or 3". (Refer to page 325.)  This function is not available in the initial status.					
Check point	<ul> <li>Check for a break in the wiring for the analog current input.</li> <li>Check that the Pr.778 setting is not too short.</li> </ul>					
Corrective action	• Check the wiring • Set the <b>Pr.778</b> se		current inp	ut.		

Operation panel indication	E.PCH	E.	PEH	FR-PU07	Fault		
Name	Pre-charge fault						
Description	• The inverter trips charging.	when the	measured valu	e exceeds Pr.763	Pre-charge time limit. Pre-charge upper detection level during pre- his protective function is not available in the		
Check point	• Check that the Pr • Check that the Pr	<ul> <li>Check that the Pr.764 setting is not too short.</li> <li>Check that the Pr.763 setting is not too small.</li> <li>Check that the Pr.127 PID control automatic switchover frequency setting is not too low.</li> <li>Check for a break in the connection to the pump.</li> </ul>					
Corrective action	• Set the Pr.764 se • Set the Pr.763 se • Set the Pr.127 se • Check the connect	ting large	er. er.				

Operation panel indication	E.PID	E.	FI	급	FR-PU07	Fault PID Signal Error
Name	PID signal fault					
Description	the absolute devia Set this function in	ion valu <b>Pr.131 I</b>	e excee PID upp	ds the P <b>er limit</b> ,	ID deviation paran Pr.132 PID lower	er limit or PID lower limit parameter setting, or neter setting during PID control.  Imit, Pr.553 PID deviation limit, and Pr.554 rotective function is not available in the initial
Check point	Check the meter     Check that the pa				rect.	
Corrective action	• Check that the me • Set the paramete			e or bre	ak.	

7	Ν
Ξ	À
•	v

Operation panel indication	E. 1 to E. 3	E.	10 	FR-PU07	Fault 1 to Fault 3
Name	Option fault				
Description	communication opt	ion is not connec	ted to th	ne connector 1.	verter and the plug-in option, or when the in option is changed.
Check point	Check that the plu (1 to 3 indicate co Check for excessi Check if the comr	nnector numbers ve noise around	for con the inve	nection of options rter.	.)
Corrective action	If the situation do	gainst noises if these not improve af munication option the plug-in option	tere are ter takin to the o which	g the above meas	g excess electrical noises around the inverter. sure, please contact your sales representative. r setting, back to the initial setting. (Refer to the

- If protective functions with indication of "Fault" are activated when using the FR-PU07, "ERR" appears in the faults history of
  - If faults other than the above appear, contact your sales representative.

#### 6.6 Check first when you have a trouble

#### NOTE

• If the cause is still unknown after every check, it is recommended to initialize the parameters, set the required parameter values and check again.

#### 6.6.1 **Motor does not start**

Check points	Possible cause	Countermeasure	Refer to page
	Appropriate power supply voltage is not applied. (Operation panel display is not provided.)	Power on a molded case circuit breaker (MCCB), an earth leakage circuit breaker (ELB), or a magnetic contactor (MC). Check for the decreased input voltage, input phase loss, and wiring.	_
	(Operation panel display is not provided.)	If only the control power is ON when using a separate power source for the control circuit, turn ON the main circuit power.	55
Main Circuit	Motor is not connected properly.	Check the wiring between the inverter and the motor.  If the electronic bypass function is active, check the wiring of the magnetic contactor (MC) between the inverter and the motor.	38
	The jumper across P/+ to P1 is disconnected. A DC reactor (FR-HEL) is not connected.	Securely fit a jumper across P/+ and P1. When using a DC reactor (FR-HEL), remove the jumper across P/+ to P1, and then connect the DC reactor. Connect the DC reactor securely when required according to the capacity.	38, 69
	Start signal is not input.	Check the start command source, and input a start signal.  PU operation mode: FWD / REV  External operation mode: STF/STR signal	203
	Both the forward and reverse rotation start signals (STF, STR) are input simultaneously.	Turn ON only one of the forward and reverse rotation start signals (STF or STR).  When the STF and STR signals are turned ON simultaneously in the initial setting, a stop command is given.	46
	Frequency command is zero. (FWD or REV LED on the operation panel is flickering.)	Check the frequency command source and enter a frequency command.	203
	AU signal is not ON when terminal 4 is used for frequency setting. (FWD or REV LED on the operation panel is flickering.)	Turn ON the AU signal. Turning ON the AU signal activates terminal 4 input.	306
	Output stop signal (MRS) or reset signal (RES) is ON. (FWD or REV LED on the operation panel is flickering.)	Turn MRS or RES signal OFF. Inverter starts the operation with a given start command and a frequency command after turning OFF MRS or RES signal. Before turning OFF, ensure the safety.	46
Input signal	CS signal is OFF while the automatic restart after instantaneous power failure function is selected ( <b>Pr.57 Restart coasting time</b> ≠ 9999). (FWD or REV LED on the operation panel is flickering.)	Turn ON the automatic restart after instantaneous power failure/flying start (CS) signal. When the CS signal is assigned to an input terminal, automatic restart operation is enabled when the CS signal is turned ON.	414
Ū	Jumper connector of sink - source is incorrectly selected. (FWD or REV LED on the operation panel is flickering.)	Check that the control logic switchover jumper connector is correctly installed.  If it is not installed correctly, input signal is not recognized.	50
	Voltage/current input switch is not correctly set for analog input signal (0 to 5 V/0 to 10 V, 4 to 20 mA). (FWD or REV LED on the operation panel is flickering.)	Set Pr.73 Analog input selection, Pr.267 Terminal 4 input selection, and a voltage/current input switch correctly, then input an analog signal in accordance with the setting.	306
	Jumper connector of sink - source is incorrectly selected. (FWD or REV LED on the operation panel is flickering.)  Voltage/current input switch is not correctly set for analog input signal (0 to 5 V/0 to 10 V, 4 to 20 mA). (FWD or REV LED on the operation panel is flickering.)	During the External operation mode, check the method of restarting from a input stop from PU.	163, 539
	For the separated converter type, terminals RDA and SE of the converter unit are not connected to terminals MRS (X10 signal) and SD (PC for source logic) of the inverter respectively.	Check for the wiring.	Refer to the Instruction Manual (Hardware) of the FR- F802.
	Two-wire or three-wire type connection is incorrect.	Check the wiring. Use the Start self-holding selection (STP (STOP)) signal when the three-wire type is used.	335

Check	Possible cause	Countermeasure	Refer to
points			page
	Under V/F control, <b>Pr.0 Torque boost</b> setting is improper.	Increase the <b>Pr.0</b> setting by 0.5% increments while observing the rotation of a motor.  If that makes no difference, decrease the setting.	496
	<b>Pr.78 Reverse rotation prevention selection</b> is set.	Check the <b>Pr.78</b> setting. Set <b>Pr.78</b> when you want to limit the motor rotation to only one direction.	217
	<b>Pr.79 Operation mode selection</b> setting is incorrect.	Select the operation mode which corresponds with input methods of start command and frequency command.	200
	Bias and gain (calibration parameter C2 to C7) settings are improper.	Check the bias and gain (calibration parameter C2 to C7) settings.	314
	<b>Pr.13 Starting frequency</b> setting is greater than the running frequency.	Set running frequency higher than <b>Pr.13</b> .  The inverter does not start if the frequency setting signal is less than the value set in <b>Pr.13</b> .	197, 198
	Frequency settings of various running frequency (such as multi-speed operation) are zero.  Especially, <b>Pr.1 Maximum frequency</b> is zero.	Set the frequency command according to the application. Set <b>Pr.1</b> higher than the actual frequency used.	222, 245
	Pr.15 Jog frequency is lower than Pr.13 Starting frequency for JOG operation.	Set Pr.15 higher than Pr.13.	197, 198, 221
Parameter	Operation mode and a writing device do not correspond.	Check Pr.79 Operation mode selection, Pr.338 Communication operation command source, Pr.339 Communication speed command source, Pr.550 NET mode operation command source selection and Pr.551 PU mode operation command source selection, and select an operation mode suitable for the purpose.	200, 210
Setting	Start signal operation selection is set by Pr.250 Stop selection.	Check the <b>Pr.250</b> setting and the connection of STF and STR signals.	335
	The motor has decelerated to a stop when power failure deceleration stop function is selected.	When power is restored, ensure the safety, and turn OFF the start signal once, then turn ON again to restart.  When <b>Pr.261 Power failure stop selection =</b> "2 or 12", the motor automatically restarts after the power is restored.	426
	Performing auto tuning.	When offline auto tuning ends, press STOP panel for the PU operation. For the External operation, turn OFF the start signal (STF or STR).  This operation resets the offline auto tuning, and the PU's monitor display returns to the normal indication.  (Without this operation, next operation cannot be started.)	341, 423
	The automatic restart after instantaneous power failure function or power failure stop function has been activated. (Performing overload operation during input phase loss may cause voltage insufficiency, and that may result in detection of power failure.)	Set Pr.872 Input phase loss protection selection ="1" (input phase failure protection active). Disable the automatic restart after instantaneous power failure function and power failure stop function. Reduce the load. Increase the acceleration time if the function was activated during acceleration.	235, 414, 420, 426
	The motor test operation is selected under PM motor control.	Check the Pr.800 Control method selection setting.	143
	When the FR-HC2, FR-CV, or FR-CC2 is used, the input logic setting of the X10 signal is incorrect.	Set <b>Pr.599=</b> "0" (initial value for standard models) to use the X10 signal with the NO contact input specification, and <b>Pr.599=</b> "1" (initial value for separated converter types) to use the X10 signal with the NC contact input specification.	508
Load	Load is too heavy.	Reduce the load.	_
	Shaft is locked.	Inspect the machine (motor).	_

#### 6.6.2 Motor or machine is making abnormal acoustic noise

Check points	Possible cause	Countermeasure	Refer to page
Input signal	Disturbance due to EMI when frequency or torque command is given from analog input	Take countermeasures against EMI.	72
Parameter Setting	(terminal 1, 2, 4).	Increase the <b>Pr.74 Input filter time constant</b> if steady operation cannot be performed due to EMI.	313
	No carrier frequency noises (metallic noises) are generated.	In the initial setting, <b>Pr.240 Soft-PWM operation selection</b> is enabled to change motor noise to an unoffending complex tone. Therefore, no carrier frequency noises (metallic noises) are generated.  Set <b>Pr.240</b> = "0" to disable this function.	179
	The motor noise increases due to activation of the carrier frequency automatic reduction function when the motor is driven overloaded.	Reduce the load. Disable the automatic reduction function by setting <b>Pr.260 PWM frequency automatic switchover</b> = "0".	179
	Resonance occurs. (output frequency)	Set Pr.31 to Pr.36, Pr.552 (Frequency jump). When it is desired to avoid resonance attributable to the natural frequency of a mechanical system, these parameters allow resonant frequencies to be jumped.	246
Parameter Setting	Resonance occurs. (carrier frequency)	Change <b>Pr.72 PWM frequency selection</b> setting. Changing the PWM carrier frequency produces an effect on avoiding the resonance frequency of a mechanical system or a motor.	179
	Auto tuning is not performed under Advanced magnetic flux vector control.	Perform offline auto tuning.	341
	Gain adjustment during PID control is insufficient.	To stabilize the measured value, change the proportional band ( <b>Pr.129</b> ) to a larger value, the integral time ( <b>Pr.130</b> ) to a slightly longer time, and the differential time ( <b>Pr.134</b> ) to a slightly shorter time.  Check the calibration of set point and measured value.	378
	The gain is too high under PM motor control.	During speed control, check the setting of Pr.820 Speed control P gain 2.	154
	The gain is too high under 1 williotor control.	During torque control, check the setting of Pr.824 Torque control P gain 2.	154
Others	Mechanical looseness	Adjust machine/equipment so that there is no mechanical looseness.	_
Mater	Contact the motor manufacturer.	Charletha makes visite	
Motor	Operating with output phase loss	Check the motor wiring.	_

## 6.6.3 Inverter generates abnormal noise

Check points	Possible cause	Countermeasure	Refer to page
Fan	Fan cover was not correctly installed when a cooling fan was replaced.	Install a fan cover correctly.	567

#### 6.6.4 **Motor generates heat abnormally**

Check points	Possible cause	Countermeasure	Refer to page
Motor	Motor fan is not working (Dust is accumulated.)	Clean the motor fan. Improve the environment.	_
WOTO	Phase to phase insulation of the motor is insufficient.	Check the insulation of the motor.	_
Main Circuit	The inverter output voltage (U, V, W) are unbalanced.	Check the output voltage of the inverter. Check the insulation of the motor.	571
Parameter Setting	Pr.71 Applied motor setting is incorrect.	Check the <b>Pr.71 Applied motor</b> setting.	337
_	Motor current is large.	Refer to "6.6.11 Motor current is too large".	557

# 6.6.5 Motor rotates in the opposite direction

Check points	Possible cause	Countermeasure	Refer to page
Main Circuit	Phase sequence of output terminals U, V and W is incorrect.	Connect phase sequence of the output cables (terminal U, V, W) to the motor correctly.	38
	The start signals (forward rotation, reverse rotation) are connected improperly.	Check the wiring. (STF: forward rotation, STR: reverse rotation)	46, 335
Input signal	The polarity of the frequency command is negative during the polarity reversible operation set by <b>Pr.73 Analog input selection</b> .	Check the polarity of the frequency command.	306

#### 6.6.6 Speed greatly differs from the setting

Check points	Possible cause	Countermeasure	Refer to page
Input	Frequency setting signal is incorrectly input.	Measure the input signal level.	_
signal	The input signal lines are affected by external EMI.	Take countermeasures against EMI, such as using shielded wires for input signal lines.	74
	Pr.1 Maximum frequency, Pr.2 Minimum frequency, Pr.18 High speed maximum	Check the settings of Pr.1, Pr.2, and Pr.18.	245
Parameter Setting	frequency, and calibration parameter C2 to C7 settings are improper.	Check the calibration parameter C2 to C7 settings.	314
	Pr.31 to Pr.36, Pr.552 (frequency jump) settings are improper.	Narrow down the range of frequency jump.	246
Load		Reduce the load weight.	_
Parameter Setting	Stall prevention function is activated due to a heavy load.	Set Pr.22 Stall prevention operation level higher according to the load. (If Pr.22 is set too high, an overcurrent trip (E.OC[]) is likely to occur.)	248
Motor		Check the capacities of the inverter and the motor.	_

## 6.6.7 Acceleration/deceleration is not smooth

Check points	Possible cause	Countermeasure	Refer to page
	Acceleration/deceleration time is too short.	Increase the acceleration/deceleration time.	187
	Torque boost ( <b>Pr.0</b> , <b>Pr.46</b> ) setting is improper under V/F control, so the stall prevention function is activated.	Increase/decrease the <b>Pr.0 Torque boost</b> setting value by 0.5% increments so that stall prevention does not occur.	496
Parameter Setting	The base frequency does not match the motor	Under V/F control, set Pr.3 Base frequency, Pr.47 Second V/F (base frequency).	497
Setting	characteristics.	Under Advanced magnetic flux vector control or PM motor control, set <b>Pr.84 Rated motor frequency</b> .	143
	Regeneration avoidance operation is performed	If the frequency becomes unstable during regeneration avoidance operation, decrease the setting of Pr.886 Regeneration avoidance voltage gain.	514
Load		Reduce the load weight.	_
Parameter Setting	Stall prevention (torque limit) function is activated due to a heavy load.	Set Pr.22 Stall prevention operation level higher according to the load. (If Pr.22 is set too high, an overcurrent trip (E.OC[]) is likely to occur.)	248
Motor		Check the capacities of the inverter and the motor.	_

#### 6.6.8 **Speed varies during operation**

Under Advanced magnetic flux vector control, the output frequency varies between 0 and 2 Hz as the load fluctuates. This is a normal operation and not a fault.

Check points	Possible cause	Countermeasure	Refer to page
Load	Load varies during an operation.	Select Advanced magnetic flux vector control.	143
	Frequency setting signal is varying.	Check the frequency setting signal.	
	The frequency setting signal is affected by	Set filter to the analog input terminal using Pr.74 Input filter time constant, Pr.822 Speed setting filter 1.	313
Input signal	EMI.	Take countermeasures against EMI, such as using shielded wires for input signal lines.	74
Sigilal	Malfunction is occurring due to the undesirable current generated when the transistor output unit is connected.	Use terminal PC (terminal SD when source logic) as a common terminal to prevent a malfunction caused by undesirable current.	51
	Multi-speed command signal is chattering.	Take countermeasures to suppress chattering.	_
	Fluctuation of power supply voltage is too large.	Under V/F control, change the <b>Pr.19 Base frequency voltage</b> setting (approximately by 3%).	497
	Pr.80 Motor capacity and Pr.81 Number of motor poles are not appropriate for the motor capacity under Advanced magnetic flux vector control, or PM motor control.	Check the settings of <b>Pr.80</b> and <b>Pr.81</b> .	143
	Wiring length exceeds 30 m when Advanced magnetic flux vector control, or PM motor control is selected.	Perform offline auto tuning.	341
Parameter	Under V/F control, wiring is too long and a voltage drop occurs.	In the low-speed range, set 0.5% in <b>Pr.0 Torque boost</b> .	496
Setting		Change the control method to Advanced magnetic flux vector control.	143
	Hunting occurs by the generated vibration, for example, when structural rigidity at load side is insufficient.	Disable automatic control functions, such as the energy saving operation, fast-response current limit operation, regeneration avoidance function, Advanced magnetic flux vector control, stall prevention, and online auto tuning.  Under PID control, set smaller values to <b>Pr.129 PID</b> proportional band and <b>Pr.130 PID</b> integral time.  Adjust so that the control gain decreases and the level of safety increases.	-
		Change Pr.72 PWM frequency selection setting.	179

#### 6.6.9 Operation mode is not changed properly

Check points	Possible cause	Countermeasure	Refer to page
Input signal	Start signal (STF or STR) is ON.	Check that the STF and STR signals are off. When either is ON, the operation mode cannot be changed.	46, 335
Parameter	Pr.79 Operation mode selection setting is improper.  the External operation mode at power ON. To switch to the operation mode, press PU on the operation panel (pre on the parameter unit (FR-PU07)). At other settings	When the <b>Pr.79</b> is set to "0 (initial value)", the operation mode is the External operation mode at power ON. To switch to the PU operation mode, press PU on the operation panel (press on the parameter unit (FR-PU07)). At other settings (1 to 4, 6, 7), the operation mode is limited accordingly.	200
Setting	Operation mode and a writing device do not correspond.	Check Pr.79 Operation mode selection, Pr.338 Communication operation command source, Pr.339 Communication speed command source, Pr.550 NET mode operation command source selection and Pr.551 PU mode operation command source selection, and select an operation mode suitable for the purpose.	200, 210

## 6.6.10 Operation panel (FR-DU08) display is not operating

Check points	Possible cause	Countermeasure	Refer to page
Main			
Circuit	Power is not input.	Input the power.	33
Control	Tower is not input.	imput the power.	33
Circuit			
Front	Operation panel is not properly connected to	Check if the inverter front cover is installed securely.	22
cover	the inverter.	official the inverter front cover is installed securely.	22

## 6.6.11 Motor current is too large

Check points	Possible cause	Countermeasure	Refer to page
	Torque boost <b>(Pr.0, Pr.46)</b> setting is improper under V/F control, so the stall prevention function is activated.	Increase/decrease the <b>Pr.0 Torque boost</b> setting value by 0.5% increments so that stall prevention does not occur.	496
	V/F pattern is improper when V/F control is performed.	Set rated frequency of the motor to <b>Pr.3 Base frequency</b> .  Use <b>Pr.19 Base frequency voltage</b> to set the base voltage (for example, rated motor voltage).	497
	(Pr.3, Pr.14, Pr.19)	Change <b>Pr.14 Load pattern selection</b> according to the load characteristic.	499
Parameter		Reduce the load weight.	_
Setting	Stall prevention function is activated due to a heavy load.	Set <b>Pr.22 Stall prevention operation level</b> higher according to the load. (If <b>Pr.22</b> is set too high, an overcurrent trip (E.OC[]) is likely to occur.)	248
		Check the capacities of the inverter and the motor.	_
	Offline auto tuning is not performed under Advanced magnetic flux vector control.	Perform offline auto tuning.	341
	When PM motor control is selected for a PM motor other than MM-EFS/MM-THE4, and offline auto tuning is not performed.	Perform offline auto tuning for a PM motor.	351

## 6.6.12 Speed does not accelerate

Check	Possible cause	Countermeasure	Refer to
points			page
	Start command and frequency command are chattering.	Check if the start command and the frequency command are correct.	_
Input signal	The wiring length used for analog frequency command is too long, and it is causing a voltage (current) drop.	Perform Analog input bias/gain calibration.	314
	The input signal lines are affected by external EMI.	Take countermeasures against EMI, such as using shielded wires for input signal lines.	74
	Pr.1 Maximum frequency, Pr.2 Minimum frequency, Pr.18 High speed maximum	Check the settings of Pr.1 and Pr.2 and set Pr.18.	245
	frequency, and calibration parameter C2 to C7 settings are improper.	Check the calibration parameter C2 to C7 settings.	314
	The maximum voltage (current) input value is not set during the External operation. (Pr.125, Pr.126, Pr.18)	Check the settings of Pr.125 Terminal 2 frequency setting gain frequency and Pr.126 Terminal 4 frequency setting gain frequency.  To operate at 120 Hz or higher, set Pr.18 High speed maximum frequency.	245, 314
	Torque boost ( <b>Pr.0</b> , <b>Pr.46</b> ) setting is improper under V/F control, so the stall prevention function is activated.	Increase/decrease the <b>Pr.0 Torque boost</b> setting value by 0.5% increments so that stall prevention does not occur.	496
Parameter	V/F pattern is improper when V/F control is performed.	Set rated frequency of the motor to <b>Pr.3 Base frequency</b> . Use <b>Pr.19 Base frequency voltage</b> to set the base voltage (for example, rated motor voltage).	497
Setting	(Pr.3, Pr.14, Pr.19)	Change <b>Pr.14 Load pattern selection</b> according to the load characteristic.	499
		Reduce the load weight.	_
	Stall prevention function is activated due to a heavy load.	Set Pr.22 Stall prevention operation level higher according to the load. (If Pr.22 is set too high, an overcurrent trip (E.OC[]) is likely to occur.)	248
		Check the capacities of the inverter and the motor.	_
	Auto tuning is not performed under Advanced magnetic flux vector control.	Perform offline auto tuning.	341
	The setting of pulse train input is improper.	Check the specification of the pulse generator (open collector output or complementary output) and check the adjustment of the pulse train and frequency (Pr.385 Frequency for zero input pulse and Pr.386 Frequency for maximum input pulse).	218
	During PID control, output frequency is automa	tically controlled to make measured value = set point.	378

## 6.6.13 Unable to write parameter setting

Check points	Possible cause	Countermeasure	Refer to page
Input signal	Operation is being performed (signal STF or STR is ON).	Stop the operation.  When <b>Pr.77 Parameter write selection</b> = "0" (initial value), write is enabled only during a stop.	169
	You are attempting to set the parameter in the External operation mode.	Choose the PU operation mode.  Or, set <b>Pr.77 Parameter write selection</b> = "2" to enable parameter write regardless of the operation mode.	169, 200
	Parameter write is disabled by the <b>Pr.77 Parameter write selection</b> setting.	Check the <b>Pr.77</b> setting.	169
Parameter Setting	Key lock mode is enabled by the Pr.161 Frequency setting/key lock operation selection setting.	Check the <b>Pr.161</b> setting.	166
	Operation mode and a writing device do not correspond.	Check <b>Pr.79</b> , <b>Pr.338</b> , <b>Pr.339</b> , <b>Pr.550</b> and <b>Pr.551</b> , and select an operation mode suitable for the purpose.	200, 210
	Pr.72 PWM frequency selection was attempted to be set to "25". Alternatively, PM motor control was attempted while Pr.72 = "25".	Pr.72 = "25" cannot be set under PM motor control. (A sine wave filter (MT-BSL/BSC) cannot be used under PM motor control.)	179

## 6.6.14 Power lamp is not lit

Check points	Possible cause	Countermeasure	Refer to page
Main Circuit Control Circuit	Wiring or installation is improper.	Check for the wiring and the installation.  Power lamp is lit when power is supplied to the control circuit (R1/L11, S1/L21).	37

## **MEMO**

# 7 PRECAUTIONS FOR MAINTENANCE AND INSPECTION

This chapter explains the "PRECAUTIONS FOR MAINTENANCE AND INSPECTION" for this product.

Always read the instructions before using the equipment. For the "PRECAUTIONS FOR MAINTENANCE AND INSPECTION" of the separated converter type, refer to the FR-F802 (Separated Converter Type) Instruction Manual (Hardware) [IB-0600550ENG].

7.1	Inspection item	<b>562</b>
7.2	Measurement of main circuit voltages, currents and powers	<b>571</b>

#### Inspection item

The inverter is a static unit mainly consisting of semiconductor devices. Daily inspection must be performed to prevent any fault from occurring due to the adverse effects of the operating environment, such as temperature, humidity, dust, dirt and vibration, changes in the parts with time, service life, and other factors.

#### Precautions for maintenance and inspection

When accessing the inverter for inspection, wait for at least 10 minutes after the power supply has been switched OFF, and then make sure that the voltage across the main circuit terminals P/+ and N/- of the inverter is not more than 30 VDC using a tester, etc.

#### 7.1 **Inspection item**

#### 7.1.1 **Daily inspection**

Basically, check for the following faults during operation.

- · Motor operation fault
- · Improper installation environment
- · Cooling system fault
- · Abnormal vibration, abnormal noise
- · Abnormal overheat, discoloration

#### 7.1.2 **Periodic inspection**

Check the areas inaccessible during operation and requiring periodic inspection.

Consult us for periodic inspection.

- Check and clean the cooling system. .............. Clean the air filter, etc.
- · Check the tightening and retighten. ..... The screws and bolts may become loose due to vibration, temperature changes, etc. Check and tighten them.

Tighten them according to the specified tightening torque. (Refer to page

- · Check the conductors and insulating materials for corrosion and damage.
- · Measure the insulation resistance.
- · Check and change the cooling fan and relay.



· When using the safety stop function, periodic inspection is required to confirm that safety function of the safety system operates correctly

For more details, refer to the Safety stop function instruction manual (BCN-A23228-001).

## 7.1.3 Daily and periodic inspection

Area of	Inspection item		Description	Inspection interval		Corrective action at fault occurrence	Check by the user
inspection			Description		Periodic		
General	Surrounding environment		Check the surrounding air temperature, humidity, dirt, corrosive gas, oil mist, etc.	0		Improve the environment.	
	Overall unit		Check for unusual vibration and noise.	0		Check fault location and retighten.	
			Check for dirt, oil, and other foreign material. •1	0		Clean.	
	Power supply voltage		Check that the main circuit voltages and control voltages are normal. 42	0		Inspect the power supply.	
	General		(1)Check with megger (across main circuit terminals and earth (ground) terminal).		0	Contact the manufacturer.	
			(2)Check for loose screws and bolts.		0	Retighten.	
			(3)Check for overheat traces on the parts.		0	Contact the manufacturer.	
Main circuit			(4)Check for stain.		0	Clean.	
	Conductors, cables		(1)Check conductors for distortion.		0	Contact the manufacturer.	
			(2)Check cable sheaths for breakage and deterioration (crack, discoloration, etc.).		0	Contact the manufacturer.	
	Transformer/ reactor		Check for unusual odor and abnormal increase of whining sound.	0		Stop the equipment and contact the manufacturer.	
	Terminal block		Check for a damage.		o	Stop the equipment and contact the manufacturer.	
	Smoothing aluminum electrolytic capacitor		(1)Check for liquid leakage.		0	Contact the manufacturer.	
			(2)Check for safety valve projection and bulge.		0	Contact the manufacturer.	
			(3)Visual check and judge by the life check of the main circuit capacitor. (Refer to page 566.)		0		
	Relay/contactor		Check that the operation is normal and no chattering sound is heard.		0	Contact the manufacturer.	
Control circuit, protective circuit	Operation check		(1)Check that the output voltages across phases are balanced while operating the inverter alone.		0	Contact the manufacturer.	
			(2)Check that no fault is found in protective and display circuits in a sequence protective operation test.		o	Contact the manufacturer.	
	Components check	Overall	(1)Check for unusual odor and discoloration.		o	Stop the equipment and contact the manufacturer.	
			(2)Check for serious rust development.		0	Contact the manufacturer.	
		Aluminum electrolytic capacitor	(1)Check for liquid leakage in a capacitor and deformation trace.		0	Contact the manufacturer.	
			(2)Visual check and judge by the life check of the control circuit capacitor. (Refer to page 566.)		0		
	Cooling fan Heatsink		(1)Check for unusual vibration and noise.	0		Replace the fan.	
Cooling			(2)Check for loose screws and bolts.		0	Fix with the fan cover fixing screws	
system			(3)Check for stain.		0	Clean.	
			(1)Check for clogging.		0	Clean.	
Display	Indication		(2)Check for stain.  (1)Check that display is normal.	0	0	Clean. Contact the	
			(2)Check for stain.		0	manufacturer. Clean.	
	Meter		Check that reading is normal.	0		Stop the equipment and contact the manufacturer.	

#### Inspection item

Area of inspection	Inspection item	Description	•	ection erval Periodic	Corrective action at fault occurrence	Check by the user
Load motor	Operation check	Check for vibration and abnormal increase in operation noise.	0	<b>*3</b>	Stop the equipment and contact the manufacturer.	

- Oil component of the heat dissipation grease used inside the inverter may leak out. The oil component, however, is not flammable, corrosive, nor conductive and is not harmful to humans. Wipe off such oil component.
- \*2 It is recommended to install a voltage monitoring device for checking the voltage of the power supplied to the inverter.
- \*3 One to two years of periodic inspection cycle is recommended. However, it differs according to the installation environment. Consult us for periodic inspection.



• Continuous use of a leaked, deformed, or degraded smoothing aluminum electrolytic capacitor (as shown in the table above) may lead to a burst, breakage or fire. Replace such a capacitor without delay.

## 7.1.4 Checking the inverter and converter modules

## **◆**Preparation

- Disconnect the external power supply cables (R/L1, S/L2, T/L3) and motor cables (U, V, W).
- Prepare a tester. (For the resistance measurement, use the 100  $\Omega$  range.)

#### **◆**Checking method


Change the polarity of the tester alternately at the inverter terminals R/L1, S/L2, T/L3, U, V, W, P/+, and N/- and check the electric continuity.

## • NOTE

- · Before measurement, check that the smoothing capacitor is discharged.
- At the time of electric discontinuity, the measured value is almost ∞. When there is an instantaneous electric continuity, due to
  the smoothing capacitor, the tester may not indicate ∞. At the time of electric continuity, the measured value is several Ω to
  several tens of Ω. If all measured values are almost the same, although these values are not constant depending on the
  module type and tester type, the modules are without fault.

#### **♦** Module device numbers and terminals to be checked

		Tes	ster			Tes	ster	
		pola	arity	Result		pola	arity	Result
		0	$\ominus$			0	$\oplus$	
<u>le</u>	D1	R/L1	P/+	Discontinuity	D4	R/L1	N/-	Continuity
Converter module	וטו	P/+	R/L1	Continuity	D4	N/-	R/L1	Discontinuity
Ē	D2	S/L2	P/+	Discontinuity	D5	S/L2	N/-	Continuity
rte	D2	P/+	S/L2	Continuity	03	N/-	S/L2	Discontinuity
) Ye	D3	T/L3	P/+	Discontinuity	D6	T/L3	N/-	Continuity
Ö	D3	P/+	T/L3	Continuity	Do	N/-	T/L3	Discontinuity
Ф	TR1	U	P/+	Discontinuity	TR4	U	N/-	Continuity
Inp	IIXI	P/+	U	Continuity	11114	N/-	U	Discontinuity
E S	TR3 V P/+ Discontinuity		TR6	V	N/-	Continuity		
ter	113	P/+ V Continuity		1170	N/-	V	Discontinuity	
Inverter module	TR5	W	P/+	Discontinuity	TR2	W	N/-	Continuity
므	11/3	P/+	W	Continuity	1132	N/-	W	Discontinuity



(Assumes the use of an analog meter.)

## 7.1.5 Cleaning

Always run the inverter in a clean status.

When cleaning the inverter, gently wipe dirty areas with a soft cloth immersed in neutral detergent or ethanol.

## • NOTE

- Do not use solvent, such as acetone, benzene, toluene and alcohol, as these will cause the inverter surface paint to peel off.
- The display, etc. of the operation panel and the parameter unit are vulnerable to detergent and alcohol. Therefore, avoid using them for cleaning.

#### 7.1.6 Replacement of parts

The inverter consists of many electronic parts such as semiconductor devices.

The following parts may deteriorate with age because of their structures or physical characteristics, leading to reduced performance or fault of the inverter. For preventive maintenance, the parts must be replaced periodically.

Use the life check function as a guidance of parts replacement.

Part name	Estimated lifespan*1	Description
Cooling fan	10 years	Replace (as required)
Main circuit smoothing capacitor	10 years*2	Replace (as required)
On-board smoothing capacitor	10 years*2	Replace the board (as required)
Relays	_	As required
Main circuit fuse (FR-F840-04320(185K) or higher)	10 years	Replace the fuse (as required)

- Estimated lifespan for when the yearly average surrounding air temperature is 40°C. (without corrosive gas, flammable gas, oil mist, dust and dirt etc.)
- \*2 Output current: 80% of the inverter rating



• For parts replacement, contact the nearest Mitsubishi FA center.

#### **◆**Displaying the life of the inverter parts

The inverter diagnoses the main circuit capacitor, control circuit capacitor, cooling fan, and inrush current limit circuit by itself and estimates their lives.

The self-diagnostic warning is output when the life span of each part is near its end. It gives an indication of replacement time.

The life warning output can be used as a guideline for life judgment.

Parts	Judgment level
Main circuit capacitor	85% of the initial capacity
Control circuit capacitor	Estimated remaining life 10%
Inrush current limit circuit	Estimated remaining life 10% (Power ON: 100,000 times left)
Cooling fan	Less than 50% of the specified speed.*1

\*1 Initial values differ according to the inverter capacity (Refer to page 183 for details.)



• Refer to page 180 to perform the life check of the inverter parts.


The replacement interval of the cooling fan used for cooling the parts generating heat such as the main circuit semiconductor is greatly affected by the surrounding air temperature. When unusual noise and/or vibration are noticed during inspection, the cooling fan must be replaced immediately.

#### ◆ Removal FR-F820-00105(2.2K) to 04750(110K), FR-F840-00083(3.7K) to 03610(160K))

1) Push the hooks from above and remove the fan cover.



FR-F820-00105(2.2K) to 00250(5.5K) FR-F840-00083(3.7K), 00126(5.5K)




FR-F820-00340(7.5K) to 01540(37K), FR-F840-00170(7.5K) to 00770(37K)




FR-F840-00930(45K) to 03610(160K)

Fan cover


- 2) Disconnect the fan connectors.
- 3) Remove the fan.



FR-F820-00105(2.2K) to 00250(5.5K) FR-F840-00083(3.7K), 00126(5.5K)



FR-F820-00340(7.5K) to 01540(37K) FR-F840-00170(7.5K) to 00770(37K)




higher FR-F840-00930(45K) to 03610(160K)


\*1 The number of cooling fans differs according to the inverter capacity.

#### Reinstallation (FR-F820-00105(2.2K) to 04750(110K), FR-F840-00083(3.7K) to 03610(160K))


1) After confirming the orientation of the fan, reinstall the fan so that the "AIR FLOW" faces up.




2) Reconnect the fan connectors.




FR-F820-00105(2.2K) to 00250(5.5K) FR-F840-00083(3.7K), 00126(5.5K)




FR-F820-00930(22K), 01250(30K) FR-F840-00470(22K), 00620(30K)








FR-F820-00105(2.2K) to 00250(5.5K) FR-F840-00083(3.7K), 00126(5.5K)



FR-F820-00340(7.5K) to 00770(18.5K),


FR-F840-00170(7.5K) to 00380(18.5K)



FR-F820-01540(37K) FR-F840-00770(37K)



FR-F820-03160(75K) or higher FR-F840-02160(90K) to 03610(160K)



FR-F820-00340(7.5K) to 01540(37K), FR-F840-00170(7.5K) to 00770(37K)




FR-F820-01870(45K) or higher FR-F840-00930(45K) to 03610(160K)

## NOTE

- Installing the fan in the opposite direction of air flow can cause the inverter life to be shorter.
- Prevent the cable from being caught when installing a fan.
- Switch the power OFF before replacing fans. Since the inverter circuits are charged with voltage even after power OFF, replace fans only when the inverter cover is on the inverter to prevent an electric shock accident.


- 1) Remove the fan cover fixing screws, and remove the fan cover.
- 2) Disconnect the fan connector and remove the fan block.
- 3) Remove the fan fixing screws, and remove the fan.



\*1 The number of cooling fans differs according to the inverter capacity.

#### Reinstallation FR-F840-04320(185K) or higher)

1) After confirming the orientation of the fan, reinstall the fan so that the arrow on the left of "AIR FLOW" faces up.



<Fan side face>

2) Install fans referring to the above figure.

- Installing the fan in the opposite air flow direction can cause the inverter life to be shorter.
- Prevent the cable from being caught when installing a fan.
- Switch the power OFF before replacing fans. Since the inverter circuits are charged with voltage even after power OFF, replace fans only when the inverter cover is on the inverter to prevent an electric shock accident.

#### **♦**Smoothing capacitors

A large-capacity aluminum electrolytic capacitor is used for smoothing in the main circuit DC section, and an aluminum electrolytic capacitor is used for stabilizing the control power in the control circuit. Their characteristics are deteriorated by the adverse effects of ripple currents, etc. The replacement intervals greatly vary with the surrounding air temperature and operating conditions. When the inverter is operated in air-conditioned, normal environment conditions, replace the capacitors about every 10 years.

The appearance criteria for inspection are as follows:

- Case: Check the side and bottom faces for expansion.
- Sealing plate: Check for remarkable warp and extreme crack.
- heck for external crack, discoloration, liquid leakage, etc. Judge that the capacitor has reached its life when the measured capacitance of the capacitor reduced below 80% of the rating.



• The inverter diagnoses the main circuit capacitor and control circuit capacitor by itself and can judge their lives. (Refer to page 180.)

#### **♦**Relays

To prevent a contact fault, etc., relays must be replaced according to the cumulative number of switching times (switching life).


#### ◆Main circuit fuse inside the inverter (FR-F840-04320(185K) or higher)

A fuse is used inside the inverter. Surrounding air temperature and operating condition affect the life of fuses. When the inverter is used in a normal air-conditioned environment, replace its fuse after about 10 years.


## 7.1.7 Inverter replacement

The inverter can be replaced with the control circuit wiring kept connected. Before replacement, remove the wiring cover of the inverter.

1) Loosen the two mounting screws at the both side of the control circuit terminal block. (These screws cannot be removed.) Slide down the control circuit terminal block to remove it.



2) Be careful not to bend the pins of the inverter's control circuit connector, reinstall the control circuit terminal block and fix it with the mounting screws.



• NOTE

Before starting inverter replacement, switch power OFF, wait for at least 10 minutes, and then check the voltage with a tester
and such to ensure safety.

## 7.2 Measurement of main circuit voltages, currents and powers

Since the voltages and currents on the inverter power supply and output sides include harmonics, measurement data depends on the instruments used and circuits measured.


When instruments for commercial frequency are used for measurement, measure the following circuits with the instruments given on the next page.

When installing meters etc. on the inverter output side

When the inverter-to-motor wiring length is large, especially in the 400 V class, small-capacity models, the meters and CTs may generate heat due to line-to-line leakage current. Therefore, choose the equipment which has enough allowance for the current rating.

To measure and display the output voltage and output current of the inverter, it is recommended to use the terminal AM and FM/CA output functions of the inverter.

#### Examples of measuring points and instruments



## **♦**Measuring points and instruments

Item	Measuring point	Measuring instrument	Remarks (reference measured v	alue)			
Power supply voltage V1	Across R/L1 and S/L2, S/L2 and T/L3, T/L3 and R/L1	Moving-iron type AC voltmeter*4	Commercial power supply Within permissible AC voltage fluctuation (Refer to page 578.)				
Power supply side current	R/L1, S/L2, T/L3 line current	Moving-iron type AC ammeter*4					
Power supply side power P1	R/L1, S/L2, T/L3 and Across R/L1 and S/L2, S/L2 and T/L3, T/L3 and R/L1	Digital power meter (for inverter) or electrodynamic type single-phase wattmeter	P1 = W11 + W12 + W13 (3-wattmeter method	od)			
Power supply side power factor Pf1	Calculate after measure $Pf_1 = \frac{P_1}{\sqrt{3}V_1 \times I_1}$		oply side current and power supply side powe	er.			
Output side voltage V2	Across U and V, V and W, and U	Rectifier type AC voltage meter*1*4 (moving-iron type cannot measure.)	Difference between the phases is within 1% maximum output voltage.	of the			
Output side current I2	U, V and W line currents	Moving-iron type AC ammeter*2*4	Difference between the phases is 10% or lo rated inverter current.	ower of the			
Output side power P2	U, V, W and across U and V, V and W	Digital power meter (for inverter) or electrodynamic type single-phase wattmeter	P2 = W21 + W22 2-wattmeter method (or 3-wattmeter metho	d)			
Output side power factor Pf2	Calculate in similar map $Pf_2 = \frac{P_2}{\sqrt{3}V_2 \times I_2}$	anner to power supply side power fac	etor.				
Converter output	Across P/+ and N/-	Moving-coil type (such as tester)	Inverter LED is lit. 1.35 × V1				
Frequency setting signal	Across 2, 4(+) and 5 Across 1(+) and 5 Across 10(+) and 5		0 to 10 VDC, 4 to 20 mA 0 to ±5 VDC and 0 to ±10 VDC 5.2 VDC				
Frequency setting power supply	Across 10E(+) and 5		10 VDC	"5" is .			
	Across AM(+) and 5		Approximately 10 VDC at maximum frequency (without frequency meter)	common			
	Across CA(+) and 5		Approximately 20 mADC at maximum frequency				
Frequency meter signal	Across FM(+) and SD	Moving-coil type (tester and such may be used.) (internal resistance 50 k $\Omega$ or more)	Approximately 5 VDC at maximum frequency (without frequency meter)  T1  BVDC  T2  Pulse width T1: Adjust with C0 (Pr.900). Pulse cycle T2: Set with Pr.55. (frequency monitor only)	"SD" is common			
Across STF, STR, Start signal Select signal Reset signal Output stop signal Output stop signal Output stop signal Across STF, STR, RH, RM, RL, JOG, RT, AU, STP (STOP) CS, RES, MRS(+) and SD (for sink logic)			When open 20 to 30 VDC ON voltage: 1 V or less				
Fault signal	Across A1 and C1 Across B1 and C1	Moving-coil type (such as tester)	Continuity check+3  [Normal] [Fault]  Across A1 and C1 Discontinuity Continuity  Across B1 and C1 Continuity Discontinuity				

<sup>\*1</sup> Use an FFT to measure the output voltage accurately. A tester or general measuring instrument cannot measure accurately.

<sup>\*2</sup> When the carrier frequency exceeds 5 kHz, do not use this instrument since using it may increase eddy current losses produced in metal parts inside the instrument, leading to burnout. In this case, use an approximate-effective value type.

<sup>\*3</sup> When the setting of Pr.195 ABC1 terminal function selection is the positive logic

<sup>\*4</sup> A digital power meter (designed for inverter) can also be used to measure.

#### 7.2.1 **Measurement of powers**

Use digital power meters (for inverter) for the both of inverter input and output side. Alternatively, measure using electrodynamic type single-phase wattmeters for the both of inverter input and output side in two-wattmeter or threewattmeter method. As the current is liable to be imbalanced especially in the input side, it is recommended to use the threewattmeter method.

Examples of measured value differences produced by different measuring meters are shown below.

An error will be produced by difference between measuring instruments, e.g. power calculation type and two- or threewattmeter type three-phase wattmeter. When a CT is used in the current measuring side or when the meter contains a PT on the voltage measurement side, an error will also be produced due to the frequency characteristics of the CT and PT.

#### [Measurement conditions]


Constant output of 60 Hz or more frequency with a constanttorque (100%). The value obtained by the 3-wattmeter method with a 4-pole 3.7 kW induction motor is assumed to be 100%.

120-100 × 3-wattmeter method (Electro-dynamometer type) 80 2-wattmeter method (Electro-dynamometer type) O Clip AC power meter (For balanced three-phase load) 60 △ Clamp-on wattmeter (Hall device power arithmetic type) 20 40 60 80 100120Hz

Example of measuring inverter input power

#### [Measurement conditions]

Constant output of 60 Hz or more frequency with a constanttorque (100%). The value obtained by the 3-wattmeter method with a 4-pole 3.7 kW induction motor is assumed to be 100%.



Example of measuring inverter output power

#### 7.2.2 Measurement of voltages and use of PT

## Inverter input side

As the input side voltage has a sine wave and it is extremely small in distortion, accurate measurement can be made with an ordinary AC meter.

## Inverter output side

Since the output side voltage has a PWM-controlled rectangular wave, always use a rectifier type voltmeter. A needle type tester cannot be used to measure the output side voltage as it indicates a value much greater than the actual value. A movingiron type meter indicates an effective value which includes harmonics and therefore the value is larger than that of the fundamental wave. The value monitored on the operation panel is the inverter-controlled voltage itself. Hence, that value is accurate and it is recommended to monitor values (analog output) using the operation panel.

#### ◆PT

No PT can be used in the output side of the inverter. Use a direct-reading meter. (A PT can be used in the input side of the inverter.)

#### 7.2.3 Measurement of currents

Use moving-iron type meters on both the input and output sides of the inverter. However, if the carrier frequency exceeds 5 kHz, do not use that meter since an overcurrent losses produced in the internal metal parts of the meter will increase and the meter may burn out. In this case, use an approximate-effective value type.

Since current on the inverter input side tends to be unbalanced, measurement of three phases is recommended. Correct value cannot be obtained by measuring only one or two phases. On the other hand, the unbalanced ratio of each phase of the output side current should be within 10%.

When a clamp ammeter is used, always use an effective value detection type. A mean value detection type produces a large error and may indicate an extremely smaller value than the actual value. The value monitored on the operation panel is accurate if the output frequency varies, and it is recommended to monitor values (provide analog output) using the operation

Examples of measured value differences produced by different measuring meters are shown below.

[Measurement conditions]


Indicated value of the moving-iron type ammeter is 100%.

Clip AC power meter Moving-iron 100 type 80 60 Clamp-on wattmeter Clamp meter current measurement 60Hz 20 40

Example of measuring inverter input current

[Measurement conditions]

Indicated value of the moving-iron type ammeter is 100%.



Example of measuring inverter output current

#### 7.2.4 **Use of CT and transducer**

A CT may be used in both the input and output sides of the inverter. Use the one with the largest possible VA ability because an error will increase if the frequency gets lower.

When using a transducer, use the effective value calculation type which is immune to harmonics.

#### 7.2.5 Measurement of inverter input power factor

Calculate using effective power and apparent power. A power-factor meter cannot indicate an exact value.

Effective power Total power factor of the inverter Apparent power Three-phase input power found by the 3-wattmeter method  $\sqrt{3} \times V$  (power supply voltage) × I (input current effective value)

#### 7.2.6 Measurement of converter output voltage (across terminals P and N)

The output voltage of the converter is output across terminals P and N and can be measured with a moving-coil type meter (tester). Although the voltage varies according to the power supply voltage, approximately 270 VDC to 300 VDC (540 VDC to 600 VDC for the 400 V class) is output when no load is connected and voltage decreases during driving load operation. When energy is regenerated from the motor during deceleration, for example, the converter output voltage rises to nearly 400 VDC to 450 VDC (800 VDC to 900 VDC for the 400 V class) maximum.

In the initial setting of the FM-type inverter, a pulse train proportional to the output frequency is output across the pulse train output terminals FM and SD of the inverter. This pulse train output can be counted by a frequency counter, or a meter (moving-coil type voltmeter) can be used to read the mean value of the pulse train output voltage. When a meter is used to measure the output frequency, approximately 5 VDC is indicated at the maximum frequency.

For detailed specifications of the pulse train output terminal FM, refer to page 279.

In the initial setting of the CA-type inverter, a pulse train proportional to the output frequency is output across the analog current output terminals CA and 5 of the inverter. Measure the current using an ammeter or tester.


For detailed specifications of the analog current output terminal CA, refer to page 281.

## 7.2.8 Insulation resistance test using megger

• For the inverter, conduct the insulation resistance test on the main circuit only as shown below and do not perform the test on the control circuit. (Use a 500 VDC megger.)

## • NOTE

- Before performing the insulation resistance test on the external circuit, disconnect the cables from all terminals of the inverter so that the test voltage is not applied to the inverter.
- For the continuity test of the control circuit, use a tester (high resistance range) and do not use the megger or buzzer.



## 7.2.9 Pressure test

Do not conduct a pressure test. Deterioration may occur.

## **MEMO**

# 8 SPECIFICATIONS

This chapter explains the "SPECIFICATIONS" of this product.

Always read the instructions before using the equipment.

For the "SPECIFICATIONS" of the separated converter type, refer to the FR-F802 (Separated Converter Type) Instruction Manual (Hardware) [IB-0600550ENG].

8.1	Inverter rating	578
	Motor rating	
	Common specifications	
8.4	Outline dimension drawings	585

#### 8.1 **Inverter rating**

#### **♦200 V class**

	Madal	FR-F820-I 1	00046	00077	00105	00167	00250	00340	00490	00630	00770	00930	01250	01540	01870	02330	03160	03800	04750
	Model	FR-F820-[ ]	0.75K	1.5K	2.2K	3.7K	5.5K	7.5K	11K	15K	18.5K	22K	30K	37K	45K	55K	75K	90K	110K
Аp	plicable motor	SLD	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90/110	132
cap	pacity (kW) *1	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110	
	Rated capacity	SLD	1.8	2.9	4	6.4	10	13	19	24	29	35	48	59	71	89	120	145	181
	(kVA) *2	LD	1.6	2.7	3.7	5.8	8.8	12	17	22	27	32	43	53	65	81	110	132	165
+	Rated current	SLD	4.6	7.7	10.5	16.7	25	34	49	63	77	93	125	154	187	233	316	380	475
Output	(A)	LD	4.2	7	9.6	15.2	23	31	45	58	70.5	85	114	140	170	212	288	346	432
ō	Overload	SLD	110% 6	0 s, 1209	% 3 s (in	verse-tin	ne chara	cteristics	) at surr	ounding	air tempe	erature 4	0°C						
	current rating	LD	120% 6	0 s, 150	% 3 s (in	verse-tin	ne chara	cteristics	s) at surr	ounding	air temp	erature 5	50°C						
	Rated voltage *	4	Three-p	hase 200	0 to 240	V													
	Rated input AC voltage/freq	uency	Three-p	hase 20	0 to 240	V 50 Hz	/60 Hz												
≥	Permissible AC	voltage fluctuation	170 to 2	264 V 50	Hz/60 H	z													
supply	Permissible free	quency fluctuation	±5%																
0	Rated input	SLD	5.3	8.9	13.2	19.7	31.3	45.1	62.8	80.6	96.7	115	151	185	221	269	316	380	475
owo-	current (A) *5	LD	5	8.3	12.2	18.3	28.5	41.6	58.2	74.8	90.9	106	139	178	207	255	288	346	432
Г.		SLD	2	3.4	5	7.5	12	17	24	31	37	44	58	70	84	103	120	145	181
	capacity (kVA) *6	LD	1.9	3.2	4.7	7	11	16	22	29	35	41	53	68	79	97	110	132	165
Pro	tective structure	(IEC 60529) *7	Enclose	type (IP	20)								Open ty	pe (IP00	))			,	
Со	oling system		Self-cod	oling	Forced	air coolir	ng												
Approx. mass (kg) 1.9				2.1	3.0	3.0	3.0	6.3	6.3	8.3	15	15	15	22	42	42	54	74	74

- The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi 4-pole standard motor.
- The rated output capacity indicated assumes that the output voltage is 220 V for 200 V class.
- The % value of the overload current rating indicated is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter \*3 and motor to return to or below the temperatures under 100% load.
- The maximum output voltage does not exceed the power supply voltage. The maximum output voltage can be changed within the setting range. However, the maximum point of the voltage waveform at the inverter output side is the power supply voltage multiplied by about  $\sqrt{2}$ .
- The rated input current indicates a value at a rated output voltage. The impedance at the power supply side (including those of the input reactor and cables) affects the rated input current.
- The power supply capacity is the value when at the rated output current. It varies by the impedance at the power supply side (including those of the input reactor and
- \*7 FR-DU08: IP40 (except for the PU connector section)

#### ♦400 V class

			00023	00038	00052	00083	00126	00170	00250	00310	00380	00470	00620	00770	00930	01160	01800	02160	02600	03250	03610	04320	04810	05470	06100	06830
	Mode	el FR-F840-[ ]	0.75K	1.5K	2.2K	3.7K	5.5K	7.5K	11K	15K	18.5K	22K	30K	37K	45K	55K	75K	90K	110K	132K	160K	185K	220K	250K	280K	315K
	plicable motor	SLD	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75/ 90	110	132	160	185	220	250	280	315	355
ca	pacity (kW) *1	LD	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110	132	160	185	220	250	280	315
		SLD	1.8	2.9	4	6.3	10	13	19	24	29	36	47	59	71	88	137	165	198	248	275	329	367	417	465	521
	capacity (kVA) *2	LD	1.6	2.7	3.7	5.8	8.8	12	18	22	27	33	43	53	65	81	110	137	165	198	248	275	329	367	417	465
+	Rated current	SLD	2.3	3.8	5.2	8.3	12.6	17	25	31	38	47	62	77	93	116	180	216	260	325	361	432	481	547	610	683
Output	(A)	LD	2.1	3.5	4.8	7.6	11.5	16	23	29	35	43	57	70	85	106	144	180	216	260	325	361	432	481	547	610
0	Overload	SLD	110%	60 s,	120%	3 s (i	nverse	-time	chara	cterist	ics) at	surro	unding	g air te	emper	ature 4	10°C									
	current rating	LD	120%	60 s,	150%	3 s (i	nverse	e-time	chara	cteris	tics) at	surro	undin	g air te	emper	ature (	50°C									
	Rated voltage	*4	Three	-phas	e 380	to 500	) V																			
	Rated input AC voltage/fre	equency	Three	-phas	e 380	to 500	) V 50	Hz/60	) Hz •	8																
ρly	Permissible A	C voltage fluctuation	323 to	550	V 50 F	lz/60	Hz																			
dr	Permissible from	equency fluctuation	±5%																							
er sı	Rated input	SLD	3.2	5.4	7.8	10.9	16.4	22.5	31.7	40.3	48.2	58.4	76.8	97.6	115	141	180	216	260	325	361	432	481	547	610	683
ower	current (A) *5	LD	3	4.9	7.3	10.1	15.1	22.3	31	38.2	44.9	53.9	75.1	89.7	106	130	144	180	216	260	325	361	432	481	547	610
-	Power supply	SLD	2.5	4.1	5.9	8.3	12	17	24	31	37	44	59	74	88	107	137	165	198	248	275	329	367	417	465	521
	capacity (kVA) *6	LD	2.3	3.7	5.5	7.7	12	17	24	29	34	41	57	68	81	99	110	137	165	198	248	275	329	367	417	465
Pro	otective structu	re (IEC 60529) *7	Enclo	se typ	e (IP2	0)								Open	type	(IP00)										
Сс	oling system		Self-c	ooling	]	Force	d air c	cooling	9																	
Approx. mass (kg)			2.5	2.5	2.5	3.0	3.0	6.3	6.3	8.3	8.3	15	15	23	41	41	43	52	55	71	78	117	117	166	166	166

- \*1 The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi 4-pole standard motor.
- \*2 The rated output capacity indicated assumes that the output voltage is 440 V for 400 V class.
- \*3 The % value of the overload current rating indicated is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load.
- \*4 The maximum output voltage does not exceed the power supply voltage. The maximum output voltage can be changed within the setting range. However, the maximum point of the voltage waveform at the inverter output side is the power supply voltage multiplied by about  $\sqrt{2}$ .
- \*5 The rated input current indicates a value at a rated output voltage. The impedance at the power supply side (including those of the input reactor and cables) affects the rated input current.
- \*6 The power supply capacity is the value when at the rated output current. It varies by the impedance at the power supply side (including those of the input reactor and cables).
- \*7 FR-DU08: IP40 (except for the PU connector section)
- \*8 For the power voltage exceeding 480 V, set **Pr.977 Input voltage mode selection**. (For details, refer to **page 168**.)

#### 8.2 **Motor rating**

### 8.2.1 **Premium high-efficiency IPM motor [MM-EFS** (1500 r/min) series]

## **♦**Motor specification

	200V class														
Moter	MM-EFS[]1M														
model	400V class	7	15	22	37	55	75	11K	15K	18K	22K	30K	37K	45K	55K
	MM-EFS[]1M4														
0	200V class		00077	00105	00167	00250	00340	00490	00630	00770	00930	01250	01540	01870	02330
Compatible	FR-F820-[]									(18.5K)		(30K)	(37K)	(45K)	(55K)
inverter	400V class	00023	00038	00052	00083	00126	00170	00250	00310	00380	00470	00620	00770	00930	01160
*3	FR-F840-[]	(0.75K)	(1.5K)	(2.2K)	(3.7K)	(5.5K)	(7.5K)	(11K)	(15K)	(18.5K)	(22K)	(30K)	(37K)	(45K)	(55K)
Continuous characteristic	(KVV)	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55
*1	(Num)		9.55	14	23.6	35	47.7	70	95.5	118	140	191	236	286	350
Rated speed (		1500													
Maximum spe	ed (r/min)	2250													
Number of pol		6	·												
Maximum torq	ue	120% 6	120% 60 s												
Frame numbe	r	M08	90L	100L	112M	132S	132M	160M	160L	180M		180L	200L		225S
Inertia momen		20	40	55	110	275	280	760	770	1700	1700	1900	3400	3850	6500
(×10 <sup>-4</sup> kg·m <sup>2</sup> )		20	40	55	110	273	200	700	770	1700	1700	1900	3400	3630	0300
Rated current	200 V class	3	6.0	8.2	13.4	20	27	40	54	66	79	110	128	157	194
(A)	400 V class	1.5	3.0	4.1	6.7	10	13.5	20	27	33	39.5	55	64	78.5	97
Structure		Totally-e	nclosed	d fan-co	oled mo	otor. Wi	th steel	framed	d legs. (	protectiv	e struct	ure IP4	4 *2)	•	
Insulation clas	S	F class													
Vibration class	3	V-15													
	Surrounding air temperature and humidity	-10°C to	+40°C	(non-fr	eezing)	· 90%F	RH or le	ss (non	ı-conde	nsing)					
	Storage temperature and -20°C to +70°C (non-freezing) · 90%RH or less (non-condensing)														
	humidity		, ,		,	1.1							·		
	•		•				a tree f	rom coi	rrosive	gas, flam	imable	gas, oil	mıst, dı	ist and	airt.
		Maximu		) m abo	ve sea	ievel									
	Vibration	4.9 m/s <sup>2</sup>													
Mass (kg)		11	15	22	31	50	53	95	100	135		155	215	230	285


<sup>\*1</sup> The above characteristics apply when the rated AC voltage is input from the inverter. (Refer to page 578.) Output and rated motor speed are not guaranteed when the power supply voltage drops.

<sup>\*2</sup> This excludes the part where the axis passes through.

<sup>\*3</sup> For the LD rating

### **◆**Motor torque characteristic

The following figure shows the torque characteristic of the premium high-efficiency IPM motor [MM-EFS (1500 r/min) series] when used with an inverter.



## NOTE

- The motor can also be used for applications which require the rated speed of 1800 r/min.
- The torque characteristic is when the armature winding temperature is 20°C, and the input voltage to the inverter is 200 VAC or 400 VAC.
- Constant-speed operation cannot be performed for the speed of 150 r/min or less.

## 8.2.2 Premium high-efficiency IPM motor [MM-THE4 (1500 r/min) series]


## **◆**Motor specification

Mot	er model	MM-THE4											
Volt	age class	200V			400V								
Applical	blo invortor	FR-F820-[]			FR-F840-[]								
Applical	ble inverter *2	03160(75K)	01800(75K)	02160(90K)	02600(110K)	03250(132K)	03610(160K)						
Continuous	Rated output (kW)	75	75	90	110	132	160						
characteristic	Rated torque (N·m)	477	477	573	700	840	1018						
Rated speed (ra	/min)	1500											
Maximum spee	d (r/min)	1800											
Number of pole	es	6											
Maximum torqu	ie	120% 60 s	20% 60 s										
Frame number		250MA	250MA	250MD	280MD								
Inertia momen	ıt J (×10 <sup>-4</sup> kg⋅m²)	6000	6000	10000	17500	20500	23250						
Rated current (	A)	270	135	170	195	230	280						
Structure		Totally-enclosed fan-cooled motor. With steel framed legs. (protective structure IP44)											
Insulation class	3	F class											
Vibration class		V-25											
	Surrounding air temperature and humidity	-10°C to +40°C (non-freezing) · 90%RH or less (non-condensing)											
Environment	Storage temperature and humidity	-20°C to +70°C	-20°C to +70°C (non-freezing) · 90%RH or less (non-condensing)										
	Atmosphere	Indoors (not under direct sunlight), and free from corrosive gas, flammable gas, oil mist, dust and dirt.											
	Altitude	Maximum 1,000 m above sea level											
	Vibration	4.9 m/s <sup>2</sup>											
Mass (kg)		470	470	610	780	810	860						

- \*1 Output and rated motor speed are not guaranteed when the power supply voltage drops.
- \*2 For the LD rating

## **♦**Motor torque characteristic

The following figure shows the torque characteristic of the premium high-efficiency IPM motor [MM-THE4 (1500 r/min) series] when used with an inverter.



## NOTE

- The motor can also be used for applications which require the rated speed of 1800 r/min.
- The torque characteristic is when the armature winding temperature is 20°C, and the input voltage to the inverter is 200 VAC or 400 VAC.
- Constant-speed operation cannot be performed for the speed of 150 r/min or less.

## **8.3** Common specifications

	Control met	thod	Soft-PWM control, high carrier frequency PWM control (selectable among V/F control (Optimum excitation control),									
			Advanced magnetic flux vector control (Advanced optimum excitation control) and PM motor control)									
		uency range	0.2 to 590 Hz (The upper-limit frequency is 400 Hz under Advanced magnetic flux vector control, and PM motor control.)									
	Frequency setting	Analog input	0.015 Hz/60 Hz (terminal 2, 4: 0 to 10 V/12 bits) 0.03 Hz/60 Hz (0 to 5 V/11 bits or 0 to 20 mA/approx. 11 bits for terminals 2 and 4, 0 to $\pm$ 10 V/12 bits for terminal 1) 0.06 Hz/60 Hz (0 to $\pm$ 5 V/11 bits for terminal 1)									
S	resolution	Digital input	0.01 Hz									
o	Frequency	Analog input	Within $\pm 0.2\%$ of the max. output frequency (25°C $\pm 10$ °C)									
ati	accuracy	Digital input	Within 0.01% of the set output frequency									
i£ic	Voltage/fred	•	Base frequency can be set from 0 to 590 Hz. Constant-torque/variable-torque pattern or adjustable 5 points V/F can be									
)ec	characteris		selected.									
Control specifications	Starting torque	Induction motor	120% 0.5 Hz (Advanced magnetic flux vector control)									
out		IPM motor	50%									
ŭ	Torque boo		Manual torque boost									
	time setting		0 to 3600 s (acceleration and deceleration can be set individually), linear or S-pattern acceleration/deceleration mode, backlash countermeasures acceleration/deceleration can be selected.									
	(induction r	notor)	Operation frequency (0 to 120 Hz), operation time (0 to 10 s), operation voltage (0 to 30%) variable									
	level	tion operation	Activation range of stall prevention operation (SLD rating: 0 to 120%, LD rating: 0 to 150%). Whether to use the stall prevention or not can be selected. (V/F control, Advanced magnetic flux vector control)									
	Frequency setting	Analog input	Terminals 2 and 4: 0 to 10 V, 0 to 5 V, 4 to 20 mA (0 to 20 mA) are available.  Terminal 1: -10 to +10 V, -5 to 5 V are available.									
	signal	Digital input	Input using the setting dial of the operation panel or the parameter unit Four-digit BCD or 16-bit binary (when used with option FR-A8AX)									
	Start signal		Forward and reverse rotation or start signal automatic self-holding input (3-wire input) can be selected.									
ns	Input signal terminals)	ls (twelve	ow-speed operation command, Middle-speed operation command, High-speed operation command, Second function election, Terminal 4 input selection, Jog operation selection, Output stop, Start self-holding selection, Forward rotation ommand, Reverse rotation command, Inverter reset the input signal can be changed using Pr.178 to Pr.189 (input terminal function selection).									
ţi	Pulse tra	ain input	100 kpps									
Operation specifications	Operational		DC injection brake, starting frequency, JOG operation, output stop (MRS), stall prevention, regeneration avoidance, increased magnetic excitation deceleration, DC feeding*I, frequency jump, rotation display, automatic restart after instantaneous power failure, electronic bypass sequence, remote setting, retry function, carrier frequency selection, fast-response current limit, forward/reverse rotation prevention, operation mode selection, slip compensation, speed smoothing control, traverse, auto tuning, applied motor selection, RS-485 communication, PID control, PID pre-charge function, cooling fan operation selection, stop selection (deceleration stop/coasting), power-failure deceleration stop function, PLC function, life diagnosis, maintenance timer, current average monitor, multiple rating, test run, 24 V power supply input for control circuit, safety stop function, self power management, BACnet communication, PID gain tuning, cleaning, load characteristics storage, emergency drive									
	Output sign Open collect terminals) Relay outputerminals)	tor output (five	Inverter running, Up to frequency, Instantaneous power failure/undervoltage*1, Overload warning, Output frequency detection, Fault The output signal can be changed using <b>Pr.190 to Pr.196 (output terminal function selection)</b> . Fault codes of the inverter can be output (4 bits) from the open collector.									
	Pulse tra	ain output	50 kpps									
		Pulse train output (FM type)	Max. 2.4 kHz: one terminal (output frequency) The monitored item can be changed using <b>Pr.54 FM/CA terminal function selection</b> .									
Indication	For meter	Current output (CA type)	Max. 20 mADC: one terminal (output current) The monitored item can be changed using <b>Pr.54 FM/CA terminal function selection</b> .									
Indic		Voltage output	Max. 10 VDC: one terminal (output voltage) The monitored item can be changed using <b>Pr.158 AM terminal function selection</b> .									
	Operation panel	Operating status	Output frequency, output current, output voltage, frequency setting value The monitored item can be changed using <b>Pr.52 Operation panel main monitor selection</b> .									
	(FR-DU08)	Fault record	Fault record is displayed when a fault occurs. Past 8 fault records and the conditions immediately before the fault (output									
wai	etective/ rning ction	Overcurrent trip during acceleration, Overcurrent trip during constant speed, Overcurrent trip during deceleration or stop, Regenerative overvoltage trip during acceleration, Regenerative overvoltage trip during constant speed, Regenerative overvoltage trip during deceleration, Regenerative overvoltage trip during decelerative overvoltage trip during deceleration, Regenerative overvoltage trip during deceleration or stop, Inverter overload trip (electronic thermal relay function), Motor overload trip (electronic thermal relay function), Heatsink overheat, Instantaneous power failure-1, Undervoltage-1, Input phase loss-1-2, Stall prevention stop, Loss of synchronism detection-2, Upper limit fault detection, Lower limit fault detection, Output side earth (ground) fault overcurrent, Output phase loss, External thermal relay operation-2, PTC thermistor operation-2, Option fault, Communication option fault, Parameter storage device fault, PU disconnection, Retry count excess-2, CPU fault, Operation panel power supply short circuit, 24 VDC power fault, Abnormal										
	Warning function  Fan alarm, Stall prevention (overcurrent), Stall prevention (overvoltage), Electronic thermal relay function pre-alarm, PU stop, Parameter copy, Safety stop, Maintenance timer 1 to 3*2, USB host error, Operation panel lock*2, Password locked*2, Parameter write error, Copy operation error, 24 V external power supply operation, Load fault warning, Emergency drive in operation											

#### **Common specifications**


*	Surrounding air temperature	-10°C to +50°C (non-freezing) (LD rating) -10°C to +40°C (non-freezing) (SLD rating)
2	Surrounding air humidity	With circuit board coating (conforming to IEC60721-3-3 3C2/3S2): 95% RH or less (non-condensing) Without circuit board coating: 90% RH or less (non-condensing)
1	Storage temperature*3	-20°C to +65°C
يُ ا	Atmosphere	Indoors (without corrosive gas, flammable gas, oil mist, dust and dirt, etc.)
1	Altitude/vibration	Maximum 1000 m above sea level*4, 5.9 m/s <sup>2</sup> or less*5 at 10 to 55 Hz (directions of X, Y, Z axes)

- \*1 Available only for the standard model.
- \*2 This protective function is not available in the initial status.
- \*3 Temperature applicable for a short time, e.g. in transit.
- \*4 For the installation at an altitude above 1,000 m (up to 2,500 m), derate the rated current 3% per 500 m.
- \*5 2.9 m/s<sup>2</sup> or less for the FR-F840-04320(185K) or higher.

#### **8.4 Outline dimension drawings**


#### 8.4.1 **Inverter outline dimension drawings**

FR-F820-00046(0.75K), FR-F820-00077(1.5K)



FR-F820-00105(2.2K), 00167(3.7K), 00250(5.5K)


FR-F840-00023(0.75K), 00038(1.5K), 00052(2.2K), 00083(3.7K), 00126(5.5K)



#### **Outline dimension drawings**


#### FR-F820-00340(7.5K), 00490(11K), 00630(15K)

FR-F840-00170(7.5K), 00250(11K), 00310(15K), 00380(18.5K)




#### FR-F820-00770(18.5K), 00930(22K), 01250(30K)

#### FR-F840-00470(22K), 00620(30K)




#### FR-F820-01540(37K)

#### FR-F840-00770(37K)




#### FR-F820-01870(45K), 02330(55K), 03160(75K), 03800(90K), 04750(110K) FR-F840-00930(45K), 01160(55K), 01800(75K), 02160(90K), 02600(110K), 03250(132K), 03610(160K)




(Unit: mm)

#### **Outline dimension drawings**


#### FR-F840-04320(185K), 04810(220K)



#### FR-F840-05470(250K), 06100(280K), 06830(315K)




#### Operation panel (FR-DU08)



#### 8.4.2 **Dedicated motor outline dimension drawings**


## ◆Premium high-efficiency IPM motor [MM-EFS (1500 r/min) series]

• 30K or lower



Model		Output	Frame								0	utlin	e din	nens	ion (ı	mm)										
Wiodei		(kW)	No.	Α	В	С	D	Е	F	Н	KA	KD	KG	KL	M	N	XB	Q	QK	R	S	Т	U	W	Х	Z
	7	0.75	80M	122	95	80	161.6	62.5	50	164	39.5	27	63	145	160	125	50	40	32	140	φ19j6	6	3.5	6	15	9
	15	1.5	90L	143	110.5	90	183.6	70	62.5	182	53	27	76	158	175	150	56	50	40	168.5	φ24j6	7	4	8	15	9
200V class	22	2.2	100L	173	128	100	207	80	70	203.5	65	27	88	169	200	180	63	60	45	193	ф28ј6	7	4	8	4	12
MM-EFS[]1M	37	3.7	112M	181	135	112	228	95	70	226	69	27	103	180	230	180	70	60	45	200	φ28j6	7	4	8	4	12
MINI-ELO[] IM	55	5.5	132S	211.5	152	132	266	108	70	265	75	27	120	197	256	180	89	80	63	239	φ38k6	8	5	10	4	12
	75	7.5	132M	230.5	171	132	266	108	89	265	94	27	120	197	256	218	89	80	63	258	φ38k6	8	5	10	4	12
400V class	11K	11	160M	252	198	160	318	127	105	316	105	56	142	266	310	254	108	110	90	323	φ42k6	8	5	12	4	14.5
MM-EFS[]1M4	15K	15	160L	274	220	160	318	127	127	316	127	56	142	266	310	298	108	110	90	345	φ42k6	8	5	12	4	14.5
WIWI-EFS[] I WI4	18K	18.5	180M	292.5	225 5	180	363	139.5	120.5	359	127	56	168	289	335	285	121	110	90	251 5	φ48k6	0	5.5	1.1	4	14.5
	22K	22	TOUN	292.5	223.5	100	303	139.5	120.5	309	127	50	100	209	335	200	121	110	90	331.5	ψ40Κ0	9	5.5	14	4	14.5
	30K	30	180L	311.5	242.5	180	363	139.5	139.5	359	146	56	168	289	335	323	121	110	90	370.5	φ55m6	10	6	16	4	14.5

<sup>• 37</sup>K to 55K




Model		Output	Frame							Out	line o	dime	nsion	(mr	1)						
Wodei		(kW)	No.	Α	В	С	D	Е	F	Н	KA	KG	KP	M	N	XB	R	S	Т	U	W
200V class MM-EFS∏1M	37K	-	200L	355	267.5	200	406	159	152.5	401	145	472	548	390	361	133	425.5	∮60m6	11	7	18
_	45K		200L	333	207.5	200	400	155	132.3	401	143	472	340	390	301	133	425.5	φοσιτίο		ľ	10
400V class MM-EFS[]1M4	55K	55	225S	365	277	225	446	178	143	446	145	517	593	428	342	149	432	φ65m6	11	7	18



<sup>·</sup> The drawings shown above are sample outline dimension drawings. The outer appearance may differ depending on the frame number.


## ◆Premium high-efficiency IPM motor [MM-THE4 (1500 r/min) series]

#### • 75kW




Frame											Outlir	ne din	nens	ion (	mm)											
No.	Α	В	С	D	Е	F	G	Н	J	KA	KG	K	K1	K2	L	M	N	Z	XB	Q	QK	R	S	Т	U	W
250MA	449.5	317	250	490	203	174.5	30	692	100	157.5	583	168	50	50	932	486	449	24	168	140	110	482.5	75m6	12	7.5	20

• 90kW



Frame											Out	line di	imens	sion	(mm)											
No.	Α	В	O	D	Е	F	G	Н	J	KA	KG	K	K1	K2	L	М	N	Z	XB	Q	QK	R	S	Т	<b>–</b>	w
250MD	545.5	317	250	535	203	174.5	30	712	100	157.5	603	130	168	50	1028	486	449	24	168	140	110	482.5	75m6	12	7.5	20

• 110kW, 132kW, 160kW



Frame											Outli	ne din	nensi	on (ı	nm)											
No.	Α	В	С	D	Е	F	G	Н	J	KA	KG	K	K1	K2	L	M	N	Z	XB	Q	QK	R	S	Т	U	W
280MD	596.5	374	280	587	228.5	209.5	30	782	110	210.5	673	130	181	40	1166	560	499	24	190	170	140	569.5	85m6	14	9	22

## • NOTE

- The drawings shown above are sample outline dimension drawings. The outer appearance may differ depending on the frame number.
- For the 200 V class, models with capacities up to 75 kW are available.

## **MEMO**



APPENDIX provides the reference information for use of this product. Refer to APPENDIX as required.

Appendix1	For customers replacing the conventional model	
Appendix2	with this inverterSpecification comparison between PM motor	594
Appendix3	control and induction motor control  Parameters (functions) and instruction codes	596
Appendix4	under different control methods For customers using HMS network options	

## Appendix1

# For customers replacing the conventional model with this inverter

## Appendix1.1 Replacement of the FR-F700(P) series

## ◆Differences and compatibility with the FR-F700(P) series

Item	FR-F700(P)	FR-F800
Control method	V/F control Simple magnetic flux vector control IPM motor control	V/F control Advanced magnetic flux vector control PM motor control (IPM motor/SPM motor)
Added functions	_	USB host function Safety stop function etc.
Maximum output frequency V/F control	400 Hz	590 Hz
PID control	Turn the X14 signal ON to enable PID control.	The X14 signal does not need to be assigned. (PID control is available by the <b>Pr.128</b> setting.)
Automatic restart after instantaneous power failure	Turn the CS signal ON to enable restart.  Pr.186 CS terminal function selection initial value "6"	CS signal assignment not required. (Restart is enabled with the <b>Pr.57</b> setting only.) <b>Pr.186 CS terminal function selection</b> initial value "9999"
PTC thermistor input	Input from the terminal AU (The function of the terminal AU is switched by a switch.)	Input from the terminal 2. (The function of the terminal 2 is switched by the <b>Pr.561</b> setting.)
USB connector	Not used	USB host: A connector USB device: mini B connector
Main circuit terminal screw size	F840-01800(75K): M8)	e 200 V class 03160(75K) (FR-F720(P)-03160(75K):
Control circuit terminal block	Removable terminal block (screw type)	Removable terminal block (spring clamp type)
Terminal response level		evel than the FR-F700(P)'s terminals. By setting nput terminal filter, the terminal response level can ximately 5 to 8 ms and adjust the setting according to
PU	FR-DU07 (4-digit LED) FR-PU07	FR-DU08 (5-digit LED) FR-LU08 (LCD) FR-PU07 (Some functions, such as parameter copy, are unavailable.) FR-DU07 is not supported.
Plug-in option	Dedicated plug-in options (not interchangeable)	
Plug-in option connector	One connector (FR-F700P, FR-F700-CHT) Two connectors (FR-F700-NA/EC)	Three connectors
Communication option	Connected to the connector 1. (FR-F700P, FR-F700-CHT) Connected to the connector 2. (FR-F700-NA/EC)	Connected to the connector 1.
Installation size	Installation size is compatible for standard models. (require new mounting holes. However, for the 200 V attachment (FR-F8AT) is required.) For separated converter types, installation size is no	, ,
Converter	Built-in for all capacities	An optional converter unit (FR-CC2) is required for separated converter types.
DC reactor	The 75K or higher comes with a DC reactor (FR-HEL).	For the FR-F820-03160(75K) or higher, the FR-F840-01800(75K) or higher, select a DC reactor suitable for the applicable motor capacity. (A DC reactor is not included.) Separated converter types (converter unit FR-CC2) have a built-in DC reactor.

#### Installation precautions

- Removal procedure of the front cover is different. (Refer to page 22.)
- Plug-in options of the FR-F700(P) series are not compatible.
- Operation panel (FR-DU07) cannot be used.

#### Wiring precautions

• The spring clamp type terminal block has changed to the screw type. Use of blade terminals is recommended.

## ◆Instructions for continuous use of the FR-PU07 (parameter unit)

- For the FR-F800 series, many functions (parameters) have been added. When setting these parameters, the parameter names and setting ranges are not displayed.
- Only the parameter with the numbers up to "999" can be read and set. The parameters with the numbers after "999" cannot be read or set.
- · Many protective functions have been added for the FR-F800 series. These functions are available, but all faults are displayed as "Fault". When the faults history is checked, "ERR" appears. Added faults will not appear on the parameter unit. (However, MT1 to MT3 are displayed as MT.)
- · Parameter copy/verification function are not available.

#### Copying parameter settings

• The FR-F700(P) series' parameter settings can be easily copied to the FR-F800 series by using the setup software (FR Configurator2). (Not supported by the setup software FR-SW3-SETUP or older.)

## Appendix 1.2 Replacement of the FR-F500(L) series

## **♦**Installation precautions

Installation size is compatible for replacing the FR-F520(L)-0.75K, 2.2K, 3.7K, 7.5K, 18.5K, 22K, 37K, 45K, 90K, 110K, FR-F540(L)-0.75K to 3.7K, 7.5K, 11K, 22K, 37K to 55K, 132K to 280K. New mounting holes are required for replacing models with other capacities. (For the 55K or lower, the installation interchange attachment can be used.)

## • NOTE

• For the installation size and the outline dimensions of the separated converter type, refer to the FR-F802 (Separated Converter Type) Instruction Manual (Hardware).

## Appendix2

## Specification comparison between PM motor control and induction motor control

Ite	m	PM motor control	Induction motor control
Applicabl		Premium high-efficiency IPM motor MM-EFS, MM-THE4 series (the same capacity as the inverter capacity)	General-purpose motor SF-JR, SF-PR series, etc.*1
Numb connectab		1: 1	Several motors can be driven under V/F control.
Number o		MM-EFS 15 kW or lower: 6 poles MM-THE4: 6 poles MM-EFS 18.5 kW or higher: 8 poles	Normally 2, 4, or 6 poles.
Rated i		MM-EFS 15 kW or lower: 75 Hz MM-THE4: 75 Hz MM-EFS 18.5 kW or higher: 100 Hz	Normally 50 Hz or 60 Hz
Maximun freque		MM-EFS 15 kW or lower: 112.5 Hz (2250 r/min with 6P) MM-EFS 18.5 kW or higher: 150 Hz (2250 r/min with 8P) MM-THE4: 90 Hz (1800 r/min with 6P)	590 Hz (17700 r/min with 4P) (Set the upper limit frequency ( <b>Pr.0</b> , <b>Pr.18</b> ) according to the motor and machine specifications.)  120% 60 s, 150% 3 s (inverse-time characteristics)
Permissi		120% 60 s, 150% 3 s (inverse-time characteristics) (The % value is a ratio to the rated motor current.)	(The % value is a ratio to the rated inverter current.)
Maximum torq	•	50%	120% (Advanced magnetic flux vector control)
Frequency setting resolution	Analog input	0.018 Hz / 0 to 75 Hz (1500 r/min) / 0.025 Hz /0 to 100 Hz (1500 r/min) (0 to 10 V/12 bits)*2 0.036 Hz / 0 to 75 Hz (1500 r/min) / 0.05 Hz / 0 to 100 Hz (1500 r/min) (0 to 5 V/11 bits, 0 to 20 mA/11bits, 0 to ±10 V/12 bits)*2 0.072 Hz / 0 to 75 Hz (1500 r/min) / 0.1 Hz /0 to 100 Hz (1500 r/min) (0 to ±5 V/11 bits)*2	0.015 Hz / 0 to 60 Hz (1800 r/min with 4P) (0 to 10 V/12 bits) 0.03 Hz / 0 to 60 Hz (1800 r/min with 4P) (0 to 5 V/11 bits, 0 to 20 mA/11 bits, 0 to ±10 V/12 bits) 0.06 Hz / 0 to 60 Hz (1800 r/min with 4P) (0 to ±5 V/11 bits)
Output signal	Pulse output for meter	In the initial setting, 1 mA is output at the rated motor frequency from across terminals FM and SD. (SD is a common terminal.)  The permissible frequency load current is 2 mA.  Pulse specification: 1440 pulses/s at the rated motor frequency	In the initial setting, 1 mA is output at 60 Hz from across terminals FM and SD. (SD is a common terminal.) The permissible frequency load current is 2 mA. Pulse specification: 1440 pulses/s at 60 Hz
Carrier fro	equency	Four patterns of 2 kHz, 6 kHz, 10 kHz, and 14 kHz <sub>*</sub> 3 Two patterns of 2 kHz and 6 kHz <sub>*</sub> 4	Selectable between 0.75 kHz to 14.5 kHz*3  0.75 kHz to 6 kHz*4
Automati after insta	ntaneous ailure	No startup waiting time. Using the regeneration avoidance function together is recommended.	Startup waiting time exists.
Startup		Startup delay of about 0.1 s for initial tuning.	No startup delay.
Driving commerci sup	al power	Not available Never connect an IPM motor to the commercial power supply.	Can be driven by the commercial power supply.
Operation motor co	pasting	While the motor is coasting, potential is generated across motor terminals.  Before wiring, make sure that the motor is stopped.	While the motor is coasting, no potential is generated across motor terminals.
Maximun wiring l		100 m or shorter	Overall length: 500 m or shorter

- \*1 For the motor capacity, the rated motor current should be equal to or less than the rated inverter current. (It must be 0.4 kW or higher.)

  If a motor with substantially low rated current compared with the rated inverter current is used, speed and torque accuracies may deteriorate due to torque ripples, etc. Set the rated motor current to 40% or higher of the rated inverter current.
- \*2 The values differ for the 15K and lower capacity premium high-efficiency IPM motor, which requires 6 poles to run at the rated motor speed (1500 r/min), or for 18K and higher, which requires 8 poles to run at the speed.
- \*3 For the FR-F820-02330(55K) or lower and the FR-F840-01160(55K) or lower
- \*4 For the FR-F820-03160(75K) or higher and the FR-F840-01800(75K) or higher

## NOTE

- Before wiring, make sure that the motor is stopped. Otherwise you may get an electric shock.
- Never connect an IPM motor to the commercial power supply.
- No slippage occurs with an IPM motor because of its characteristic. If an IPM motor, which took over an induction motor, is
  driven at the same frequency as for the general-purpose motor, the rotation speed of the IPM motor becomes faster by the
  amount of the general-purpose motor's slippage. Adjust the speed command to run the IPM motor at the same speed as the
  induction motor, as required.

## **Appendix3** Parameters (functions) and instruction codes under different control methods

- \*1 Instruction codes are used to read and write parameters in accordance with the Mitsubishi inverter protocol of RS-485 communication. (For RS-485 communication, refer to page 449.)
- \*2 Function availability under each control method is shown as below:
  - O: Available
  - x: Not available
- \*3 For "parameter copy", "parameter clear", and "all parameter clear", "O" indicates the function is available, and "x" indicates the function is not
- \*4 These parameters are not cleared by the parameter clear (all parameter clear) command, which are sent through RS-485 communication. (For RS-485 communication, refer to page 449.)
- \*5 When a communication option is installed, parameter clear (lock release) during password lock (Pr.297 ≠ "9999") can be performed only from the communication option.
- \*6 Reading and writing via the PU connector are available.

Symbols in the table indicate parameters that operate when the options are connected.

AR FR-A8AR, AX FR-A8AX, AY FR-A8AY, NC FR-A8NC, NCE FR-A8NCE, ND FR-A8ND, NP FR-A8NP

			struct code		Cont	rol met	hod <sub>*2</sub>	P	aramet	er
Pr.	Name	Read	Write	Extended	J/A	Magnetic flux		Copy₃	Clears	All clear₃
0	Torque boost	00	80	0	0	×	×	0	0	0
1	Maximum frequency	01	81	0	0	0	0	0	0	0
2	Minimum frequency	02	82	0	0	0	0	0	0	0
3	Base frequency	03	83	0	0	×	×	0	0	0
4	Multi-speed setting (high speed)	04	84	0	0	0	0	0	0	0
5	Multi-speed setting (middle speed)	05	85	0	0	0	0	0	0	0
6	Multi-speed setting (low speed)	06	86	0	0	0	0	0	0	0
7	Acceleration time	07	87	0	0	0	0	0	0	0
8	Deceleration time	08	88	0	0	0	0	0	0	0
9	Electronic thermal O/L relay	09	89	0	0	0	0	0	0	0
10	DC injection brake operation frequency	0A	8A	0	0	0	0	0	0	0
11	DC injection brake operation time	0B	8B	0	0	0	0	0	0	0
12	DC injection brake operation voltage	0C	8C	0	0	0	×	0	0	0
13	Starting frequency	0D	8D	0	0	0	0	0	0	0
14	Load pattern selection	0E	8E	0	0	×	×	0	0	0
15	Jog frequency	0F	8F	0	0	0	0	0	0	0
16	Jog acceleration/deceleration time	10	90	0	0	0	0	0	0	0
17	MRS input selection	11	91	0	0	0	0	0	0	0
18	High speed maximum frequency	12	92	0	0	0	0	0	0	0
19	Base frequency voltage	13	93	0	0	×	×	0	0	0
20	Acceleration/deceleration reference frequency	14	94	0	0	0	0	0	0	0
21	Acceleration/deceleration time increments	15	95	0	0	0	0	0	0	0
22	Stall prevention operation level	16	96	0	0	0	0	0	0	0
23	Stall prevention operation level compensation factor at double speed	17	97	0	0	0	×	0	0	0
24	Multi-speed setting (speed 4)	18	98	0	0	0	0	0	0	0
25	Multi-speed setting (speed 4)	19	99	0	0	0	0	0	0	0
26	Multi-speed setting (speed 5)  Multi-speed setting (speed 6)	1A	9A	0	0	0	0	0	0	0
27	Multi-speed setting (speed 7)	1B	9B	0	0	0	0	0	0	0
28	Multi-speed input compensation selection	1C	9C	0	0	0	0	0	0	0
29	Acceleration/deceleration pattern selection	1D	9D	0	0	0	0	0	0	0
30	Regenerative function selection	1E	9E	0	0	0	0	0	0	0
31	Frequency jump 1A	1F	9E 9F	0	0	0	0	0	0	0
32	Frequency jump 1B	20	A0	0	0	0	0	0	0	0
33	Frequency jump 2A	21	A1	0	0	0	0	0	0	0
34	Frequency jump 2B	22	A1	0	0	0	0	0	0	0
35		23	A2	0	0	0	0	0	0	0
36	Frequency jump 3A Frequency jump 3B	24	A3 A4	0	0	0	0	0	0	0
36	Speed display	25	A4 A5	0	0	0	0	0	0	0
31	ореси изріау	20	AS	U	J	9	J	J	J	9

			structi code		Cont	rol met	hod <sub>*2</sub>	P	aramet	er
Pr.	Name	Read	Write	Extended	N/F	Magnetic flux	Z	Copys	Clear	All clear.
41	Up-to-frequency sensitivity	29	A9	0	0	0	0	0	0	0
42	Output frequency detection	2A	AA	0	0	0	0	0	0	0
43	Output frequency detection for reverse rotation	2B	AB	0	0	0	0	0	0	0
44	Second acceleration/deceleration time	2C	AC	0	0	0	0	0	0	0
45	Second deceleration time	2D	AD	0	0	0	0	0	0	0
46	Second torque boost	2E	AE	0	0	×	×	0	0	0
47	Second V/F (base frequency)	2F	AF	0	0	×	×	0	0	0
48	Second stall prevention operation level	30	B0	0	0	0	×	0	0	0
49	Second stall prevention operation frequency	31	B1	0	0	0	×	0	0	0
50	Second output frequency detection	32	B2	0	0	0	0	0	0	0
51	Second electronic thermal O/L relay	33	B3	0	0	0	0	0	0	0
52 54	Operation panel main monitor selection	34 36	B4	0	0	0	0	0	0	0
54 55	FM/CA terminal function selection  Frequency monitoring reference	36	B6 B7	0	0	0	0	0	0	0
56	Current monitoring reference	38	B8	0	0	0	0	0	0	0
57	Restart coasting time	39	B9	0	0	0	0	0	0	0
58	Restart cushion time	3A	BA	0	0	0	×	0	0	0
59	Remote function selection	3B	BB	0	0	0	Ô	0	0	0
60	Energy saving control selection	3C	BC	0	0	0	×	0	0	0
65	Retry selection	41	C1	0	0	0	Ô	0	0	0
66	Stall prevention operation reduction starting frequency	42	C2	0	0	0	×	0	0	0
67	Number of retries at fault occurrence	43	C3	0	0	0	0	0	0	0
68	Retry waiting time	44	C4	0	0	0	0	0	0	0
69	Retry count display erase	45	C5	0	0	0	0	0	0	0
70	Parameter for manufacturer setting. Do not set.	1.0			_	_	_	_	_	
71	Applied motor	47	C7	0	0	0	0	0	0	0
72	PWM frequency selection	48	C8	0	0	0	0	0	0	0
73	Analog input selection	49	C9	0	0	0	0	0	0	0
74	Input filter time constant	4A	CA	0	0	0	0	0	0	0
75	Reset selection/disconnected PU detection/PU stop selection	4B	СВ	0	0	0	0	0	×	×
76	Fault code output selection	4C	CC	0	0	0	0	0	0	0
77*6	Parameter write selection	4D	CD	0	0	0	0	0	0	0
78	Reverse rotation prevention selection	4E	CE	0	0	0	0	0	0	0
79*6	Operation mode selection	4F	CF	0	0	0	0	0	0	0
80	Motor capacity	50	D0	0	×	0	0	0	0	0
81	Number of motor poles	51	D1	0	×	0	0	0	0	0
82	Motor excitation current	52	D2	0	×	0	×	0	×	0
83	Rated motor voltage	53	D3	0	×	0	0	0	0	0
84	Rated motor frequency	54	D4	0	×	0	0	0	0	0
89	Speed control gain (Advanced magnetic flux vector)	59	D9	0	×	0	×	0	×	0
90	Motor constant (R1)	5A	DA	0	×	0	0	0	×	0
91	Motor constant (R2)	5B	DB	0	×	0	×	0	×	0
92	Motor constant (L1)/d-axis inductance (Ld)	5C	DC	0	×	0	0	0	×	0
93 94	Motor constant (L2)/q-axis inductance (Lq)	5D 5E	DD DE	0	×	0	0	0	×	0
95	Motor constant (X)	5F	DF	0	×	0	×	0	×	0
96	Online auto tuning selection	60	E0	0	×	0	×	0	0	0
100	Auto tuning setting/status V/F1 (first frequency)	00	80	1	×	×	×	0	×	0
100	V/F1 (first frequency) V/F1 (first frequency voltage)	01	81	1	0	×	×	0	0	0
102	V/F2 (second frequency)	02	82	1	0	×	×	0	0	0
103	V/F2 (second frequency voltage)	03	83	1	0	×	×	0	0	0
104	V/F3 (third frequency)	04	84	1	0	×	×	0	0	0
105	V/F3 (third frequency voltage)	05	85	1	0	×	×	0	0	0
106	V/F4 (fourth frequency)	06	86	1	0	×	×	0	0	0
107	V/F4 (fourth frequency voltage)	07	87	1	0	×	×	0	0	0
108	V/F5 (fifth frequency)	08	88	1	0	×	×	0	0	0
109	V/F5 (fifth frequency voltage)	09	89	1	0	×	×	0	0	0
117	PU communication station number	11	91	1	0	0	0	0	O*4	<b>O</b> *4
118	PU communication speed	12	92	1	0	0	0	0	O*4	O*4

			structi code•		Cont	rol meti	hod•2	P	aramet	er
Pr.	Name	Read	Write	Extended	V/F	Magneticíflux	Z	Copy*3	Clear	All clear₃
119	PU communication stop bit length / data length	13	93	1	0	0	0	0	<b>O</b> *4	<b>O</b> *4
120	PU communication parity check	14	94	1	0	0	0	0	O*4	O*4
121	Number of PU communication retries	15	95	1	0	0	0	0	O*4	O*4
122	PU communication check time interval	16	96	1	0	0	0	0	O*4	O*4
123	PU communication waiting time setting	17	97	1	0	0	0	0	O*4	<b>O</b> *4
124	PU communication CR/LF selection	18	98	1	0	0	0	0	O*4	O*4
125	Terminal 2 frequency setting gain frequency	19	99	1	0	0	0	0	×	0
126	Terminal 4 frequency setting gain frequency	1A	9A	1	0	0	0	0	×	0
127	PID control automatic switchover frequency	1B	9B	1	0	0	0	0	0	0
128	PID action selection	1C	9C	1	0	0	0	0	0	0
129	PID proportional band	1D 1E	9D	1	0	0	0	0	0	0
130 131	PID integral time PID upper limit	1F	9E 9F	1	0	0	0	0	0	0
132	PID lower limit	20	A0	1	0	0	0	0	0	0
133	PID action set point	21	A1	1	0	0	0	0	0	0
134	PID differential time	22	A2	1	0	0	0	0	0	0
135	Electronic bypass sequence selection	23	A3	1	0	0	×	0	0	0
136	MC switchover interlock time	24	A4	1	0	0	×	0	0	0
137	Start waiting time	25	A5	1	0	0	×	0	0	0
138	Bypass selection at a fault	26	A6	1	0	0	×	0	0	0
139	Automatic switchover frequency from inverter to bypass operation	27	A7	1	0	0	×	0	0	0
140	Backlash acceleration stopping frequency	28	A8	1	0	0	0	0	0	0
141	Backlash acceleration stopping time	29	A9	1	0	0	0	0	0	0
142	Backlash deceleration stopping frequency	2A	AA	1	0	0	0	0	0	0
143	Backlash deceleration stopping time	2B	AB	1	0	0	0	0	0	0
144	Speed setting switchover	2C	AC	1	0	0	0	0	0	0
145	PU display language selection	2D 2F	AD	1	0	0	0	0	×	×
147 148	Acceleration/deceleration time switching frequency Stall prevention level at 0 V input	30	AF B0	1	0	0	×	0	0	0
149	Stall prevention level at 0 V input	31	B1	1	0	0	×	0	0	0
150	Output current detection level	32	B2	1	0	0	0	0	0	0
151	Output current detection signal delay time	33	B3	1	0	0	0	0	0	0
152	Zero current detection level	34	B4	1	0	0	0	0	0	0
153	Zero current detection time	35	B5	1	0	0	0	0	0	0
154	Voltage reduction selection during stall prevention operation	36	B6	1	0	0	×	0	0	0
155	RT signal function validity condition selection	37	B7	1	0	0	0	0	0	0
156	Stall prevention operation selection	38	B8	1	0	0	0	0	0	0
157	OL signal output timer	39	B9	1	0	0	0	0	0	0
158	AM terminal function selection	3A	BA	1	0	0	0	0	0	0
159	Automatic switchover frequency range from bypass to inverter operation	3B	BB	1	0	0	×	0	0	0
160	User group read selection	00	80	2	0	0	0	0	0	0
161 162	Frequency setting/key lock operation selection  Automatic restart after instantaneous power failure selection	01 02	81 82	2	0	0	0	0	×	0
163	First cushion time for restart	03	83	2	0	0	×	0	0	0
164	First cushion voltage for restart	04	84	2	0	0	×	0	0	0
165	Stall prevention operation level for restart	05	85	2	0	0	×	0	0	0
166	Output current detection signal retention time	06	86	2	0	0	0	0	0	0
167	Output current detection operation selection	07	87	2	0	0	0	0	0	0
168 169	Parameter for manufacturer setting. Do not set.									
170	Watt-hour meter clear	0A	8A	2	0	0	0	0	×	0
171	Operation hour meter clear	0B	8B	2	0	0	0	×	×	×
172	User group registered display/batch clear	0C	8C	2	0	0	0	×	×	×
173	User group registration	0D	8D	2	0	0	0	×	×	×
174	User group clear	0E	8E	2	0	0	0	×	×	×
178	STF terminal function selection	12	92	2	0	0	0	0	×	0
179	STR terminal function selection	13	93	2	0	0	0	0	X	0

		Instruction code <sub>*1</sub>			Cont	rol met	hod <sub>*2</sub>	Parameter		
Pr.	Name	Read	Write	Extended	N/F	Magneticflux	2	Copys	Clears	All clear.
180	RL terminal function selection	14	94	2	0	0	0	0	×	0
181	RM terminal function selection	15	95	2	0	0	0	0	×	0
182	RH terminal function selection	16	96	2	0	0	0	0	×	0
183	RT terminal function selection	17	97	2	0	0	0	0	×	0
184	AU terminal function selection	18	98	2	0	0	0	0	×	0
185	JOG terminal function selection	19	99	2	0	0	0	0	×	0
186 187	CS terminal function selection	1A	9A 9B	2	0	0	0	0	×	0
188	MRS terminal function selection STOP terminal function selection	1B 1C	9B	2	0	0	0	0	×	0
189	RES terminal function selection	1D	9D	2	0	0	0	0	×	0
190	RUN terminal function selection	1E	9E	2	0	0	0	0	×	0
191	SU terminal function selection	1F	9F	2	0	0	0	0	×	0
192	IPF terminal function selection	20	A0	2	0	0	0	0		0
193	OL terminal function selection	21	A1	2	0	0	0	0	×	0
194	FU terminal function selection	22	A2	2	0	0	0	0	×	0
195	ABC1 terminal function selection	23	A3	2	0	0	0	0	×	0
196	ABC2 terminal function selection	24	A4	2	0	0	0	0	×	0
232	Multi-speed setting (speed 8)	28	A8	2	0	0	0	0	Ô	0
233	Multi-speed setting (speed 9)	29	A9	2	0	0	0	0	0	0
234	Multi-speed setting (speed 10)	2A	AA	2	0	0	0	0	0	0
235	Multi-speed setting (speed 11)	2B	AB	2	0	0	0	0	0	0
236	Multi-speed setting (speed 12)	2C	AC	2	0	0	0	0	0	0
237	Multi-speed setting (speed 13)	2D	AD	2	0	0	0	0	0	0
238	Multi-speed setting (speed 14)	2E	AE	2	0	0	0	0	0	0
239	Multi-speed setting (speed 15)	2F	AF	2	0	0	0	0	0	0
240	Soft-PWM operation selection	30	B0	2	0	0	0	0	0	0
241	Analog input display unit switchover	31	B1	2	0	0	0	0	0	0
242	Terminal 1 added compensation amount (terminal 2)	32	B2	2	0	0	0	0	0	0
243	Terminal 1 added compensation amount (terminal 4)	33	B3	2	0	0	0	0	0	0
244 245	Cooling fan operation selection  Rated slip	34 35	B4 B5	2	0	0	0	0	0	0
245	Slip compensation time constant	36	B6	2	0	×	×	0	0	0
247	Constant-power range slip compensation selection	37	B7	2	0	×	×	0	0	0
248	Self power management selection	38	B8	2	0	Ô	Ô	0	0	0
249	Earth (ground) fault detection at start	39	B9	2	0	0	×	0	0	0
250	Stop selection	3A	BA	2	0	0	0	0	0	0
251	Output phase loss protection selection	3B	BB	2	0	0	0	0	0	0
252	Override bias	3C	ВС	2	0	0	0	0	0	0
253	Override gain	3D	BD	2	0	0	0	0	0	0
254	Main circuit power OFF waiting time	3E	BE	2	0	0	0	0	0	0
255	Life alarm status display	3F	BF	2	0	0	0	×	×	×
256	Inrush current limit circuit life display	40	C0	2	0	0	0	×	×	×
257	Control circuit capacitor life display	41	C1	2	0	0	0	×	×	×
258	Main circuit capacitor life display	42	C2	2	0	0	0	×	×	×
259	Main circuit capacitor life measuring	43 44	C3	2	0	0		0	0	0
260 261	PWM frequency automatic switchover  Power failure stop selection	44	C4 C5	2	0	0	0	0	0	0
262	Subtracted frequency at deceleration start	46	C6	2	0	0	0	0	0	0
263	Subtraction starting frequency	47	C7	2	0	0	0	0	0	0
264	Power-failure deceleration time 1	48	C8	2	0	0	0	0	0	0
265	Power-failure deceleration time 2	49	C9	2	0	0	0	0	0	0
266	Power failure deceleration time switchover frequency	4A	CA	2	0	0	0	0	0	0
267	Terminal 4 input selection	4B	СВ	2	0	0	0	0	×	0
268	Monitor decimal digits selection	4C	CC	2	0	0	0	0	0	0
269	Parameter for manufacturer setting. Do not set.									
289	Inverter output terminal filter	61	E1	2	0	0	0	0	×	0
290	Monitor negative output selection	62	E2	2	0	0	0	0	0	0
291	Pulse train I/O selection	63	E3	2	0	0	0	0	×	0

		Instruction code <sub>*1</sub>		Cont	rol meti	nod•₂	Parameter			
Pr.	Name	Read	Write	Extended	A//E	Magneticiflux	2	Copy.3	Clear	All clear <sub>*3</sub>
294	UV avoidance voltage gain	66	E6	2	0	0	0	0	0	0
295	Frequency change increment amount setting	67	E7	2	0	0	0	0	0	0
296	Password lock level	68	E8	2	0	0	0	0	×	0
297 298	Password lock/unlock	69 6A	E9 EA	2	0	0	0	0	<b>O</b> *5	0
290	Frequency search gain  Rotation direction detection selection at restarting	6B	EB	2	0	0	×	0	×	0
300	BCD input bias AX	00	80	3	0	0	Ô	0	0	0
301	BCD input gain AX	01	81	3	0	0	0	0	0	0
302	·	02	82	3	0	0	0	0	0	0
303	BIN input bias AX	03	83	3	0	0	•	0	0	0
303	BIN input gain X  Digital input and analog input compensation enable/disable	03	03	3	U	O		U	0	0
304	selection AX	04	84	3	0	0	0	0	0	0
305	Read timing operation selection AX	05	85	3	0	0	0	0	0	0
306	Analog output signal selection AY	06	86	3	0	0	0	0	0	0
307	Setting for zero analog output AY	07	87	3	0	0	0	0	0	0
308	Setting for maximum analog output AY	80	88	3	0	0	0	0	0	0
309	Analog output signal voltage/current switchover AY	09	89	3	0	0	0	0	0	0
310	Analog meter voltage output selection AY	0A	8A	3	0	0	0	0	0	0
311	Setting for zero analog meter voltage output AY	0B	8B	3	0	0	0	0	0	0
312	Setting for maximum analog meter voltage output AY	0C	8C	3	0	0	0	0	0	0
313	DO0 output selection AY NC	0D	8D	3	0	0	0	0	×	0
314	DO1 output selection AY NC	0E	8E	3	0	0	0	0	×	0
315	DO2 output selection AY NC	0F	8F	3	0	0	0	0	×	0
316	DO3 output selection AY	10	90	3	0	0	0	0	×	0
317	DO3 output selection AY	11	91	3	0	0	0	0	×	0
318		12	92	3	0	0	0	0		0
319	DO5 output selection AY	13	93	3	0	0	0	0	×	0
	DO6 output selection AY			3					×	
320	RA1 output selection AR	14	94	-	0	0	0	0	×	0
321	RA2 output selection AR	15	95	3	0	0	0	0	×	0
322	RA3 output selection AR	16	96	3	0	0	0	0	×	0
323	AM0 0V adjustment AY	17	97	3	0	0	0	0	×	0
324	AM1 0mA adjustment AY	18	98	3	0	0	0	0	×	0
329	Digital input unit selection AX	1D	9D	3	0	0	0	0	×	0
331	RS-485 communication station number	1F	9F	3	0	0	0	0	O*4	O*4
332	RS-485 communication speed	20	A0	3	0	0	0	0	O*4	O*4
333	RS-485 communication stop bit length / data length	21	A1	3	0	0	0	0	0*4	O*4
334	RS-485 communication parity check selection	22	A2	3	0	0	0	0	0*4	O*4
335 336	RS-485 communication retry count  RS-485 communication check time interval	23 24	A3 A4	3	0	0	0	0	0*4	O*4
337	RS-485 communication waiting time setting	25	A4 A5	3	0	0	0	0	O*4 O*4	O*4
338	Communication operation command source	26	A6	3	0	0	0	0	O*4	O*4
339	Communication speed command source	27	A7	3	0	0	0	0	0*4	0*4
340	Communication startup mode selection	28	A8	3	0	0	0	0	0*4	0*4
341	RS-485 communication CR/LF selection	29	A9	3	0	0	0	0	0*4	0*4
342	Communication EEPROM write selection	2A	AA	3	0	0	0	0	0	0
343	Communication error count	2B	AB	3	0	0	0	×	×	×
345	DeviceNet address ND	2D	AD	3	0	0	0	0	O*4	<b>O</b> *4
346	DeviceNet baud rate ND	2E	ΑE	3	0	0	0	0	O*4	O*4
349	Communication reset selection NC ND NP	31	B1	3	0	0	0	0	<b>O</b> *4	<b>O</b> *4
374	Overspeed detection level	4A	CA	3	×	×	0	0	0	0
384	Input pulse division scaling factor	54	D4	3	0	0	0	0	0	0
385	Frequency for zero input pulse	55	D5	3	0	0	0	0	0	0
386	Frequency for maximum input pulse	56	D6	3	0	0	0	0	0	0

			struct code		Cont	rol met	hod <sub>*2</sub>	Parameter			
Pr.	Name	Read	Write	Extended	N/F	Magneticflux	2	Copys	Clear	All clear.	
390	% setting reference frequency	5A	DA	3	0	0	0	0	0	0	
414	PLC function operation selection	0E	8E	4	0	0	0	0	×	×	
415	Inverter operation lock mode setting	0F	8F	4	0	0	0	0	0	0	
416	Pre-scale function selection	10	90	4	0	0	0	0	0	0	
417	Pre-scale setting value	11	91	4	0	0	0	0	0	0	
418	Extension output terminal filter AY AR	12	92	4	0	0	0	0	×	0	
434	IP address 1 NCE	22	A2	4	0	0	0	0	O*4	O*4	
435	IP address 2 NCE	23	A3	4	0	0	0	0	O*4	O*4	
450	Second applied motor	32	B2	4	0	0	0	0	0	0	
453	Second motor capacity	35	B5	4	×	0	0	0	0	0	
454	Number of second motor poles	36	B6	4	×	0	0	0	0	0	
455	Second motor excitation current	37	B7	4	×	0	×	0	×	0	
456	Rated second motor voltage	38	B8	4	×	0	0	0	0	0	
457	Rated second motor frequency	39	B9	4	×	0	0	0	0	0	
458 459	Second motor constant (R1) Second motor constant (R2)	3A 3B	BA BB	4	×	0	0	0	X	0	
460	Second motor constant (R2)  Second motor constant (L1) / d-axis inductance (Ld)	3C	BC	4	×	0	0	0	×	0	
461	Second motor constant (L2) / q-axis inductance (Lq)	3D	BD	4	×	0	0	0	×	0	
462	Second motor constant (X)	3E	BE	4	×	0	×	0	×	0	
463	Second motor auto tuning setting/status	3F	BF	4	×	0	0	0	×	0	
495	Remote output selection	5F	DF	4	0	0	0	0	0	0	
496	Remote output data 1	60	E0	4	0	0	0	×	×	×	
497	Remote output data 2	61	E1	4	0	0	0	×	×	×	
498	PLC function flash memory clear	62	E2	4	0	0	0	×	×	×	
500	Communication error execution waiting time  NC NCE ND NP	00	80	5	0	0	0	0	0	0	
501	Communication error occurrence count display  NC NCE ND NP	01	81	5	0	0	0	×	0	0	
502	Stop mode selection at communication error	02	82	5	0	0	0	0	0	0	
503	Maintenance timer 1	03	83	5	0	0	0	×	×	×	
504	Maintenance timer 1 warning output set time	04	84	5	0	0	0	0	×	0	
505	Speed setting reference	05	85	5	0	0	0	0	0	0	
514	Emergency drive dedicated waiting time	0E	8E	5	0	0	0	0	×	0	
515	Emergency drive dedicated retry count	0F	8F	5	0	0	0	0	×	0	
522	Output stop frequency	16	96	5	0	0	0	0	0	0	
523	Emergency drive mode selection	17	97	5	0	0	0	0	×	0	
524	Emergency drive running speed	18	98	5	0	0	0	0	×	0	
539	Modbus-RTU communication check time interval	27	A7	5	0	0	0	0	O*4	<b>O</b> *4	
541	Frequency command sign selection NC NCE NP	29	A9	5	0	0	0	0	O*4	O*4	
542	Communication station number (CC-Link) NC	2A	AA	5	0	0	0	0	O*4	O*4	
543	Baud rate selection (CC-Link) NC	2B	AB	5	0	0	0	0	O*4	O*4	
544	CC-Link extended setting NC	2C	AC	5	0	0	0	0	O*4	O*4	
547	USB communication station number	2F	AF	5	0	0	0	0	O*4	O*4	
548	USB communication check time interval	30	B0	5	0	0	0	0	<b>O</b> *4	O*4	
549	Protocol selection	31	B1	5	0	0	0	0	O*4	O*4	
550	NET mode operation command source selection	32	B2	5	0	0	0	0	<b>O</b> *4	O*4	
551	PU mode operation command source selection	33	ВЗ	5	0	0	0	0	O*4	O*4	
552	Frequency jump range	34	B4	5	0	0	0	0	0	0	
553	PID deviation limit	35	B5	5	0	0	0	0	0	0	
554	PID signal operation selection	36	B6	5	0	0	0	0	0	0	
555	Current average time	37	B7	5	0	0	0	0	0	0	
556	Data output mask time	38	B8	5	0	0	0	0	0	0	
557	Current average value monitor signal output reference current	39	В9	5	0	0	0	0	0	0	
560	Second frequency search gain	3C	BC	5	0	0	×	0	×	0	
561	PTC thermistor protection level	3D	BD	5	0	0	0	0	×	0	
563	Energization time carrying-over times	3F	BF	5	0	0	0	×	×	×	
564	Operating time carrying-over times	40	C0	5	0	0	0	×	×	×	

			structi code.		Cont	rol meti	hod•2	Pa	aramet	er
Pr.	Name	Read	Write	Extended	N/F	Magneticflux	M	Copys	Clears	All clear.
569	Second motor speed control gain	45	C5	5	×	0	×	0	×	0
570	Multiple rating setting	46	C6	5	0	0	0	0	×	×
571	Holding time at a start	47	C7	5	0	0	×	0	0	0
573	4 mA input check selection	49	C9	5	0	0	0	0	0	0
574	Second motor online auto tuning	4A	CA	5	×	0	×	0	0	0
575 576	Output interruption detection time	4B 4C	CB CC	5 5	0	0	0	0	0	0
577	Output interruption detection level Output interruption cancel level	4D	CD	5	0	0	0	0	0	0
578	Auxiliary motor operation selection	4E	CE	5	0	0	0	0	0	0
579	Motor connection function selection	4F	CF	5	0	0	0	0	0	0
580	MC switching interlock time	50	D0	5	0	0	0	0	0	0
581	Start waiting time	51	D1	5	0	0	0	0	0	0
582	Auxiliary motor connection-time deceleration time	52	D2	5	0	0	0	0	0	0
583	Auxiliary motor disconnection-time acceleration time	53	D3	5	0	0	0	0	0	0
584	Auxiliary motor 1 starting frequency	54	D4	5	0	0	0	0	0	0
585	Auxiliary motor 2 starting frequency	55	D5	5	0	0	0	0	0	0
586	Auxiliary motor 3 starting frequency	56	D6	5	0	0	0	0	0	0
587	Auxiliary motor 1 stopping frequency	57	D7	5	0	0	0	0	0	0
588	Auxiliary motor 2 stopping frequency	58	D8	5	0	0	0	0	0	0
589	Auxiliary motor 3 stopping frequency	59	D9	5	0	0	0	0	0	0
590	Auxiliary motor start detection time	5A	DA	5	0	0	0	0	0	0
591	Auxiliary motor stop detection time	5B	DB	5	0	0	0	0	0	0
592	Traverse function selection	5C	DC	5	0	0	0	0	0	0
593	Maximum amplitude amount	5D 5E	DD DE	5	0	0	0	0	0	0
594 595	Amplitude compensation amount during deceleration  Amplitude compensation amount during acceleration	5E 5F	DF	5	0	0	0	0	0	0
596	Amplitude acceleration time	60	E0	5	0	0	0	0	0	0
597	Amplitude deceleration time  Amplitude deceleration time	61	E1	5	0	0	0	0	0	0
598	Undervoltage level	62	E2	5	0	0	×	0	0	0
599	X10 terminal input selection	63	E3	5	0	0	0	0	0	0
600	First free thermal reduction frequency 1	00	80	6	0	0	0	0	0	0
601	First free thermal reduction ratio 1	01	81	6	0	0	0	0	0	0
602	First free thermal reduction frequency 2	02	82	6	0	0	0	0	0	0
603	First free thermal reduction ratio 2	03	83	6	0	0	0	0	0	0
604	First free thermal reduction frequency 3	04	84	6	0	0	0	0	0	0
606	Power failure stop external signal input selection	06	86	6	0	0	0	0	0	0
607	Motor permissible load level	07	87	6	0	0	0	0	0	0
608	Second motor permissible load level	08	88	6	0	0	0	0	0	0
609	PID set point/deviation input selection	09	89	6	0	0	0	0	0	0
610	PID measured value input selection	0A	8A	6	0	0	0	0	0	0
611 653	Acceleration time at a restart  Speed smoothing control	0B 35	8B B5	6	0	0	0	0	0	0
654	Speed smoothing cutoff frequency	36	B6	6	0	0	×	0	0	0
655	Analog remote output selection	37	B7	6	0	0	Ô	0	0	0
656	Analog remote output 1	38	B8	6	0	0	0	×	×	×
657	Analog remote output 2	39	B9	6	0	0	0	×	×	×
658	Analog remote output 3	3A	ВА	6	0	0	0	×	×	×
659	Analog remote output 4	3B	ВВ	6	0	0	0	×	×	×
660	Increased magnetic excitation deceleration operation selection	3C	вс	6	0	0	×	0	0	0
661	Magnetic excitation increase rate	3D	BD	6	0	0	×	0	0	0
662	Increased magnetic excitation current level	3E	BE	6	0	0	×	0	0	0
663	Control circuit temperature signal output level	3F	BF	6	0	0	0	0	0	0
665	Regeneration avoidance frequency gain	41	C1	6	0	0	0	0	0	0
668	Power failure stop frequency gain	44	C4	6	0	0	0	0	0	0
673	SF-PR slip amount adjustment operation selection	49	C9	6	0	×	×	0	0	0
674	SF-PR slip amount adjustment gain	4A	CA	6	0	×	×	0	0	0
684	Tuning data unit switchover	54	D4	6	×	0	0	0	0	0
686	Maintenance timer 2	56	D6	6	0	0	0	×	X	×
687	Maintenance timer 2 warning output set time	57	D7	6	0	0	0	0	×	0

			structi code•		Cont	Control method <sub>*2</sub>			Parameter			
Pr.	Name	Read	Write	Extended	N/F	Magneticflux	Z	Copys	Clear	All clear <sub>33</sub>		
688	Maintenance timer 3	58	D8	6	0	0	0	×	×	×		
689	Maintenance timer 3 warning output set time	59	D9	6	0	0	0	0	×	0		
692	Second free thermal reduction frequency 1	5C	DC	6	0	0	0	0	0	0		
693	Second free thermal reduction ratio 1	5D	DD	6	0	0	0	0	0	0		
694	Second free thermal reduction frequency 2	5E	DE	6	0	0	0	0	0	0		
695	Second free thermal reduction ratio 2	5F	DF	6	0	0	0	0	0	0		
696	Second free thermal reduction frequency 3	60	E0	6	0	0	0	0	0	0		
699	Input terminal filter	63	E3	6	0	0	0	0	×	0		
702	Maximum motor frequency	02	82	7	×	×	0	0	0	0		
706 707	Induced voltage constant (phi f)  Motor inertia (integer)	06 07	86 87	7	×	×	0	0	×	0		
711	Motor Ld decay ratio	07 0B	8B	7	×	×	0	0	×	0		
712	Motor Lq decay ratio	0C	8C	7	×	×	0	0	×	0		
717	Starting resistance tuning compensation	11	91	7	×	×	0	0	×	0		
721	Starting magnetic pole position detection pulse width	15	95	7	×	×	0	0	×	0		
724	Motor inertia (exponent)	18	98	7	×	×	0	0	0	0		
725	Motor protection current level	19	99	7	×	×	0	0	0	0		
726	Auto Baudrate/Max Master	1A	9A	7	0	0	0	0	O*4	<b>O</b> *4		
727	Max Info Frames	1B	9B	7	0	0	0	0	O*4	O*4		
728	Device instance number (Upper 3 digits)	1C	9C	7	0	0	0	0	0*4	O*4		
729	Device instance number (Copper e digits)	1D	9D	7	0	0	0	0	0*4	O*4		
738	Second motor induced voltage constant (phi f)	26	A6	7	×	×	0	0	X ×	0		
739	Second motor Ld decay ratio	27	A7	7	×	×	0	0	×	0		
740	Second motor Lq decay ratio	28	A8	7	×	×	0	0	×	0		
741	Second starting resistance tuning compensation	29	A9	7	×	×	0	0	×	0		
742	Second motor magnetic pole detection pulse width	2A	AA	7	×	×	0	0	×	0		
743	Second motor maximum frequency	2B	AB	7	×	×	0	0	0	0		
744	Second motor inertia (integer)	2C	AC	7	×	×	0	0	0	0		
745	Second motor inertia (exponent)	2D	AD	7	×	×	0	0	0	0		
746	Second motor protection current level	2E	AE	7	×	×	0	0	0	0		
753	Second PID action selection	35	B5	7	0	0	0	0	0	0		
754	Second PID control automatic switchover frequency	36	B6	7	0	0	0	0	0	0		
755	Second PID action set point	37	B7	7	0	0	0	0	0	0		
756	Second PID proportional band	38	B8	7	0	0	0	0	0	0		
757	Second PID integral time	39	B9	7	0	0	0	0	0	0		
758	Second PID differential time	3A	BA	7	0	0	0	0	0	0		
759	PID unit selection	3B	BB	7	0	0	0	0	0	0		
760	Pre-charge fault selection	3C 3D	BC BD	7	0	0	0	0	0	0		
761 762	Pre-charge ending level Pre-charge ending time	3E	BE	7	0	0	0	0	0	0		
763	Pre-charge upper detection level	3F	BF	7	0	0	0	0	0	0		
764	Pre-charge time limit	40	C0	7	0	0	0	0	0	0		
765	Second pre-charge fault selection	41	C1	7	0	0	0	0	0	0		
766	Second pre-charge ending level	42	C2	7	0	0	0	0	0	0		
767	Second pre-charge ending time	43	C3	7	0	0	0	0	0	0		
768	Second pre-charge upper detection level	44	C4	7	0	0	0	0	0	0		
769	Second pre-charge time limit	45	C5	7	0	0	0	0	0	0		
774	Operation panel monitor selection 1	4A	CA	7	0	0	0	0	0	0		
775	Operation panel monitor selection 2	4B	СВ	7	0	0	0	0	0	0		
776	Operation panel monitor selection 3	4C	CC	7	0	0	0	0	0	0		
777	4 mA input fault operation frequency	4D	CD	7	0	0	0	0	0	0		
778	4 mA input check filter	4E	CE	7	0	0	0	0	0	0		
779	Operation frequency during communication error	4F	CF	7	0	0	0	0	0	0		
791	Acceleration time in low-speed range	5B	DB	7	×	×	0	0	0	0		
792	Deceleration time in low-speed range	5C	DC	7	×	×	0	0	0	0		
799	Pulse increment setting for output power	63	E3	7	0	0	0	0	0	0		
800	Control method selection	00	80	8	0	0	0	0	0	0		
820	Speed control P gain 1	14	94	8	×	×	0	0	0	0		
821	Speed control integral time 1	15	95	8	×	×	0	0	0	0		

		Instruction code <sub>*1</sub>			Cont	rol met	hod•2	Parameter			
Pr.	Name	Read	Write	Extended	N/F	Magneticflux	Z	Copys	Clear	All clears	
822	Speed setting filter 1	16	96	8	×	×	0	0	0	0	
824	Torque control P gain 1 (current loop proportional gain)	18	98	8	×	×	0	0	0	0	
825	Torque control integral time 1 (current loop integral time)	19	99	8	×	×	0	0	0	0	
827	Torque detection filter 1	1B	9B	8	×	×	0	0	0	0	
828	Parameter for manufacturer setting. Do not set.	1	1		T		T	T		T	
830	Speed control P gain 2	1E	9E	8	×	×	0	0	0	0	
831	Speed control integral time 2	1F	9F	8	×	×	0	0	0	0	
832	Speed setting filter 2	20	A0	8	×	×	0	0	0	0	
834	Torque control P gain 2	22	A2	8	×	×	0	0	0	0	
835	Torque control integral time 2	23	A3	8	×	×	0	0	0	0	
837	Torque detection filter 2	25	A5	8	×	×	0	0	0	0	
849	Analog input offset adjustment	31	B1	8	0	0	0	0	0	0	
858	Terminal 4 function assignment	3A	BA	8	0	0	×	0	×	0	
859	Torque current/Rated PM motor current Second motor torque current/Rated PM motor current	3B 3C	BB BC	8	×	0	0	0	×	0	
860	,			8	×	0		0	×	0	
864	Torque detection	40 42	C0 C2	8	×	×	0	0	0	0	
866 867	Torque monitoring reference	42	C2	8	×	0	0	0	0	0	
	AM output filter						_	0		_	
868 869	Terminal 1 function assignment	44 45	C4 C5	8	0	0	×	0	×	0	
	Current output filter				0	0			0	0	
870	Speed detection hysteresis	46 48	C6 C8	8	0	0	0	0	0	0	
872 874	Input phase loss protection selection OLT level setting	4A	CA	8		0	0	0	0	0	
882	· ·	52	D2	8	×	×	0	0	0	0	
883	Regeneration avoidance operation selection	53	D3	8	0	0	0	0	0	0	
003	Regeneration avoidance operation level Regeneration avoidance at deceleration detection	55	טט	0	U	0	U	U	U	U	
884	sensitivity	54	D4	8	0	0	0	0	0	0	
885	Regeneration avoidance compensation frequency limit value	55	D5	8	0	0	0	0	0	0	
886	Regeneration avoidance voltage gain	56	D6	8	0	0	0	0	0	0	
888	Free parameter 1	58	D8	8	0	0	0	0	×	×	
889	Free parameter 2	59	D9	8	0	0	0	0	×	×	
891	Cumulative power monitor digit shifted times	5B	DB	8	0	0	0	0	0	0	
892	Load factor	5C	DC	8	0	0	0	0	0	0	
893	Energy saving monitor reference (motor capacity)	5D	DD	8	0	0	0	0	0	0	
894	Control selection during commercial power-supply operation	5E	DE	8	0	0	0	0	0	0	
895	Power saving rate reference value	5F	DF	8	0	0	0	0	0	0	
896	Power unit cost	60	E0	8	0	0	0	0	0	0	
897	Power saving monitor average time	61	E1	8	0	0	0	0	0	0	
898	Power saving cumulative monitor clear	62	E2	8	0	0	0	0	×	0	
899	Operation time rate (estimated value)	63	E3	8	0	0	0	0	0	0	
C0 (900)	FM/CA terminal calibration	5C	DC	1	0	0	0	0	×	0	
C1 (901)	AM terminal calibration	5D	DD	1	0	0	0	0	×	0	
C2 (902)	Terminal 2 frequency setting bias frequency	5E	DE	1	0	0	0	0	×	0	
C3 (902)	Terminal 2 frequency setting bias	5E	DE	1	0	0	0	0	×	0	
125 (903)	Terminal 2 frequency setting gain frequency	5F	DF	1	0	0	0	0	×	0	
C4 (903)	Terminal 2 frequency setting gain	5F	DF	1	0	0	0	0	×	0	
C5 (904)	Terminal 4 frequency setting bias frequency	60	E0	1	0	0	0	0	×	0	
C6 (904)	Terminal 4 frequency setting bias	60	E0	1	0	0	0	0	×	0	
126 (905)	Terminal 4 frequency setting gain frequency	61	E1	1	0	0	0	0	×	0	

	Instruction code <sub>*1</sub>				Cont	rol met	hod•2	Parameter			
Pr.	Name	Read	Write	Extended	V/F	Magneticiflux	PM	Copy.s	Clear₃	All clear₃	
C7 (905)	Terminal 4 frequency setting gain	61	E1	1	0	0	0	0	×	0	
C12 (917)	Terminal 1 bias frequency (speed)	11	91	9	×	×	×	0	×	0	
C13 (917)	Terminal 1 bias (speed)	11	91	9	×	×	×	0	×	0	
C14 (918)	Terminal 1 gain frequency (speed)	12	92	9	×	×	×	0	×	0	
C15 (918)	Terminal 1 gain (speed)	12	92	9	×	×	×	0	×	0	
C16 (919)	Terminal 1 bias command (torque)	13	93	9	×	×	×	0	×	0	
C17 (919)	Terminal 1 bias (torque)	13	93	9	×	×	×	0	×	0	
C18 (920)	Terminal 1 gain command (torque)	14	94	9	×	×	×	0	×	0	
C19 (920)	Terminal 1 gain (torque)	14	94	9	×	×	×	0	×	0	
C8 (930)	Current output bias signal	1E	9E	9	0	0	0	0	0	0	
C9 (930)	Current output bias current	1E	9E	9	0	0	0	0	0	0	
C10 (931)	Current output gain signal	1F	9F	9	0	0	0	0	0	0	
C11 (931)	Current output gain current	1F	9F	9	0	0	0	0	0	0	
C38	Terminal 4 bias command (torque)	20	A0	9	×	×	×	0	×	0	
(932) C39	Terminal 4 bias (torque)	20	A0	9	×	×	×	0	×	0	
(932) C40	Terminal 4 gain command (torque)	21	A1	9	×	×	×	0	×	0	
(933) C41	Terminal 4 gain (torque)	21	A1	9	×	×	×	0	×	0	
(933) C42	PID display bias coefficient	22	A2	9	0	0	0	0	×	0	
(934) C43	PID display bias analog value	22	A2	9	0	0	0	0	×	0	
(934) C44	PID display gain coefficient	23	A3	9	0	0	0	0	×	0	
(935) C45	PID display gain analog value	23	A3	9	0	0	0	0	×	0	
(935) 977	Input voltage mode selection	4D	CD	9	0	0	0	0	×	×	
989	Parameter copy alarm release	59	D9	9	0	0	0	0	×	0	
990	PU buzzer control	5A	DA	9	0	0	0	0	0	0	
991	PU contrast adjustment	5B	DB	9	0	0	0	0	×	0	
992	Operation panel setting dial push monitor selection	5C	DC	9	0	0	0	0	0	0	
997	Fault initiation	61	E1	9	0	0	0	×	×	×	
998	PM parameter initialization	62	E2	9	0	0	0	0	0	0	
999	Automatic parameter setting	63	E3	9	0	0	0	×	×	0	
1000	Parameter for manufacturer setting. Do not set.	00	00					_			
1002	Lq tuning target current adjustment coefficient	02	82	Α	×	×	0	0	0	0	
1006	Clock (year)	06	86	A	0	0	0	X	×	×	
1007	Clock (month, day)	07	87	Α	0	0	0	×	×	×	
1008	Clock (hour, minute)	08	88	A	0	0	0	×	×	×	
1013	Emergency drive running speed after retry reset	0D 0F	8D 8F	A	0	0	0	0	×	0	
1015 1016	Integral stop selection at limited frequency PTC thermistor protection detection time	10	90	A	0	0	0	0	0	0	
1019	† · · · · · · · · · · · · · · · · · · ·	13	93	A	0	0	0	0	×	0	
	Analog meter voltage negative output selection AY										
1020	Trace operation selection	14 15	94 95	Α	0	0	0	0	0	0	
1021	Trace mode selection	10	ყე	Α	U	U	U	U	J	0	

PF,   Name			Instruction code <sub>*1</sub> Control method <sub>*2</sub>			hod•2	Parameter				
1023	Pr.	Name	Read	Write	Extended	N/F	Magneticflux	M	Copys	Clear	All clears
	1022	Sampling cycle	16	96	Α	0	0	0	0	0	0
1026					Α			0		0	
Number of sampling before trigger   1A   9A   A   0   0   0   0   0   0   0   0		· -			_						
										_	
1029											
1930   Analog source selection (4ch)   1E   9E   A   O   O   O   O   O   O   O   O   O		` '									
1931   Analog source selection (5ch)   1F 9F A O O O O O O O O O O O O O O O O O O		` '									
1932   Analog source selection (6ch)   20   A0   A   O   O   O   O   O   O   O   O   O		` '									
1033		, ,									
1035		\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \									
1035   Analog trigger operation selection   24   A4   A   O   O   O   O   O   O   O   O   O											
1036   Analog trigger operation selection   24   A4   A   O   O   O   O   O   O   O   O   O		` ,									
1038		0 00									
1038   Digital source selection (1ch)   26   A6   A   O   O   O   O   O   O   O   O   O											
1039   Digital source selection (2ch)   27   A7   A   O   O   O   O   O   O   O   O   O											
1041   Digital source selection (4ch)   29   A9   A   O   O   O   O   O   O   O   O   O		· ,			Α	0	0	0	0	0	0
1042   Digital source selection (5ch)		` '			Α	0	0	0	0	0	0
1043   Digital source selection (6ch)   2B   AB   A   O   O   O   O   O   O	1041	Digital source selection (4ch)			Α	0	0	0	0	0	0
1044   Digital source selection (7ch)   2C   AC   A   O   O   O   O   O   O     1045   Digital source selection (8ch)   2D   AD   A   O   O   O   O   O   O     1046   Digital trigger channel   2E   AE   A   O   O   O   O   O     1047   Digital trigger operation selection   2F   AF   A   O   O   O   O   O     1048   Display-off waiting time   30   BO   A   O   O   O   O   O     1048   Display-off waiting time   30   BO   A   O   O   O   O   O   O     1049   USB host reset   31   B1   A   O   O   O   O   X   X     1106   Torque monitor filter   06   86   B   O   O   O   O   O   O     1107   Running speed monitor filter   07   87   B   O   O   O   O   O     1108   Excitation current monitor filter   08   88   B   O   O   O   O   O     1132   Pre-charge change increment amount   20   AO   B   O   O   O   O   O     1133   Second pre-charge change increment amount   21   A1   B   O   O   O   O   O   O     1134   Parameter for manufacturer setting. Do not set.    1136   Second PID display bias coefficient   24   A4   B   O   O   O   O   X   O     1137   Second PID display gain analog value   25   A5   B   O   O   O   O   X   O     1140   Second PID set point/deviation input selection   28   A8   B   O   O   O   O   O   O     1141   Second PID measured value input selection   29   A9   B   O   O   O   O   O   O     1141   Second PID user limit   20   AO   B   O   O   O   O   O     1143   Second PID set point/deviation input selection   28   A8   B   O   O   O   O   O   O     1144   Second PID user limit   20   AO   B   O   O   O   O   O   O     1145   Second PID second provide training telection   28   A8   B   O   O   O   O   O   O   O     1146   Second PID user limit   20   AO   B   O   O   O   O   O   O   O   O	1042	Digital source selection (5ch)	2A	AA	Α	0	0	0	0	0	0
1045   Digital source selection (8ch)   2D   AD   A   O   O   O   O   O   O   O   O   O	1043	Digital source selection (6ch)	2B	AB	Α	0	0	0	0	0	0
1046   Digital trigger channel   2E   AE   A   O   O   O   O   O   O   O   O   O	1044	Digital source selection (7ch)	2C	AC	Α	0	0	0	0	0	0
1047   Digital trigger operation selection   2F   AF   A   O   O   O   O   O   O   O   O   O	1045	Digital source selection (8ch)	2D	AD	Α	0	0	0	0	0	0
1048   Display-off waiting time   30   B0   A   0   0   0   0   0   0   0   1049   USB host reset   31   B1   A   0   0   0   0   0   0   0   0   0	1046	Digital trigger channel		AE	Α	0	0	0	0	0	0
1049   USB host reset	1047	Digital trigger operation selection	2F	AF	Α	0	0	0	0	0	0
1106   Torque monitor filter					Α	0	0	0	0	0	0
1107   Running speed monitor filter											
1108		•					0				
1132   Pre-charge change increment amount   20   A0   B   0   0   0   0   0   0   0   1   1   1		<b>0</b> 1						0		_	
1133   Second pre-charge change increment amount   21											
1134		<u> </u>									
1135   Parameter for manufacturer setting. Do not set.     1136   Second PID display bias coefficient   24   A4   B   O   O   O   O   X   O     1137   Second PID display bias analog value   25   A5   B   O   O   O   O   X   O     1138   Second PID display gain coefficient   26   A6   B   O   O   O   O   X   O     1139   Second PID display gain analog value   27   A7   B   O   O   O   O   O     1140   Second PID set point/deviation input selection   28   A8   B   O   O   O   O   O     1141   Second PID measured value input selection   29   A9   B   O   O   O   O   O     1142   Second PID unit selection   24   A4   B   O   O   O   O   O     1143   Second PID upper limit   2B   AB   B   O   O   O   O   O     1144   Second PID lower limit   2C   AC   B   O   O   O   O   O     1145   Second PID deviation limit   2D   AD   B   O   O   O   O   O     1146   Second PID signal operation selection   2E   AE   B   O   O   O   O   O     1147   Second output interruption detection time   2F   AF   B   O   O   O   O   O     1148   Second output interruption cancel level   30   BO   B   O   O   O   O   O     1149   Second output interruption cancel level   31   B1   B   O   O   O   O   O     1150   User parameters 2   33   B3   B   O   O   O   O   O     1151   User parameters 3   34   B4   B   O   O   O   O   O     1153   User parameters 4   35   B5   B   O   O   O   O   O     1156   User parameters 5   36   B6   B   O   O   O   O   O     1157   User parameters 7   38   B8   B   O   O   O   O   O     1157   User parameters 8   39   B9   B   O   O   O   O   O     1157   User parameters 8   39   B9   B   O   O   O   O   O     1157   User parameters 8   39   B9   B   O   O   O   O   O     1157   User parameters 8   39   B9   B   O   O   O   O   O     1157   User parameters 8   39   B9   B   O   O   O   O   O     1157   User parameters 8   39   B9   B   O   O   O   O   O     1158   User parameters 8   39   B9   B   O   O   O   O   O     1157   User parameters 8   39   B9   B   O   O   O   O   O     1158   User parameters 8   39		Second pre-charge change increment amount	21	A1	В	0	0	0	0	0	0
1137   Second PID display bias analog value   25   A5   B   O   O   O   O   X   O   O   O   O   O		Parameter for manufacturer setting. Do not set.									
1138	1136			A4		0	0	0		×	0
1139	1137	Second PID display bias analog value		A5	В	0	0	0	0	×	0
1140         Second PID set point/deviation input selection         28         A8         B         O         <		. , ,			В		0			×	0
1141         Second PID measured value input selection         29         A9         B         O<		1 70 0					0	0		×	0
1142         Second PID unit selection         2A         AA         B         O <td< td=""><td></td><td>·</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></td<>		·									
1143         Second PID upper limit         2B         AB         B         O<		·									
1144         Second PID lower limit         2C         AC         B         O<											
1145         Second PID deviation limit         2D         AD         B         O <t< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></t<>											
1146         Second PID signal operation selection         2E         AE         B         O											
1147         Second output interruption detection time         2F         AF         B         O<											
1148         Second output interruption detection level         30         B0         B         O		· · ·									
1149       Second output interruption cancel level       31       B1       B       O		·									
1150       User parameters 1       32       B2       B       O <td></td> <td>·</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>		·									
1151       User parameters 2       33       B3       B       O <td></td>											
1152       User parameters 3       34       B4       B       O       O       O       O       O         1153       User parameters 4       35       B5       B       O       O       O       O       O         1154       User parameters 5       36       B6       B       O       O       O       O       O         1155       User parameters 6       37       B7       B       O       O       O       O       O         1156       User parameters 7       38       B8       B       O       O       O       O       O         1157       User parameters 8       39       B9       B       O       O       O       O       O		·									
1153       User parameters 4       35       B5       B       O <td></td> <td>·</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>		·									
1154       User parameters 5       36       B6       B       O       O       O       O       O         1155       User parameters 6       37       B7       B       O       O       O       O       O         1156       User parameters 7       38       B8       B       O       O       O       O       O         1157       User parameters 8       39       B9       B       O       O       O       O       O											
1155       User parameters 6       37       B7       B       O       O       O       O       O         1156       User parameters 7       38       B8       B       O       O       O       O       O         1157       User parameters 8       39       B9       B       O       O       O       O		·									
1156         User parameters 7         38         B8         B         O         O         O         O         O           1157         User parameters 8         39         B9         B         O         O         O         O         O											
1157 User parameters 8 39 B9 B O O O O O											
		'									
, , , , , , , , , , , , , , , , , , ,	1158	User parameters 9	3A	BA		0					
1159 User parameters 10 3B BB B O O O O O					В		0	0	0	0	0
		User parameters 11		ВС	В	0		0	0	0	0

1161       User parameters 12       3D       BD       B       O       O       O         1162       User parameters 13       3E       BE       B       O       O       O       O         1163       User parameters 14       3F       BF       B       O	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 O All clears
1162       User parameters 13       3E       BE       B       O       O       O         1163       User parameters 14       3F       BF       B       O       O       O         1164       User parameters 15       40       C0       B       O       O       O         1165       User parameters 16       41       C1       B       O       O       O         1166       User parameters 17       42       C2       B       O       O       O	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0
1163       User parameters 14       3F       BF       B       O       O       O         1164       User parameters 15       40       C0       B       O       O       O         1165       User parameters 16       41       C1       B       O       O       O         1166       User parameters 17       42       C2       B       O       O       O		0 0 0 0
1164       User parameters 15       40       C0       B       O       O       O         1165       User parameters 16       41       C1       B       O       O       O         1166       User parameters 17       42       C2       B       O       O       O		0 0 0
1165         User parameters 16         41         C1         B         O         O         O         O           1166         User parameters 17         42         C2         B         O         O         O         O		0 0
1166 User parameters 17 42 C2 B O O O		0
	0 0	0
1167 User parameters 18 43 C3 B O O O	0 0	
	\ \	0
1170 User parameters 21 46 C6 B O O O	, ,	0
1171 User parameters 22 47 C7 B O O	0	0
	0	0
	0	0
500.   500.	0	0
	0	0
	0 0	0
550.   parameter   12	0 0	0
	0 0	0
	0 0	0
·	0 0	0
	0	0
	0	0
1184 User parameters 35 54 D4 B O O O	0	0
1100   D. 1100	0	0
1186 User parameters 37 56 D6 B <b>O O O</b>		0
1187 User parameters 38 57 D7 B O O O		0
1100   200	0	0
1189         User parameters 40         59         D9         B         O         O         O           1190         User parameters 41         5A         DA         B         O         O         O	0 0	0
1190         User parameters 41         5A         DA         B         O         O         O           1191         User parameters 42         5B         DB         B         O         O         O		0
· ·	0	0
	0 0	0
	0	0
1195 User parameters 46 5F DF B O O O	0	0
	0	0
1197 User parameters 48 61 E1 B O O O		0
1198 User parameters 49 62 E2 B O O O		0
1199 User parameters 50 63 E3 B O O O		0
	0	0
		0
		0
1215 Limit cycle output upper limit		0
1216 Limit cycle output lower limit 10 90 C O O O		0
	0	0
1218 PID gain tuning setting 12 92 C O O O	0	0
	×	×
	0	0
1461         PID multistage set point 2         3D         BD         E         O         O         O		0
1462         PID multistage set point 3         3E         BE         E         O         O         O		0
	0	0
1464         PID multistage set point 5         40         C0         E         O         O         0           1465         PID multistage set point 6         41         C1         E         O         O         O         O		0
1465         PID multistage set point 6         41         C1         E         O         O         O           1466         PID multistage set point 7         42         C2         E         O         O         O	0 0	0
	< ×	×
	Ô	Ô
	0	0
1472 Cleaning reverse rotation frequency 48 C8 E O O O		0
1473 Cleaning reverse rotation operation time 49 C9 E O O O	0	0

			structi code		Cont	rol met	hod•2	Parameter		
Pr.	Name	Read	Write	Extended	V/F	Magneticiflux	Md	Copy*3	Clear	All clear <sub>s</sub>
1474	Cleaning forward rotation frequency	4A	CA	Е	0	0	0	0	0	0
1475	Cleaning forward rotation operation time	4B	СВ	Е	0	0	0	0	0	0
1476	Cleaning stop time	4C	CC	Е	0	0	0	0	0	0
1477	Cleaning acceleration time	4D	CD	Е	0	0	0	0	0	0
1478	Cleaning deceleration time	4E	CE	Е	0	0	0	0	0	0
1479	Cleaning time trigger	4F	CF	Е	0	0	0	0	0	0
1480	Load characteristics measurement mode	50	D0	Е	0	0	0	0	0	0
1481	Load characteristics load reference 1	51	D1	Е	0	0	0	0	0	0
1482	Load characteristics load reference 2	52	D2	Е	0	0	0	0	0	0
1483	Load characteristics load reference 3	53	D3	Е	0	0	0	0	0	0
1484	Load characteristics load reference 4	54	D4	Е	0	0	0	0	0	0
1485	Load characteristics load reference 5	55	D5	Е	0	0	0	0	0	0
1486	Load characteristics maximum frequency	56	D6	Е	0	0	0	0	0	0
1487	Load characteristics minimum frequency	57	D7	Е	0	0	0	0	0	0
1488	Upper limit warning detection width	58	D8	Е	0	0	0	0	0	0
1489	Lower limit warning detection width	59	D9	Е	0	0	0	0	0	0
1490	Upper limit fault detection width	5A	DA	Е	0	0	0	0	0	0
1491	Lower limit fault detection width	5B	DB	Е	0	0	0	0	0	0
1492	Load status detection signal delay time / load reference measurement waiting time	5C	DC	Е	0	0	0	0	0	0

# **Appendix4** For customers using HMS network options

## **♦**List of inverter monitored items

The following items can be set using a communication option.

#### 16bit data

No.	Description	Unit	Туре	Read/ write
H0000	No data	-	-	-
H0001	Output frequency	0.01Hz	unsigned	R
H0002	Output current	0.01A/0.1A	unsigned	R
H0003	Output voltage	0.1V	unsigned	R
10004	reserved	-	-	-
H0005	Frequency setting value	0.01Hz	unsigned	R
H0006	Motor speed	1r/min	unsigned	R
H0007	Motor torque	0.1%	unsigned	R
H0008	Converter output voltage	0.1V	unsigned	R
H0009	reserved	-	-	-
H000A	Electric thermal relay function load factor	0.1%	unsigned	R
H000B	Output current peak value	0.01A/0.1A	unsigned	R
1000C	Converter output voltage peak value	0.1V	unsigned	R
H000D	Input power	0.01kW/0.1kW	unsigned	R
1000E	Output power	0.01kW/0.1kW	unsigned	R
1000F	Input terminal status*1	-	-	R
H0010	Output terminal status*1	-	-	R
H0011	Load meter	0.1%	unsigned	R
H0012	Motor excitation current	0.01A/0.1A	unsigned	R
H0013	reserved	-	-	-
H0014	Cumulative energization time	1h	unsigned	R
H0015	reserved	-	-	-
H0016	Orientation status	1	unsigned	R
H0017	Actual operation time	1h	unsigned	R
H0018	Motor load factor	0.1%	unsigned	R
H0019	Cumulative power	1kWh	unsigned	R
H001A to H0021	reserved	-	-	-
H0022	Motor output	0.1kW	unsigend	R
H0023 to H002D	reserved	-	-	-
H002E	Motor temperature			R
H002F to H0031	reserved	-	-	-
H0032	Power saving effect	-	unsigned	R
H0033	Cumulative saving power	-	unsigned	R
H0034	PID set point	0.1%	unsigned	R/W
H0035	PID measured value	0.1%	unsigned	R/W
H0036	PID deviation	0.1%	unsigned	R/W
H0037 to H0039	reserved	-	-	-
H003A	Option input terminal status1*1	-	-	R
H003B	Option input terminal status2*1	-	-	R
H003C	Option output terminal status*1	-	-	R
H003D	Motor thermal load factor	0.1%	unsigned	R
H003E	Transistor thermal load factor	0.1%	unsigned	R
H003F	reserved	-	-	-
H0040	PTC thermistor resistance	ohm	unsigned	R

No.	Description	Unit	Туре	Read/ write
H0041	Output power (with regenerative display)			R
H0042	Cumulative regenerative power			R
H0043	reserved			
H0044	2nd PID set point	0.1%	unsigned	R/W
H0045	2nd PID measured value	0.1%	unsigned	R/W
H0046	2nd PID deviation	0.1%	unsigned	R/W
H0048 to H004F	reserved	-	-	-
H0050	Integrated power on time			R
H0051	Running time			R
H0052	Saving energy monitor			R
H0053	reserved	-	-	-
H0054	Fault code (1)	-	-	R
H0055	Fault code (2)	-	-	R
H0056	Fault code (3)	-	-	R
H0057	Fault code (4)	-	-	R
H0058	Fault code (5)	-	-	R
H0059	Fault code (6)	-	-	R
H005A	Fault code (7)	-	-	R
H005B	Fault code (8)	-	-	R
H00F9	Run command*2	-	-	R/W
H00FA to H01FF	reserved	-	-	-

- \*1 For details, refer to page 263.
- \*2 Run command Users can specify the terminal function using this data. These bits function is depending on inverter parameter setting. (Refer to page 329)

b15															bU
-	-	-	-	RES	STP (STOP)	CS	JOG	MRS	RT	RH	RM	RL	-	1	AU

### <32bit data>

No.	Description	Unit	Туре	Read/ write	
H0200	reserved	-	-	-	
H0201	Output frequency (0-15bit)	0.01Hz	signed	R	
H0202	Output frequency (16-31bit)	0.01112	signed	K	
H0203	Setting frsequency (0-15bit)	0.01Hz	aignad	R	
H0204	Setting frequency (16-31bit)	0.01H2	signed	K	
H0205	Motor rotation (0-15bit)	1r/min	aignad	R	
H0206	Motor rotation (16-31bit)	11/111111	signed	K	
H0207	Load meter (0-15bit)	0.1%	aignad	R	
H0208	Load meter (16-31bit)	0.1%	signed	K	
H0209, H020A	reserved	-	-	-	
H020B	Watt-hour meter (1kWh step) (0-15bit)	1kWh	ungigned	R	
H020C	Watt-hour meter (1kWh step) (16-31bit)	IKVVII	unsigned	K	
H020D	Watt-hour meter (0.1/0.01kWh step) (0-15bit)	0.1/0.01kWh	unaignad	R	
H020E	Watt-hour meter(0.1/0.01kWh step) (16-31bit)	U. 1/U.U 1KVVII	unsigned	K	
H020F to H03FF	l reserved		-	-	

\*The manual number is given on the bottom left of the back cover.

Print Date	*Manual Number	Revision
Jul. 2014	IB(NA)-0600547ENG-A	First edition
L	L	

## **⚠** For Maximum Safety

- · Mitsubishi inverters are not designed or manufactured to be used in equipment or systems in situations that can affect or endanger human life.
- · When considering this product for operation in special applications such as machinery or systems used in passenger transportation, medical, aerospace, atomic power, electric power, or submarine repeating applications, please contact your nearest Mitsubishi sales representative.
- · Although this product was manufactured under conditions of strict quality control, you are strongly advised to install safety devices to prevent serious accidents when it is used in facilities where breakdowns of the product are likely to cause a serious accident.

Please do not use this product for loads other than three-phase induction motors.

