



TRANSISTORIZED INVERTER INSTRUCTION MANUAL

—
HIGH-DUTY BRAKE RESISTOR
—

FR-ABR-(H)0.4K to 22K

K

Thank you for choosing the Mitsubishi transistorized inverter option unit.

This instruction manual gives handling information and precautions for use of this equipment.

Incorrect handling might cause an unexpected fault. Before using the equipment, please read this manual carefully to use the equipment to its optimum.

Please forward this instruction manual to the end user.

Safety Instructions

Do not attempt to install, operate, maintain or inspect this product until you have read through this instruction manual and appended documents carefully and can use the equipment correctly.

Do not use this product until you have a full knowledge of the equipment, safety information and instructions.

In this manual, the safety instruction levels are classified into "WARNING" and "CAUTION".



Denotes that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



Denotes that incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause physical damage only.

Note that even the  CAUTION level may lead to a serious consequence under some circumstances. Please follow the instructions of both levels as they are important to personnel safety.

SAFETY INSTRUCTIONS

1. Electric Shock Prevention



WARNING

- Before starting wiring or inspection, switch power off, wait for more than 10 minutes, and check for no residual voltage with a meter, etc.
- Any person who is involved in the wiring or inspection of this equipment should be fully competent to do the work.

2. Fire Prevention

CAUTION

- Mount the brake resistor on a nonflammable surface. Installing it directly on or near a flammable surface could cause a fire.
- Use the alarm signal to switch power off. A failure to do so can overheat the brake resistor due to a brake transistor failure etc., causing a fire.

3. Injury Prevention

CAUTION

- Ensure that the cables are connected to the correct terminals. Otherwise, damage, etc. may occur.
- While power is on or for some time after power-off, do not touch the brake resistor as it is hot. Touching it can cause burns.

4. Additional Instructions

Also note the following points to prevent an accidental failure, injury, electric shock, etc.:

(1) Transportation and installation

CAUTION

- Transport products in a correct manner according to their weights. Not doing so can cause injury.
- Install the product in a place secure enough to withstand its weight according to the instruction manual.

(2) Usage

WARNING

- Do not modify the equipment.
- Do not perform parts removal which is not instructed in this manual. Doing so may lead to fault or damage of the inverter.

(3) Disposal

CAUTION

- Dispose of this product as general industrial waste.

(4) General instructions

Many of the diagrams and drawings in this instruction manual show the inverter without a cover, or partially open. Never run the inverter like this. Always replace the cover and follow the instruction manual when operating the inverter.

INSTALLATION INSTRUCTIONS FOR COMPLIANCE WITH UL

Install the high-duty brake resistor FR-ABR as follows:

- The brake resistor may be mounted horizontally or vertically, depending on a suitable surface location.
- When the brake resistor is mounted externally to the enclosure housing the inverter, install a solid Type 1 enclosure at least 8 times the volume size of the brake resistor that incorporates mesh or perforated steel type ventilation openings at each end of the resistor. Note, the vent openings shall not be greater than 10 mm diameter.
- Secure the enclosure to a nonflammable surface only, such as metal or concrete.
- Mount the brake resistor inside the Type 1 enclosure and wire it in accordance with the NEC for North America installations or any other local codes.

Note, when the brake resistor and inverter are mounted together within a suitable enclosure, the mesh covering is not required. Take care that the temperature inside the enclosure does not exceed 50°C.

Since the enclosure surface becomes a high temperature, it presents a possible burn hazard. After installation, the following marking in minimum 3 mm (1/8 in.) sized lettering shall be provided on the enclosure where visible:

CAUTION : HOT SURFACE. TO REDUCE RISK OF BURN - DO NOT TOUCH.

1. UNPACKING AND CHECKING THE MODEL AND APPLICABLE INVERTERS

Take the brake resistor out of the package and confirm that the product is as you ordered and intact.

• Type FR-ABR - 0.4 K
 Indicate capacity (kW)

| Symbol | Voltage class |
|--------|---------------|
| No | 200V class |
| H | 400V class |

(For the FR-ABR-H15K, a terminal block for connecting resistors is enclosed as two resistors need to be connected in parallel.) FR-ABR-15K is indicated on the resistor. (A type name indicated on the package is different.)

The FR-ABR Series brake resistors are a UL Listed accessory for use only with the following UL listed inverter models:

| High-Duty Brake Resistor Model | | Applicable Inverter Models |
|--------------------------------|--------------|--|
| 200V Class | FR-ABR-0.4K | FR-A520-0.4K(-**) FR-E520-0.4K(C)(-**), FR-E520S-0.4K(-**), FR-E510W-0.4K(-**) FR-A024-0.4K(-**) FR-S520E-0.4K(-**) FR-A720-0.4K(-**) FR-E720-0.4K(-**) |
| | FR-ABR-0.75K | FR-A520-0.75K(-**) FR-E520-0.75K(C)(-**), FR-E520S-0.75K(-**), FR-E510W-0.75K(-**) FR-A024-0.75K(-**) FR-S520E-0.75K(-**) FR-A720-0.75K(-**) FR-E720-0.75K(-**) |
| | FR-ABR-2.2K | FR-A520-1.5K(-**), FR-A520-2.2K(-**) FR-E520-1.5K(C)(-**), FR-E520-2.2K(C)(-**) FR-V520-1.5K(-**), FR-V520-2.2K(-**) FR-A024-1.5K(-**), FR-A024-2.2K(-**) FR-S520E-1.5K(-**), FR-S520E-2.2K(-**) FR-A720-1.5K(-**), FR-A720-2.2K(-**) FR-E720-1.5K(-**), FR-E720-2.2K(-**) |
| | FR-ABR-3.7K | FR-A520-3.7K(-**) FR-E520-3.7K(C)(-**) FR-V520-3.7K(-**) FR-A024-3.7K(-**) FR-S520E-3.7K(-**) FR-A720-3.7K(-**) FR-E720-3.7K(-**) |
| | FR-ABR-5.5K | FR-A520-5.5K(-**) FR-E520-5.5K(C)(-**) FR-V520-5.5K(-**) FR-A720-5.5K(-**) FR-E720-5.5K(-**) |
| | FR-ABR-7.5K | FR-A520-7.5K(-**) FR-E520-7.5K(C)(-**) FR-V520-7.5K(-**) FR-A720-7.5K(-**) FR-E720-7.5K(-**) |

Note : ** indicates alpha numeric combination which means an inverter type such as A1 and A2.

| High-Duty Brake Resistor Model | | Applicable Inverter Models |
|--------------------------------|---------------|---|
| 200V Class | FR-ABR-11K | FR-V520-11K(-**) FR-A720-11K(-**) FR-E720-11K(-**) |
| | FR-ABR-15K | FR-V520-15K(-**) FR-A720-15K(-**) FR-E720-15K(-**) |
| | FR-ABR-22K | FR-A720-18.5K(-**) FR-A720-22K(-**) |
| 400V Class | FR-ABR-H0.4K | FR-A540-0.4K(-**) FR-E540-0.4K(C)(-**) FR-A044-0.4K(-**) FR-A740-0.4K(-**) FR-E740-0.4K(-**) |
| | FR-ABR-H0.75K | FR-A540-0.75K(-**) FR-E540-0.75K(C)(-**) FR-A044-0.75K(-**) FR-A740-0.75K(-**) FR-E740-0.75K(-**) |
| | FR-ABR-H1.5K | FR-A540-1.5K(-**) FR-E540-1.5K(C)(-**) FR-V540-1.5K(-**) FR-A044-1.5K(-**) FR-A740-1.5K(-**) FR-E740-1.5K(-**) |
| | FR-ABR-H2.2K | FR-A540-2.2K(-**) FR-E540-2.2K(C)(-**) FR-V540-2.2K(-**) FR-A044-2.2K(-**) FR-A740-2.2K(-**) FR-E740-2.2K(-**) |
| | FR-ABR-H3.7K | FR-A540-3.7K(-**) FR-E540-3.7K(C)(-**) FR-V540-3.7K(-**) FR-A044-3.7K(-**) FR-A740-3.7K(-**) FR-E740-3.7K(-**) |
| | FR-ABR-H5.5K | FR-A540-5.5K(-**) FR-E540-5.5K(C)(-**) FR-V540-5.5K(-**) FR-A740-5.5K(-**) FR-E740-5.5K(-**) |
| | FR-ABR-H7.5K | FR-A540-7.5K(-**) FR-E540-7.5K(C)(-**) FR-V540-7.5K(-**) FR-A740-7.5K(-**) FR-E740-7.5K(-**) |
| | FR-ABR-H11K | FR-V540-11K(-**) FR-A740-11K(-**) FR-E740-11K(-**) |
| | FR-ABR-H15K | FR-V540-15K(-**) FR-A740-15K(-**) FR-E740-15K(-**) |
| | FR-ABR-H22K | FR-A740-18.5K(-**) FR-A740-22K(-**) |

Note : ** indicates alpha numeric combination which means an inverter type such as A1 and A2.


2. GENERAL INSTRUCTIONS FOR INSTALLATION

(For compliance with UL standard, refer to page A-3.)


- Never mount the resistor near wood, paper or any other flammable material. Doing so can cause a fire.
- To prevent burns, do not install the resistor in a place where it is readily accessible. If it is easily accessible, mount in a well-ventilated enclosure (e.g. punched metal), suitable for the environment.
- Mount the resistor carefully so that the leads do not come from the top of the resistor.
- Avoid contact with the resistor when running the leads of the resistor and any other wiring.

Install the resistor in a place with good heat dissipation. The reason for this is that the surface temperature of the resistor may exceed 360°C in an operation pattern where the resistor is used frequently.


To increase the heat dissipation effect, we recommend you to install the resistor on a metal surface outside the enclosure.



How to Install the Resistor




Interval between resistors Installed



Orientation of installed resistor

3. INSTRUCTIONS FOR WIRING

When the regenerative brake transistor is damaged, the wiring sequence as shown in the following diagrams is recommended to prevent overheating and burnout of the brake resistor.




- Remove the jumper from across the PR and PX terminals of the inverter. (*1) This disables (switches off) the built-in brake resistor. (Refer to the instruction manual of the inverter for details.)

Note that the built-in brake resistor need not be removed. The leads of the built-in brake resistor need not be disconnected from the terminals.


- *1 Some inverters do not have the terminal PX. Some inverters do not have the terminal PR and in this case there is no jumper that needs to be removed. (For details, refer to Instruction Manual of the inverter.)
- *2 For the 400V class power supply, install a voltage-reducing transformer.
- *3 Refer to the table below for the type number of each capacity of thermal relay and the diagram below for the connection. (Always install a thermal relay when using the 11K, 15K, 22K.)

| Power Supply Voltage | High-duty Brake Resistor | Thermal Relay Type (Mitsubishi product) | Contact Rating |
|----------------------|--------------------------|---|---|
| 200V | FR-ABR-0.4K | TH-N20CXHZ-0.7A | 110VAC 5A, 220VAC 2A(class AC-11) 110VDC 0.5A, 220VDC 0.25A(class DC-11) |
| | FR-ABR-0.75K | TH-N20CXHZ-1.3A | |
| | FR-ABR-2.2K | TH-N20CXHZ-2.1A | |
| | FR-ABR-3.7K | TH-N20CXHZ-3.6A | |
| | FR-ABR-5.5K | TH-N20CXHZ-5A | |
| | FR-ABR-7.5K | TH-N20CXHZ-6.6A | |
| | FR-ABR-11K | TH-N20CXHZ-11A | |
| | FR-ABR-15K | TH-N20CXHZ-11A | |
| | FR-ABR-22K | TH-N60-22A | |
| 400V | FR-ABR-H0.4K | TH-N20CXHZ-0.24A | |
| | FR-ABR-H0.75K | TH-N20CXHZ-0.35A | |
| | FR-ABR-H1.5K | TH-N20CXHZ-0.9A | |
| | FR-ABR-H2.2K | TH-N20CXHZ-1.3A | |
| | FR-ABR-H3.7K | TH-N20CXHZ-2.1A | |
| | FR-ABR-H5.5K | TH-N20CXHZ-2.5A | |
| | FR-ABR-H7.5K | TH-N20CXHZ-3.6A | |
| | FR-ABR-H11K | TH-N20CXHZ-6.6A | |
| | FR-ABR-H15K | TH-N20CXHZ-6.6A | |
| | FR-ABR-H22K | TH-N20-9A | |



- Connect the leads of the high-duty brake resistor to the P and PR terminals of the inverter. For the following high-duty brake resistors, connect them as specified in the table below.

| High-duty brake resistor | Resistance(Ω) | Connection method |
|--------------------------|------------------------|---------------------------------------|
| FR-ABR-15K | 18 | 2 units in parallel |
| FR-ABR-22K | 13 | 2 units in parallel |
| FR-ABR-H15K | 18 | 2 units in series (as shown below) |
| FR-ABR-H22K | 52 | 2 units in parallel |



- If you extend the high-duty resistor lead wire to use, use the wire with a size as noted below and not exceeding 5m in length. Installation shall be in accordance with the North American or Canadian Electrical Code and any applicable provincial codes (codes of each state).

CAUTION

1. The high-duty brake resistor cannot be used with a brake unit, high power factor converter, power return converter, built-in brake, etc.
2. Twist the leads of the high-duty brake resistor when increasing their length 2m or more. (The wire size used should be minimum 14 AWG (2.1mm²)).
Note that even the twisted leads cannot be made longer than 5m. Doing so can cause an inverter failure.
3. The FR-ABR-(H)11K, 15K, 22K cannot be used with the FR-A500 series.

4. INSTRUCTIONS FOR USE

- Setting of inverter parameters
The parameter setting method varies with the inverter series. Refer to the instruction manual of the inverter.

5. SPECIFICATIONS


Permissible duty and torque

| Item | FR-ABR-□ (200V Class) | | | | | | | | FR-ABR-H□ (400V Class) | | | | | | | | | |
|-------------------|-----------------------|-------|---------|------|------|------|-----|-----|------------------------|------|---------|------|------|------|------|------|-----|-----|
| | 0.4K | 0.75K | 2.2K | 3.7K | 5.5K | 7.5K | 11K | 15K | 22K | 0.4K | 0.75K | 1.5K | 2.2K | 3.7K | 5.5K | 7.5K | 11K | 15K |
| Braking torque | 150% 5s | | 100% 5s | | | | | | | | 100% 5s | | | | | | | |
| Permissible duty* | 10%ED | | | | 6%ED | | | | 10%ED | | | | 6%ED | | | | | |

* The permissible duty represents the braking capability including the motor loss.
The actual duty of the resistor is slightly lower than that.

6. OUTLINE DIMENSIONS


FR-ABR-0.4K to 7.5K, H0.4K to H7.5K



| Brake Resistor Model | | Dimensions (Unit: mm) | | | | | Resistance (Ω) | Crimping Terminal (Unit: mm) | | | |
|----------------------|---------------|-----------------------|----------------|----------------|----|----|-------------------------|------------------------------|----------------|----------------|----------------|
| | | W | W ₁ | W ₂ | D | H | | A ₁ | | A ₂ | |
| | | | | | | | | B ₁ | d ₁ | B ₂ | d ₂ |
| 200V Class | FR-ABR-0.4K | 140 | 125 | 100 | 40 | 21 | 200 | 7.0 | 4.3 | 7.0 | 4.3 |
| | FR-ABR-0.75K | 215 | 200 | 175 | 40 | 21 | | | | | |
| | FR-ABR-2.2K*1 | 240 | 225 | 200 | 50 | 26 | | | | | |
| | FR-ABR-3.7K | 215 | 200 | 175 | 61 | 33 | 40 | 9.5 | 5.3 | 9.5 | 5.3 |
| | FR-ABR-5.5K | 335 | 320 | 295 | 61 | 33 | | | | | |
| | FR-ABR-7.5K | 400 | 385 | 360 | 80 | 40 | | | | | |
| 400V Class | FR-ABR-H0.4K | 115 | 100 | 75 | 40 | 21 | 1200 | 7.0 | 4.3 | 7.0 | 4.3 |
| | FR-ABR-H0.75K | 140 | 125 | 100 | 40 | 21 | | | | | |
| | FR-ABR-H1.5K | 215 | 200 | 175 | 40 | 21 | | | | | |
| | FR-ABR-H2.2K | 240 | 225 | 200 | 50 | 26 | 250 | 9.5 | 5.3 | 9.5 | 5.3 |
| | FR-ABR-H3.7K | 215 | 200 | 175 | 61 | 33 | | | | | |
| | FR-ABR-H5.5K | 335 | 320 | 295 | 61 | 33 | | | | | |
| | FR-ABR-H7.5K | 400 | 385 | 360 | 80 | 40 | 75 | | | | |

*1 Used for 1.5K and 2.2K.

FR-ABR-11K, 15K, 22K, H11K, H15K, H22K



| Brake Resistor Model | | Dimensions (Unit: mm) | | | Resistance (Ω) | Crimping Terminal (Unit: mm) | | | |
|----------------------|---------------------------|--------------------------|----------------|----------------|-------------------|---------------------------------|----------------|----------------|----------------|
| | | W | W ₁ | W ₂ | | A ₁ | | A ₂ | |
| | | | | | | B ₁ | d ₁ | B ₂ | d ₂ |
| 200V Class | FR-ABR-11K | 400 | 385 | 360 | 13 | 12 | 6.4 | 9.5 | 5.3 |
| | FR-ABR-15K* ¹ | 300 | 285 | 260 | 18 | 12 | 8.4 | 12 | 8.4 |
| | FR-ABR-22K* ³ | 400 | 385 | 360 | 13 | 12 | 8.4 | 12 | 8.4 |
| 400V Class | FR-ABR-H11K | 400 | 385 | 360 | 52 | 12 | 6.4 | 9.5 | 5.3 |
| | FR-ABR-H15K* ² | 300 | 285 | 260 | 18 | 12 | 8.4 | 12 | 8.4 |
| | FR-ABR-H22K* ⁴ | 450 | 435 | 410 | 52 | 9.0 | 6.4 | 9.0 | 6.4 |

*1 For the 15K, connect two resistors (18Ω) in parallel.

*2 For the H15K, connect two resistors (18Ω) in series. FR-ABR-15K is indicated on the resistor. (Same resistor as the 200V class 15K)

*3 For the 22K brake resistor, configure so that two 13Ω resistors are connected in parallel. FR-ABR-22K is indicated on the resistor.

*4 For the H22K brake resistor, configure so that two 52Ω resistors are connected in parallel. FR-ABR-H22K is indicated on the resistor.

7. BRAKING CAPABILITIES

7.1 Continuous Permissible Power

| 200V Class | | | 400V Class | | |
|--------------|------------|------------------------------|---------------|------------|------------------------------|
| Model | Resistance | Continuous Permissible Power | Model | Resistance | Continuous Permissible Power |
| FR-ABR-0.4K | 200Ω | 60W | FR-ABR-H0.4K | 1200Ω | 45W |
| FR-ABR-0.75K | 100Ω | 80W | FR-ABR-H0.75K | 700Ω | 75W |
| FR-ABR-2.2K | 60Ω | 120W | FR-ABR-H1.5K | 350Ω | 115W |
| FR-ABR-3.7K | 40Ω | 155W | FR-ABR-H2.2K | 250Ω | 120W |
| FR-ABR-5.5K | 25Ω | 185W | FR-ABR-H3.7K | 150Ω | 155W |
| FR-ABR-7.5K | 20Ω | 340W | FR-ABR-H5.5K | 110Ω | 185W |
| FR-ABR-11K | 13Ω | 560W | FR-ABR-H7.5K | 75Ω | 340W |
| FR-ABR-15K | 9Ω*1 | 805W | FR-ABR-H11K | 52Ω | 530W |
| FR-ABR-22K | 6.5Ω*1 | 1120W | FR-ABR-H15K | 36Ω*2 | 870W |
| | | | FR-ABR-H22K | 26Ω*3 | 1060W |


*1 When two resistors are connected in series.

*2 When two resistors are connected in series.


*3 When two resistors are connected in parallel.

7.2 Short-Duration Permissible Power per Braking

• 200V Class



• 400V Class



REVISIONS

*The manual number is given on the bottom left of the back cover.

| Print Date | *Manual Number | Revision |
|------------|----------------|---|
| Nov. 1998 | IB(NA)-66891-A | First edition |
| Mar. 2001 | IB(NA)-66891-B | <div style="border: 1px solid black; padding: 2px;">Partial Addition</div> <ul style="list-style-type: none"> • Applicable inverters • Instructions for wiring |
| Apr. 2002 | IB(NA)-66891-C | <div style="border: 1px solid black; padding: 2px;">Addition</div> FR-ABR-11K, FR-ABR-15K |
| Aug. 2002 | IB(NA)-66891-D | <div style="border: 1px solid black; padding: 2px;">Addition</div> FR-ABR-H11K, FR-ABR-H15K <div style="border: 1px solid black; padding: 2px;">Partial Addition</div> Instructions for wiring |
| Oct. 2003 | IB(NA)-66891-E | <div style="border: 1px solid black; padding: 2px;">Addition</div> UL compliance |
| Mar. 2004 | IB(NA)-66891-F | <div style="border: 1px solid black; padding: 2px;">Modification</div> Outline dimensions, outline dimension drawings |
| Aug. 2005 | IB(NA)-66891-G | <div style="border: 1px solid black; padding: 2px;">Addition</div> FR-ABR-22K |
| Nov. 2005 | IB(NA)-66891-H | <div style="border: 1px solid black; padding: 2px;">Addition</div> <ul style="list-style-type: none"> • FR-ABR-H22K • FR-A740 specifications |
| Aug. 2008 | IB(NA)-66891-J | <div style="border: 1px solid black; padding: 2px;">Partial Addition</div> Applicable inverters |
| Oct. 2012 | IB(NA)-66891-K | <div style="border: 1px solid black; padding: 2px;">Modification</div> <ul style="list-style-type: none"> • 3. INSTRUCTIONS FOR WIRING |
| | | |

